Interposers

- TAP-PSC (used with ECM-700) Interposer for Intel Pentium 4 with 478pin PGA
- TAP-BN (used with ECM-700) Interposer for Intel Pentium M with 478pin PGA



 TAP-MB (used with ECM-XDP3 or LX1000) Interposer for Intel Socket P Core Duo/ Core 2 Duo processor

Interposers -- Continued

- LGA775 interposer
- LGA771 interposer
- LGA1366 interposer
- (used with ECM-XDP3 or LX1000)

