

Based on December 2025 Update to Commissioning Processes, the following information should be used when handling emergency jobs.

Emergency (ECO) Jobs - General Requirements

- All ECO jobs *MUST* be completed using a Smart meter and Communications Hub (CHUB)
- SP Policy requires that Customer are *NOT* left vulnerable (no supply / no heating / no hot water).
- If the Engineer *CANNOT* replace equipment, due to lack of stock, this *MUST* be escalated to the Line Manager or Out of Hours (OOH) Manager for support.

Gas Emergency - Hot Shoe Requirements

A Hot Shoe *MUST* be installed unless one of the following applies:

- No Live Electric Supply -> Install & Leave
- No Access to the Electricity Service Position -> Install & Leave code from Team Leader (TL) or OOH Manager with photographic evidence
- Inadequate Space for Hot Shoe -> Install & Leave code from Team Leader (TL) or OOH Manager with photographic evidence

Customer Refusal to Power Down

- There is *NO AGREEMENT* allowing customer refusal to power down when a Hot Shoe is required.
- If the Customer *REFUSES* to Power Down, the Engineer *MUST* escalate to Dispatch/OOH team.

*** The three (3) reasons listed above are the *ONLY VALID REASONS* for NOT installing a Hot Shoe on emergency jobs.