


Steps to create DeviceType on Artik cloud

https://developer.artik.cloud/



Click on Device types under Dashboard





BRIJESH SINGH *

OVERVIEW

TOOLS & RESOURCES

DOCUMENTATION BLOG

ARTIK Cloud is open and device agnostic

Devices can upload data to ARTIK Cloud in any format that works for them.

- Any data, any message, sent and received in real-time
- · Develop private device types with security built in
- Share device type capabilities with other developers

Add your device type

Tell ARTIK Cloud what your device type is called then start building a Manifest to describe it further.

+ NEW DEVICE TYPE








OVERVIEW TOOLS & RESOURCES

DOCUMENTATION BLOG DASHBOARD

New Device Type



Add device display and It's unique name

Then click create

CREATE DEVICE TYPE



OVERVIEW TOOLS & RESOURCES DOCUMENTATION BLOG

ARTIK CLOUD

DEVICE TYPES

Overview

todayTempDevice

<- Device created

Device Info

DOCUMENTATION

Device Manifest

Platform Basics

Secure Your Devices

Create a manifest for todayTempDevice

ARTIK Cloud is designed to communicate with any device regardless of how data is structured. The Manifest provides a way for you to describe your data, so that you can start sending data to ARTIK Cloud.

now create manifest->




New Manifest

todayTempDevice: Simple Manifest

Switch to Advanced

The active manifest describes the capabilities of your device type to other users and devices on the ARTIK Cloud platform. Use fields and actions to describe the data that this device type produces and accepts, LEARN MORE >



<- add field name, data type and unit

DOCUMENTATION

DESCRIPTION

to other users.

The field description is an important way for you to explain in more detail what this data is

Device Manifest

Device Types in 1 Minute

Platform Basics

NEXT: DEVICE ACTIONS

CANCEL

New Manifest

ACTION NAME


Choose a name that beat describes what this Action is capable of doing. For consistency with the ARTIK Cloud platform, use a Standard Action if it matches the capability of your Action. To receive actions, your device type must be connected to ARTIK Cloud via WebSockets.

HIDE GUIDANCE

todayTempDevice: Simple Manifest

Switch to Advanced

The active manifest describes the capabilities of your device type to other users and devices on the ARTIK Cloud platform. Use fields and actions to describe the data that this device type produces and accepts. LEARN MORE -





Action we don't need So keep blank

NEXT: ACTIVATE MANIFEST

CANCEL

Click next





Click

ACTIVATE MANIFEST

CANCEL

CHANGE

DEVICE TYPES

Overview

Manifest

Device Info

Errors

DOCUMENTATION

Device Manifest

Platform Basics

Secure Your Devices

todayTempDevice

ID: dt71d19fb1d42940c4e53ee284c3ec4887 UNIQUE NAME: todayTempDate



Device type is private

This device type is available only to you and your organization

Connected: 0 devices

Current plan is Hobbyist

Active since 22nd September, 2016

Daily quota per device: 150 messages # of free devices included: Unlimited devices Maximum message size: 1024 bytes

Monthly cost per device: Free





CONNECTED APPS

DEVICES CREATED

DEVICES DELETED

0

MESSAGES /HR

API CALLS /HR

ERRORS /HR

RAW STORAGE NORMALIZED STORAGE

0

DEVICE TYPES

Overview

rainPredictDevice

Manifest

Device Info

todayTempDevice

DOCUMENTATION

Device Manifest

Platform Basics

Secure Your Devices



rainPredictDevice

ID: dt8c804555159f41e8a3b82bd7ad8fb36e

UNIQUE NAME: predictData

Similarly create another device type name and it's unique as shown marking

Create a manifest to start sending data

ARTIK Cloud is designed to communicate with any device regardless of how data is structured. The Manifest provides a way for you to describe your data




<- Add it's manifest

rainPredictDevice: Simple Manifest

Switch to Advanced

The active manifest describes the capabilities of your device type to other users and devices on the ARTIK Cloud platform. Use fields and actions to describe the data that this device type produces and accepts, LEARN MORE »





BRIJESH SINGH ▼

EARCH Q

TOOLS & RESOURCES DOCUMENTATION BLOG DASHBOARD Overview DEVICE TYPES + NEW DEVICE TYPE rainPredictDevice rainPredictDevice DEDIT DEVICETYPE ... Q 0 ERRORS todayTempDevice DOCUMENTATION API CALLS CONNECTED MESSAGES ERRORS Device Manifest APPS CREATED /HR /HR STORAGE Platform Basics Secure Your Devices todayTempDevice DEDIT DEVICETYPE ... Q 0 ERRORS MESSAGES API CALLS ERRORS USED CONNECTED APP5 CREATED STORAGE /HR /HR 0



Next you need to connect devices and Set their Rules

On https://artik.cloud/