Android / Google TV — Install BM TV Enabler and TV Apps

Installation · Android / Google TV

Install the Android phone Enabler and log in

1. Prepare your devices

Have an Android phone, the TV and its normal remote ready. Put the phone and TV on the same home Wi-Fi, not mobile data or an isolated guest network. Leave both awake. BM TV Enabler runs on an Android phone or Windows PC, not on the TV, iPhone or iPad. If you do not have Android, use the Windows PC card and matching Windows guides.

2. Get the official phone download

Sign in at bmsupport.uk > Install Guides > Set up a device and choose your TV type, or open Remote setup on your ticket. In the Android phone card scan the QR with your phone, or tap the phone download link. On the download page press Download BM TV Enabler and save the APK to the Android phone.

3. Install and open

Open the APK in the phone’s Downloads or Files. If prompted, allow installation from the browser or Files app named by Android, return and press Install, then Open. You can turn that install permission off afterwards. Only use the official BM Support download; ask staff about an unexpected security warning rather than disabling phone protection.

4. Log in with the account PIN

Get or reveal your BM TV Enabler PIN in website Settings > BM TV Enabler PIN, or the PIN box in ticket Remote setup. Enter the six-digit PIN in the app and press Log in, then Get started. The same account PIN is used until its original 24-hour expiry and is required on every app launch. It is separate from install/sharing references and TV pairing codes. If no current PIN exists, press Get BM TV Enabler PIN; if a PIN is already allocated, press Reveal PIN and use it.

Choose and connect to the correct TV

5. Choose a mode and TV type

After Get started, choose Install our apps for installation only, or Screen-share support for staff help. Select Android / Google TV. The Enabler on your phone makes the local connection; the website cannot discover your home TV itself. If you picked the wrong TV type, change it before connecting.

6. Android / Google TV

On the TV open Settings > System > About (some TVs use Device Preferences > About). Highlight Android TV OS build and press Select seven times. Return to System > Developer options and enable Network debugging, or Wireless debugging where offered. Menu names vary by TV. Do not expose debugging ports to the internet.

7. If Wireless debugging requires code pairing

The Android phone app has no pairing-code form. Use the Windows PC Enabler for TVs which require pairing: on the TV open Wireless debugging > Pair device with pairing code. In Windows expand Android / Google TV with Wireless debugging: pair with code, enter its six-digit pairing code and pairing port. In TV address use the main Wireless debugging screen’s IP address and connection port. Press Pair with code and set up my TV. The pairing port and connection port can differ. Setup continues after successful pairing.

8. Find and connect

Press I’ve switched debugging on — next. Press Find my Android TV, select the correct named TV and check its address. If it is missing, enter the address from the TV’s network settings. Press Connect to this TV. On the TV, press Allow for debugging and tick Always allow from this computer if offered. Keep the Enabler open.

9. If the TV is missing or unreachable

Check TV awake, correct address, same-network access and debugging ON. A discoverable TV can still have unreachable debugging. Guest Wi-Fi, VPN routing and router isolation can block connection. Discovery alone never grants access. Enter the address from the TV’s network settings if it is not listed; do not guess or expose debugging to the internet.

Install the TV apps

10. Wait for the install results

In Install our apps mode the Enabler checks the TV and installs the BM Support TV apps one by one. Apps already enabled in the current TV profile are skipped. Keep both devices awake until the results appear. This mode does not start screen sharing or install/check the remote-help setup for staff access.

11. Let the installation finish

Keep the phone or PC and TV connected and wait while the Enabler checks and installs the apps. Apps already enabled in the selected TV’s current profile are skipped. Read each result: Installed, Already on your TV, or a failure. Do not assume every app succeeded if one result reports a failure.

12. Use the install reference if needed

After a successful installation check, the app may show an install reference. Enter it in the reference box in your own ticket’s Remote setup when you need to confirm installation. Install and sharing references are separate. An install reference confirms installation, not screen-share readiness or permission for staff to view your TV.

13. Return home without resetting

Press Return to home to choose another section. You do not need Reset setup after an ordinary successful install. Installed TV apps remain installed. The Enabler remembers the selected TV and valid references; switching sections does not require a reinstall.

Saved references and troubleshooting

14. Understand expiry

The install reference keeps its original maximum 24-hour expiry; reopening the app does not extend it. It can expire earlier if its linked ticket/order closes. New code becomes available after the reference has been used or expired. Ending a screen share clears the sharing reference, not the separate install reference or login PIN.

15. If the TV cannot connect

Check same-network access, correct TV address, TV awake and debugging ON. Guest Wi-Fi or router isolation can block discovery and connection. A TV can be listed while debugging is unreachable. Approve the TV’s Allow prompt. If you refused it or permission remains stuck, ask staff before resetting authorisations or the TV.

16. Wireless debugging pairing

The Android phone Enabler does not have a Wireless debugging pairing-code form. If your Android/Google TV requires Pair device with pairing code, use the Windows PC Enabler: expand Android / Google TV with Wireless debugging: pair with code, enter the TV’s six-digit pairing code and pairing port, and use the main Wireless debugging screen’s IP address and connection port in TV address. Pairing and connection ports can differ. Press Pair with code and set up my TV; after successful pairing setup continues. Never type this pairing code into the ticket.

17. Retry safely or request help

If an app fails, read its result and error. Where no saved valid reference is being resumed, Return to home and choose Install our apps to run the install again. If the app only restores an earlier valid reference, or no install reference appeared after success, ask staff before resetting: a saved reference is not a fresh app check. Reset setup is a separate confirmed destructive action for saved TV choices/references; it does not uninstall TV apps or remove debugging authorisation. Request staff installation help from Install Guides > Help from staff during office hours, or the paid order’s help button.

Privacy and safety
Only share with BM Support staff through your own support ticket. Close banking, payment, password and other private screens on the TV first. You can decline a request or end a session. Never publish your PIN or reference.