Windows PC — Install BM TV Enabler and TV Apps

Install the Windows Enabler, sign in with your PIN and put BM Support apps on your TV.

1. Install Windows Enabler and log in

01 Check what you need

Use a Windows 10 or 11, 64-bit PC and an Amazon Fire TV/Stick or Android/Google TV. The PC and TV must be on the same home network, not isolated guest Wi-Fi. Keep both awake; disconnect a VPN if it prevents local connections. BM TV Enabler runs on the PC, not on the TV, iPhone or iPad.

02 Download from BM Support

Sign in at bmsupport.uk, open Install Guides > Set up a device and choose your TV type. In the Windows PC card, download BM TV Enabler. The same Windows download is also shown in ticket Remote setup. Use the official download button for the latest installer.

03 Install and open

Open the downloaded BM-TV-Enabler-Setup installer and follow its installation prompts. The Windows installer is unsigned, so Windows may show a publisher warning. Check that it came from BM Support. If your PC blocks it or you are unsure, ask staff; do not disable antivirus or security protection.

04 Enter your account PIN

Open Settings > BM TV Enabler PIN on the website, or reveal the PIN in ticket Remote setup. Enter the six-digit PIN in BM TV Enabler, press Log in, then Get started. The app asks for the PIN on every launch; use the current PIN, which changes after 24 hours. This login PIN is not the later Enabler reference or a TV pairing code.

Windows PC — Install BM TV Enabler and TV Apps

2. Prepare debugging and select the TV

05 Choose your TV type

Select Amazon Fire TV / Stick or Android / Google TV. Follow only the instructions for the TV you are using. The website cannot discover or connect to your home TV itself: BM TV Enabler does this from your PC.

06 Amazon Fire TV / Stick

On the TV open Settings > My Fire TV > About. Highlight the device name and press Select seven times to reveal Developer options. Go Back to My Fire TV > Developer options and turn ADB debugging ON. If Developer options already exists, use it directly. Leave the TV awake.

07 Android / Google TV

On the TV open Settings > System > About (some TVs use Device Preferences > About). Highlight Android TV OS build and press Select seven times. Return to System > Developer options and enable Network debugging, or Wireless debugging where offered. Menu names vary by TV. Do not expose debugging ports to the internet.

08 Find and connect

Press I’ve switched debugging on — next. Choose Find my Fire TV or Find my Android TV, select the correct named TV and check its address. If it is missing, enter the address from the TV’s network settings. Press Connect to this TV. On the TV, press Allow for debugging and tick Always allow from this computer if offered. Keep the Enabler open.

Windows PC — Install BM TV Enabler and TV Apps

3. Install the TV apps

09 Choose Install our apps

After Get started, choose Install our apps, then select and connect to your TV as described above. This mode installs BM Support’s TV apps; it does not start a screen share. For staff remote help, use the separate Windows PC — Use Screen-share Support guide.

10 Let the installation finish

Keep the PC and TV connected and wait while the Enabler checks and installs the apps. Apps already enabled in the selected TV’s current profile are skipped. Read each result: Installed, Already on your TV, or a failure. Do not assume every app succeeded if one result reports a failure.

11 Use the install reference if needed

After a successful installation check, the app may show an install reference. Enter it in the reference box in your own ticket’s Remote setup when you need to confirm installation. Install and sharing references are separate. An install reference confirms installation, not screen-share readiness or permission for staff to view your TV.

12 Return home without resetting

Press Return to home to choose another section. You do not need Reset setup after an ordinary successful install. Installed TV apps remain installed. The Enabler remembers the selected TV and valid references; switching sections does not require a reinstall.

Windows PC — Install BM TV Enabler and TV Apps

4. Saved references and troubleshooting

13 Understand expiry

The install reference keeps its original maximum 24-hour expiry; reopening the app does not extend it. It can expire earlier if its linked ticket/order closes. New code becomes available after the reference has been used or expired. Ending a screen share clears the sharing reference, not the separate install reference or login PIN.

14 If the TV cannot connect

Check same-network access, correct TV address, TV awake and debugging ON. Guest Wi-Fi or router isolation can block discovery and connection. A TV can be listed while debugging is unreachable. Approve the TV's Allow prompt. If you refused it or permission remains stuck, ask staff before resetting authorisations or the TV.

15 Wireless debugging pairing

If Android/Google TV requires pairing, expand Android / Google TV with Wireless debugging: pair with code. On the TV choose Wireless debugging > Pair device with pairing code. Enter that six-digit code and its pairing port in the app. Use the IP address and connection port from the main Wireless debugging screen for TV address; the two ports can differ.

16 Retry safely or request help

For a failed app, read the error, choose Return to home and retry installation. Reset setup asks for confirmation and clears saved TV choices/references; the next reference takes over. It does not uninstall TV apps or remove the PC's existing TV authorisation. For staff installation help use Install Guides > Help from staff during office hours, or the paid order's help button to raise a ticket.

Privacy and consent

Only share with BM Support staff through your own support ticket. Close banking, payment, password and other private screens on the TV first. You can decline a request or end a session. Never publish your PIN or reference.