Android / Google TV — Install and Set Up BM Remote Helper

Install the TV helper and grant the Accessibility permissions required for remote control.

1. Download and install

01 Prepare the correct TV

Have your Android TV/Google TV box or television awake, its remote and internet access. Keep a phone or computer signed in to BM Support for the download link. Follow the Android/Google TV instructions; BM TV Enabler and the Fire TV debugging workaround are not needed for this platform.

02 Get the official current app

Sign in at bmsupport.uk, open Install Guides, then Download BM Support Apps. Find the current remote app (listed as BM Support Remote). Press Request download link, then View download options. Use the current official link; if it has expired, request a fresh one. Do not use APKs from unrelated websites.

03 Download onto the TV

On the TV, open Downloader. If it is not installed, get Downloader from the TV's app store first, open it and accept its initial prompts. On your phone, display the official download options, then type the complete download URL into Downloader on the TV and select Go. Wait for the download to finish. Do not enter the TV's six-digit pairing code here: this field needs the download URL.

04 Allow the installer

If installation is blocked, open the settings prompt and allow this source. Depending on the TV, this is Settings > Apps > Special app access > Install unknown apps, or Settings > Security & restrictions > Unknown sources. Enable only Downloader or the installer named in the prompt, return to the downloaded file and choose Install, then Open. Menu names vary by brand and Android version.

Android / Google TV — Installation

2. Install the control app and grant Accessibility

05 Open and complete Helper setup

Open BM Remote Helper (the download may be labelled BM Support Remote). Follow its setup prompts for BM Remote Control. If a separate control-app installation is offered, approve Install. If asked to allow installs from the Helper/BM Support app, enable that named source, go Back and retry its installer. Keep both Helper and Control installed.

06 Open Accessibility settings

From the remote-control setup prompt, open Accessibility. Alternatively use TV Settings > Accessibility, or Settings > Device Preferences/System > Accessibility, depending on the TV. Look under Downloaded apps or Services for BM Remote Control. Select it. Choose Use service/Enable and confirm the system warning with Allow/OK.

07 If Android blocks the service

Some sideloaded installs show Restricted setting or For your security, this setting is currently unavailable. Open Settings > Apps > See all apps > BM Remote Control, then its three-dot menu if available, and choose Allow restricted settings. Confirm using the device’s normal security prompt, then return to Accessibility and enable the service. Apply this to the app whose service is blocked, not an unrelated app.

08 If the restricted-settings option is missing

Do not force the switch, disable security protection or assume debugging solves it. Ask BM Support to check the current official build and supported in-app/session installer for your device. Menu locations and sideload restrictions vary. The control app’s Accessibility service must actually be enabled for remote operation; having the Helper installed alone is not enough.

Android / Google TV — Installation

3. Check setup and get ready to connect

09 Verify remote-control permission

Return to the Helper and check its remote-control status. If it remains off, reopen Accessibility and verify BM Remote Control is enabled, then return. If the switch turns itself off, stop and ask staff to check device compatibility or the installation method. Screen viewing may still work without remote-control permission.

10 Keep sharing consent separate

Accessibility permission enables remote operation; it does not approve the screen recording/casting prompt for a particular session. When staff connects later, you must also approve Allow and Start now/Start on the TV when asked. Do not grant access to a request you did not make.

11 Finish the installation checks

Confirm the Helper shows a six-digit code and keep it installed. Ordinary restarts normally retain Accessibility settings; some TV software may reset permissions, so check them if control stops. Turn off optional unknown-source permission after installation if desired; you may need it again for updates.

12 Move on to the usage guide

Use Android / Google TV — Use Remote Help for the staff invitation, code entry, TV permissions, chat and ending the session. No Fire TV Enabler is required. Only share with BM Support staff through your own support ticket or secure order. Do not post your TV code publicly. Anything visible on the TV may be seen by staff: close banking, payment, password and other private screens first. You can decline a request or end a session.