Amazon Fire TV — Install and Set Up BM Remote Helper

Installation · Amazon Fire TV

Prepare the Enabler for remote help

1. Use the correct apps

BM TV Enabler runs on your Android phone or Windows PC. BM Remote Helper and BM Remote Control run on the TV. You do not need the Helper installed beforehand: Screen-share support installs missing remote-help apps and checks them. Install our apps is the separate mode for the viewing/store apps.

2. Download and log in

Use Install Guides > Set up a device or your ticket’s Remote setup to download the official Android phone or Windows Enabler. Follow the matching Enabler installation guide. Reveal your six-digit BM TV Enabler PIN in Settings or ticket Remote setup; log in and press Get started. iPhone/iPad cannot run the Enabler; use a Windows PC instead.

3. Choose Screen-share support

Select Screen-share support, then the correct TV type. Keep the phone/PC on the same home network as the TV. Enable the TV’s debugging setting and press I’ve switched debugging on — next. The following page gives the device-specific steps.

4. Do not sideload Helper with Downloader

Let BM TV Enabler install the Helper and control app using its secured installer. Installing them through Downloader can trigger restricted Accessibility settings on newer Android TVs. Do not use old Helper download/code-entry instructions or uninstall a working app during an active share.

Choose and connect to the correct TV

5. Choose a mode and TV type

After Get started, choose Install our apps for installation only, or Screen-share support for staff help. Select Amazon Fire TV / Stick. The Enabler on your phone or Windows PC makes the local connection; the website cannot discover your home TV itself. If you picked the wrong TV type, change it before connecting.

6. Amazon Fire TV / Stick

On the TV open Settings > My Fire TV > About. Highlight the device name and press Select seven times to reveal Developer options. Go Back to My Fire TV > Developer options and turn ADB debugging ON. If Developer options already exists, use it directly. Leave the TV awake.

7. Find and connect

Press I’ve switched debugging on — next. Press Find my Fire TV, select the correct named TV and check its address. If it is missing, enter the address from the TV’s network settings. Press Connect to this TV. On the TV, press Allow for debugging and tick Always allow from this computer if offered. Keep the Enabler open.

8. If the TV is missing or unreachable

Check TV awake, correct address, same-network access and debugging ON. A discoverable TV can still have unreachable debugging. Guest Wi-Fi, VPN routing and router isolation can block connection. Discovery alone never grants access. Enter the address from the TV’s network settings if it is not listed; do not guess or expose debugging to the internet.

Install, enable control and check

9. Allow the Enabler connection

On the TV approve Allow debugging/Allow USB debugging and tick Always allow from this computer if offered. Keep the Enabler open. Debugging authorises this phone/PC to set up the TV; it is not consent for staff to see your picture.

10. Let the app complete setup

The Enabler checks what is installed, installs BM Remote Helper and BM Remote Control where needed, enables remote control and runs a fresh readiness check. Read and resolve any error before continuing. On newer Fire OS, the TV cannot enable its own control through self-ADB; the external phone/PC Enabler performs this setup.

11. If Accessibility needs attention

The Enabler should report a passing control/Accessibility check after configuring the Fire TV. If it does not, check debugging approval and read the displayed error. Ask staff rather than repeatedly reinstalling or resetting the TV. Fire TV and Android/Google TV permission menus differ.

12. Keep Helper in front and get a sharing reference

When BM Remote Helper opens, leave it in front so the TV can show its sharing permission prompt. Wait for the Enabler’s fresh successful TV check, then press Get my confirmation code if no sharing reference is shown. Enter that Enabler reference on your ticket, not the Helper’s six-digit code. Use the matching Use Remote Help guide next.

Finish safely and troubleshoot

13. Understand the different codes

The six-digit account PIN logs in to Enabler. Its install reference confirms app installation only. Its sharing reference links a checked TV to one ticket/order. Android Wireless debugging may also have a separate six-digit pairing code. Never type the Helper’s TV code on the website for this Enabler flow; the Enabler transfers it automatically.

14. Do not skip sharing consent

Control/Accessibility allows operation, but each share still needs the TV’s requested Allow and recording/casting approval. Decline unexpected requests. A setup check or reference does not give staff permanent access.

15. If no prompt or no picture appears

Keep Helper in front, Enabler open and TV awake. Confirm the network and selected TV. Ask staff to join the exact ticket. Use the website’s Send to BM TV Enabler or Ask my TV again if a fresh connection is requested. Do not press Home before the permission prompt; staff controls can move the TV once the picture connection is ready.

16. Later sessions need a fresh reference

Ending a screen share expires its sharing reference immediately. The website resets; when the Enabler receives expiry it clears that sharing reference and offers New code. Do a fresh TV check and enter the new reference for the next share. Install reference, login PIN, installed TV apps and ordinary saved debugging authorisation remain separate.

Privacy and safety
Only share with BM Support staff through your own support ticket. Close banking, payment, password and other private screens on the TV first. You can decline a request or end a session. Never publish your PIN or reference.