Amazon Fire TV — Use Remote Help

Using remote help · Amazon Fire TV

Prepare your ticket and Enabler

1. Check the prerequisites

Have your TV and normal remote, internet access and an Android phone or Windows 10/11 64-bit PC on the same home network. Keep all devices awake. For iPhone/iPad users, the Windows PC Enabler is the alternative. Complete the matching Enabler installation guide first; do not install Enabler on the TV.

2. Raise installation help in the right place

For installation assistance choose Install Guides > Set up a device > Help from staff during office hours. A paid order’s remote installation help button creates a support ticket during office hours too. Open that ticket and its Remote setup; customer orders do not have remote setup tabs.

3. Log in and choose Screen-share support

Reveal your current account BM TV Enabler PIN in Settings or ticket Remote setup. Enter it in the phone/Windows app, press Log in, Get started, then Screen-share support. Each launch asks for the PIN. Return to home changes sections without clearing valid references.

4. Protect private information

Close password, bank, payment and other private TV screens before sharing. Staff may see anything on the TV during the session. Only approve BM Support help you requested in your own ticket. Do not post PINs, references or TV codes publicly.

Choose and connect to the correct TV

5. Choose a mode and TV type

After Get started, choose Install our apps for installation only, or Screen-share support for staff help. Select Amazon Fire TV / Stick. The Enabler on your phone or PC makes the local connection; the website cannot discover your home TV itself. If you picked the wrong TV type, change it before connecting.

6. Amazon Fire TV / Stick

On the TV open Settings > My Fire TV > About. Highlight the device name and press Select seven times to reveal Developer options. Go Back to My Fire TV > Developer options and turn ADB debugging ON. If Developer options already exists, use it directly. Leave the TV awake.

7. Find and connect

Press I’ve switched debugging on — next. Press Find my Fire TV, select the correct named TV and check its address. If it is missing, enter the address from the TV’s network settings. Press Connect to this TV. On the TV, press Allow for debugging and tick Always allow from this computer if offered. Keep the Enabler open.

8. If the TV is missing or unreachable

Check TV awake, correct address, same-network access and debugging ON. A discoverable TV can still have unreachable debugging. Guest Wi-Fi, VPN routing and router isolation can block connection. Discovery alone never grants access. Enter the address from the TV’s network settings if it is not listed; do not guess or expose debugging to the internet.

Check the TV and enter the reference

9. Approve debugging and wait

Select the correct TV, press Connect to this TV and approve the TV’s Allow debugging prompt, ticking Always allow if offered. Enabler checks, installs missing remote-help apps and enables control. Wait for a passing fresh TV check. Keep Helper in front when it opens.

10. Get the Enabler sharing reference

Press Get my confirmation code if no reference is displayed after setup. Use the sharing reference shown by your phone/Windows Enabler, not the account PIN, install reference, Wireless debugging pairing code or Helper’s six-digit TV code. The Helper connection is transferred automatically.

11. Enter it on the ticket

In ticket Remote setup, type the reference in its reference box and confirm. If another ticket/order used it, get New code in the Enabler. If the website shows an older/different reference, press Change reference number and enter the app’s current one. A valid reference does not move another ticket’s session.

12. Read the three status ticks

App logged in means the Enabler login is recognised, not that staff can see the TV. TV connected means the TV check is recognised. Ready to share follows acceptance of the sharing reference and readiness checks. If a tick is delayed, keep the Enabler open and check the reference belongs to this ticket; permission still has to be approved on the TV.

Link the reference, share and finish

13. Enter the Enabler reference

Type the sharing reference shown by BM TV Enabler into your own ticket’s Remote setup reference box and confirm it. Each reference belongs to one ticket/order while valid. If another ticket/order already used it, get New code in the Enabler. If your PC shows a different reference from the website, use Change reference number and enter the current one.

14. Connect and approve

When the website offers Connect my screen, press it and follow the TV’s Allow and recording/casting prompts. If the website needs a fresh TV check, keep the Enabler open and use Send to BM TV Enabler or Ask my TV again as shown. Wait for the new connection to arrive rather than repeatedly pressing the button. A green readiness tick is not a substitute for TV consent.

15. Work with staff

Your ticket’s Screen share opens when connected. Ask staff to confirm they can see the TV. Keep the PC Enabler open, the TV awake and the Helper running while the connection is being established. Use the ticket conversation to speak with staff. Tell staff before opening private screens; enabled remote control allows them to operate the TV during the session.

16. End and request a fresh reference

End the session from the sharing controls or ask staff to end it. Once the linked screen share ends, its sharing reference expires and the website setup clears. The Enabler clears the expired reference when it receives the server update; press New code and complete a fresh TV check before sharing again. Closure of the ticket/order also expires it; otherwise its maximum lifetime is 24 hours. Install reference and login PIN are unaffected.

Reconnect and solve problems

17. Reopen or switch sections

Every app launch requires the current account PIN. After login, valid saved references can be resumed without extending expiry. Return to home switches between Install our apps and Screen-share support while retaining TV details and each section’s valid reference. A network error alone does not erase a reference.

18. Restart website setup

Restart setup clears the ticket’s setup and releases its still-valid reference so you can type the reference the Enabler currently shows again. It does not make an expired sharing reference valid. After a share ends, ask for New code in the Enabler. Reset setup inside the app is a separate confirmed action which clears local TV details and both references; the next code takes over.

19. No picture or no permission box

Keep BM Remote Helper in front on the TV and approve the requested prompts. Check the PC and TV still share the same network. Ask staff to confirm they joined this ticket. If no picture appears, tell staff before ending and retrying with a fresh reference. Do not factory-reset or reinstall the TV as your first troubleshooting step.

20. Pairing or control problems

If Android/Google TV requires Wireless debugging code pairing, use the Windows PC Enabler: its pairing form accepts the TV’s six-digit pairing code and pairing port, while TV address uses the main Wireless debugging connection IP:port. The Android phone app has no pairing-code form. If control/Accessibility is unavailable, report the Enabler’s error to staff; do not disable TV security.

Privacy and safety
Only share with BM Support staff through your own support ticket. Close banking, payment, password and other private screens on the TV first. You can decline a request or end a session. Never publish your PIN or reference.