
2H1V1T5W Assembly Guide

2 Humbuckers, 1 Volume, 1 Tone, 5 Way Blade Switch (Coil Split)



Circuit Overview



2 humbuckers with coil split capabilities (In this example the pickups used are Gibson 490R & 498T Pickups)

Note: Other pickup brands may have different colour coding for their conductors, please check the pickup conductor guide.

5 way blade switch


- Position 1: Bridge pickup (Both Coils)
- Position 2: Bridge pickup (Single Coil)
- Position 3: Both pickups (Both Coils)
- Position 4: Neck pickup (Single Coil)
- Position 5: Neck pickup (Both Coils)

Master Volume & Master Tone

1/4" Mono Output Jack Socket

Connectors






Connector A will be pre-wired to the controls on terminals 1a & 2a. 1b & 2b are where you will connect the output jack in step 4

Connector B will be pre wired to the controls on terminals 1-6a. 1-6b are where you will connect the pickups in steps 1-3

Step 1 - Connect Pickup's Bare & South Start to Connector B






Connect the bare (No insulation) wire and the south start wire (black) of the Neck pickup to terminal 3b on Connector B.

Connect the bare (No insulation)wire and the south start wire (black) of the Bridge pickup to terminal 6b on Connector B.

Step 2 - Connect Pickup's North Finish & South Finish to Connector B






Connect the North Finish wire (White) and the south finish wire (Green) of the Neck pickup to terminal 2b on Connector B.

Connect the North Finish wire (White) and the south finish wire (Green) of the Bridge pickup to terminal 5b on Connector B.

Step 3 - Connect Pickup's North Start to Connector B





Connect the North start wire (Red) of the Neck pickup to terminal 1b on Connector B.


This is the pickup's Hot/Live Output.

Connect the North start wire (Red) of the Bridge pickup to terminal 4b on Connector B.

This is the pickup's Hot/Live Output.

Step 4 - Connect Output Jack Socket to Connector A





Connect the Sleeve wire (Black) of the Pre-wired output jack socket to terminal 2b on connector A.

Connect the Tip wire (Yellow) of the Pre-wired output jack socket to terminal 1b on connector A.