

Basic Radar Altimetry Toolbox v3.3 User Manual

Contents	
Introduction	5
Global Overview	5
Toolbox Contents	5
BRAT Library	5
CODA	5
BRATHL	<i>6</i>
BRAT Console Applications	<i>6</i>
BRAT GUI Applications	<i>6</i>
BratGui	7
BratDisplay	
BratScheduler	
Data read and processed	8
Background	8
Level 1B/2 data products	8
Higher-level products	9
How to install and uninstall BRAT	10
Supported Platforms	10
The BRAT Distribution CD	10
MS Windows	10
Installing the binary distribution	10
Installing from source	11
Uninstalling	11
Linux	11
Installing the binary distribution	11
Installing from source	12
Uninstalling	12
Mac OS X	12
Installing the binary distribution	12
Installing from source	13
Uninstalling	13
BRAT Graphical User Interface (GUI)	14
Overview	14
Starting with BRAT GUI	14
Create a workspace	14

Create a dataset	
Create an operation	17
Select source data	18
Define expressions	19
Generalities	19
X, Y and Data Expressions	20
Selection criteria expression	21
Output	22
Export	23
Create a view	23
BRAT GUI tabs description	26
Workspace menu	26
Datasets tab	27
Creation of a dataset	28
Management of the data files list	28
Selection of data files	28
Data file information	29
Operations tab	29
Manage Operations	30
Define source data	
Define expressions	33
Expression information and parameters	34
Units	36
Functions	37
Formulas	40
Algorithms	41
Data computation	46
Resolution and Filters	47
Views tab	49
Management of the views	49
Data to be visualised	49
General plot properties	50
Display Expression properties	51
Logs tab	52
lineae	52

Using aliases	53
Structure	53
Modifying an alias	54
Creating an alias	54
For a field for which no alias exists	54
For a field for which an alias has already been defined	54
Visualisation interface	56
'Y=F(X)'	56
'Z=F(Lon, Lat)'	59
Display properties	60
Color table editor	62
Two-color gradient color tables	63
Multi-color gradient color tables	63
Contour table editor	64
'Z=F(X,Y)'	65
Vector Plots	66
BRAT scheduler interface	67
Pending Tasks tab	67
Processing Tasks tab	68
Ended Tasks tab	69
Scheduler Logs tab	70
Using BRAT in 'command lines' mode with parameter files	71
Creating an output netCDF file	
Visualising an output netCDF file through BRAT	
Using the parameter files to process many datasets	74
BRATHL Application Programming Interfaces (APIs)	76
Data reading function	76
Cycle/date conversion functions	77
Date conversion/computation functions	78
Named structures	79
Annex A.List of datasets read by BRAT	81
Annex B.Y=F(X) parameter file keys	
Annex C.Z=F(X,Y) parameter file keys	87
Annex D.Display parameter file keys	
Annex E.BRATHL-IDL API	95

Basic Radar Altimetry Toolbox User Manual	5
Annex F.BRATHL-MATLAB API	107
Annex G.BRATHL-Fortran API	118
Annex H.BRATHL-C API	
Annex I.BRATHL-PYTHON API	137

Introduction

Global Overview

The Basic Radar Altimetry Toolbox (BRAT) is a collection of tools and tutorial documents designed to facilitate the processing of radar altimetry data. BRAT is able to handle most distributed radar altimetry data formats, providing support for ingesting, processing, editing (to a certain extent), generating statistics, visualising and exporting the results.

BRAT consists of several modules operating at different levels of abstraction. These modules can be Graphical User Interface (GUI) applications, command-line tools, interfaces to existing applications (such as IDL and MATLAB) or application program interfaces (APIs) to programming languages such as C, Fortran and Python.

The main BRAT functions are:

- **Data Import and Quick Look**: basic tools for extracting data from standard formats and generating quick-look images.
 - **Data Export**: output of data to the netCDF binary format, ASCII text files, or GeoTiff+GoogleEarth; raster images (PNG, JPEG, BMP, TIFF, PNM) of visualisations can be saved.
 - Statistics: calculation of statistical parameters from data.
 - Combinations: computation of formulas involving combinations of data fields (and saving of those formulas).
 - Resampling: over- and under-sampling of data; data binning.
 - Data Editing: data selection using simple criteria, or a combination of criteria (that can also be saved)
 - Exchanges: data editing and combinations can be exchanged between users
 - **Data Visualisation**: display of results, with user-defined preferences. The viewer enables the user to display data stored in the internal format (netCDF).

APIs are available with data reading, date and cycle/pass conversion and statistical computation functions for C, Fortran, IDL, MATLAB and Python, allowing the integration of BRAT functionality in custom applications. For the most common use cases (selection, combinations, visualisations, etc.), command-line tools are available that can be configured by creating parameter files. For beginners, we recommend using the BRAT GUI application, which enables the operator to easily specify the processing parameters required by each tool (and then invoke those tools at the push of a button).

BRAT is provided as Open Source Software, enabling the user community to participate in further development and quality improvement.

Toolbox Contents

BRAT consists of the following parts:

BRAT Library

The core part of the toolbox is the BRAT library package itself. This package provides data ingestion functionality for each of the supported data products. The data access functionality is provided via two different layers, called CODA and BRATHL:

CODA

The first BRAT layer (formerly known as BRATLL) is implemented using the Common Data Access framework CODA. CODA allows direct access to product data, supporting a very wide range of products and formats. It provides a single consistent hierarchical view on data independent of the underlying storage format.

The version of CODA that comes with BRAT supports over 200 altimetric product files. All product file data is accessible via the CODA C library. Furthermore, the version of CODA in BRAT also comes with a set of command-line tools (*codacheck*, *codacmp*, *codadump*, and *codafind*). Typically, BRAT users will not need to deal with the CODA library directly (although it is included if it is needed), but the CODA command-line tools can be useful for investigating or debugging product data files directly.

More information about the CODA framework and tools can be found in the CODA documentation, supplied in the BRAT doc/coda/ directory in (HTML format). Be aware that in order for the CODA command-line tools to function correctly in a BRAT environment, the user must manual set the CODA DEFINITION path environment variable to

include the location of the BRAT data directory (i.e. the data/ subdirectory of the BRAT installation root directory). This is necessary because the CODA command-line tools need to be told where to find the BRAT product format definition files. In order to check if everything is set properly, the command:

codadd list

will yield a list of all the products CODA recognises. (For a correct BRAT configuration, this list will e.g. include JASON and River_Lake products.)

More information about the specific altimetry product formats made accessible from BRAT through CODA can be found in the CODA definitions documentation, supplied in the BRAT doc/codadef/ directory (HTML format), and in Chapter 2, Data read and processed and Annex A, List of Datasets read by BRAT.

BRATHL

The second layer of BRAT provides an abstraction to the product data to make it easier for the user to get the most important data from a product. A single function will allow the user to ingest selected altimetric product data values (from one or more files), into an array. It is also possible (in the same function call) to request statistics on the ingested data and to perform calculations on the data values (e.g. *field1 + field2*). In addition to the ingestion function, a number of date and cycle data structures and conversion functions are also available.

The BRATHL library is implemented in C++, and built on top of the CODA framework (plus various other third-party libraries). It is possible to develop programs that make direct use of the C++ classes that make up the BRATHL library, but this is mainly intended for the (rare) case in which users need to develop BRATHL itself.

Instead, the simple public BRATHL functionality described earlier is accessible via C, Fortran, IDL, MATLAB and Python interfaces.

More information about the various BRATHL APIs can be found in Chapter 9, BRATHL Application Programming Interfaces (APIs).

More information about the C++ BRATHL API can be found in the BRAT reference manual, supplied in the BRAT doc/ directory (PDF format).

BRAT Console Applications

Most BRAT users will not be programmers and will interact with the BRAT library via the use of one or more of the supplied executable applications.

The toolbox contains a number of console applications that are to be run from the command-line. These applications shield the user from the library and the programming level by providing a set of the most commonly needed BRAT functionalities (data computations, data conversions, etc.). These functionalities are in turn user-configurable by so-called parameter files that can easily be created, stored, and shared.

The console applications included in BRAT are: BratCreateYFX, BratCreateZFXY, BratListFieldNames, BratShowInternalFile, BratStats, BratExportAscii and BratExportGeoTiff.

In addition, BRAT also contains the lower-level CODA console applications mentioned in Section 1.2.1.1, as well as the similarly low-level *ncdump* and *ncgen* utilities. These latter two are part of the netCDF library and can be used to inspect (*ncdump*) or create (*ncgen*) data files in the netCDF format.

More information about the BRAT Console Applications can be found in Chapter 8, Using BRAT in 'command lines' mode with parameter files.

BRAT GUI Applications

In order to provide a truly pleasant, user-friendly interface to the BRAT functionality, BRAT also contains three applications that present a Graphical User Interface (GUI). It is expected that most BRAT users will primarily interact with BRAT through these applications.

BratGui

BratGui is the main BRAT application. It allows the user to create and manage Workspaces, Datasets, Operations and Views at a very high level of abstraction, and with all the power and convenience of a modern-day graphical user interface. BratGui is built on top of the BRAT Console Applications, which it invokes 'under the hood', shielding the user from having to deal with command line options or parameter files directly.

There is a price to pay for the convenience of BratGui: not *all* functionality of the console applications is available through BratGui. If the users reach the limits of what can be done with BratGui, they will have to learn to work with the console applications after all. For a majority of important uses, however, the functionality of BratGui should be sufficient.

More information about BratGui can be found in Chapter 4 BRAT Graphical User Interface (GUI).

BratDisplay

BratDisplay is the BRAT visualisation component used as a component of BratGui but also available as a standalone utility. It is partially a GUI Application because it presents a windowed environment for further interaction with the visualisation, and partially a Console Application as it needs a parameter file as input and has to be started from the command-line.

As with the Console Applications, many users will typically interact with *BratDisplay* through *BratGui* only, but it is a useful tool to be aware of.

More information about BratDisplay can be found in Chapter 57 Visualisation interface.

BratScheduler

BratScheduler enables BRAT user to delay the execution of an Operation (e.g. having it running at night). It is available through BratGUI in the Operations tab, but can also be accessed through its own icon/executable (to check and modify a scheduled task, in particular).

More information about BratScheduler can be found in Chapter 7 BRAT scheduler interface.

Data read and processed

Background

The Basic Radar Altimetry Toolbox is able to read most distributed radar altimetry data, from (ERS-1 & 2 (ESA), Topex/Poseidon (NASA/CNES), Geosat Follow-On (US Navy), Jason-1 (CNES/NASA), Envisat (ESA), Cryosat (ESA) and Jason-2 (CNES/NASA/EUMETSAT/NOAA) missions. The different types of data readable and processed by the Basic Radar Altimetry Toolbox are listed below (for a description of the exact datasets with their nomenclature, see 82, List of datasets read by BRAT).

Note that data stored in arrays (e.g. waveforms) are not available individually (i.e. you can't access one value in the array) through the Graphical User Interface, but "only" through the API (See Chapter 9, BRATHL Application Programming Interfaces (APIs)), except for high-resolution GDR data (10, 18 and 20-Hz data) that you can access individually via the GUI.

NetCDF COARDS-CF compliant data can be read by BRAT. Note, however, that no warning/error message will be issued if different data are mixed, thus leading to incoherent datasets.

Level 1B/2 data products

Data	Satellite(s)	Data center	Format
Level 1B & level 2	Cryosat	ESA	ESA PDS
RA-2 wind/wave product for Meteo Users (RA2_WWV_2P)	Envisat	ESA	ESA PDS
RA-2 Fast Delivery Geophysical Data Record (RA2_FGD_2P)	Envisat	ESA	ESA PDS
RA-2 Geophysical Data Record (RA2_GDR_2P)	Envisat	ESA	ESA PDS
RA-2 Intermediate Geophysical Data Record (RA2_IGD_2P)	Envisat	ESA	ESA PDS
RA-2 Sensor Data Record (RA2_MWS_2P)	Envisat	ESA	ESA PDS
Interim Geophysical data record (IGDR)	Jason-1, Topex/Poseidon	AVISO PO.DAAC	binary
Geophysical data record (GDR)	Jason-1, Topex/Poseidon	AVISO PO.DAAC	binary
Operational Sensor Data Record (OSDR)	Jason-1	AVISO PO.DAAC	binary
Sensor Geophysical data record (SGDR)	Jason-1	AVISO PO.DAAC	binary
Operational / Interim / Geophysical data record (O/I/GDR)	Jason-2	AVISO EUMETSAT NOAA	netCDF
Sensor (Interim) Geophysical data record (S(I)GDR)	Jason-2	AVISO EUMETSAT NOAA	netCDF
Sea Surface Height Anomaly Operational / Interim / Geophysical data record (SSHA O/I/GDR)	Jason-2	AVISO EUMETSAT NOAA	netCDF
Topex waveforms	Topex/Poseidon	PO.DAAC	binary
RA OPR	ERS-1 and 2	CERSAT	ESA PDS
RA WAP	ERS-1 and 2	CERSAT	ESA PDS
Geophysical data record (GDR)	GFO	NOAA	binary

Higher-level products

Data	Satellite(s)	Data center	Format
Along-track Delayed-Time and Near Real Time Sea Level Anomalies (DT- & NRT-SLA) (Ssalto/Duacs multimission products)	Cryosat*, Jason-1, Jason-2, Topex/Poseidon, GFO, Envisat, ERS-2, ERS-1	AVISO	netCDF
Along-track Delayed-Time and Near Real Time Absolute Dynamic Topography (DT- & NRT-ADT) (Ssalto/Duacs multimission products)	Cryosat*, Jason-1, Jason-2, Topex/Poseidon, GFO, Envisat, ERS-2, ERS-1	AVISO	netCDF
Gridded Delayed-Time and Near Real Time Maps of Sea Level Anomalies (DT- & NRT-MSLA) (Ssalto/Duacs multimission products)	merged	AVISO	netCDF
Gridded Delayed-Time and Near Real Time Maps of Sea Level Anomalies mapping error (DT- & NRT-MSLA) (Ssalto/Duacs multimission products)	merged	AVISO	netCDF
Gridded Delayed-Time and Near Real Time Maps of Sea Level Anomalies geostrophic velocities (DT- & NRT-MSLA) (Ssalto/Duacs multimission products)	merged	AVISO	netCDF
Gridded Delayed-Time and Near Real TimeMaps of Absolute Dynamic Topography (DT- & NRT-MADT) (Ssalto/Duacs multimission products)	merged	AVISO	netCDF
Delayed-Time and Near Real Time Absolute Dynamic Topography geostrophic velocities (DT- & NRT-MADT) (Ssalto/Duacs multimission products)	merged	AVISO	netCDF
Along-track Delayed-Time Sea Level Anomalies (DT-SLA) (monomission product)	Cryosat*, Jason-1, Jason-2, Topex/Poseidon, Envisat, ERS-2	AVISO	netCDF
Along-track Delayed-Time Corrected Sea Surface Height (DT-CorSSH) (monomission product)	Cryosat*, Jason-1, Jason-2, Topex/Poseidon, Envisat, ERS-2	AVISO	netCDF
Along-track Sea Surface Height Anomalies (AT-SSHA)	Topex/Poseidon, Jason-1	PO.DAAC	binary
Along-track Gridded Sea Surface Height Anomalies (ATG-SSHA)	Topex/Poseidon, Jason-1	PO.DAAC	binary
Gridded Near Real Time Maps of Significant Wave Height (NRT-MSWH) (mono- and multi-mission products)	Jason-1, Jason-2, Topex/Poseidon, Envisat, GFO, merged	AVISO	netCDF
Gridded Near Real Time Maps of Wind Speed modulus (NRT-MWind)	Jason-1, Jason-2, Topex/Poseidon, Envisat, GFO, merged	AVISO	netCDF
Heracles along-track land-ice (multimission products)*	Cryosat*, Envisat	ESA	netCDF
Heracles crossover land-ice (multimission products)*	Cryosat*, Envisat	ESA	netCDF
Gridded Heracles SHA land-ice (multimission products)*	Cryosat*, Envisat, merged	ESA	netCDF
Gridded Heracles Sigma0 land-ice (multimission products)*	Cryosat*, Envisat, merged	ESA	netCDF
Gridded Heracles Leading Edge Width (LEW) land-ice (multimission products)*	Cryosat*, Envisat, merged	ESA	netCDF
River & Lake products	Envisat	ESA	binary

^{*} Forecoming dataset, or forecoming satellite for this dataset

How to install and uninstall BRAT

Supported Platforms

BRAT binaries are available as single-file installer packages for the three major operating systems: Windows¹, Linux², and Mac OS X^3 , for 32 bit and 64 bit architectures. These standalone installers can be downloaded from the BRAT Website (http://earth.esa.int/BRAT/html/data/toolbox_en.html) or copied from the top-level directory of the BRAT Distribution CD.

On not directly supported platforms and for certain purposes, BRAT will have to be compiled from source. A source archive is therefore also available, but as compilation is a rather complex affair it is highly recommended to try one of the binary installers first.

The BRAT Distribution CD

The BRAT Distribution CD contains:

- The binary installers for the supported platforms.
- The source archive.
- A copy of all the BRAT documentation (also already included in the binary installers).
- A large directory of sample data files (which is too large to be included in the binary installers).

MS Windows

Installing the binary distribution

BRAT supports Windows XP and higher. The binary distribution contains pre-built versions of the full toolbox as well as all the BRAT documentation and examples. For the IDL, MATLAB and Python interfaces, pre-built versions are included that will work with IDL 6.3 or higher and MATLAB V8.1/R2013a or higher.

The BRAT Windows binary installers are found in the files:

brat-3.3.0-Win32-installer.exe (32 bit architectures)

brat-3.3.0-x64-installer.exe (64 bit architectures)

In order to install BRAT, select and double-click the installer file that matches the architecture of your Windows version and follow the instructions.

By default, BRAT will be installed in C:/Program Files/BRAT-3.3.0/, or in the user's local profile directory when installed as a user without Administrator privileges. It is also possible to specify a custom installation location during the installation process. Note that using the 32 bit installer to install BRAT on a 64 bit system is not fully supported, so the installer will, for instance, suggest C:/Program Files/BRAT-3.3.0 as default installation directory instead of C:/Program Files (x86)/BRAT-3.3.0.

After installation, the BRAT Console and GUI applications are immediately ready for use. A shortcut to the BratGui application will have been placed on the desktop and is also accessible via the *Start > Programs > Brat* menu. In order to use the Console Applications (including BratDisplay), open a command window and call the applications directly from their installed location (C:/Program Files/ BRAT-3.0/bin/ by default, or else wherever you instructed the installer to install BRAT).

There a number of optional software prerequisites to using BRAT after installation:

• If you plan on using the C interface, you should have a C or C++ compiler installed on your system. The C interface has been verified to work with Microsoft Visual Studio 13, but it is expected to work with previous versions since at least Microsoft Visual Studio 10.

¹ Windows® is a registered trademark of Microsoft Corporation in the United States and other countries.

² Linux® is the registered trademark of Linus Torvalds in the U.S. and other countries.

³ Mac OS X® is a registered trademark of Apple Inc. in the U.S. and other countries.

- If you plan on using the Fortran interface, you should have a FORTRAN 77 or Fortran 90 compiler installed on your system.
- If you plan on using the IDL interface, you need a recent version of IDL for Windows: The IDL interface has been verified to work with IDL version 6.3 and higher.
- If you plan on using the MATLAB interface you need a recent version of MATLAB for Windows: The MATLAB interface will only work with MATLAB version V8.1/R2013a or higher.
- If you plan on using the Python interface you need to have a version of Python 3.x installed on your Windows system that matches the installed BRAT architecture (32 bit or 64 bit). You will then be able to open a console in the sub-directory \examples\python of your installation directory and run

\> python example.py

Installing from source

Generally, installation from source will be necessary if:

• You want to use IDL or MATLAB interfaces to BRAT for versions of these applications that are incompatible with the pre-compiled interfaces in BRAT.

The BRAT source distribution can be found in the file:

brat-3.3.0.tar.gz

After unpacking this archive in a suitable location, instructions for configuring, compiling and installing BRAT for Windows can be found in the top-level file INSTALL.txt

Uninstalling

Open the 'Add/Remove Programs' control panel, and select the BRAT entry. Everything created during installation will then be removed.

Alternatively, choose the 'Uninstall BRAT' menu item from *Start > Programs > BRAT* (or wherever you installed BRAT) – this will have the same result.

These uninstall methods only work for BRAT installations created through the binary installations. For BRAT installations from source, you will need to remove the various files and directories manually.

Linux

Installing the binary distribution

BRAT is developed on platforms running the Debian GNU/Linux 7.x operating systems, 32 bit (PAE) and 64 bit. Other Linux distributions (especially ones released in the past two years or so) are quite likely to work equally well, provided the operating system contains the following components:

- X11 Windowing System (BRAT has been tested on Xorg Xserver v1.1.1 and higher)
- GTK 2 libraries (BRAT has been tested on libgtk2 v2.8.20 or higher)
- C run-time libraries (BRAT has been tested on libc6 v2.3.6 or higher)

You will have to consult your Linux distribution's package manager to verify or update these components, but in general it is easier to install the BRAT binary distribution and simply see if it works or not (if it does not, you can always try to compile BRAT from source – see below for details).

The binary distribution contains pre-built versions of the full toolbox as well as all the BRAT documentation, examples, C, Fortran and Python interfaces. Because of inherent library versioning and path issues on the Linux platform, no IDL or MATLAB interfaces are included in the binary installation. If desired, these can be created by compiling from source for your specific installed version of IDL or MATLAB.

The BRAT Linux binary installers are found in the files:

brat-3.3.0-i386-installer.run (32 bit architecture)

brat-3.3.0-x86_64-installer.run (64 bit architecture)

In order to install BRAT, double-click on the installer file from a desktop manager window (or execute it from a command-line shell) and follow the instructions. (If you downloaded the installer via a network it may have been given the wrong file permissions and not be recognised by the system as executable. You should run the command 'chmod +x brat-3.3.0-x-installer.run', replacing "x" by "i386" or "x86_64" as appropriate, in order to make it executable.)

By default, BRAT will be installed in \$HOME/brat-3.3.0/ (where \$HOME stands for the user's home directory), or /usr/local/brat-3.3.0/ when installed as the root user. It is also possible to specify a custom installation location during the installation process.

After installation, the BRAT Console and GUI applications are immediately ready for use. A shortcut to the BratGui application will have been placed on the desktop. In order to use the Console Applications (including BratDisplay), open a command-line shell and call the applications directly from their installed location (\$HOME/BRAT-3.3.0/bin or else wherever you instructed the installer to install BRAT).

There are a number of optional software prerequisites to using BRAT after installation:

- If you plan on using the C interface, you should have the GNU C or C++ compiler installed on your system. The C interface has been verified to work with GNU C/C++ 4.1.1.
- If you plan on using the Fortran interface, you should have a FORTRAN 77 or Fortran 90 compiler installed on your system. The Fortran interface has been verified to work with GNU Fortran 4.1.1.
- If you plan on using the Python interface you need to have installed a version of Python 3.x matching the installed BRAT architecture (32 bit or 64 bit). You will then be able to open a console in the sub-directory /examples/python of your installation directory and run
- \$ python3 example.py

Installing from source

Generally, installation from source on Linux will only be necessary if:

- You want to use the IDL or MATLAB interfaces to BRAT.
- You are on a system that is older than the one used to create the BRAT Linux binary distribution (in which case BRAT will fail to run if installed as a binary).

The BRAT source distribution can be found in the file:

brat-3.3.0.tar.gz

After unpacking this archive in a suitable location, instructions for configuring, compiling and installing BRAT on Linux (or other Unix-based systems) can be found in the top-level file INSTALL.

Uninstalling

In the installation folder (the default one or the one chosen), there is a script called *uninstall-brat-3.3.0-linux or uninstall-brat-3.3.0-linux-x64* which can be executed to remove everything created during the installation.

There is also a shortcut, called 'Uninstall Basic Radar Altimetry Toolbox', which can be double-clicked from within your desktop manager (if you use the KDE or GNOME desktop environment) to get the same result.

Mac OS X

Installing the binary distribution

BRAT is supported on Intel-based systems running Mac OS X versions 10.6 or later.

This binary distribution contains pre-built versions of the full toolbox as well as all the BRAT documentation, examples, C, Fortran and Python interfaces. Because of inherent library versioning issues on the Mac OS Unix-based platform, no IDL or MATLAB interfaces are included in the binary installation. If desired, these can be created by compiling from source for your specific installed version of IDL or MATLAB.

The BRAT Mac OS X binary installers can be found in the disk image files:

brat-3.3.0-macosx-i386.dmg (for 32 bit architectures)

or:

brat-3.3.0-macosx-x86_64.dmg (for 64 bit architectures)

In order to install BRAT, double-click on the image file to mount and open it. Then copy the BratGui and BratScheduler applications that are inside the disk image to your Applications folder.

After installation, the BRAT Console and GUI applications are immediately ready for use. BratGui can be started by double-clicking the Applications/BratGui icon.

In order to use the Console Applications (including BratDisplay), drag the 'brat' folder from the image window to any appropriate location. Then, using e.g. the Terminal application, run the applications via a console directly from brat/bin.

There a number of optional software prerequisites to using BRAT after installation:

- If you plan on using the C interface, you should have the GNU C or C++ compiler installed on your system. The C interface has been verified to work with GNU C/C++ 4.1.1.
- If you plan on using the Fortran interface, you should have a FORTRAN 77 or Fortran 90 compiler installed on your system. The Fortran interface has been verified to work with GNU Fortran 4.1.1.
- If you plan on using the Python interface you need to have Python 3.x for Mac OS X installed on your system. You will then be able to open a console in the sub-directory /examples/python of the 'brat' folder and run

\$ python3 example.py

or

\$ arch -i386 python3 example.py

Installing from source

Generally, installation from source on Mac OS X will only be necessary if:

You want to use the IDL or MATLAB interfaces to BRAT.

The BRAT source distribution can be found in the file:

brat-3.3.0.tar.gz

After unpacking this archive in a suitable location, up-to-date instructions for configuring, compiling and installing BRAT on Mac OS X can be found in the top-level file INSTALL.

Uninstalling

To uninstall BRAT, simply move the applications BratGui and BratScheduler and the brat folder to the trash.

BRAT Graphical User Interface (GUI)

Overview

The BRAT Graphical User Interface (GUI) is a windowed interface to the BRAT Tools. Note that not all tool functions are accessible from the GUI (some options are only available using the command files directly).

The BRAT GUI includes:

- a "Workspace" menu
- a "Datasets" tab
- · an "Operations" tab
- a "Views" tab
- a "Logs" tab

BRAT GUI basically creates parameter files (see Section 8, Using BRAT in 'command lines' mode with parameter files), that are stored in an 'Operations' and a 'Views' folders, and runs several executables. It also enables to save your preferences and work.

The next section of this manual (4.2, Starting with BRAT GUI) explains the basics of the interface. For more detailed information about all the functionalities, see section 4.3, BRAT GUI tabs description.

Starting with BRAT GUI

Using BRAT GUI is basically a 4-step process.

You have to:

- 1. define a 'Workspace': preferences to be saved and retrieved for future use (see section 4.2.1, Create a workspace)
- 2. define one or several 'Dataset(s)': the data you want to work on (see section 4.2.2, Create a dataset)
- 3. define one or several 'Operation(s)' (see section 4.2.3, Create an operation):

define 'Data Expressions': the field(s) you wish and what you what to do with them (one field with respect to one or two others, combine them, statistics, resampling...)

(optionally) define 'Selection criteria': edit the data and/or select them with respect to your criteria (geographical, time, thresholds....)

Execute it to create an output file

4. define your "View(s)": visualise the results of your operations.

Execute it to open the data visualisation tool, and produce an output image (to be saved in PNG, JPEG, BMP, TIFF, PNM) (see section 4.2.4, Create a view)

BRAT GUI is organised in four tabs (Datasets, Operations, Views and Logs), and a 'Workspace' menu. Each tab corresponds to a different function, and to a different step in the process, so you'll have to use all of them one after the other.

This section gives the main information for a quick-start with BRAT GUI. For more complete information, see the relevant sections within the 4.3, BRAT GUI tabs description.

Create a workspace

When you open BRAT GUI, the software asks for the name and location of the 'Workspace' you will be working in. A 'Workspace' is a way of saving your preferences, computations and generally the work done with BRAT GUI. Some or all elements of a workspace can be imported into another workspace. There is no specific tab for the Workspace, only the menu the furthest to the left.

It is highly recommended to save your workspace (ctrl+s, or 'save' in the workspace menu) while working. You will be asked whether or not you wish to save the workspace when you quit BRAT GUI. Note that if you answer "no" and have not saved anything previously, none of your work can be recalled later.

If there are already one or more valid workspace(s), BRAT GUI recalls the last used Workspace by default.




Figure 1: 'Create a new workspace' window. You can choose to save it wherever you want on your hard drive or local network, and name it as you prefer (preferably in such a way you will remember what's in it).

Create a dataset

The first tab opened if you have never used BRAT is 'Datasets' (otherwise, the default tab is the the one that was opened when you left BRAT GUI the last time you used it). This 'Datasets' tab is dedicated to the definition and selection of the data you want to use. You **must** define **at least one** dataset to be able to further use BRAT.

To create a dataset, click on the 'new' button in the Datasets tab.

Figure 2: The Dataset tab as it appears when opening a new Workspace. The "New" button enables to create a new dataset.

Default name for a new dataset is 'Dataset_1', with the number incrementing each time you create a dataset. You are strongly encouraged to re-name it, so that you'll remember what's in it when using it later on. To rename it, simply select the name, type in another one and press the Enter key.

When you have created your dataset and named it, you then have to add one or more data file(s), chosen from your hard drive, CD/DVD driver, local network or other medium,. You can do so:

by using the 'Add Files' button. At least one file is necessary.

If you wish to add a long list of files, the 'Add Dir' button allows you to choose all of the files within a folder by simply choosing the folder in which they are stored. Be careful that some data have header files in their data folders (you can remove them after selecting the whole folder) that won't be considered as homogeneous with the data files by BRAT.

By **dragging and dropping** one or several files, or even a complete directory. Note that you have to have created the dataset beforehand.

Only coherent datasets are possible (i.e. same format, same data product). BRAT netCDF outputs can be used, even several of them, provided they have exactly the same variables, with the same names. The 'Check Files' button enable to verify this homogeneity.

Once you have added at least one data file, if you click on one file name in the list, you can see, right, information about the available fields within the data product, and (for netCDF files), about the file description below.

You can pre-select files relevant for your work by using the 'Define selection criteria' button and the 'Apply selection criteria' check box (see 4.3.2.3, Selection of data files), in order not to uselessly process files out of desired area/period/cycle or pass. This feature DOES NOT EXTRACT DATA from files, it "only" selects relevant files.

asets Operations Views Logs Product: ENVISAT_RA2MWR / RA2_GDR_2P Dataset Name GDR_En • hz18 diff_1hz_lon ra2 mds hz18 diff 1hz lon double hz18 ku ice2 edge width ra2 mds hz18 ku ice2 edge width int16 ra2_mds hz18_s_ice2_edge_width hz18_s_ice2_edge_width int16 hz18_s_k_cal_s ra2_mds hz18_s_k_cal_s dB double ra2_mds ap_18hz_k_cal_ku_flags double sd 18hz ku ocean bscat ra2 mds sd 18hz ku ocean bscat double ra2_mds sd_18hz_s_ocean_bscat sd_18hz_s_ocean_bscat num_18hz_ku_ocean_bscat num_18hz_ku_ocean_bscat uint16 num_18hz_s_ocean_bscat ra2_mds num_18hz_s_ocean_bscat uint16 hz18 ku ice1 bscat hz18_ku_ice1_bscat double ra2_mds hz18_s_ice1_bscat ra2_mds hz18_s_ice1_bscat ra2_mds double hz18_s_ice2_edge_bscat hz18_ku_ice2_bscat hz18_s_ice2_edge_bscat hz18_ku_ice2_bscat ra2_mds double ra2_mds hz18_s_ice2_bscat hz18_s_ice2_bscat hz18_ku_seaice_bscat ra2 mds hz18_ku_seaice_bscat ku_net_instr_corr_ago ku_net_instr_corr_ago 卪 ku_ocean_bscat_coeff: Cu-band corrected Ocean backscatter coefficient Check Files Apply selection criteria 4

Figure 3: A dataset. On the left, the list of files; right (top) the list of available fields for the selected file format, right (bottom), the description of the selected field as it appears in the data dictionary. Bottom left box give the file description for netCDF data.

Create an operation

When you have defined which data you want to work on, you have to define what you want to do with them. This is done in the 'Operations' tab.

If none exist, you have to create an Operation. Click on the 'new' button.

Default name for a new Operation is 'Operations_1', with the number incrementing each time you create an operation. You are strongly encouraged to re-name it, so that you'll remember what's in it when using it later on. To rename it, simply select the name, type in another one and press the Enter key.

Figure 4: An empty 'Operations' tab. The 'New' button enable to create a new 'Operation'.

Otherwise, you may work with a previously saved operation. The 'Operation Name' dropdown list contains all the already defined operations within the workspace, which can be selected, renamed, duplicated, modified... Note that if you change the name of an operation within the 'name' box, it renames your operation. To copy an operation, use the '**Duplicate**' button.

Select source data

The information about the source data are in the leftmost part of the Operations tab.

You first have to choose the dataset you want to work with from the list of existing datasets (topmost box). Then, within this dataset, the whole list of available fields is proposed, organised as a tree. If the data are split in different records, click on the '+' to expand the tree, '-' to flatten it.

The description of each field is given in a tooltip appearing when your mouse goes over the name of the field.




Figure 5: Choosing a dataset (here only one dataset is available, but many more can be added); below, the tree with records and data fields.

Define expressions

Generalities

An operation consists mainly in the definition of 'Expressions'.

An expression can be simple (one data field), or complex (with the use of arithmetic combinations, functions applied on several fields, etc.).

In the second column box of the 'Operations' tab ('Data expression'), you can see four categories of Expressions:

- X
- Y (optional)
- Data
- Selection criteria (optional)

At least one expression as 'X', and one as 'Data' must be defined for an Operation to be valid.

These expressions can be filled by several means, the quickest being by **drag & drop**: drag a field from the leftmost list and drop it in either one of those, or in the 'Expression' box (you can also use contextual menus by right-clicking either on the data fields or on the expressions, or use the 'Insert expression' and/or 'Insert field' button, or type in an empty expression the field names and functions you want to apply).

A 'brat_index_data' can be listed within the available data field. This is the index of the data (i.e. Measurement number in the file and/or record) **ordered along the time within a given file**. This means that it is not available for (e.g.) longitude-latitude grids, or for some data where the time is not provided explicitly.

If using this index with several different files in the same dataset, note that **the order of the files as appears within the dataset will be kept** (thus, if the files are not ordered chronologically, the net result will **not** be chronological either)

Note that only **one** expression can be defined as X, and (optionally) one as Y, whereas more than twenty can be defined as Data.

An Expression can be:

- only one field in a dataset (typically, for a map, longitude as X-axis, latitude as Y-axis, and e.g. significant wave height as Data, etc.)
- a combination of fields, either +,-,* and /, or by using the available Functions (see 4.3.3.4.2, *Functions*).
- a pre-set combination of fields among the ones you will find in the 'Formulas' (see 4.3.3.4.3, *Formulas*), e.g. SSH computation.

To check if your expression is well formulated, you can click on the '**Check syntax**' button (note, however, that this won't provide you with a validation of the relevance of your expression from the point of view of physics).

The '**Show Info**' button provides information about the original units (the ones defined in the data products) and the units used during computation or selection.

The 'Show Aliases' button provides information about the aliases available for the chosen dataset. Aliases are equivalents that you can use instead of the fields' name.

E.g. a %{swh} alias exists, that works for all GDR data for the Ku-band significant wave height. Note, however, that since not all the fields exists for all the data, you may encounter warnings if you try some aliases on all the altimetry data.

If you want to go back on your work later on, of to save an expression as formula, we strongly suggest that you take the time to fill the information in the 'Title/comment' fields (available by clicking on the button)

X, Y and Data Expressions

You can change the name of any X, Y or Data Expression, by double-clicking on their name, or by using the contextual menu available by right-click. This will then be the default name on the plots, on the axis or near to the scale if you have not given a title to your Expression (in the title/comment).

You can change the unit as it appears above the Expression box.

BRAT is able to understand all SI units and their sub-units <u>as defined in the International System</u>, i.e. <u>case sensitive</u> (e.g. "ms" means milliseconds, whereas "Ms" would means megaseconds). There are also "count" for data without dimension, and "dB" (see section 4.3.3.4.1, Units). If you let "count" (which is the default) as unit, the resulting data will be in the basic SI unit (e.g. in metres, even if the field you used was defined in mm). **Note that you have to validate your change of unit by typing "enter" or clicking on the box below**.

If you choose a pre-saved formula, a default unit will appear as the unit. If you select one field in the dataset list and insert it, it will automatically be filled with the correct unit (but if you finally write your own formula, beware that the final unit might be different). If the unit you defined does not fit the unit of the data as defined, an error message will be generated (again, this does not work for complex expressions).

On any X, Y or Data Expression, you can apply 'data computation' (see 4.3.3.4.5, Data computation), to:

- compute statistics at each point (same X, optionally same Y): MEAN, STDDEV (standard deviation),
 COUNT.
- do some arithmetic operations **between files** within a dataset: adding, subtracting or multiplying: SUM, SUBTRACTION, PRODUCT)
- it can also be used for the display (MEAN, FIRST, LAST, MIN, MAX), if you prefer to visualise, for instance, the last value rather than the mean one.

Note that to compute the statistics for the Data Expressions as a whole (Number of valid data, Mean, Standard deviation, Minimum, Maximum), you can use the 'Compute Statistics' button.

There are two main kinds of Operations:

- one or several Data expression(s) with respect to another one (X), leading to a "curve" plot
- or one or more Data expression(s) with respect to two others, leading to a "map" plot

In the first case, you'll fill only the "X" expression; in the second, you'll fill both X and Y expressions. Note that X and Y can be Longitude and Latitude, but can also be any other two fields or combination of fields within the dataset.

If you fill **both X and Y**, **you have to define a resolution**. For Longitude, Latitude a default resolution (1/3 of a degree for both axis), minimum and maximum are proposed. For other X and/or Y, a step of 1 is proposed, but no minimum and maximum. You can define a step, minimum and maximum values, or use the minimum and maximum value of your expression by clicking on the 'Get min/max expression values' button). The number of intervals is automatically computed from those elements, and cannot be directly changed.




Figure 6: An 'Operations' tab window when both X and Y are filled. Note the 'Resolution and filter Information' below the Expression box

Note that

- you cannot choose different resolutions for different data expressions within the same operation (they all share the same X and Y!).
- by choosing a step, you may sub-sample your source data.
- Changing the Min/Max can be used to extract a smaller X-Y area (as well as the selection criteria).
- And, of course, the smaller the steps, the higher the computation time! (and the heavier the output file)

You can also choose to smooth and/or extrapolate the data by means of a Loess filter so as to obtain a fully colored plot (and not individual tracks or points on a map). In that case, you will have to fill in the corresponding information for X and Y, too (see section 4.3.3.4.6, *Resolution and Filters*).

Selection criteria expression

The Selection criteria expression is used to select data e.g. by date and/or boundaries, etc. and/or for editing it using flag values, thresholds, etc. Logical, relational functions can be used, separated by && ('and'), || ('or') or with! ('not'). Only the data fulfilling the whole set of conditions, and not equal to default values, are selected.

The Selection criteria expression can be filled the same way than X, Y and Data expression. There can be only one Selection criteria expression. It is optional; when it is filled the 'Selection criteria' title is bold.

All the fields, or combination of fields of the source data can be used. To use a combination of fields, it can be clearer to use a formula (see section 4.3.3.4.3, *Formulas*).

Note that the selection criteria expression is working only with the basic SI units (i.e. when defining thresholds, you have to put values in e.g. meters, even if the data source field is in mm).




Figure 7: An example of a Selection criteria expression (Ocean data editing for Envisat GDRs.

Output

To process the defined operation on the whole selected dataset., you have to click on the 'Execute', button. The Logs tab then opens (see section 4.3.5, Logs tab), and you can see the current task(s) being executed (both operations and views), comments during execution (verbose mode) and errors.

The "**Delay Execution**" button enable to launch the Operation or an export (see next section) at a scheduled time. The "Launch scheduler" button launch the scheduler, which have to be running in order to have the task executed (NB. the Brat scheduler interface icon gives access to the same interface). (see chapter 7 for more details).

You may perform several different operations at the same time (i.e. execute one while another is being processed), or an operation and a view (provided you are not trying to visualise expression(s) from an operation being processed). However, this will slow down each individual execution.

Executing an operation build an output netCDF. The name of this netCDF file is predefined using the name you gave to your operation, and cannot be changed within the GUI. It is stored in the Operation folder within your workspace.

BRAT output netCDF files can be used as source data in a new dataset, seen though the BRAT Display tool, or used with any other tool reading netCDF.

Export

You can choose to export the output data by clicking on the '**Export**' button.

Several formats are available:

- NetCDF (the same than the automatic one, but you can choose where you want it, and how it is named)

for name The

the




Figure 8: Export pop-up window netCDF export: you can choose the and location of the exported file. operation can be re-executed before export or not (depending if modifications were done or not) 'delay execution' enables to programme the scheduler and have processing done later.

Ascii




Figure 9: Export pop-up window for Ascii export. You can choose the name and location of the exported file.

'delay execution' enables to programme the scheduler and have the processing done later.

The Ascii export can also be seen (once saved) through a built-in text viewer ('Edit Ascii export' button)

 GeoTiff (if the axis of the operation are longitude and latitude), which also provides a Google Earth KML export format.




Figure 10: 'Export pop-up window for GeoTiff export. You can choose the name and location of the exported file. You can also create a KML file to visualise the GeoTiff in GoogleEarth. Min, Max and color table can be defined for the data expression.

'delay execution' enables to programme the scheduler and have the processing done later.

Create a view

When you have executed your operation, you may want to have a look at the results in a graphical way. This is done through the 'Views' tab.

If none exist, you have to create a View. Click on the 'new' button.

Default name for a new View is 'Displays_1', with the number incrementing each time you create an operation. You are strongly encouraged to re-name it, so that you'll remember what's in it when using it later on. To rename it, simply select the name, type in another one and press the Enter key.

The main interest of creating several Views is to be able to retrieve your view in the future, with all its parameters (minimum and maximum on each axis, projection, color table with its minimum and maximum, etc.).




Figure 11: An empty 'Views' tab. The 'New' button enable to create a new 'View'.

Once you have named your view, you have to choose between the different expressions already computed (outputs from operations computed within the workspace). They are given by operation/expression name. You can refresh the list to update it with respect to the latest operations.

The list of available data is organised as a tree, with three main categories:

- Y=F(X), which are basically curve plots
- Z=F(X,Y), which are the representation of a value (in colors/contours) with respect to two others
- Z=F(Lon,Lat), i.e. maps

Under each category (click on '+' to expand the tree, '-' to flatten it), you will see the names of the operations already computed, and under each operation, the list of Data expressions defined within this operation.

The operations are listed in one category or the other depending on the way they were defined (see section 4.3.4.2, Data to be visualised for more details)

Norkspace Datasets Operations Views Help Datasets Operations Views Logs View name GOCE **General Plot Properties** North: 90 7 West: -180 East: 180 South: -90 **~** ☐ With animation Projection 3D View type: Z=F(Lon,Lat) ☑ Group expressions in the same plot Z=F(Lon,Lat) Unit 1st dim. (unit) 2nd dim. (unit) Title ▶ ■ GEOID_GOCE_DIRECT1 Operation Name **Expression Name** MDT GSV CSV m s-1 lon (degree... lat (degree... CSV **□** GOCE_DIRECT1 lon (degree... lat (degree. MDT_GSV astward_velocity eastward_velocity eastward velocity (m s-1) northward_velocity (m s-1) Refresh ▼ INTERP GSV GSV (count) eastward_velocity (m s-1) northward_velocity (m s-1) MDT_GSV ▶ **B** GSV (m s-1) Display Expression Properties astward_velocity (m s-1) Name northward_veloc Min. Max. northward_velocity (m s-1) ☐ East Component ✓ Solid color Departion gsv Color table GreenToRed V Browse... ✓ North Component ☐ Contour Expression_5 (m s-1)

Figure 12: A 'View' tab with one view created. Note the list of available data left.

To select a data expression for visualisation, drag & drop it from the 'Available' list to the 'Selected' list. You will the see in the 'Selected' box the operation name, the data expression name, its unit, and the unit of the axis (1st dim unit, 2nd dim unit).

You can select more than one data expression to be displayed. Provided they have the same axis (same X, or same X and Y), you can overlay the different data on the same plot by using the check box 'Group expressions in the same plot' (default is checked). Typically, you can have a color and a contour map plotted one overlaying the other, or curves of several different colors on the same plot. If unchecked, or if the data are not compatible, BRAT will open as many visualisation windows as there are expressions selected.

To un-select an expression, either use the arrow button, or press on the 'Delete' key on your keyboard.

'With Animation' can be used to animate a series of plots (Z=F(X,Y) or Z=F(Lon,Lat)). If you have several identical expression names from several operations (e.g. if you have computed the same expression at different dates) and if you check this option, you will have access to the 'animation toolbar' in the visualisation interface.

Some properties can be defined for the plot, either for the all plot (general properties), or for each data expression separately (Expression properties). Most of them can be changed or be defined in the visualisation window (see Erreur: source de la référence non trouvée, Error! Reference source not found.) but, if only done there, have to be re-defined each time you launch a plot. Filling those information in the Views tab has the advantage of being able to re-use them later on, for another plot.

- You can give your View a 'title' (just below the 'name' of the view). This will appear as the title of the plot. It can also be used as a reminder. By default, it is the title of the field given in the 'title/comment' of the data expression, or the name of the data expression.
- For the maps, you can choose between several projections (default is a 3D projection)

- You can define a sub-set to be plotted (by X min, X max, Y (=data expression or =axis) min, Y (=data expression or =axis) max) in the 'Zoom' boxes.
- The name of the plotted expression.

 By default, this will be the title of the expression given in the 'title/comment' of the data expression, or the name of the data expression (if no title was given). It will be used either as title of the color scale, or as title of the axis.

For the Z=F(X,Y) and Z=F(Lon,Lat) cases,

- **East/North Component** can be selected to display vector plots, in which one expression has to be selected as north component and a different one for east component. Only one vector plot can be displayed at a time. Both expressions must be of the same data type.
- A choice between '**solid color**' and '**contour**' representation. It is of course highly recommended to choose at most two different fields to be displayed on the same plot, one represented in solid colors, the other in contours, to be able to see something on the plot.
- Minimum and maximum of the color scale
- The color scale, among a pre-defined list of color scales, or in previously made and saved color scale (see section 6.2.1.Color table editor).

For Z=F(Lon,Lat), you have necessarily X=Longitude, Y=Latitude. However, when you use other fields as X and/or Y, you may wish to switch them – this is the goals of the 'invert X/Y' check box

The 'Execute' button will launch the visualisation tool (see chapter 6 for a description of this interface). You can see in the 'Log' tab the current executions (both operations and views) and the errors.

BRAT GUI tabs description

Workspace menu

A 'workspace' is a way of saving your preferences, computations and generally the work done with BRAT.

A workspace contains definitions of:

- Datasets, that define the collections of files of the same kind you want to use,
- Operations, for reading and/or processing and/or selecting data within a dataset,
 An operation produces an intermediate file (netCDF) and a parameter file. Alternatively, data can be exported, in netCDF, Ascii or GeoTiff and KML.
- **Formulas**, to enable you to use pre-defined combinations of data fields or to define them yourself and reuse them later.
- Views, that plot results of one or more operations
 A 'view' produces a parameter file and opens the visualisation tool

All these are stored within a folder named from the workspace, with a sub-folder for each part: Datasets, Displays, Formulas and Operations. Displays and Operations folders include parameter files (.par), which define the Views and Operations done, and the latter also include the netCDF intermediate files produced by the tool.

Workspace folders can be copied and exchanged. Results saved within a workspace can be accessed even if the source data are not available (but warning messages will be emitted when opening the workspace if some source data are not available).

Workspaces in BRAT GUI are managed by the menu the further to the left. It contains the following items:

- 'New': creates a new workspace
- 'Open': opens a previously saved workspace
- 'Save': (or ctrl+s) saves the current workspace and all its datasets, operations, formulas and views

- 'Import': imports a previously saved workspace within the current one (Datasets, Operations, Formulas and/or Views). Formulas can be imported separately, but otherwise, Views need the Operations and Operations need Datasets, so that you can't import Views without Operations and Datasets, nor Operations without Datasets.
- 'Rename': renames the current workspace (note that it is not a copy, but a change of name)
- 'Delete': deletes the current workspace
- 'Recent workspaces': lists the 2 most recently used workspaces

Datasets tab

This tab is dedicated to the choice of the source data product files.

In this tab window:

- The selected files' names are on the left; as well as the tools to select them.
 - The right-hand display lists all fields defined for this kind of data and, below there is a more detailed description of the selected field (extracted from the data dictionary).

You may define as many datasets as you wish.

Note that if you want the same operation to be applied to several files separately, you will have to define several datasets, or use the parameter files directly with a script (see section 8.3).




Figure 13: Example of dataset with netCDF data selected.

Creation of a dataset

- The 'Dataset Name' dropdown list contains all the defined dataset names and allows you to select and rename a dataset. You have to give the dataset a name (with no spaces or special characters in the name). If you change the name within the 'name' box, and press the Enter key it **renames** your dataset.
- The 'New' button creates a new dataset, with a name like 'Datasets_2' This can also be done using the Datasets menu.
- The '**Delete**' button enables to delete an existing dataset , if your dataset is not used in an Operation. This can also be done using the Datasets menu.

Management of the data files list

The 'Files in dataset' list includes all the files of the dataset. Note that only coherent datasets are possible (i.e. same format, same data product).

- The 'Clear' button will remove the whole list.
- You can delete the selected file by using the 'Remove' button, or the 'delete' key on your keyboard.
- The '**Up**' '**Down**' and '**Sort**' buttons are useful when the order in which files are processed is important (e.g. subtracting one file from another).
- 'Up' moves the selected file upwards in the list,
- 'Down' moves it downwards.
- 'Sort' puts the whole list into alphabetical or numerical order. It can also be used to check for two occurrences) of the same file, or missing files, or to remove unwanted files from a list.

Selection of data files

Data can be selected in a quite long list of altimetry data (see 2, Data read and processed). File names don't have to be the original ones. However, files within a dataset have to be of the same data product (no mixing of e.g. Envisat and Jason-1 GDR data).

- The 'Add files' button (at the bottom of the window) enables you to select those data files you wish to work on. Drag&drop of files within the interface has the same result.
- If there are a lot of files, you should preferably select a whole folder by clicking on 'Add Dir', or proceed in several steps. Otherwise, some files names could be truncated, thus leading to an error. Drag&drop of a directory within the interface has the same result.
- the 'Check files' button at the bottom of the window checks for the dataset coherence.

For a more automatic selection of data files, you can use the data pre-selection function:

- the 'Define selection criteria' button enables to pre-select only the files relevant for your work. To use this feature, you have to define the kind of data and the selection criteria, then tick the "Apply selection criteria" before selecting e.g. a whole folder of data. When you add the files or the whole directory, the selection will be applied, and only the relevant files will appear within your dataset.
- Date/Time are to be defined as YYYY-MM-DD HH:MM:SS (if no HH:MM:SS are given, default is 00:00:00). Alternatively, Julian days since 1950 can be used Longitude / Latitude given are the North and South, West and East limits. Latitudes South of the Equator are negatives. Longitudes can be written either as 0-360 or -180 180. (thus example left is 350-0°E, 40-50°N)
- You can check what was done using the '**Show selection report**' button. This feature uses the information given in the data 'headers' to select only the files that could include the area (or period) of interest, or the files matching the selected cycle(s)/pass(es). Note that this implies that the possibilities of selection depends on the satellite/data product, since the headers do not always include the same information.




Figure 14: Example data selection criteria definition: top, choose your satellite/data product (here, Jason-2) Once this is done, you can choose below the date/time period, Latitude/longitude, cycle number, and/or pass number.

Note that the choice in latitude in inactivated in Jason-2 GDR case, as in most GDR cases, since those data files typically includes data for a full half-orbit (thus all the files have the same minimum and maximum in latitude, making such a selection irrelevant).

Data file information

On the right of the Datasets tab, you can see information about the fields within the source data product.

The list of all the fields of the currently selected file is divided into 6 columns:

- 'Full name': the fully described name in the file structure hierarchy and related to the record.
- 'Record': the record containing the field. Many altimetry data products have only 'header' and 'data' records while others have more (e.g. Envisat ones)
- 'Name': the short field name
- 'Unit': the unit of the field
- 'Format': the format of the field inside the file. In BRAT all fields are read as floating-point values (double).
- 'Dim': Dimension of the field (number of values in arrays, if the data is stored in an array)

You can sort the fields alphabetically by clicking on 'name', 'record', 'unit', 'format', or 'dim' (off screen), at the top of the box, or view a field whose name begins with one or more letters by typing them (fast).

Under the list there is the 'Fields description' box with a detailed description of the currently selected field (as extracted from the data dictionary)

Left, under the file list is a 'File description' box, that give the information about the file for netCDF products.

Operations tab

This tab is dedicated to the definition of what kind of computation(s) and/or selection(s) you want to apply on the data.

Building an operation in fact creates a 'parameter' files (.par), which keeps all the informations and which is stored in the Workspace Operations folder. Executing an operation use either the BRATCreateYFX or the BRATCreateZFXY programme on this parameter file to generate the output of the operation. The whole process can however be done completely through the GUI.

In this Operations tab window:

- The management of the operations is at the top.
- The data source (datasets and fields available within) are on the left.
- The middle part shows the different Expressions within the current Operation
- The right-hand part shows the content of the selected Expression.

You may define as many Operations as you wish.

Note that an Operation must contains at least one X expression, and one Data expression.



Figure 15: Operations tab, with an operation being built. Left the dataset chosen is called 'test_dataset', with Envisat GDR data product; below the list of fields within the ra2_mds record being expanded. In the middle, only one Expression is defined yet ('lat' as X). Right, the content of the 'lat' expression (only one field, in this case), its unit is degrees.

Manage Operations

Several functions are meant to 'manage' the operations.

- The 'Name of operations' dropdown list contains all the defined operation names and allows you to select and rename an operation. When renaming an operation, take care that it does not copy it, but it replaces the old one.
- The 'New' button is used to create a new operation, with a name like 'Operations_2' This can also be done using the Operations menu.
- The 'Duplicate' button enables you to copy an existing operation, and modify it (e.g. change the dataset for another one with the same kind of data at another date, change the selection criteria, etc.).

.....

- The '**Delete**' button enables to delete an existing operation, if none of your operation's expression is used in a View.
 - This can also be done using the Operations menu.
- The 'Execute' button executes the active operation. BRAT GUI then switch to the 'Logs' tab.
- The 'Export' button enables to save the BRAT GUI output on either another format (Ascii, GeoTiff and KML) or in netCDF, and under another name wherever you prefer it.
- The 'Delay execution' button schedules the active operation at a time given by the user. Note that it won't be processed if the 'Launch scheduler' is not running. So please remember to click on the 'launch scheduler' button, or to double-click on the "BRAT scheduler interface" icon in order to have the task(s) executed. BRAT GUI can be closed.



Figure 16: The "delay execution" pop-up window. Date and time for the execution, as well as an optional name for the operation can be defined. Once scheduled, such an operation can be viewed or removed within BRAT scheduler interface.

- The 'Launch scheduler' button opens BRAT scheduler interface (it can also be launched using the desktop icon). See chapter 7 for details on this interface.




Figure 17: An example of Ascii export as seen though the built-in text viewer.

- The 'Compute Statistics' button gives the global statistics for each Data expression. You can thus retrieve:

- Number of valid data,
- o Mean,
- Standard deviation,
- o Minimum,
 - o Maximum,

If you want to apply the same operation to different datasets, and be able to compare their outputs, you will have to re-create it as many times as needed, using the '**Duplicate**' button. You can also use the parameter file directly with a script (see section 8.3, Using the parameter files to process many datasets). Or, you can export the data in netCDF for future use (otherwise, the output file will be replaced by the new one)

Define source data

- 'Datasets' box lists the names of the datasets available within this workspace: you have to select one of them
- 'Fields' box shows the list of all fields available within the selected dataset, organised as a tree.

 Right-click provides a contextual menu, with 'sort ascending' and 'sort descending' at the bottom, to sort the data field names in alphabetical order (or reverse).
 - To know some information about one field, hover the mouse pointer over it, and a tooltip will appear.




Figure 18: Operations tab with a tooltip active over one of the data fields ('alt_cog_ellip').

Define expressions

In the middle of the Operations tab is the tree with the expressions, including the selection applied. You have four kinds of expressions:

- 'X': as axis (the data will be organised relative to the values within this field); only one X expression is possible, and one is necessary.
- 'Y (optional)': to be used as second axis (e.g. X=longitude, Y=latitude); only one Y expression is possible
- 'Data': at least one Data expression is necessary, but you can add up to twenty of them.
- 'Selection criteria' (optional; the title is bold when it is filled): it enables to select data e.g. by date and/or boundaries, etc. and/or for editing it using flag values, thresholds, etc. Logical, relational functions can be used, separated by && ('and'), || ('or') or with! ('not'). All the fields, or combination of fields of the source data can be used. To use a combination of fields, it can be clearer to use a formula. Note that the selection criteria expression is working only with the basic SI units (i.e. when defining thresholds, you have to put values in e.g. meters, even if the data source field is in mm).

X an Y are used as axis: BRAT will read the source data and extract, for each X (optionally Y), the corresponding value of each Data expression fulfilling the conditions defined as 'selection criteria'.

All expressions can be filled the same ways.

The expressions can be filled by several means:

- The quickest is by **drag & drop**: drag a field from the leftmost list and drop it in either one of those, or in the 'Expression' box;
- you can also use the contextual menus that appear by right-clicking either on the data fields or on the expressions,





Figure 19: An example of menu that appears by right-click on a data field (here, the 'lat' field'). 'Set as X', 'Set as Y' and 'Set as Data' define the chosen field as either X, Y or Data. 'Insert into Selection criteria' insert the field within the Selection criteria expression. 'Sort' enable to sort all the fields in either ascending or descending (alphabetical) order.

Figure 20: Example of menu that appears by right-click on a data expression (here called 'test'). Note that here one data field ('alt_cog_ellip') is selected (left-click); if no data field is selected, this item is inactive.

'Insert empty expression' will add a new expression (in 'Data'), or replace the active expression by an empty one (in X and Y). 'Insert (field) into expression' add the selected data field (if any) in the active expression. 'Insert function' enable to use the list of mathematical and logical functions, and 'Insert formula' insert one of the predefined expressions saved.

'Sort' enable to sort all the expressions (if there's more than one) by their name in either ascending or descending (alphabetical) order.



or use the 'Insert field' button (which will insert the selected data field in the active expression).

 or you can always use the 'Insert expression' (which will insert an empty expression, to be filled by one or several combined fields) and type in an empty expression the field names and functions you want to apply, using your keyboard

Since you can do more than insert one field, a set of functions is available, as well as


- The 'Insert Function' button opens the pop-up window with the list of available functions (see section 4.3.3.4.2, *Functions*) for the complete list and specifications)
- The 'Insert Formula' button opens the pop-up window with the list of available formulas. A set of those is pre-defined (see 4.3.3.4.3, *Formulas*); more can be saved using 'Save as Formula' button and re-used, in the same Workspace or imported in another one
- The 'Insert Algorithm' button opens the pop-up window with the list of available algorithms (see section 4.3.3.4.4, *Algorithms*) for the complete list and specifications)
- 'Delete expression' button enables to delete an expression (the Delete key on your keyboard has also the same effect). Remember, however, that you have to have an X and a Data expression defined.

Expression information and parameters

When an expression is selected, several parameters can be filled/used.

- 'Unit' of the expression: this text field is filled whenever you define a data field as expression, or use a predefined formula. Default is 'count' (meaning, without unit). See section 4.3.3.4.1, Unitsbelow for details about the units you can use. The unit of the Selection criteria expression is always 'count', since it is a logical expression)
- The 'Type of the expression' dropdown list is mainly of use for longitude, latitude and time as X and Y, and help manage specific needs for those type of data. Most of the time it should be automatically filled. If a discrepancy is detected, an error can be issued in the Logs tab.
- The 'Expression' box: this where the expression itself is defined
- 'Data Computation' rolling list
- 'Check Syntax' button
- 'Show info' button

Figure 21: "Show Info' pop-up window.
Here it is applied on a Sea Surface Height expression. You can see that the original data product expresses all the fields in mm, whereas the computation is done in metres



- 'Show aliases' button

Aliases have been added within BRAT to take into account the fact that the equivalent fields are not named similarly for all the datasets (names following the User documentation made by the data provider). The equivalent fields have been defined with the same alias(es) for all the altimetry data. If a given field is not available within the current dataset, a warning will be issued.

Note that there may be several aliases for a same field, in order to speed the typing (e.g. %{mss}), or be more self-explaining (e.g. %{mean sea surface}).

An alias can be a field or a combination of fields. They are stored in a "aliases.xml" file that can be edited (in brat program folder, data/ sub-folder). In the same folder, the aliases.xsd.html file gives the rules to define new aliases and/or modify the existing ones.

See section 54 Aliases for more information.

list below shows the available	aliases for the product ENVISAT_RA2MWR_RA2.	GDR 2P		
ist below stows the available	allases for the produce of tracking one.	_dox_2		
	Value	Syntax	Description	Select (*)
ılt	ra2_mds.alt_cog_ellip	%{alt}	altitude (Synonym of altitude).	
oltitude	ra2_mds.alt_cog_ellip	%{altitude}		
lry_tropo_corr	ra2_mds.mod_dry_tropo_corr	%{dry_tropo_corr}		
dynamic_atmos_corr	((ra2_mds.dib_hf + ra2_mds.inv_barom_corr))	%{dynamic_atmos_corr}		
b	ra2_mds.inv_barom_corr	%{b}	inv_baro_corr (Synonym of inv_baro_corr).	
nv_baro_corr	ra2_mds.inv_barom_corr	%{inv_baro_corr}		
ono_corr	(iif(((mph.cyde == 47) && (sph.pass_number > 935)) ((mph.cyde == 48) && (sph.pass_number < 848)) ((mph.cyde == 65) && (sph.pass_number > 288)) (mph.cyde > 65), ra2_mds.ion_corr_mod_ku, ra2_mds.ra2_ion_corr_ku))	%{iono_corr}		
at	ra2_mds.lat	%{lat}		
at_hr	ra2_mds.lat	%{lat_hr}	lat (Synonym of lat).	
on	ra2_mds.lon	%{lon}		
on_hr	ra2_mds.lon	%{lon_hr}	lon (Synonym of lon).	
nean_sea_surface	ra2_mds.m_sea_surf_ht	%{mean_sea_surface}		
ทรร	ra2_mds.m_sea_surf_ht	%{mss}	mean_sea_surface (Synonym of mean_sea_surface).	
ange	ra2_mds.ku_band_ocean_range	%{range}		
range_band2	ra2_mds.s_band_ocean_range	%{range_band2}		
range_ku	ra2_mds.ku_band_ocean_range	%{range_ku}	range (Synonym of range).	
sea_state_bias_corr	ra2_mds.sea_bias_ku	%{sea_state_bias_corr}		
on etato hine com hand	sa2 mda aaa biaa a	0/ Jana atata bisa care band?		

Figure 22: "Show Aliases' pop-up window. Here for an Envisat GDR file. Note the 'Syntax' column, where the alias syntax is given, while the 'Value' column gives the original field name (or combination).

If you are in an expression (X, Y or Data expression, or Selection criteria) you can insert one or

several alias(es) in your expression by checking the box(es) in the 'Select' rightmost column. If no expression is selected, this column won't appear.

'Title/Comment' button




Figure 23: 'Title/Comment' pop-up window. Filling those fields can be useful for later references. The unit is the one defined for the expression.

The title will be displayed as the default name of the field in the plots (if no title is entered, it will be the data expression name).

- when X and Y are both filled, a 'Resolution and filter information' appears at the bottom of the window.

The 'Set Resolution / Filter' button is used to define:

The data resolution.

When choosing both X and Y, you 'grid' the data. Thus **you have to define a step** in both X and Y, as well as a minimum and maximum for both axis. Pre-defined steps are proposed, but may not fit your need. Minimum and Maximum are $0 - 360^{\circ}$, $-90^{\circ} - 90^{\circ}$ by default for longitude/latitude (whatever the data source), but have to be defined for any other type of X and Y.

o Filter: BRAT provides you with the possibility of smoothing the data, using Loess filter

See section 4.3.3.4.6, Resolution and Filters for more precise information.

Units

BRAT is able to understand all SI units and their sub-units, <u>as defined in the International System</u>, i.e. <u>case sensitive</u>: "ms" means milliseconds, whereas "Ms" would means megaseconds), plus "count" for data without dimension, and "dB".

Typically, the units you might use are:

- metres (m, mm, cm, km,...)
- seconds (s, ms, etc., but also hours, h, days)
- m/s (km/s,...)
- degrees East (longitude)
- degrees North (latitude)
- degrees
- count
- dB

Note that all data fields are converted in SI units in the data dictionary.

Thus practical units such as "TECU" are converted (1 TECU (Total Electron Content Unit) = 1×10^{16} electrons/m²).

If you let "count" (which is the default) as unit, the resulting data will be in the basic SI unit (e.g. in metres, even if the field(s) you used was defined in mm)

Every Operation is computed using SI units even if a sub-unit is defined for the data source and for the Expression (e.g. metres instead of cm, mm or km). Thus you can put 'km' as unit even if the data source field is defined in mm and still end up with correct values.

Functions

The 'Functions' button provides a simple way of including (and knowing) the available functions and constants which can be used in expressions. The functions are organised by categories, but you can have a look at all of them. For each function, if selected, you will see a short explanation of what it does.

You can use those functions for, among others:

- compute geostrophic velocities modulus : sqrt(sqr(U) + sqr(V))
- a test on a flag: Surface_type == 0 will return only the 'open ocean' flagged Jason-1 GDR data
- boundaries: is_bounded(-130, alt_cog_ellip-ku_band_ocean_range ,100) (or: (alt_cog_ellip-ku_band_ocean_range >= -130) && (alt_cog_ellip-ku_band_ocean_range <= 100)) select only the data for which the uncorrected altimetric distance is between -130 and +100 metres

They are available for processing or selecting a data expression.

Basics functions (not listed below) are +, -, *, /, and (and); you can also use '^' to indicate a number to the power of another number (or data field or data expression) e.g. '10^-6' means '10^-6'. Use the keyboard to insert them.

Name	Description	Syntax	Туре
!	logical negation operator NOT The logical negation operator (!) reverses the meaning of its operand. The result is <i>true</i> if the converted operand is false; the result is <i>false</i> if the converted operand is true.	! expr1	Logical
!=	not-equal-to operator The not-equal-to operator (!=) returns <i>true</i> if the operands do not have the same value; otherwise, it returns <i>false</i> A != B is true (when no default in A or B) if abs(A-B) >= epsilon	expr1 != expr2	Relational
&&	Iogical AND operator The logical AND operator (&&) returns the boolean value true if both operands are true and returns false otherwise. Logical AND has left associativity.	expr1 && expr2	Logical
II	logical OR operator The logical OR operator () returns the boolean value <i>true</i> if either one operand is true or both operands are true and returns <i>false</i> otherwise. Logical OR has left associativity	expr1 expr2	Logical
<	less than It yields values of the Boolean type. The value returned is false (0) if the relationship in the expression is false; otherwise, the value returned is true (1).	arithmetic expr1 < arithmetic expr2	Logical
<=	less than or equal to It yields values of the Boolean type. The value returned is false (0) if the relationship in the expression is false; otherwise, the value returned is true (1).	arithmetic expr1 <= arithmetic expr2	Logical
==	equal-to operator A == B is true (when there is no default in A or B) if abs(A-B) < epsilon The equal-to operator returns true (1) if both operands have the same value; otherwise, it returns false (0).	==	Relational
>	greater than It yields values of the Boolean type. The value returned is false (0) if the relationship in the expression is false; otherwise, the value returned is true (1).	arithmetic expr1 > arithmetic expr2	Relational

>=	greater than or equal to It yields values of the Boolean type. The value returned is false (0) if the relationship in the expression is false; otherwise, the value returned is true (1).	arithmetic expr1 >= arithmetic expr2	Relational
~	bitwise not operator Takes the value as an integer (a default value if the floating point one is outside the integer range) and reverses each bit.	~ expr1	Bitwise operator
&	bitwise and operator Takes the value of each operand as an integer (a default value if the floating point one is outside the integer range) and does an and operation on each corresponding bit And operation: 0011 & 0101 = 0001	expr1 & expr2	Bitwise operator
I	bitwise or operator Takes the value of each operand as an integer (a default value if the floating point one is outside the integer range) and does an <i>or</i> operation on each corresponding bit <i>Or</i> operation: 0011 & 0101 = 0111	expr1 expr2	Bitwise operator
0	parenthesis operator Isolates an expression (or a sub expression) in order to take it as a whole. Exemple: A * (B + C) multiplies (B + C) by A. without parentheses, B would by multiplied by A and then C added	(expr1)	
DV	Default value	DV	Constant
PI	PI value	PI	Constant
PI2	PI/2 value	PI2	Constant
PI4	PI/4 value	PI4	Constant
abs	absolute value Calculates the absolute value.	abs(param1)	Math&Trigo
ceil	ceiling of a value Calculates the ceiling of a value.	ceil(param1)	Math&Trigo
cos	cosine (radian) Calculates the cosine (radian) of a value.	cos(param1)	Math&Trigo
cosd	cosine (degree) Calculates the cosine (degree) of a value.	cosd(param1)	Math&Trigo
deg2rad	Translates Degree to Radian.	deg2rad(param1)	Math&Trigo
deg_normalize	Normalizes longitude (degree) $Z = \text{deg_normalize}(X, Y)$ returns a value which makes the following expressions true: $Z = Y + n*360$, $X <= Z < X+360$	deg_normalize(param1, param2)	geographical
dv (DV)	Default value	DV	Constant
exp	exponential Calculates the exponential.	exp(param1)	Math&Trigo
floor	floor of a value Calculates the floor of a value	floor(param1)	Math&Trigo
frac	fractional parts Calculates the fractional parts of a value.	frac(param1)	Math&Trigo
iif	Inline if If the first parameter is true (not 0 and not default value), the second parameter is returned, otherwise the third one is returned. Logically equivalent to: if (param1 is true) return param2 else return param3 end if	iif(param1, param2, param3)	Logical
iif3	Inline if with default value case If the first parameter is true (not 0 and not default value), the second parameter is returned. If is is 0, the third one is returned, otherwise (it is a default value) the fourth one is returned. Logically equivalent to: if (param1 is default value)	iif3(param1, param2, param3, param4)	Logical

ĺ	return param4		
	else		
	if (param1 is true)		
	return param2		
	else return param3		
	end if		
	end if		
int	integer parts Calculates the integer parts of a value.	int(param1)	Math&Trigo
is_bounded	Checks whether a value x is included between two	is_bounded(param1,par	Relational
	values (min/max).	am2,param3)	
is becoming a state.	is_bounded(min, x, max) Checks whether a value x is stricly included between	is here ded strict/s as	Dalatianal
is_bounded_strict	two values (min/max).	is_bounded_strict(para m1,param2,param3)	Relational
	is_bounded_strict(min, x, max)	iiii,paraiii2,paraiii3)	
is default	Checks whether a value is a default value (1: yes, 0: no)	is_default(param1)	Logical
log	logarithm	log(param1)	Math&Trigo
J	Calculates the logarithm of a value		
log10	base-10 logarithm	log10(param1)	Math&Trigo
	Calculates the base-10 logarithm of a value		
max	Maximum	max(param1,param2)	
min	Calculates the larger of two values Minimum	min(norom1 norom2)	
min	Calculates the smaller of two values	min(param1,param2)	
mod	floating-point remainder	mod(param1,param2)	Math&Trigo
mod	Calculates the floating-point remainder	mea(param, param_)	Matriarrigo
rad2deg	Translates Radian to Degree	rad2deg(param1)	Math&Trigo
round	rounded value	round(param1)	Math&Trigo
al	Calculates the rounded value rounded value	Disd(serent serence)	Math 9 Trian
rnd	Calculates the rounded value of a number x with a decimal precision of n figures after decimal point. rnd(x,decimal precision)	Rnd(param1,param2)	Math&Trigo
sign	Checks the sign of a value (-1: negative, 1: positive or	sign(param1)	Math&Trigo
	zero)		NA (1.0 T.)
sin	sine (radian)	sin(param1)	Math&Trigo
sind	Calculates the sine (radian) of a value. sine (degreee)	sind(param1)	Math&Trigo
Siriu	Calculates the sine (degreee) of a value.	Sind(paramir)	Matrix riigo
sqr	square	sqr(param1)	Math&Trigo
•	Calculates the square of a value.		
sqrt	square root	sqrt(param1)	Math&Trigo
tan	Calculates the square root of a value. tangent (radian)	tan(param1)	Math&Trigo
lan	Calculates the tangent (radian) of a value.	tan(parami)	Matrix riigo
tand	tangent (degree) Calculates the tangent (degree) of a value.	tand(param1)	Math&Trigo
to_date	Date formats conversion	to_date(param1)	Date&Time
10_0010	Translates a string value into a date value	to_aato(parami)	2 4.0 6.1
	Allowed formats are:		
	YYYY-MM-DD HH:MN:SS.MS string.		
	For instance:		
	'1995-12-05 12:02:10.1230' '1995-12-05 12:02:10'		
	'1995-12-05 12.02.10 '1995-12-05'		
	a Julian string: format:positive 'Days Seconds Microseconds'		
	Seconds must be stricty less 86400 and Microseconds		
	must be stricty less than 1000000		
	For instance:		
	'2530 230 4569'		

Dates prior to 1950-01-01 00:00:00.0 are invalid

a Julian string: format:positive decimal Julian day
For instance:
'850.2536985'

For Julian string, it can contain its reference date at the end
by specifying @YYYY where YYYY is the reference year
that's must be one of 1950, 1958, 1985, 1990, 2000
The reference year YYYY stands for YYYY-01-01
00:00:00.0
If no reference date is specified the default reference date
(1950) is used.
For instance:
'2530 230 4569@2000'
'850.2536985@1990'
'850.2536985@1950' is equal to '850.2536985'

NOTE: except when explicitly stated (as with iif3, is_default) every expression involving a default value (also called missing value) is a default value. A true expression is an expression which is not 0 and not a default value. The descriptions below are for expressions which do not contain default values (to simplify their writing). For example the result of 'A || B' (A or B) is a default value if B is one even if A is true. 0 and default values are considered as false values (! X is a default value if X is also one, so X is false and ! X too)

Formulas

In the Formula box, you will find pre-defined formulas (Sea Surface Height and Sea Level Anomaly formulas from the different satellites' GDR fields, and also 'Ocean editing' formulas, to use as selection criteria to select only valid data over ocean). If you have saved as formula an expression in the current workspace (or imported one from another workspace), you will also find it here. Any expression, i.e. valid combination of data fields and functions can be saved as formula. You can insert a developed formula and modify it, or use a formula as part of an expression.

The formula will appear either by its name only (if you leave the 'as alias' checked), or complete (if you un-check 'as alias').




Figure 24: The 'Formulas' pop-up window, with the list of available formulas, top (sorted in alphabetical order). Here, one of them (Ocean_data_editing_Envisat_GdrA) is selected, thus you can see the unit of the formula ('count', i.e. no unit, this is a selection formula), and the full formula in the box below.

The check-box 'As alias' enables to insert the formula by its name only ('as alias') or, when unchecked, to insert in its full extent.

Datasets Operations Views Logs




Figure 25: use of a pre-defined formula (Ocean_data_editing_Envisat_GdrC), by inserting its developed version Note the use in this particular formula of another formula as alias (%{SLA_Envisat_GdrC} on the next to last line)

Algorithms

Algorithms provide means of computing complex operations. They are pre-defined and compiled within BRAT. They include an algorithm name and a number of input parameters (depending on the algorithm) to be filled in by the user. The button "insert algorithm" enable to access the available algorithms with the relevant information provided.

Eleven algorithms are available at this time:

- computation of U (zonal) and of V (meridional) component of geostrophic velocities from gridded data
- computation of across-track geostrophic velocities from along-track data.
- Filters to apply on along-track data (Gaussian, Median, Lanczos or Loess)
- Filters to apply on gridded data (Gaussian, Median, Lanczos or Loess)

Note that, as in the all of BRAT, computations are done in SI units. If the field(s) you are using have a unit defined, BRAT will take care of the conversion. However, beware if there is no unit really defined ("count"). BRAT will then consider the data as in S.I.

Name	Description	Input parameters
BratAlgoGeosVelAtp	Geostrophic velocity computation for along-track data; result is the value of the geostrophic velocity component perpendicular to the track. Input data must contain at least longitude, latitude and a field corresponding to an height information.	Latitude: to be replaced by the name of the latitude field within the data Longitude: to be replaced by the name of the longitude field within the data Height: to be replaced by the name of a field corresponding to an height (e.g. SLA, ADT), or a formula enabling to compute it.

BratAlgoGeosVelGridU	Geostrophic velocity computation for gridded data; result is the value of the geostrophic velocity zonal (North) component, U. Input data must contain at least longitude, latitude and a field corresponding to an height information.	Latitude: to be replaced by the name of the latitude field within the data Longitude: to be replaced by the name of the longitude field within the data Height: to be replaced by the name of a field corresponding to an height (e.g. SLA, ADT), or a formula enabling to compute it. 5: latitude North and South below which the computation won't be done, to take into account the lack of Coriolis force at the Equator.
BratAlgoGeosVelGridV	Geostrophic velocity computation for gridded data; result is the value of the geostrophic velocity meridional (East) component, V Input data must contain at least longitude, latitude and a field corresponding to an height information.	Latitude: to be replaced by the name of the latitude field within the data Longitude: to be replaced by the name of the longitude field within the data Height: to be replaced by the name of a field corresponding to an height (e.g. SLA, ADT), or a formula enabling to compute it. 5: latitude North and South below which the computation won't be done, to take into account the lack of Coriolis force at the Equator
BratAlgoFilterGaussianAtp	Gaussian Kernel filter for along-track data. A gaussian filter is a linear weighted mean filter. Weights in the filter are calculated according to a gaussian distribution.	Expr: The input data (variable or Brat expression) on which the filter is applied WindowLength: Window/region size (N). The value must be odd. 1: The standard deviation (sigma) of the distribution. Set by default to 1. The parameter must be a constant value. 3: The coefficient of spreading to the left and right of the distribution." Set by default to 3. The parameter must be a strictly positive constant value. Usually in practice, the value used is 3 with sigma equals to 1. The part of Gaussian distribution utilized is the range [(-3 x sigma), (3 x sigma)], the Gaussian distribution is truncated at points +/- (3 x sigma). When the range is [(-3 x sigma), (3 x sigma), (3 x sigma)], the bell-shaped curve adjusts the corner values to 0.01. ValidPts: The minimum number of valid points below which the algorithm is not applied. 0: A flag to specify if the algorithm is applied when the current data is 'defaut value' (no value). 0: not applied, 1: applied.
BratAlgoFilterGaussianGrid	Gaussian Kernel filter for gridded data. A gaussian filter is a linear weighted mean filter. Weights in the filter are calculated according to a gaussian distribution.	expr: The input data (variable or Brat expression) on which the filter is applied WindowLength: Window/region size (N x N). The value must be odd. 1: The standard deviation (sigma) of the distribution. Set by default to 1. The parameter must be a constant value. 3: The coefficient of spreading to the left and right of the distribution." Set by default to 3. The parameter must be a strictly positive constant value. Usually in practice, the value used is 3 with sigma equals to 1. The part of Gaussian distribution utilized is the range [(-3 x sigma), (3 x sigma)], the Gaussian distribution is truncated at points +/- (3 x sigma). When the range is [(-3 x sigma), (3 x sigma)], the bell-shaped curve adjusts the corner values to 0.01. ValidPts: The minimum number of valid points below which the algorithm is not applied.

		0 : A flag to specify if the algorithm is applied when the current data is 'defaut value' (no value). 0: not applied, 1: applied.
BratAlgoFilterLanczosAtp	Lanczos kernel filter for along-track data.	Expr : The input data (variable or Brat expression) on which the filter is applied
	A Lanczos filter is a weighted filter. Weights in the filter are calculated in the Frequency space, using Fourier transform.	WindowLength: Window/region size (N). The value must be odd. CutOff: The value of the cut-off period (number of data points). The frequency (1/CutOff) is the value at which the response passes from one to zero. ValidPts: The minimum number of valid points below which the algorithm is not applied. 0: A flag to specify if the algorithm is applied when the current data is 'defaut value' (no value). 0: not applied, 1: applied.
BratAlgoFilterLanczosGrid	Lanczos kernel filter for gridded data. A Lanczos filter is a weighted filter. Weights in the filter are calculated in the Frequency space, using Fourier transform.	Expr: The input data (variable or Brat expression) on which the filter is applied WindowLength: Window/region size (N x N) The value must be odd. CutOff: The value of the cut-off period (number of data points). The frequency (1/CutOff) is the value at which the response passes from one to zero. ValidPts: The minimum number of valid points below which the algorithm is not applied. 0: A flag to specify if the algorithm is applied when the current data is 'defaut value' (no
BratAlgoFilterLoessAtp	Loess kernel filter for along-track data.	value). 0: not applied, 1: applied. Expr : The input data (variable or Brat
Didungor mereocco np	A Loess filter is a low-pass filter mostly used for smoothing. It is based on a local regression using weighted linear least squares and a 2nd degree polynomial model	expression) on which the filter is applied X: The input data (X values) used to compute weights. WindowLength: Window/region size. The value must be odd. ValidPts: The minimum number of valid points below which the algorithm is not applied. Extrapolate: A flag to specify if the algorithm is applied when the current data is 'defaut value' (no value). 0: not applied, 1: applied.
BratAlgoFilterLoessGrid	Loess kernel filter for gridded data. When used with X=longitude, Y=latitude, it is equivalent to the filter available in the 'set resolution/filter' box (but it can be applied here on any and every X and Y) A Loess filter is a low-pass filter mostly used for smoothing. It is based on a local regression using weighted linear least squares and a 2nd degree polynomial model	Expr: The input data (variable or Brat expression) on which the filter is applied WindowWidth: Window/region width (x). The parameter must be a constant odd value. WindowHeight: Window/region height (y). The parameter must be a constant odd value. ValidPts: The minimum number of valid points below which the algorithm is not applied. 0: A flag to specify if the algorithm is applied when the current data is 'defaut value' (no value). 0: not applied, 1: applied.
BratAlgoFilterMedianAtp	Median kernel filter for along-track data. A Median filter is often used for speckle noise reduction. A median filter is a non-linear filter which orders the elements within a window and pick the middle one.	Expr: The input data (variable or Brat expression) on which the filter is applied WindowLength: Window/region size ValidPts: The minimum number of valid points below which the algorithm is not applied. 0: A flag to specify if the algorithm is applied when the current data is 'defaut value' (no value). 0: not applied, 1: applied. Expr: WindowLength:
BratAlgoFilterMedianGrid	Median kernel filter for gridded data. A Median filter is often used for speckle noise	Expr: The input data (variable or Brat expression) on which the filter is applied WindowWidth: Window/region width (x)

Limbish and any the advanced a within a visit day.

which orders the elements within a window and pick the middle one.

ValidPts: The minimum number of valid points below which the algorithm is not applied.

0: A flag to specify if the algorithm is applied when the current data is 'defaut value' (no value). 0: not applied, 1: applied.




Figure 26: Insert Algorithm pop-up, with the BratAlgoGeosVelGridV selected.

A list of available algorithm is shown (top)
Description of the selected algorithm is available (just below) as well as the necessary input parameters (middle) and standard output unit (here m/s, bottom).
Clicking on "OK" will insert the call to the algorithm within the current expression (it will appear as

exec("BratAlgoGeosVelGridV",%{lat],%{lon],Height,5) in the expression box.

You then have to change the four input parameters (or not; most of the time, only "Height" will have to be changed; Latitude and Longitude aliases are used, so they will work for any dataset) to fit your dataset and your needs.




Figure 27: Operation resulting from the insertion of algorithms (here the "V" algorithm is visible; the "U" algorithm has also been inserted). Latitude, Longitude and 5 have been left as default; Height is replaced by "grid 0001", which is the name of the Sea Level Anomaly height in the gridded dataset used.

Data computation




Figure 28: Choice of the data computation

The data computation is used whenever you have several values of a field for a given (X) or (X,Y). This is typically the case for:

- crossover points between tracks
- several files available for different dates
- sub-sample data

Possible computations are:

- 'MEAN' (default): computes the mean for all values of the field within the dataset at each X (or (X,Y))
- 'COUNT': returns the number of values of the field within the dataset at each X (or (X,Y))
- 'FIRST': returns the first encountered value of the field within the dataset (in the order of the list of files as it appears in the 'dataset' tab)
- 'LAST': returns the last encountered value of the field within the dataset (in the order of the list of files as it appears in the 'dataset' tab)
- 'MAX': gives the maximum value of the field within the dataset
- 'MIN': gives the minimum value of the field within the dataset
- 'PRODUCT:' multiplies the selected field for each file within the dataset
- 'STDDEV': computes the standard deviation for all values of the field within the dataset at each X (or (X,Y))
- 'SUBTRACTION': subtracts the selected field for each file from the first of the list (file order dependent)
- 'SUM': adds the selected field for each file

Take care, however, that for along-track data, on a given ground track, longitudes or latitudes are scarcely ever exactly the same from one cycle to the next. So if you want to (e.g.) average data over several cycles for a given track with respect to **only** longitude or latitude, you will have to round the data in the X expression (see round or rnd functions).

Resolution and Filters

When you fill both X and Y, you 'grid' the data. You then have to define the grid parameters, i.e. **minimum**, **maximum and step**, **for the whole operation**. Note that by choosing a step, you may sub-sample your source data, and that by changing the Min/Max you can extract a smaller X-Y area.

- for longitude/latitude, Minimum and Maximum are set by default to 0 360°,-90° 90° (whatever the data source),
 - for any other type of X and Y, Minimum and maximum have to be defined.
 - The 'Get min/max expression' button is here to help you: if you don't have an idea of what the values of your field could reasonably be, this will provide you with the absolute minimum and maximum of your expression (note that if your dataset include a long list of files, it can take some time to be computed). The unit in which the minimum and maximum have to be defined are those defined in the corresponding expressions, and are recalled, top of each sub-part of the window.
- Pre-defined steps are proposed (1/3° for longitude and latitude, 1 for any other data), but may not fit your need. The number of intervals is automatically computed from those elements, and cannot be directly changed.

However, note that the higher the step, the smaller the resolution, and the longer the execution time for the operation.




Figure 29: 'Set X/Y resolution' pop-up window. Left, for X,Y different from Longitude and Latitude at the opening; right, once clicked on 'Get min/max expression' values for both X and Y. Min, Max and step can be modified. In this example, you can e.g. put -0,4 and 0 as minimum and maximum for both axis, and 0.01 as step.

BRAT provides you with the possibility of "smoothing", "binning", or to extrapolate the data, using Loess filter There are three different filters:

- 'Smooth': smoothes the values of the data where there are already data (i.e. it will not fill in gaps between tracks)
- 'Extrapolate': fills in the gaps between values (with some overlay on continents)
- 'Loess': smoothes and fills in the gap values (with some overlay on continents)

The choice depend on the result you want. 'Extrapolate tends' to keep data ground tracks visible. 'Smooth' spreads out the data, but tends to level the maxima and minima and to generate 'data' on continents from ocean-only measurements. 'Loess' does both extrapolation and smoothing.

If you select one of them, you have t fill the 'Loess cut-off' value for each axis (both X and Y), i.e. the number of grid points before the Loess filter becomes equal to zero (odd number) are then to be

Typical Loess filter cut-off values depend on the Step you choose and on the kind of filter you have selected in your field (Smooth, Extrapolate or Loess). They are odd numbers (if you fill in an even number, the number used will be your number+1).

The general rule is that the higher the cut-off value, the more spread out the data will be, since the radius of action of the filter will be greatest.

For good results to render along-track data, values of 31 begins to gives rather correct results, even if they still show a hint of ground tracks.




Figure 30: The same data (Envisat Significant wave height) computed with (top to bottom) 'Smooth', 'Extrapolate' and 'Loess' filters, and with (left) a Loess cut-off value of 9 (all with a resolution of 1/3°). With a Loess cut-off of 9, tracks are still visible.




Figure 31: Envisat Significant wave height computed with a 'Loess' filter and a Loess cut-off value of 31 in longitude and latitude.

Views tab

When you have executed your operation, you may want to have a look at the results in a graphical way. This is done through the 'Views' tab. For Display window description, see chapter Erreur: source de la référence non trouvée, Error! Reference source not found.. The main interest of creating several Views is to be able to retrieve your view in the future, with all its parameters (minimum and maximum on each axis, projection, color table with its minimum and maximum, etc.).

The name is used to call the parameter file that will be executed to display the data and if need be to retrieve your view in the future.

The tab is split in several parts:

- The management of the views is at the top.
- Data panels
- General plot properties just underneath the View names
- Display Expression properties bottom right, under the selected data.

Management of the views

- The 'Name of views' dropdown list contains all the defined operation names and allows you to select and rename an operation. When renaming a view, take care that it does not copy it, but it replaces the old one.
- The 'New' button is used to create a new view, with a name like 'Displays_2'
 This can also be done using the Views menu.
- The '**Delete**' button enables to delete an existing view This can also be done using the Views menu.
- The 'Execute' button launches the visualisation interface, with the parameters defined in the Views tab.

Data to be visualised

The data that can be visualised through BRAT GUI are data from an operation, if only a simple one. You can't visualise directly any file without undergoing the definition of a dataset and an operation.

To include a data expression for visualisation, you have to insert it in the 'Selected data' list, either by drag & drop, or by using the arrows button.

- '**Available**' data lists all the operations and expressions computed in the current workspace. They are sorted through three main categories:
 - 'Y=F(X)', which are basically curve plots
 - o 'Z=F(X,Y)', which are the representation of a value (in colors/contours) with respect to two others
 - o 'Z=F(Lon,Lat)', i.e. maps

Under each category (click on '+' to expand the tree, '-' to flatten it), you will see the names of the operations already computed, and under each operation, the list of Data expressions defined within this operation.

The operations are listed in one category or the other depending on the way they were defined:

- if the Y expression was not filled (only X expression defined), the operation can only be in the 'Y=F(X)' category.
- If (X,Y)=(Longitude,Latitude), the operation can only be in Z=F(Lon,Lat)
- If $(X,Y)\neq$ (Longitude, Latitude), then the operation will be in both Y=F(X) and Z=F(X,Y), the former as an "animation" of Z=F(X) for each Y

The one exception to this categorisation is for expressions including altimetric Waveforms, for which only with an X expression is defined, but which can also be visualised as Z=F(X,Y). This is due to the fact that waveform data fields are stored as arrays of values, thus the array index has been defined as a virtual supplementary field. In fact, even if only X can be defined in this case, an operation including a waveform field can be compared to the $(X,Y)\neq(Longitude,Latitude)$ case.

- 'Selected' data lists the data expression selected for visualisation. You can put there more than one data expression, provided there are compatible, i.e.
 - o for Y=F(X), same X, Data expression must be of the same unit (e.g. metres, but also centimetres and metres)
 - o For Z=F(X,Y), same X, same Y, any data expression
- The 'Refresh' button refresh the list of available data
- The '=>' button enables to switch a data expression from the 'available' list to the 'selected' list, as an alternative to drag & drop and the '<=' button enables to delete it from the selected list (the 'Delete' key can also be used)

General plot properties

You can just create a view and drag&drop whatever expression you want to visualise. More properties are, however, available, and can be useful.



Figure 32: General properties box (for a Z=F(X,Y) data expression).

- The '**Title**' text box is meant to define the title of your plot (top of the plot for Y=F(X) and Z=F(X,Y), near the color scale for maps)

- 'With animation' check-box is available for Z=F(X,Y) and Z=F(Lon,Lat).

 If you have computed several identical operations (same X, same Y, same Data expression names, different operations names, however), you can select all of them and choose to animate them (see the section about the visualisation interface 6.2, 'Z=F(Lon, Lat)').
- The '**Projection**' dropdown list is available only for Z=F(Lon,Lat). Several map projections are proposed. Default is '3D projection', but the list also includes
 - o Azimuthal equidistant
 - Lambert azimuthal
 - Lambert cylindrical
 - Mercator
 - Mollweide
 - Near-Sighted Perspective
 - o Orthographic
 - Plate Carree
 - o Robinson
 - Stereographic
- The 'Zoom' boxes can be used
 - o for Y=FX) to delimit either or both axis, to look only at part of the curve, or to limit the range for the data (about the same for Z=F(X,Y))
 - o for maps, to zoom on a region.

Display Expression properties

The Display expression properties box active content depends on the category of data selected. It applies on one expression and only one (click on an expression in the 'Selected' list to define properties for this expression, and only this one)

- Y=F(X)

Expression 'Name' text box. Default is the expression title (if any), or its name.

If from a Z=F(X,Y) operation, '**X axis**' dropdown list enable you to choose between the two possible axis (the one defined as X or the. You will then have an animations of curves at each Y

'X label' text box proposes you to enter a name for the axis (Default is the expression title (if any), or its name)

If from an data expression including a Waveform data field, 'X axis' dropdown list enables you to choose between the Waveform index (which is the most relevant) and the X expression you defined as abscissa. If you leave X as Waveform index, you will be able to see the series of waveforms for each values of the X expression you defined in the operation (e.g. Latitude at 20Hz).

'X label' text box proposes you to enter a name for the axis (Default is the expression title (if any), or its name)

Z=F(X,Y)

Expression 'Z=F(X,Y)' text box. Default is the expression title (if any), or its name.

'Minimum', 'Maximum' and name of the 'color table'

'Solid color' or 'Contour' check-box (either one, or both can be checked)

'invert X/Y' check box, if you decide that it makes more sense to switch the axis

'East/North Component' check box if the field corresponds to a vector plot. Vector plots require one north and one east component, and only one vector plot can be visualized at a time.

Z=F(Lon,Lat)
same than Z=F(X,Y), except for the 'invert X/Y' check box: for maps, this is not possible, the X and Y axis
are defined as respectively longitude and latitude, without possibility of change

Logs tab

The '**Logs**' tab displays the state of the programmes being run. Several operations and views can be executed at the same time. Errors can be detected using the messages from the Logs tab.

If things go well, you should have messages like:

'===> Task 'DisplayDisplays_17' (pid 284) SUCCESSFULLY ENDED <===

To kill an ongoing task, select it in the list, and click on the 'Kill' button.

As soon as a task is finished, BRAT GUI goes back to the tab from where it was launched (either Operations or Views)




Figure 33: Logs tab, with two operations running. The execution of a View is also registered on this tab..

Aliases

Aliases are short names or unified names for data fields. Aliases have been added within BRAT to take into account the fact that the equivalent fields are not named similarly for all the datasets (names always follow the User documentation made by the data provider, in order that the user can refer to this documentation for more information).

Some are already defined. The equivalent fields have been defined with the same alias(es) for all the relevant altimetry data. If a given field is not available within the current dataset, a warning will be issued. However, you can either modify them, or create your own ones.

A few aliases are "universal" (pre-defined for all known datasets read by BRAT) : %{lon}, %{lat}, %{time} (NB. you may encounter NetCDF data read by BRAT but not pre-defined, for which this won't work, however)

Note that there may be several aliases for a same field, in order to either speed the typing (e.g. %{mss}), or be more self-explaining (e.g. %{mean sea surface}).

An alias can be a field or a combination of fields. They are stored in a "aliases.xml" file that can be edited (in brat program folder, data/ sub-folder). In the same folder, the aliases.xsd.html file gives the rules to define new aliases and/or modify the existing ones.

The following must be kept in mind:

- an alias always refer to a given data product.
- BRAT GUI call to aliases.xml for alias definition. If you modify this file, the aliases can change! (and, thus, if you used aliases previously, your Operations may not work anymore)

Using aliases

Aliases can be used as any field or combination of field, by using "%" before the name, and encompassing it between "{" and "}"

For example, a (nearly) universal SSH formula could be written as follow in the 'data expression' of an Operation: %{alt} - %{range} - %{dry_tropo_corr} -%{dynamic_atmos_corr} - %{tides_all_corr} - %{ssb} - %{iono_corr} - %{wet_tropo_corr}

(note that the fact that not all corrections are available for all satellites make it not absolutely universal!)

or, in a "selection criteria" expression, you could write:

is_bounded(40,%{lat},60)

to select data between 40°N and 60°N.

Structure

Here is an example of the structure of the xml file. For more information on this structure, please refer to aliases.xsd.html file.

```
<defaultRecord name="ra2 mds"/>
<aliases>
```

```
<alias name="range">ku_band_ocean_range</alias>
....
</aliases>
</product>
```

Figure 34: example of the definition of an alias. This example is for Envisat RA2 and MWR products, by default for data within the "ra2_mds" record. "ku_band_ocean_range" is the name give by default in the documentation and thus in BRAT. To keep it simpler, we call it here "range".

See Brat products format definitions in the doc/codadef/index.html file located in the Brat directory.

Products are classified in 'class' (product class) and 'type' (product type)

Modifying an alias

To modify an alias, edit the xml file in a text editor. And just change its name in <alias name="....">..

For example, you could replace:

alias name="range">ku_band_ocean_range</alias>

by

<alias name="THERANGE">ku_band_ocean_range</alias>

thus, afterwards, you would be using %{THERANGE} as alias. Note that, in this case, previous use of %{range} won't work anymore.

Creating an alias

For a field for which no alias exists

Find the product(s) for which you want the alias to work, and just add a line like:

```
<alias name="range">ku_band_ocean_range</alias>
```

defining the name you wish to use, and the given name of the field. You have to do it for any and every data product where you want to use this alias.

See Brat products format definitions in the doc/codadef/index.html file located in the Brat directory. Products are classified in 'class' (product class) and 'type' (product type)

You may have to specify a record within the default record.

```
You will put this in a ProductType tag, like aliases productType="RA2_MWS_2P" record="avg_waveforms_mds" ref="RA2_GDR_2P">
```

You can use combination of fields to define an alias. E.g. an alias including all tide-related corrections can be:

```
" <alias name="tides_all_corr">(ocean_tide_sol1+ solid_earth_tide + pole_tide)</alias> "
```

For a field for which an alias has already been defined

If you'd prefer something else than the predefined name, but do not want to erase it by modifying it, you can create alternate aliases.

For example, above we decided that when we will be using %{range}, it will be the field "ku_band_ocean_range". However, it can be misunderstood (there's a 'C-Band' range in Envisat data). So you may want to specify at least in some cases that you are using the Ku-band range (e.g. if you're using C-Band data close-by).

To do this, you would define:

```
<alias name="range">ku_band_ocean_range</alias>
```

[as previously]

<alias name="range_ku" ref="range"/>

[referring to the above alias]

You can then use either %{range} or %{range_ku} in an expression with the same results.

Visualisation interface

The visualisation interface is called by executing a command file from the 'views' tab of the GUI. It can also be used with a command file.

The visualisation options are quite different for an 'Y=F(X)' (curve) than for a 'Z=F(Ion,Iat)' (map); the other plots ('Z=F(X,Y)') have functionalities from both types.

'Y=F(X)'





Figure 35: An example Y=F(X) visualisation

In the '**File**' menu, you can save your plot, in different image format (bmp – windows bitmap – jpeg, png, pnm or tiff). The '**View**' menu enables you to display or not the right-hand panel with the properties.




First tab ('datasets') recalls the name of the field as it appears in the Display Field properties of the 'Views' tab.

When a field is selected in this 'datasets' tab, you have some options to choose the color and style (full, dots, etc.) of the line and of the points (none by default, circles, crosses, etc.). If there are several fields to plot, you can thus enhance the legibility of your plot.

Second tab ('properties') enable to choose several options (some being already available within the 'views' tab; however, modifications done only in the visualisation window will not be saved as part of the workspace and thus cannot be recalled for future use. We thus strongly recommend that you choose options as min, max of both axis, units, plot title and axis name within the Operations and Views tabs.

Figure 36: Datasets tab of the visualisation tool



The label of each axis includes by default the name of the plotted field and its unit, with \n for line break and \t for space.

'Fallback range' enables you to select in a more restricted range (e.g. you selected a whole ground track, but finally wish to look only at a -10 + 10°N range.

You can also zoom in on a portion of curve using middle button of your mouse.

'Current range' indicates the min max of your current view.

To go back to the first opened view, type on 'r'.

Figure 37: Y-axis properties of a Y=F(X) plot, with only one field selected for view. Label (including the unit), number of ticks in the axis, min and max of the axis are shown. X-axis properties are similar.




Figure 38: Zoom of the same curve than above




Figure 39: Two curves overlaid, with different point glyphs defined

'Z=F(Lon, Lat)'

In the '**File'** menu, you can save your plot, in different image format (bmp – windows bitmap – jpeg, png, pnm or tiff). The '**View'** menu enables you

- to display or not display the right-hand panel with the properties.
- display the color bar or not
- display the animation toolbar (if relevant, i.e. if you are visualising a series of fields with the same name and chose the option 'With animation'). Once in this toolbar, you can launch the animation of the fields, stop it and control its speed.
- to open the color table editor and the contour table editor



Figure 40: Animation toolbar (available for a series of fields with the same name, option 'With animation' chosen). The animation is available as visualisation (not to be saved). 'Animate' launch the animation, Reset reset the animation to the first frame. The number after is the number of the frame. 'Loop' enables to loop the animation and 'Speed' to choose its speed (in frames per second).




Figure 41: An example Z=F(lon, lat) visualisation, with default projection (3D) and the 'Ozone' color table

Display properties

Available display properties are:

- 'Projection': several of them are available (see 4.2.4 Create a view). You can change it on the fly, even if you decided on another one in the 'view' tab of the GUI (but your choice will not be saved)




Figure 42: Same plot than above, but with a different projection (Plate Carree)

- 'Centre point': define the centre of the display (only relevant for 2D maps, not for the '3D' projection)
- 'Data layers': lists the different fields visualised and if each one is visualised as solid color or as contours. 'Edit' open either the color table or the contour table editor (see section 6.2.2 and 6.2.3 below) With these editors you can modify previous definitions (but, once again, your choices will not be saved). If two fields are superimposed, you can switch contours and colors. This is why, in this case, you will have two color tables in your plot (one for each field)

The number of labels and the range define those for the color table.

For vector plots, a vector scaling factor [0.1-20] will be enabled to increase or reduce the size of vectors. A Glyphs checkbox substitutes vector lines for arrow glyphs.

Ten also a second prior table of the plot at 2

| Ten also at 2
| Ten also at 2
| Ten also at 2
| Ten also at 2
| Ten also at 2
| Ten also at 2
| Ten also at 2
| Ten also at 2
| Ten also at 2
| Ten also at 3
| Ten also at

Figure 43: Visualisation with color and contour (for the same field)

- 'View': There are 3 tabs available:
 - 'State': used to save a particular display for the duration of the session and to recall it by its number.
 - 'Clear': erases all the saved displays,
 - 'Full' goes back to a full-sized view of the chosen area (if a zoom had been made)
 - o '**Zoom**': used to visualise a specified area, defined by its minimum and maximum longitude and latitude respectively (this does not work for the '3D' projection).
 - 'Z-height': only available for the 3D projection, it is used to render field values at the surface as bumpiness (radius gives the height, factor the scale factor).

Color table editor

Several color tables are available within BRAT.

You can use any one of them. You can also make your own color table.



Figure 44: The color table editor, with the list of predefined tables

In the 'File' menu of the color table editor, 'Load color table' loads a previously made color table. 'Recent color table' recall recently used ones, and use 'Save as' to save the one you've just done.

The 'Edit' menu enables to change the number of color within an existing color table and the interpolation between the different colors.

The 'Mode' menu enables to choose between predefined color tables, two-color gradient color tables or multi-color gradient color tables.

Two-color gradient color tables

The two-color gradient color table editor enables to make a color table by defining its first and last colors. Colors are defined by their Red, Green and Blue components and Alpha channel (for transparency).

Default is black (RGB=0,0,0) for both and no transparency (A=255). You can click on 'apply' to look at the way it shows on your plot. When you are satisfied of your color table, you can save it and recall it in future sessions.




Figure 45: Two-color gradient color table editor

Multi-color gradient color tables

The multi-color gradient color table editor works much as the two-color one, except that you have to define not only the first and last values, but also define intermediate one(s).

The definition of colors is the same (Red, Green, Blue + Alpha channel) and you also have a cursor beneath the preview of the table that enables you to place your new color in the range.

To add a new color , click on '0' in the 'X-values' list, then on 'Insert color'. You will then have a new value, '1', that you can change by moving the cursor. When you have placed your new value in the range, define your color . Repeat the operation as many time as you wish to add colors. Note that you do not have to define 255 colors (if you want a 255-color table) one by one, since the software interpolates between the values you are giving, so choosing 5 or 7 of them is usually sufficient.

You can click on 'Apply' to look at the way it shows on your plot. When you are satisfied with your color table, you can save it and recall it for future sessions.

File Edit Mode

Color:

Color:

Color:

R: 0

Separat Color Table for sigma 0 ku

File Edit Mode

Color:

Color:

Color:

Color:

Color:

Color:

R: 255

R: 255

Insert Color

Deselect Color

Remove Color

Apply

Apply

Figure 46: Multi-color gradient, color table editor. When first opening it (left) and after defining 5 colors over the whole range; equally distributed (on the right

Contour table editor

The contour table editor enables you to choose the range and number of contours that you wish to see on your plot, the width and color of the lines and whether you want labels on the contours or not and if so, which style.

Note that your contour table cannot be saved and re-used for future use.




Figure 47: Contour table editor

'Z=F(X,Y)'

Most of the functionalities for this kind of plot matches those for X=Lon, Y=Lat, except:

- there are no projection, of course
- X and Y axis name, min, max and number of ticks can be changed, much like what is possible with the 'Y=F(X)' plots.




Figure 48: An example Y=F(X) visualisation

The 'General properties', the 'X axis' and 'Y axis' definitions are similar to the one of the curves (see Figure 37 on page 52). Zoom can be done by choosing the min/max range in both or either X and Y, or using the mouse middle button.

The 'Data layers' box, with the color table and the contour choices are the same than maps (see 6.2.1, Display properties, and also 6.2.2, Color table editor and 6.2.3, Contour table editor).

Vector Plots

Vector plots are displayed when fields from the visualization tab are selected as East and North vector components. Both components have to be present, otherwise an error message will be issued.




Figure 49: An example vector plot visualisation for geostrophic velocities

Vectors are naturally visualized as arrows. To avoid creating too much overhead in machines with low or no graphic acceleration, the amount of vectors displayed varies according to the zoom level: zooming in increases the number of elements visualized and zooming out will combine a number of vectors together, averaging their magnitude, direction and origin.

A Vector Scale parameter can be used to increase or reduce the size of vectors, which is particularly useful if the area of interest contains elements of small magnitude.

The range fields will display the magnitudes available in the data, starting from 0 until the maximum magnitude. This maximum value can be edited and therefore provides an alternative way to scale the vectors.

BRAT scheduler interface

BRAT scheduler interface enable to postpone execution of operations. It has to be programmed through BRAT GUI (by clicking on the 'delay execution' button)

BRAT scheduler can be launched either from BRAT GUI or from the desktop icon. If it is not open and running, no scheduled task will be processed.

Pending Tasks tab

Pending tasks tab list all the executions delayed. The name and date/time for the start is listed, as well as the command line that will be launched.

Two buttons appear:

- 'Remove' to remove the selected task. It will not be launched.
- 'Clear' to remove the whole list of tasks.




Figure 50: Pending tasks tab

'Uid' is the ID number of the task

'Name' is the (optional) name of the task as filled when clicking on 'delay execution' in BRAT GUI

'Start' is the start time as scheduled

'Status' is pending.

'Command line' is the command as it will be executed

'Log file' is the path for the result Log file of the task (like BRAT GUI Log, see section Log tab)

Processing Tasks tab

Pending tasks tab list all the executions delayed currently running. The name and date/time for the start is listed, as well as the status of the task.

A processing task can be killed, by clicking on the 'kill' button.




Figure 51: Pending tasks tab

'Uid' is the ID number of the task

'Name' is the (optional) name of the task as filled when clicking on 'delay execution' in BRAT GUI

'Start' is the start time as scheduled

'Status' is 'in progress'.

'Command line' is the command as it will be executed

'Log file' is the path for the result Log file of the task (like BRAT GUI Log, see section Log tab)

Ended Tasks tab

Ended task tab lists the tasks that had run.

Three buttons appear:

- 'Remove' to remove the selected task. It will not be launched.
- 'Clear' to remove the whole list of tasks.
- 'Show log' enables to view the Log as within BRAT, and thus if the task ended in error, to analyse why.



Figure 52: Ending tasks tab

'**Uid**' is the ID number of the task

'Name' is the (optional) name of the task as filled when clicking on 'delay execution' in BRAT GUI

'Start' is the start time as scheduled

'Status' is ended or error. Look at the log by clicking on the button at right to see why (this log is BRAT GUI log, see section 4.3.5 (Log Tab)

'Command line' is the command as it will be executed

'Log file' is the path for the result Log file of the task (like BRAT GUI Log, see section Log tab)

Scheduler Logs tab

The Scheduler Logs tab list the activity of the scheduler. This log is different from BRAT GUI log (to which you can access through the Ended Task of the scheduler interface)




Figure 53: Scheduler Logs tab

Using BRAT in 'command lines' mode with parameter files

The GUI is there to ease the use of BRAT. However, everything made with the GUI can be made directly by writing parameter files and execute them and more than what can be done with the GUI is possible with parameter files.

Dictionaries of key functions that can be called within parameter files are available in annex B (Y=F(X), annex C (Z=F(X,Y)) and annex D (Display parameter file keys).

'-h' option offers help for launching the executable file

'-k' offers help on parameter keys

BratCreateYFX.exe create an output netCDF with one or several data field(s) with respect to a single field

BratCreateZFXY.exe create an output netCDF with one or several data field(s) with respect to two different

fields (e.g. longitude, latitude)

enable to visualise an output netCDF BratDisplay.exe

BratExportAscii.exe export an output to Ascii

BratExportGeoTiff.exe

wrapper)

export gridded data from a netCDF product to GeoTiff (with optional GoogleEarth

BratListFieldNames.exe BratShowInternalFile.exe

BratStats.exe

Creating an output netCDF file

A 'Create' parameter file typically consist of:

- the definition of a dataset (a list of files that will be processed),
- the name of the record within the dataset in which the data you are interested in are stored.
- = the definition of an X axis and of one or several 'Field(s)'; in the Z=F(X,Y) case, also the definition of an Y-axis,
- a selection expression, if need be
- the name and location of the netCDF output file.

The definition of the axis or of a field includes the name of an existing data field, or the expression that you wish to compute from several of them, a name (without any spaces or special characters), a unit, a title (that may include spaces or special characters), a min and a max and information about a possible filter

```
#---- GENERAL PROPERTIES -----
DATA MODE=MEAN
#---- DATASET ----
RECORD=ra2_mds
FILE=File1
FILE=File2
#---- FIELDS ----
Y=lat
Y NAME=lat
Y TYPE=Latitude
Y UNIT=degrees north
Y TITLE=Latitude
Y_FILTER=DV
Y MIN=DV
Y_MAX=DV
Y INTERVALS=DV
Y LOESS CUTOFF=DV
X=lon
X NAME=lon
X TYPE=Longitude
X UNIT=degrees east
X TITLE=Longitude
X_FILTER=DV
X_WIN=DA
X MAX=DV
X INTERVALS=DV
X LOESS CUTOFF=DV
FIELD=ra2_wind_sp
FIELD NAME=my first field
FIELD TYPE=Data
FIELD UNIT=mm/s
FIELD TITLE=Altimeter wind speed modulus
FIELD_FILTER=DV
FIELD MIN=DV
FIELD MAX=DV
FIELD INTERVALS=DV
FIELD_LOESS_CUTOFF=DV
FIELD=alt_cog_ellip - ku_band_ocean_range - mod_dry_tropo_corr - inv_barom_corr -
(tot_geocen_ocn_tide_ht_sol1 + tidal_load_ht + long_period_ocn_tide_ht) - solid_earth_tide_ht - geocen_pole_tide_ht - sea_bias_ku - ra2_ion_corr_ku - mwr_wet_tropo_corr
FIELD NAME=SSH
FIELD_TYPE=Data
FIELD_UNIT=m
FIELD TITLE=my second field
FIELD FILTER=DV
FIELD MIN=DV
FIELD MAX=DV
FIELD_INTERVALS=DV
FIELD LOESS CUTOFF=DV
#---- SELECT ----
#---- OUTPUT ----
OUTPUT=output file.nc
```

Example parameter file for creating a Z=F(X,Y) output

You create the netCDF file by typing

```
'BratCreateZFXY.exe command_file.par'
(or 'BratCreateYFX.exe command_file.par')
```

You will then have a netCDF file that you can either visualise through the tool provided within BRAT, or with some other tool capable of reading netCDF.

Visualising an output netCDF file through BRAT

To visualise an output file, you have to write a second parameter file. This kind of file is simpler than the one needed to create a netCDF.

Basically, the commands needed are:

- the type of data to be displayed (Y=F(X) ==> 0 Z=F(Lat,Lon) ==> 2 Z=F(X,Y) ==> 1)
- the name of the file(s) to be displayed
- the title, projection
- the name of the field(s) to be displayed
- some information about the display (min, max, name, whether there is a contour or not, color table...)

```
#!/usr/bin/env BratCreateZFXY
#Type:Z=F(X,Y)
#---- DATASET ----
FILE=Createenvisat_cycle.nc
#---- GENERAL PROPERTIES -----
DISPLAY TITLE=title of the plot
DISPLAY_PLOT_TYPE=1
DISPLAY_GROUPBY_FILE=Y
DISPLAY PROJECTION=3D
#---- sigma 0 ku FIELD -----
FIELD=sigma 0 ku
#---- sigma 0 ku FIELDS PROPERTIES -----
DISPLAY NAME=sigma 0 ku
FIELD GROUP=1
DISPLAY_MINVALUE=0.00000
DISPLAY MAXVALUE=50.000
DISPLAY CONTOUR=N
DISPLAY SOLID COLOR =Y
DISPLAY COLORTABLE=DV
```

Example 'display' parameter file

You open the visualisation tool by typing:

'BratDisplay.exe command_file.par'

Using the parameter files to process many datasets

A typical case in which using the parameter files will be much easier than using the GUI is when you want to process the same operation on all the altimetry satellite cycles or for a long series of them. Parameter files enable you to write a script that will process the same operation on a number of files.

You can either write the parameter file directly, or you can make the parameter file through the GUI, test it on one cycle and then modify it (right-click) by replacing the cycle number by a character that will be replaced consecutively by a list of cycle numbers through a script;

```
#!/usr/bin/env BratCreateZFXY
# SRC DATA DIR and CYCLE are environment variables that can be set in a shell # script
FILE=${SRC_DATA_DIR}/JA1_GDR_2PAP${CYCLE}_001.CNES
FILE=${SRC DATA DIR}/JA1 GDR 2PAP${CYCLE}
                                         002.CNES
FILE=${SRC_DATA_DIR}/JA1_GDR_2PAP${CYCLE}_003.CNES
RECORD = data
VERBOSE = 2
ALIAS NAME
            = SLA JASON
ALIAS VALUE = altitude - range ku - model_dry_tropo_corr - inv_bar_corr - (ocean_tide_sol1 +
ocean_tide_equil + load_tide_sol1) - solid_earth_tide - pole_tide - sea_state_bias_ku -
iono_corr_alt_ku - rad_wet_tropo_corr - mss
     = longitude
X TYPE = longitude
X NAME = Longitude
X UNIT = DV
X_TITLE
            = Longitude
X MIN
            = DV
X MAX
            = DV
X INTERVALS = 1800
     = latitude
Y TYPE = latitude
Y NAME = Latitude
Y UNIT = DV
Y TITLE
            = Latitude
Y MIN
            = DV
Y MAX
            = DV
Y INTERVALS = 900
# SLA_JASON is an alias see ALIAS_NAME and ALIAS VALUE above
FIELD = %{SLA JASON}
FIELD TYPE = data
            = SLA
FIELD NAME
FIELD UNIT
            = m
FIELD TITLE = Sea Level Anomalies - Cycle ${CYCLE}
FIELD FILTER = LOESS EXTRAPOLATE
X LOESS CUTOFF = 5
Y LOESS CUTOFF
                  = 5
SELECT = is_bounded(-1.0, %{SLA_JASON},1.0)
OUTPUT
            = ${BRATHL DATA DIR}/JasonSLA${CYCLE}.nc
OUTPUT TITLE = Jason - Cycle ${CYCLE}
```

An example parameter file for creating output netCDF for several cycles (SLA from Jason-1 GDRs)

```
REM Set the cycle number

REM Set the data source path

SET SRC_DATA_DIR=D:\data\gdr_jason\cycle_%CYCLE%

REM Launch 'BRAT create Z=F(X,Y)' process

BratCreateZFXY C:\BRAT\MyCmdPath\BratCreateZFXYJasonSLASample.par

REM --------

REM Set another cycle number

SET CYCLE=110

REM Set the data source path

SET SRC_DATA_DIR=D:\data\gdr_jason\cycle_%CYCLE%

REM Launch 'BRAT create Z=F(X,Y)' process

BratCreateZFXY C:\BRAT\MyCmdPath\BratCreateZFXYJasonSLASample.par
```

An example script for DOS (to be inserted in a .bat file) to launch a parameter file over several cycles

An example Shell script for Linux for launching a parameter file over several cycles

BRATHL Application Programming Interfaces (APIs)

Some functions of BRAT are not available through the GUI, but through C, Fortran, Python, IDL and MATLAB APIs. Note that for IDL and MATLAB under Linux and Mac OS you need to compile the API before being able to use them – they are not included in the binary distributions of BRAT.

Data reading function

BRATHL_READDATA reads data from a set of files; each measurement for a data is a scalar value (a single number). It also gives statistics (e.g. a mean over a geographical area)

Possible arguments of this function are:

[in] fileNames: file name string (one file) or file names array

[in] recordName: Name of the fields record (for netCDF files the recordName is 'data')

[in] selection: Expression involving data fields which has to be true to select returned data. (if the string is empty nothing is selected (in other words all of the data is taken)

[in] dataExpressions: Expression string (one expression) or expressions array applied to data fields to build the wanted value.

[in] units: Wanted unit for each expression (string (one unit) or units array). (if empty string, no unit conversion is applied to the data of the corresponding expression. When a unit conversion has to be applied, the result of the expression is considered to be the base unit (SI). For example if the wanted unit is grammes/litre, the unit of the expression is supposed to be kilogrammes/m³ (internally all data are converted to the basic unit of the actual fields unit which is coherent with the above assumption).

[in/out] results: Data read. Must be an array (dim = number of dataExpressions) of values to read.

[in] ignoreOutOfRange: Skip excess data. 0=false, other = true

Must be false if 'statistics' is true.

[in] statistics: returns statistics on data instead of data themselves

0=false, other = true

If statistics is *true*, ignoreOutOfRange must be *false*. The returned values (5 values) for each expression are:

- Count of valid data taken into account.

Invalid data are those which are equal to the default/missing value

- Mean of the valid data.
- Standard deviation of the valid data
- Minimum value of the valid data
- Maximum value of the valid data

[in] defaultValue: value to use for default/missing values

This is the value you want to indicate that a value is missing or invalid. return 0 or error code.

Syntax: see annexes

- for IDL
- for MATLAB
- for Fortran
- for C
- for Python

Cycle/date conversion functions

Two functions are available to convert between cycle/pass and date.

Syntax: see annexes

- for IDL
- for MATLAB
- for Fortran
- for C
- for Python

BRATHL_CYCLE2YMDHMSM Converts a cyle/pass into a date

Arguments of this function are:

[in] mission:

0: Topex/Poseidon

1 : Jason-1

2:ERS2

3: Envisat

4: ERS1-A

5: ERS1-B

6: GFO

[in] cycle: number of cycles

[in] pass: number of passes in the cycle

Outputs are:

[out] dateYMDHMSM : date to convert

BRATHL_YMDHMSM2CYCLE Converts a date into a cycle/pass

Arguments of this function are:

[in] mission: mission type:

0: Topex/Poseidon

1: Jason-1

2:ERS2

3: Envisat

4: ERS1-A

5 : ERS1-B

6: GFO

 $\textbf{[in] dateYMDHMSM}: date \ to \ convert$

Outputs are:

[out] cycle: number of cycles

[out] pass : number of passes in the cycle

Date conversion/computation functions

A set of functions is available to convert between the different kinds of date formats:

- days-seconds-microseconds dates:
- Julian decimal dates:
- year, month, day, hour, minute, second, microsecond dates:

Syntax: see annexes

- for IDL
- for MATLAB
- for Fortran
- for C
- for Python

BRATHL_DAYOFYEAR	Retrieves the day of year of a date
BRATHL_NOWYMDHMSM	Gets the current date/time
BRATHL_SETREFUSER1	Set user-defined reference dates
BRATHL_SETREFUSER2	Set user-defined reference dates
BRATHL_DIFFDSM	Computes the difference between two days-seconds-microseconds dates (date1 - date2) the result is expressed in a decimal number of seconds
BRATHL_DIFFJULIAN	Computes the difference between two decimal Julian dates (date1 - date2) the result is expressed in a decimal number of seconds
BRATHL_DIFFYMDHMSM	Computes the difference between two year, month, day, hour, minute, second, microsecond dates (date1 - date2) the result is expressed in a decimal number of seconds
BRATHL_DSM2JULIAN	Converts a days-seconds-microseconds date into a decimal Julian date, according to refDate parameter
BRATHL_DSM2SECONDS	Converts a days-seconds-microseconds date into seconds, according to refDate parameter
BRATHL_DSM2YMDHMSM	Converts a days-seconds-microseconds date into a year, month, day, hour, minute, second, microsecond date
BRATHL_JULIAN2DSM	Converts a decimal Julian date into a days-seconds-microseconds date, according to refDate parameter
BRATHL_JULIAN2SECONDS	Converts a decimal Julian date into seconds, according to refDate

parameter

BRATHL_JULIAN2YMDHMSM Converts a decimal Julian date into a year, month, day, hour, minute,

second, microsecond date

BRATHL_SECONDS2DSM Converts seconds into a days-seconds-microseconds date, according to

refDate parameter

BRATHL_SECONDS2JULIAN Converts seconds into a decimal Julian date, according to refDate

parameter

BRATHL_SECONDS2YMDHMSM Converts seconds into a a decimal Julian date, according to refDate

parameter

BRATHL_YMDHMSM2DSM Converts a year, month, day, hour, minute, second, microsecond date into

a days-seconds-microseconds date, according to refDate parameter

BRATHL_YMDHMSM2JULIAN Converts a year, month, day, hour, minute, second, microsecond date into

a decimal Julian date, according to refDate parameter

BRATHL_YMDHMSM2SECONDS Converts a year, month, day, hour, minute, second, microsecond date into

seconds, according to refDate parameter

Named structures

Several structures are also available, to represent the different kinds of date formats

Syntax: see annexes

for IDL

for MATLAB

for Fortran

for C

for Python

BRATHL DATEYMDHMSM YYYY-MM-DD HH:MN:SS:MS date structure

YEAR

MONTH

DAY

HOUR

MINUTE

SECOND

MUSECOND

BRATHL_DATEDSM day/seconds/microseconds date structure

REFDATE reference date

DAYS numbers of days

SECONDS numbers of seconds

MUSECONDS numbers of microseconds

REFDATE is the reference date i.e:

0: 1950-01-01 00:00:00.0

1: 1958-01-01 00:00:00.0

2: 1985-01-01 00:00:00.0

3: 1990-01-01 00:00:00.0

4: 2000-01-01 00:00:00.0

5: user reference 1

6: user reference 2

values of 5 and 6 allow users to set two specific reference dates of their choice (see BRATHL_SETREFUSER1 and BRATHL_SETREFUSER2

functions)

BRATHL_DATESECOND decimal seconds date structure

REFDATE reference date - see :BRATHL_DATEDSM

NBSECONDS decimal numbers of seconds (seconds.microseconds)

BRATHL_DATEJULIAN decimal Julian date structure

REFDATE reference date - see :BRATHL_DATEDSM

JULIAN decimal Julian day

Annex A. List of datasets read by BRAT

Cryosat product overview

product type	description
SIR_LRM_1B	SIRAL L1B LRM product
SIR_SAR_1B	SIRAL L1B SAR mode product
SIR_SIN_1B	SIRAL L1B SARin mode product
SIR1LRM_0M	SIRAL MON-LRM/TRK product (Rx1 channel)
SIR2LRM_0M	SIRAL MON-LRM/TRK product (Rx2 channel)
SIR1SAR_0M	SIRAL MON-SAR product (Rx1 channel)
SIR2SAR_0M	SIRAL MON-SAR product (Rx2 channel)
SIR_SIN_0M	SIRAL MON-SARin product
SIR_SIC40M	SIRAL MON-CAL4 product
SIR1LRC11B	SIRAL CAL1-LRM product (Rx1 channel)
SIR2LRC11B	SIRAL CAL1-LRM product (Rx2 channel)
SIR1SAC11B	SIRAL CAL1-SAR product (Rx1 channel)
SIR2SAC11B	SIRAL CAL1-SAR product (Rx2 channel)
SIR_SIC11B	SIRAL CAL1-SARin product
SIR_SICC1B	SIRAL complex CAL1-SARin product
SIR1SAC21B	SIRAL CAL2-SAR product (Rx1 channel)
SIR2SAC21B	SIRAL CAL2-SAR product (Rx2 channel)
SIR1SIC21B	SIRAL CAL2-SARin product (Rx1 channel)
SIR2SIC21B	SIRAL CAL2-SARin product (Rx2 channel)
SIR_LRM_2_	SIRAL L2 product from LRM processing
SIR_FDM_2_	SIRAL L2 product from fast delivery ocean processing
SIR_SIN_2_	SIRAL L2 product from SARin processing
SIR_SID_2_	SIRAL L2 product from SARin degraded processing
SIR_SAR_2A	SIRAL L2 product from SAR step 1 processing
SIR_SAR_2B	SIRAL L2 product from SAR step 2 processing
SIR_GDR_2A	SIRAL L2 consolidated product including SAR step 1 data (SIR_SAR_2A)
SIR_GDR_2B	SIRAL L2 consolidated product including SAR step 2 data (SIR_SAR_2B)
SIR_LRMI2_	SIRAL intermediate L2 product from LRM processing
SIR_FDMI2_	SIRAL intermediate L2 product from fast delivery ocean processing
SIR_SINI2_	SIRAL intermediate L2 product from SARin processing
SIR_SIDI2_	SIRAL intermediate L2 product from SARin degraded processing
SIR_SARI2A	SIRAL intermediate L2 product from SAR step 1 processing
SIR_SARI2B	SIRAL intermediate L2 product from SAR step 2 processing

Jason-2 product overview

product type	description
JA2_OPN_2P	The Operational Geophysical Data Record (OGDR), produced on a NRT basis
JA2_OPR_2P	The reduced Operational Geophysical Data Record(SSHA-OGDR), produced on a NRT basis
JA2_IPN_2P	The Interim Geophysical Data Record (IGDR)
JA2_IPR_2P	The reduced Interim Geophysical Data Record (SSHA-IGDR), produced on a NRT basis
JA2_IPS_2P	The Sensor Interim Geophysical Data Record (SIGDR)
JA2_GPN_2P	The Geophysical Data Record (GDR)
JA2_GPR_2P	The reduced Geophysical Data Record (SSHA-GDR), produced on a NRT basis
JA2_GPS_2P	The Sensor Geophysical Data Record (SGDR)

Envisat product overview

product type	description	
RA2_FGD_2P	RA-2 Fast Delivery Geophysical Data Record	
RA2_GDR_2P	RA-2 Geophysical Data Record	
RA2_IGD_2P	RA-2 Intermediate Geophysical Data Record	
RA2_MWS_2P	RA-2 Sensor Data Record	
RA2_WWV_2P	RA-2 wind/wave product for Meteo Users	

Jason-1 product overview

product type	description	
JA1_OSD_2P	The Operational Sensor Data Record (OSDR), produced on a NRT basis	
JA1_IGD_2P	The Interim Geophysical Data Record (IGDR)	
JA1_GDR_2P	I_GDR_2P The Geophysical Data Record (GDR)	
JA1_SDR_2P	The Sensor Geophysical Data Record (SGDR)	

Topex/Poseidon product overview

Topex/Poseidon radar altimetry products

product type	description
MGDR_cycle_header_File	Merged GDR Topex/Poseidon cycle header file
MGDR_pass_file	Merged GDR Topex/Poseidon pass file
MGDR_crossover_point_file	Merged GDR Topex/Poseidon crossover point file (XNG)
SDR_pass_file	SDR Topex/Poseidon pass file

ERS-1 and 2 product overview

ERS-1 and ERS-2 radar altimetry products

product type	description	
OPR_pass_file	Same as the off-line intermediate product but enhanced with all geophysical corrections and precise orbit altitude.	
URA	Radar Altimeter Fast delivery	
WAP	Radar Altimeter Waveform product	

GFO product overview

product type	description	
	The GDR is generated from GFO Sensor Data Records (SDRs), precise laser orbit ephemerides provided by NASA Goddard Space Flight Center and Raytheon ITSS, environmental corrections, and ancillary geophysical variables.	

PODAAC product overview

Physical Oceanography Distributed Active Archive Center radar altimetry products for Jason-1 and Topex/Poseidon

product type	description
J1SSHA_CYCLE_HEADER_FILE	The PODAAC JASON-1 SSHA cycle header file
TPSSHA_CYCLE_HEADER_FILE	The PODAAC TOPEX/POSEIDON SSHA cycle header file
J1SSHA_PASS_FILE	The PODAAC JASON-1 SSHA pass file
TPSSHA_PASS_FILE	The PODAAC TOPEX/POSEIDON SSHA pass file

J1SSHA_ATG_FILE	The PODAAC JASON-1 Along Track Gridded SSHA file
TPSSHA_ATG_FILE	The PODAAC TOPEX/POSEIDON Along Track Gridded SSHA file

River and Lake product overview

ENVISAT-ERS Exploitation River and Lake Products

product type	description
RLH	River/Lake Hydrology Product
RLA	River/Lake Altimetry Product

NetCDF products

NetCDF products are self describing products.

This means that when an netCDF file is opened one can retrieve the product structure from the file itself. For this reason, BRAT will not store fixed product format descriptions for HDF files in the Data Dictionary (you will therefore also not find netCDF product format descriptions in this documentation). What BRAT will do is use the underlying netCDF library to retrieve the product format dynamically once an netCDF file is opened. Based on this format BRAT will create, on the fly, a mapping of the HDF product structure to one that is based on the Data Dictionary data types

However, to be properly interpreted in the toolbox, a HDF product needs a description module to be added.

For example, in order to (really) read a netCDF files we need to:

- 1. Access to netCDF attributes
- 2. Identify default/missing values (see _FillValue standard attribute)
- 3. Convert data to its actual value (not the value stored in file): see scale_factor and add_offset standard attributes.
- 4. Interpret the structure of file to compute actual values of data (and not solely returning the netCDF variables values 'as is').
- 5. Avoid making available variables belonging to data structure (which are not the data themselves)

Aviso Altimetry data in netCDF

product type	description
NRT- or DT-MSLA (h)	Ssalto/Duacs multimission Near real-time or Delayed time Maps of sea level anomalies (gridded)
NRT- or DT-MSLA (uv)	Ssalto/Duacs multimission Near real-time or Delayed time Geostrophic velocities associated to the Maps of sea level anomalies (gridded)
NRT- or DT-MSLA (err)	Ssalto/Duacs multimission Near real-time or Delayed time Maps of sea level anomalies Formal mapping error (gridded)
NRT- or DT-SLA	Ssalto/Duacs multimission Near real-time or Delayed time Sea level anomalies (along-track)
NRT- or DT-NRT- or DT-MADT (h)	Ssalto/Duacs multimission Near real-time or Delayed time Maps of absolute dynamic topography (gridded)
NRT- or DT-MADT (uv)	Ssalto/Duacs multimission Near real-time or Delayed time Geostrophic velocities associated to the Maps of absolute dynamic topography (gridded)
NRT- or DT-ADT	Ssalto/Duacs multimission Near real-time or Delayed time Absolute dynamic topography (along-track)
Monomission DT-SLA	Delayed time Sea level anomalies (along-track)
Monomission DT-CorSSH	Delayed time Corrected sea surface height (along-track)

NRT-MSWH	Near real-time Maps of Significant wave height (gridded)
NRT-MWind	Near real-time Maps of Wind speed modulus (gridded)

Annex B. Y=F(X) parameter file keys

NOTE: The following table of parameter file keyword help can be always be obtained by calling: "BratCreateYFX -k".

FILE Type : Str Count : [1-n]

Input file name.

RECORD Type: Str Count: 1

Record set name to take into account for a file.

OUTPUT Type: Str Count: 1

Name of created/modified file.

OUTPUT_TITLE Type : Str Count : [0-1]

Title of created/modified file (string describing the content and which should appear as a graphic title,

for example). (Default="")

SELECT Type: Expr Count: [0-n]

True for record values selected.

(Default=1)

FIELD Type: Expr Count: [1-20]=X

Expression of fields of *RECORD* to take into account.

FIELD_NAME Type : Name Count : X

Name of the *FIELD* data

FIELD_TYPE Type: KW1 Count: X

Type of *FIELD* data.

FIELD_UNIT Type : Unit Count : X

Unit of *FIELD* expression.

FIELD_TITLE Type : Str Count : X

Long name describing *FIELD*. The one which should appear in graphics on axis or legends, for example.

DATA_MODE Type : KW2 Count : [0-1]

Keyword to indicate how data are stored/computed.

(Default=MEAN)

X Type: Expr Count: 1

Expression of fields of *RECORD* to take into account.

X_NAME Type : Name Count : 1

Name of the *X* data

X_TYPE Type: KW1 Count: 1

Type of ${}^*X^*$ data (normally X, T or longitude).

X_UNIT Type : Unit Count : 1

Unit of *X* expression

X_TITLE Type : Str Count : 1

Long name describing *X*. The one which should appear

in graphics on axis or legends, for example.

ALIAS_NAME Type : Name Count : [0-n]=N

Name of an alias. An alias is a value which can be used

anywhere in another value of field by mean of %{NAME} construct. Names are case sensitive.

If a name reference (%{XXX}) does not correspond to an actually defined alias, the expansion is an empty

string.

(Default=None)

ALIAS_VALUE Type : Str Count : N

The value of the alias. ALIAS_VALUE keyword must have at

least as many occurences as the ALIAS_NAME one.

VERBOSE Type: Int Count: [0-1]

Amount of output: 0=None...5=Debug.

(Default=0)

Description of types:

Name String beginning with a letter and containing only letters,

digits and '_'

Int Integer

Expr Combination of fields of the current record.

An expression which can contain function calls like

trigonometric, conversion, test...

Str String. Leading and trailing blanks are ignored.

Unit Unit string conforming to Udunits package and the special

keyword 'DATE' which means that the data is a date.

KW1 Keywords: X/Y/Z/T/Latitude/Longitude/Data

KW2 Keywords: FIRST/LAST/MIN/MAX/MEAN/STDDEV/COUNT

Annex C. Z=F(X,Y) parameter file keys

NOTE: The following table of parameter file keyword help can be always be obtained by calling: "BratCreateZFXY - k"

FILE Type : Str Count : [1-n]

Input file name.

OUTPUT Type: Str Count: 1

Name of created/modified file.

OUTPUT_TITLE Type : Str Count : [0-1]

Title of created/modified file (string describing the content and which should appear as a graphic title,

for example). (Default="")

SELECT Type: Expr Count: [0-n]

True for record values selected.

(Default=1)

RECORD Type: Str Count: 1

Record set name to take into account for a file.

DATA_MODE Type : KW2 Count : [0-1]

Keyword to indicate how data are stored/computed.

(Default=MEAN)

POSITION_MODE Type : KW3 Count : [0-1]

How position is computed. (Default=NEAREST)

(Default=NEAREST)

OUTSIDE_MODE Type : KW4 Count : [0-1]

How data outside limits are managed.

(Default=STRICT)

X Type : Expr Count : 1

Expression of fields of *RECORD* to take into account.

X_NAME Type : Name Count : 1

Name of the *X* data

X_TYPE Type : KW1 Count : 1

Type of *X* data (normally X, T or longitude).

X_UNIT Type : Unit Count : 1

Unit of *X* expression

X_TITLE Type : Str Count : 1

Long name describing *X*. The one which should appear

in graphics on axis or legends, for example.

X_INTERVALS Type : Int Count : 1

Number of intervals between Min and Max for *X*.

(Default=180 for lat 360 for lon)

X_MIN Type : Flt Count : 1

Min value for *X* expression storage. (Default=-90 for lat, -180 for lon)

X_MAX Type: Flt Count: 1

Max value for *X* expression storage. (Default=90 for lat, 180 for lon)

X_LOESS_CUTOFF Type: Int Count: 1

Distance (in dots) where LOESS filter reaches 0 along X axis. Must be an odd integer. If 1 or 0, Distance computation is disabled. Needed only if at least

one filter is asked. (Default=0)

Y Type: Expr Count: 1

Expression of fields of *RECORD* to take into account.

Y_INTERVALS Type: Int Count: 1

Number of intervals between Min and Max for *Y*.

(Default=180 for lat 360 for lon)

Y_NAME Type : Name Count : 1

Name of the *Y* data.

Y_TYPE Type: KW1 Count: 1

Type of *Y* data (normally X, T or longitude).

Y_UNIT Type : Unit Count : 1

Unit of *Y* expression.

Y_TITLE Type : Str Count : 1

Long name describing *Y*. The one which should appear

in graphics on axis or legends, for example.

Y_MIN Type: Flt Count: 1

Min value for *Y* expression storage. (Default=-90 for lat, -180 for lon)

Y_MAX Type: Flt Count: 1

Max value for *Y* expression storage. (Default=90 for lat, 180 for lon)

Y_LOESS_CUTOFF Type: Int Count: 1

Distance (in dots) where LOESS filter reaches 0 along Y axis. Must be an odd integer. If 1 or 0, Distance computation is disabled. Needed only if at least

one filter is asked.

(Default=0)

FIELD Type : Expr Count : [1-20]=X

Expression of fields of *RECORD* to take into account.

FIELD_NAME Type : Name Count : X

Name of the *FIELD* data

FIELD_TYPE Type : KW1 Count : X

Type of *FIELD* data.

FIELD_UNIT Type : Unit Count : X

Unit of *FIELD* expression.

FIELD_TITLE Type : Str Count : X

Long name describing *FIELD*. The one which should appear in graphics on axis or legends, for example.

FIELD_FILTER Type: KS1 Count: X

How to filter the data.

ALIAS_NAME Type : Name Count : [0-n]=N

Name of an alias. An alias is a value which can be used

anywhere in another value of field by mean of %{NAME} construct. Names are case sensitive. If a name reference (%{XXX}) does not correspond to an actually defined alias, the expansion is an empty

string.

(Default=None)

ALIAS_VALUE Type : Str Count : N

The value of the alias. ALIAS_VALUE keyword must have at

least as many occurences as the ALIAS_NAME one.

VERBOSE Type: Int Count: [0-1]

Amount of output: 0=None...5=Debug.

(Default=0)

Description of types:

Name String beginning with a letter and containing only letters,

digits and '_'

Flt Floating point number

Int Integer

Expr Combination of fields of the current record.

An expression which can contain function calls like

trigonometric, conversion, test...

Str String. Leading and trailing blanks are ignored.

Unit Unit string conforming to Udunits package and the special

keyword 'DATE' which means that the data is a date.

KW1 Keywords: X/Y/Z/T/Latitude/Longitude/Data

KW2 Keywords: FIRST/LAST/MIN/MAX/MEAN/STDDEV/COUNT

KW3 Keywords: EXACT/NEAREST

EXACT: Measures which are exactly on boundaries

(grid lines) are keeped others are ignored NEAREST: Get the nearest boundary.

KW4 Keywords: STRICT/RELAXED/BLACK_HOLE

STRICT: Measure outside limits are ignored RELAXED: Measure outside limits are ignored if

they are farther than a half step from

the limit.

BLACK_HOLE: Everything outside the limit is

considered to be on the limit.

KS1 Set of keywords from: NONE, LOESS_SMOOTH, LOESS_EXTRAPOLATE,

LOESS (LOESS means LOESS_SMOOTH and LOESS_EXTRAPOLATE)

Annex D. Display parameter file keys

NOTE: The following table of parameter file keyword help can be always be obtained by calling: "BratDisplay –k".

FILE Type : Str Count : [1-n]

Input file name.

FIELD Type: Expr Count: [1-23]=X

Expression of fields of *RECORD* to take into account.

FIELD_GROUP Type: Int Count: X

Group id from where belongs *FIELD*. generally used to

group many fields in one plot.

DISPLAY_PROPERTIES

Type: Bool Count: [0-1]

Indicates if property panel is shown.

(Default=No)

DISPLAY_TITLE Type : Str Count : [0-1]

Title of the plot to be displayed.

(Default="")

DISPLAY ANIMATIONBAR

Type: Bool Count: [0-1]

Keyword to indicate if property panel is shown.

(Default=No)

DISPLAY_COLORBAR Type: Bool Count: [0-1]

Keyword to indicate if color bar (legend) is shown.

(Default=Yes)

DISPLAY_CENTERLAT

Type: Flt Count: [0-1]

Latitude of the projection's center point.

(Default=0)

DISPLAY_CENTERLON

Type: Flt Count: [0-1]

Longitude of the projection's center point.

(Default=0)

DISPLAY_PROJECTION

Type: KW9 Count: [0-1]

Projection to use for mapping the world globe.

(Default=3D)

DISPLAY_COASTRESOLUTION

Type: KW6 Count: [0-1]

Resolution of the coast line drawm on the map.

Recommended value: low.

(Default=low)

DISPLAY_ZOOM_LON1

Type: Flt Count: [0-1] Zoom area west side. (Default=-180)

DISPLAY ZOOM LON2

Type: Flt Count: [0-1] Zoom area east side. (Default=180)

DISPLAY_ZOOM_LAT1

Type: Flt Count: [0-1] Zoom area south side. (Default=-90)

DISPLAY_ZOOM_LAT2

Type: Flt Count: [0-1] Zoom area north side. (Default=90)

DISPLAY_GROUPBY_FILE

Type: Bool Count: [0-1]

For world plot. When several files are in input, this parameter indicates if fields are displayed in the same plot (group field by file) or in different plots (one plot by file).

(Default=Yes)

DISPLAY_XMINVALUEType: Flt Count: [0-1]

Minimum X coordinate value to use in XY plot. (Default=min of data values for X axis)

DISPLAY_XMAXVALUE

Type: Flt Count: [0-1]

Maximum X coordinate value to use in XY plot. (Default=max of data values for X axis)

DISPLAY_YMINVALUEType: Flt Count: [0-1]

Minimum Y coordinate value to use in XY plot. (Default=min of data values for Y axis)

DISPLAY_YMAXVALUE

Type: Flt Count: [0-1]

Maximum Y coordinate value to use in XY plot. (Default=max of data values for Y axis)

DISPLAY_XLABEL Type : Str Count : [0-1]

X axis label to be displayed. (Default=field title or field name)

DISPLAY_YLABEL Type : Str Count : [0-1]

Y axis label to be displayed. (Default=field title or field name)

DISPLAY_XTICKS Type: Int Count: [0-1]

Number of ticks for the X axis.

(Default=6)

DISPLAY_YTICKS Type: Int Count: [0-1]

Number of ticks for the Y axis.

(Default=6)

DISPLAY_NAME Type : Str Count : [0-n]=W

Field name to be displayed.

DISPLAY_OPACITY Type : Flt Count : 0 or W

Opacity of the color value map image:

1.0 color is totally opaque0.0 is completely transparent.

(Default=0.7)

DISPLAY_MINVALUE Type: Flt Count: 0 or W

Minimum color table value to use in plot.

(Default=min of data values)

DISPLAY_MAXVALUE Type: Flt Count: 0 or W

Maximum color table value to use in plot.

(Default=max of data values)

DISPLAY_NUMCOLORLABELS

Type: Int Count: 0 or W

Number of labels shown on the plot's color bar.

(Default=2)

DISPLAY_COLORTABLE

Type: Str Count: 0 or W

Name of a predefined color table:

Aerosol Blackbody BlackToWhite Cloud Ozone GreenToRed Rainbow

RedToGreen WhiteToBlack

or name of a file containing the color table definition

(absolute or relative path).

(Default=Aerosol)

DISPLAY_COLORCURVE

Type: KW5 Count: 0 or W Set the color table on a specific curve.

(Default=Linear)

DISPLAY_CONTOUR Type: Bool Count: 0 or W

Indicates if the contour layer of the field is shown or not.

(Default=No)

DISPLAY_CONTOUR_NUMBER

Type: Int Count: 0 or W

Number of contour lines to generate

(equally spaced contour values between specified range

See DISPLAY CONTOUR MINVALUE and DISPLAY CONTOUR MAXVALUE).

(Default=5)

DISPLAY_CONTOUR_LABEL

Type: Bool Count: 0 or W

Indicate if the contour labels (value) are shown or not.

(Default=No)

DISPLAY_CONTOUR_LABEL_NUMBER

Type: Int Count: 0 or W

Number of labels on each contour.

(Default=1)

DISPLAY_CONTOUR_MINVALUE

Type: Flt Count: 0 or W

Minimum value to use to contour calculation. Default values are the same as the color scale one.

(Default=min of data values)

DISPLAY_CONTOUR_MAXVALUE

Type: Flt Count: 0 or W

Maximum value to use to contour calculation. Default values are the same as the color scale one.

(Default=max of data values)

DISPLAY_SOLID_COLOR

Type: Bool Count: 0 or W

Indicates if color layer of the field is shown or not.

(Default=Yes)

DISPLAY_EAST_COMPONENT

Type: Bool Count: 0 or W

Indicates if this field is the East component of a vector plot.

(Default=No)

DISPLAY_NORTH_COMPONENT

Type: Bool Count: 0 or W

Indicates if this field is the North component of a vector plot.

(Default=No)

DISPLAY_COLOR Type: KW7 Count: 0 or W

Color name of the XY plot field.

(Default=randow color)

DISPLAY_POINTS Type : Bool Count : 0 or W

Indicates if points are displayed in a XY plot

(for the field). (Default=No)

DISPLAY_LINES Type : Bool Count : 0 or W

Indicates if line is displayed in a XY plot (for the field).

(Default=Yes)

DISPLAY_POINTSIZE Type: Flt Count: 0 or W

Size of the points (XY plot, for the field).

(Default=1.0)

DISPLAY_LINEWIDTH Type: Flt Count: 0 or W

Width of the line (XY plot, for the field).

(Default=0.8)

DISPLAY_STIPPLEPATTERN

Type: KW10 Count: 0 or W

Stipple pattern for the line (field) (XY plot).

(Default=Full)

DISPLAY_POINTGLYPH

Type: KW8 Count: 0 or W Glyph of the points (field) (XY plot).

(Default=Circle)

DISPLAY_POINTFILLED

Type: Bool Count: 0 or W Indicates if points are filled or not.

(Default=Yes)

ALIAS_NAME Type : Name Count : [0-n]=N

Name of an alias. An alias is a value which can be used

anywhere in another value of field by mean of %{NAME} construct. Names are case sensitive. If a name reference (%{XXX}) does not correspond to an actually defined alias, the expansion is an empty

string.

(Default=None)

ALIAS_VALUE Type : Str Count : N

The value of the alias. ALIAS VALUE keyword must have at

least as many occurences as the ALIAS_NAME one.

VERBOSE Type: Int Count: [0-1]

Amount of output: 0=None...5=Debug.

(Default=0)

Description of types:

Name String beginning with a letter and containing only letters,

digits and '_'

Bool Boolean

true if: YES/Y/TRUE/T/OUI/O/VRAI/V/1 false if: NO/N/FALSE/F/NON/N/FAUX/0

Flt Floating point number

Int Integer

Expr Combination of fields of the current record.

An expression which can contain function calls like

trigonometric, conversion, test...

Str String. Leading and trailing blanks are ignored.

KW5 Keywords: cosine, linear, sqrt (square root)

KW6 Keywords: In incresing resolution: crude, low, intermediate,

full

KW7 Keywords: AQUAMARINE, BLACK, BLUE, BLUE VIOLET, BROWN,

CADET BLUE, CORAL, CORNFLOWER BLUE, CYAN, DARK GREY,

DARK GREEN, DARK OLIVE GREEN, DARK ORCHID

DARK SLATE BLUE, DARK SLATE GREY, DARK TURQUOISE, DIM GREY, FIREBRICK, FOREST GREEN, GOLD, GOLDENROD,

GREY, GREEN, GREEN YELLOW, INDIAN RED, KHAKI,

LIGHT BLUE, LIGHT GREY, LIGHT STEEL BLUE, LIME GREEN, MAGENTA, MAROON, MEDIUM AQUAMARINE, MEDIUM BLUE, MEDIUM FOREST GREEN, MEDIUM GOLDENROD, MEDIUM ORCHID,

MEDIUM SEA GREEN, MEDIUM SLATE BLUE, MEDIUM SPRING GREEN, MEDIUM TURQUOISE,

MEDIUM VIOLET RED, MIDNIGHT BLUE, NAVY, ORANGE, ORANGE RED, ORCHID, PALE GREEN, PINK, PLUM, PURPLE, RED, SALMON, SEA GREEN, SIENNA, SKY BLUE, SLATE BLUE, SPRING GREEN, STEEL BLUE, TAN, THISTLE, TURQUOISE,

VIOLET, VIOLET RED, WHEAT, WHITE, YELLOW,

YELLOW GREEN.

KW8 Keywords: ARROW, CIRCLE, CROSS, DASH, DIAMOND, HOOKEDARROW,

SQUARE, THICKARROW, THICKCROSS, TRIANGLE

KW9 Keywords: 3D, Azimuthal Equidistant, Lambert Cylindrical,

Lambert Azimuthal, Mercator, Mollweide, Plate Caree,

Robinson

KW10 Keywords: DASHTINY, DASH, DASHDOT, DOT, FULL

Annex E. BRATHL-IDL API

The BRAT-IDL API consists of a handful of IDL 'named structures' and functions.

'named structures':

BRATHL_DATEYMDHMSM BRATHL_DATEDSM BRATHL_DATESECOND BRATHL_DATEJULIAN

BRATHL_DATEYMDHMSM named structure

This structure represents a YYYY-MM-DD HH:MN:SS:MS date structure :

YEAR MONTH DAY HOUR MINUTE SECOND MUSECOND

Example:

MyDate={BRATHL_DATEYMDHMSM}

MyDate.YEAR=2003 MyDate.MONTH=12 MyDate.DAY=5 MyDate.HOUR=18 MyDate.MINUTE=0 MyDate.SECOND=21 MyDate.MUSECOND=1069

BRATHL_DATEDSM named structure

This structure represents a day/seconds/microseconds date structure:

REFDATE reference date
DAYS numbers of days
SECONDS numbers of seconds
MUSECONDS numbers of microseconds

REFDATE is the reference date i.e:

0: 1950-01-01 00:00:00.0

1: 1958-01-01 00:00:00.0

2: 1985-01-01 00:00:00.0

3: 1990-01-01 00:00:00.0

4: 2000-01-01 00:00:00.0

5: user reference 1

6: user reference 2

values of 5 and 6 allow the user to set two specifics reference date of his choice (see BRATHL_SETREFUSER1 and BRATHL_SETREFUSER2 functions)

Basic Radar Altimetry Toolbox User Manual Example: MyDate={BRATHL_DATEDSM} MyDate.REFDATE=3 MyDate.DAYS=423 MyDate.SECONDS=5 MyDate.MUSECONDS=0 BRATHL DATESECONDS named structure This structure represents a decimal seconds date structure: reference date - see :BRATHL_DATEDSM REFDATE **NBSECONDS** decimal numbers of seconds (seconds.microseconds) Example: MyDate={BRATHL_DATESECONDS} MyDate.REFDATE=0 MyDate.NBSECONDS=56236.0253 BRATHL_DATEJULIAN named structure This structure represents a decimal julian date structure: REFDATE reference date - see :BRATHL_DATEDSM **JULIAN** decimal julian day Example: MyDate={BRATHL_DATESECONDS} MyDate.REFDATE=0 MyDate.JULIAN=123.569 **Functions** Date conversion/computation functions BRATHL_DAYOFYEAR BRATHL_DIFFDSM BRATHL_DIFFJULIAN BRATHL_DIFFYMDHMSM BRATHL_DSM2JULIAN BRATHL_DSM2SECONDS BRATHL_DSM2YMDHMSM

BRATHL_JULIAN2DSM BRATHL_JULIAN2SECONDS BRATHL_JULIAN2YMDHMSM

BRATHL_SECONDS2DSM BRATHL_SECONDS2JULIAN

BRATHL_SECONDS2YMDHMSM

BRATHL_NOWYMDHMSM

BRATHL_YMDHMSM2DSM BRATHL_YMDHMSM2JULIAN BRATHL_YMDHMSM2SECONDS

BRATHL_SETREFUSER1 BRATHL_SETREFUSER2

==========

Cycle/date conversion functions

=============

BRATHL_CYCLE2YMDHMSM BRATHL_YMDHMSM2CYCLE

Data reading function

BRATHL_READDATA

BRATHL_DAYOFYEAR

Retrieves the day of year of a date

BRATHL_DAYOFYEAR(BRATHL_DATEYMDHMSM dateYMDHMSM, ULONG dayOfYear)

[in] dateYMDHMSM: date

[out] dayOfYear : day of year of the date parameter

returns 0 or error code (see Date error codes in brathl general documentation)

Example:

MyDate={BRATHL_DATEYMDHMSM}

MyDate.YEAR=2003 MyDate.MONTH=12 MyDate.DAY=5 MyDate.HOUR=18 MyDate.MINUTE=0 MyDate.SECOND=21 MyDate.MUSECOND=1069

dayOfYear=0L r = BRATHL_DAYOFYEAR(MyDate, dayOfYear) print, r, dayOfYear

BRATHL_DIFFDSM

Computes the difference between two dates (date1 - date2) the result is expressed in a decimal number of seconds

BRATHL_DIFFDSM(BRATHL_DATEDSM date1, BRATHL_DATEDSM date2, DOUBLE diff)

[in] date1 [in] date2

[out] diff : difference in seconds (date1 - date2)

return 0 or error code (see Date error codes in brathl general documentation)

Example:

d2.DAYS=36

d1={BRATHL_DATEDSM} d1.REFDATE=3 d1.DAYS=423 d1.SECONDS=5 d1.MUSECONDS=0 d2={BRATHL_DATEDSM} d2.REFDATE=2

d2.SECONDS=54 d2.MUSECONDS=2536

 $\begin{array}{l} \mbox{diff} = 0.0D \\ \mbox{r} = \mbox{BRATHL_DIFFYMDHMSM(d1, d2, diff)} \\ \mbox{print, r, diff} \end{array}$

BRATHL_DIFFJULIAN

Computes the difference between two dates (date1 - date2) the result is expressed in a decimal number of seconds

BRATHL_DIFFJULIAN (BRATHL_DIFFJULIAN date1, BRATHL_DIFFJULIAN date2, DOUBLE diff)

[in] date1 [in] date2

[out] diff : difference in seconds (date1 - date2)

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DIFFDSM

BRATHL_DIFFYMDHMSM

_

Computes the difference between two dates (date1 - date2) the result is expressed in a decimal number of seconds

BRATHL_DIFFYMDHMSM(BRATHL_DIFFYMDHMSM date1, BRATHL_DIFFYMDHMSM date2, DOUBLE diff)

[in] date1 [in] date2

[out] diff : difference in seconds (date1 - date2)

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DIFFDSM

BRATHL_DSM2JULIAN

Converts a days-seconds-microseconds date into a decimal julian date, according to refDate parameter

BRATHL_DSM2JULIAN(BRATHL_DATEDSM dateDSM, INT refDate, BRATHL_DATEJULIAN dateJulian);

[in] dateDSM: date to convert

[in] refDate : date reference conversion [out] dateJulian : result of the conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example:

dIn={BRATHL_DATEDSM}

dIn.REFDATE=3 dIn.DAYS=423 dIn.SECONDS=5 dIn.MUSECONDS=0

dOut={BRATHL_DATEJULIAN}

refDateDestination = 0

r = BRATHL_DSM2JULIAN(dln, refDateDestination, dOut) print, r, dOut.REFDATE, dOut.JULIAN

BRATHL_DSM2SECONDS

Converts a days-seconds-microseconds date into secnods, according to refDate parameter

BRATHL_DSM2SECONDS(BRATHL_DATEDSM dateDSM, INT refDate, BRATHL_DATESECOND dateSeconds);

[in] dateDSM: date to convert

[in] refDate : date reference conversion [out] dateSeconds : result of the conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DSM2JULIAN

BRATHL_DSM2YMDHMSM

_

Converts a days-seconds-microseconds date into a year, month, day, hour, minute, second, microsecond date

BRATHL_DSM2YMDHMSM(BRATHL_DATEDSM dateDSM, BRATHL_DATEYMDHMSM dateYMDHMSM);

[in] dateDSM: date to convert

[in] refDate : date reference conversion [out] dateYMDHMSM : result of the conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example:

dIn={BRATHL_DATEDSM}

dln.REFDATE=3 dln.DAYS=423 dln.SECONDS=5 dln.MUSECONDS=0

 $dOut = \{BRATHL_DATEYMDHMSM\}$

refDateDestination = 0

r = BRATHL_DSM2YMDHMSM(dln, dOut)

print, r, dOut.YEAR, dOut.JULIAN, dOut.MONTH, dOut.DAY, dOut.HOUR, dOut.MINUTE, dOut.SECOND, dOut.MUSECOND

BRATHL_JULIAN2DSM

_

Converts a decimal julian date into a days-seconds-microseconds date, according to refDate parameter

BRATHL_JULIAN2DSM(BRATHL_DATEJULIAN dateJulian, INT refDate, BRATHL_DATEDSM dateDSM);

[in] dateJulian : date to convert

[in] refDate : date reference conversion [out] dateDSM : result of conversion

return 0 or error code (see Date error codes in brathl general documentation)

BRATHL_DSM2YMDHMSM(BRATHL_DATEDSM dateDSM, BRATHL_DATEYMDHMSM dateYMDHMSM);

[in] dateDSM: date to convert

[in] refDate : date reference conversion [out] dateYMDHMSM : result of the conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DSM2JULIAN

BRATHL_JULIAN2SECONDS

Converts a decimal julian date into seconds, according to refDate parameter

BRATHL_JULIAN2SECONDS(BRATHL_DATEJULIAN dateJulian, INT refDate, BRATHL_DATESECOND dateSeconds)

[in] dateJulian : date to convert

[in] refDate : date reference conversion [out] dateSeconds : result of conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DSM2JULIAN

BRATHL_JULIAN2YMDHMSM

Converts a decimal julian date into a year, month, day, hour, minute, second, microsecond date

BRATHL_JULIAN2YMDHMSM(BRATHL_DATEJULIAN dateJulian, BRATHL_DATEYMDHMSM dateYMDHMSM);

[in] dateJulian : date to convert

[in] refDate : date reference conversion [out] dateYMDHMSM : result of conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DSM2YMDHMSM

BRATHL_SECONDS2DSM

Converts seconds into a days-seconds-microseconds date, according to refDate parameter

BRATHL_SECONDS2DSM(BRATHL_DATESECOND dateSeconds, INT refDate, BRATHL_DATEDSM dateDSM);

[in] dateSeconds : date to convert [in] refDate : date reference conversion [out] dateDSM : result of the conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DSM2JULIAN

BRATHL_SECONDS2YMDHMSM

Converts seconds into a a decimal julian date, according to refDate parameter

BRATHL_SECONDS2YMDHMSM(BRATHL_DATESECOND dateSeconds, INT refDate, BRATHL_DATEJULIAN dateJulian)

[in] dateSeconds : date to convert [in] refDate : date reference conversion [out] dateJulian : result of the conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DSM2JULIAN

BRATHL_NOWYMDHMSM

Gets the current date/time,

LIBRATHL_API int32_t brathl_NowYMDHMSM(brathl_DateYMDHMSM *dateYMDHMSM);

[out] dateYMDHMSM : current date/time

 ${\sf BRATHL_NOWYMDHMSM} ({\sf BRATHL_DATEYMDHMSM})$

Example: see BRATHL_DSM2JULIAN

 $\begin{aligned} & dOut = & \{BRATHL_DATEYMDHMSM\} \\ & r = BRATHL_NOWYMDHMSM(dOut) \end{aligned}$

print, r, dOut.YEAR, dOut.JULIAN, dOut.MONTH, dOut.DAY, dOut.HOUR, dOut.MINUTE, dOut.SECOND, dOut.MUSECOND

BRATHL_YMDHMSM2DSM

Converts a year, month, day, hour, minute, second, microsecond date into a days-seconds-microseconds date, according to refDate parameter

BRATHL_YMDHMSM2DSM(BRATHL_DATEYMDHMSM dateYMDHMSM, INT refDate, BRATHL_DATEDSM dateDSM)

[in] dateYMDHMSM: date to convert [in] refDate: date reference conversion [out] dateDSM: result of the conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DSM2JULIAN

BRATHL_YMDHMSM2JULIAN

Converts a year, month, day, hour, minute, second, microsecond date into a decimal julian date, according to refDate parameter

BRATHL_YMDHMSM2JULIAN(BRATHL_DATEYMDHMSM dateYMDHMSM, INT refDate, BRATHL_DATEJULIAN dateJulian)

[in] dateYMDHMSM: date to convert [in] refDate: date reference conversion [out] dateJulian: result of the conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DSM2JULIAN

BRATHL_YMDHMSM2SECONDS

Converts a year, month, day, hour, minute, second, microsecond date into a seconds, according to refDate parameter

BRATHL_YMDHMSM2SECONDS(BRATHL_DATEYMDHMSM dateYMDHMSM, INT refDate, BRATHL_DATESECOND dateSeconds)

[in] dateYMDHMSM : date to convert [in] refDate : date reference conversion [out] dateSeconds : result of the conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DSM2JULIAN

BRATHL_SETREFUSER1 BRATHL_SETREFUSER2

Set user-defined reference dates

BRATHL_SETREFUSER1(STRING dateRef)

[in] dateRef: date to set - format: YYYY-MM-DD HH:MN:SS.MS

return 0 or error code (see Date error codes in brathl general documentation)

Example:

dateRefUser1 = '2001 01 12 14:57:23:1456'

```
dateRefUser2 = '2005 11 14'
brathl_setrefuser1(dateRefUser1)
brathl_setrefuser2(dateRefUser2)
MyDate={BRATHL_DATEDSM}
. Set user-defined ref. date 2001 01 12 14:57:23:1456
MyDate.REFDATE=5
MyDate.DAYS=423
MyDate.SECONDS=5
MyDate.MUSECONDS=0
AnotherDate={BRATHL_DATEDSM}
. Set user-defined ref. date 2005 11 14
AnotherDate.REFDATE=6
AnotherDate.DAYS=423
AnotherDate.SECONDS=5
AnotherDate.MUSECONDS=0
; ref. date for MyDate is now 2005 11 14
MyDate.REFDATE=6
brathl setrefuser2('2005 05 18 13:08:00')
; ref. date for MyDate and AnotherDate is now 2005 05 18 13:08:00
BRATHL_CYCLE2YMDHMSM
Converts a cyle/pass into a date
BRATHL_CYCLE2YMDHMSM(INT mission, ULONG cycle, ULONG pass, BRATHL_DATEYMDHMSM dateYMDHMSM)
[in] mission : mission type :
        0: Topex/Poseidon
        1 : Jason-1
        2: ERS2
        3: Envisat
        4: ERS1-A
        5: ERS1-B
                                      6: GFO
[in] cycle: number of cycle to convert
[in] pass: number of pass in the cycle to cinvert
[out] dateYMDHMSM: date corresponding to the cycle/pass
return 0 or error code (see Cycle/date conversion error codes in brathl general documentation)
Example:
cycle=120L
pass=153L
mission=3
dOut={BRATHL_DATEYMDHMSM}
r = BRATHL_CYCLE2YMDHMSM(mission, cycle, pass, dOut)
print, "result ", r
print, "mission ", mission , " cycle ", cycle, " pass ", pass
```

print, "Y", dOut.year, " M ", dOut.month, " D ", dOut.day, " H ", dOut.hour, " MN ", dOut.minute, " S ", dOut.second, " MS ", dOut.muSecond BRATHL_YMDHMSM2CYCLE Converts a date into a cycle/pass BRATHL_YMDHMSM2CYCLE(INT mission, BRATHL_DATEYMDHMSM dateYMDHMSM, ULONG cycle, ULONG pass) [in] mission : mission type : 0: Topex/Poseidon 1 : Jason-1 2: ERS2 3: Envisat 4: ERS1-A 5: ERS1-B 6: GFO [in] dateYMDHMSM : date to convert [out] cycle: number of cycle [out] pass : number of pass in the cycle return 0 or error code (see Cycle/date conversion error codes in brathl general documentation) Example: cycle=0L pass=0L mission=1 dIn={BRATHL_DATEYMDHMSM} dln.YEAR=2003 dln.MONTH=12 dln.DAY=5 dln.HOUR=18 dln.MINUTE=0 dln.SECOND=21 dln.MUSECOND=1069 r = BRATHL_YMDHMSM2CYCLE(mission, dln, cycle, pass) print, "result ", r print, "Y", dOut.year, " M ", dOut.month, " D ", dOut.day, " H ", dOut.hour, " MN ", dOut.minute, " S ", dOut.second, " MS ", dOut.muSecond print, "mission", mission, "cycle", cycle, "pass", pass BRATHL_READDATA Read data from a set of files Each measure for a data is a scalar value (a single number) [in] fileNames: file name string (one file) or file names array [in] recordName: Name of the fields record (for netCDF files recordName is 'data') [in] selection: Expression involving data fields which has to be true to select returned data. (if empty string no selection is done (all data is selected) [in] dataExpressions: Expression string (one expression) or expressions array applied to data fields to build the wanted value. [in] units: Wanted unit for each expression (string (one unit) or units array). (if empty string, no unit conversion is applied to the data of the corresponding expression. When a unit conversion has to be applied, the result of the expression is considered to be the base unit (SI). For

example if the wanted unit is gram/l, the unit of the expression

Basic Radar Altimetry Toolbox User Manual is supposed to be kilogram/m3 (internaly all data are converted to base unit of the actual fields unit which is coherent with the above assumption). [in/out] results: Data read. Must be an array (dim = number of dataExpressions) to values to read. [in] ignoreOutOfRange: Skip excess data. 0=false, other = true Must be false if statistics is true. [in] statistics: returns statistics on data instead of data themselves 0=false, other = true If statistics is true, ignoreOutOfRange must be false. The returned values (5 values) for each expression are: - Count of valid data taken into account. Invalid data are those which are equal to the default/missing value - Mean of the valid data. - Standard deviation of the valid data - Minimum value of the valid data - Maximum value of the valid data [in] defaultValue : value to use for default/missing values This is the value you want to indicate that a value is missing or invalid. return 0 or error code. Example: ; Set data input file files=SINDGEN(3) files[0]="/data/samples/JA1_GDR_2PaP124_001.CNES" files[1]="/data/samples/JA1_GDR_2PaP124_002.CNES" files[2]="/data/samples/JA1_GDR_2PaP124_003.CNES" ; Set record name record="data" ; Set data selection - (set selection = "" to retrieve all data row) selection="latitude > 20 && latitude < 30" ; Set expressions (here 2 expressions) expr=SINDGEN(2) ; A compute expression expr[0]="latitude + longitude" ; A single expression expr[1]="swh_ku" ; Set units for each expression units=SINDGEN(2) ; Convert unit to radians for expression 1 (latitude + longitude) units[0]="radians" ; No unit conversion for expression 2 (swh_ku) - result will be in SI unit.

units[1]="'

; Create results array (dimension is number of expression) dataResults=DINDGEN(2)

ignoreOutOfrange=0

; No statistics statistics=0

for j = 0,dim[1] - 1 do begin print, "Data", i ,j, data[i,j]

endfor endfor

; Default value is 0 defaultValue=0 ; Call ReadData function r = BRATHL_READDATA(files, record, selection, expr, units, dataResults, ignoreOutOfrange, statistics, defaultValue) print, "return code ", r print, size(dataResults) print, "NDIMS", size(dataResults, /N_DIMENSIONS) print, "DIMS", size(dataResults, /DIMENSIONS)
print, "NELTS", size(dataResults, /N_ELEMENTS)
print, "TYPE", size(dataResults, /TYPE) dim = size(dataResults, /DIMENSIONS) ; Print data value on the screen for i = 0, 1 do begin

Annex F. BRATHL-MATLAB API

The BRATHL-MATLAB API consists of just a handful of MATLAB structures and functions.

structures

BRATHL_DATEYMDHMSM = 0 BRATHL_DATEDSM = 1 BRATHL_DATESECOND = 2 BRATHL_DATEJULIAN = 3

To create a structure, use BRATHL_CREATESTRUCT (see description below)

BRATHL_DATEYMDHMSM structure

This structure represents a YYYY-MM-DD HH:MN:SS:MS date structure :

YEAR MONTH DAY HOUR MINUTE SECOND MUSECOND

Example:

MyDate=BRATHL_CREATESTRUCT(0)

MyDate.YEAR=2003 MyDate.MONTH=12 MyDate.DAY=5 MyDate.HOUR=18 MyDate.MINUTE=0 MyDate.SECOND=21 MyDate.MUSECOND=1069

BRATHL_DATEDSM structure

This structure represents a day/seconds/microseconds date structure:

REFDATE reference date
DAYS numbers of days
SECONDS numbers of seconds
MUSECONDS numbers of microseconds

REFDATE is the reference date i.e:

0: 1950-01-01 00:00:00.0 1: 1958-01-01 00:00:00.0 2: 1985-01-01 00:00:00.0 3: 1990-01-01 00:00:00.0 4: 2000-01-01 00:00:00.0 5: user reference 1 6: user reference 2

values of 5 and 6 allow the user to set two specifics reference date of his choice (see BRATHL_SETREFUSER1 and BRATHL_SETREFUSER2 functions)

: Example :

MyDate=BRATHL_CREATESTRUCT(1)

MyDate.REFDATE=3 MyDate.DAYS=423 MyDate.SECONDS=5 MyDate.MUSECONDS=0

BRATHL_DATESECONDS structure

This structure represents a decimal seconds date structure:

REFDATE reference date - see :BRATHL_DATEDSM

NBSECONDS decimal numbers of seconds (seconds.microseconds)

.

Example:

MyDate=BRATHL_CREATESTRUCT(2)

MyDate.REFDATE=0 MyDate.NBSECONDS=56236.0253

BRATHL_DATEJULIAN structure

This structure represents a decimal julian date structure:

REFDATE reference date - see :BRATHL_DATEDSM

JULIAN decimal julian day

:

Example:

MyDate=BRATHL_CREATESTRUCT(3)

MyDate.REFDATE=0 MyDate.JULIAN=123.569

Functions

structure creation functions

BRATHL_CREATESTRUCT

===============

Date conversion/computation functions

BRATHL_DAYOFYEAR

BRATHL_DIFFDSM BRATHL_DIFFJULIAN BRATHL_DIFFYMDHMSM

BRATHL_DSM2JULIAN BRATHL_DSM2SECONDS BRATHL_DSM2YMDHMSM

BRATHL_JULIAN2DSM BRATHL_JULIAN2SECONDS BRATHL_JULIAN2YMDHMSM

BRATHL_SECONDS2DSM BRATHL_SECONDS2JULIAN BRATHL_SECONDS2YMDHMSM

BRATHL_NOWYMDHMSM

BRATHL_YMDHMSM2DSM BRATHL_YMDHMSM2JULIAN BRATHL_YMDHMSM2SECONDS

BRATHL_SETREFUSER1 BRATHL_SETREFUSER2

Cycle/date conversion functions

To convert cycle <-> date, these functions use an asci parameter file (ascii file) with records:

field 1: Name of the mission

field 2 : Cycle reference

field 3 : Pass reference

field 4: Reference date in decimal julian day

Each field has to be separated by, at least, a non-numeric character

The file can contained several records for a same mission. Only the field with the greatest date is taken into account

You can add records.

You can add comments, commented lines start by '#' character.

If the file doesn't exist, default values are:

<u>Name</u>	<u>Cycle</u>	<u>Pass</u>	Reference date		
Jason-1	99		230	19987.9081795	
Topex/Poseidon	442		230	19987.9127535	
ERS2	66		598	18831.768334	
ERS1-A	15		1	15636.938955	
ERS1-B	42		108	16538.6732895	
ENVISAT	30		579	19986.106016	

BRATHL_CYCLE2YMDHMSM BRATHL_YMDHMSM2CYCLE

BRATHL_DAYOFYEAR

Retrieves the day of year of a date

dayOfYear = BRATHL_DAYOFYEAR(BRATHL_DATEYMDHMSM dateYMDHMSM)

[in] dateYMDHMSM : date

[out] dayOfYear : day of year of the date parameter

Example:

```
MyDate={BRATHL_DATEYMDHMSM}
MyDate.YEAR=2003
MyDate.MONTH=12
MyDate.DAY=5
MyDate.HOUR=18
MyDate.MINUTE=0
MyDate.SECOND=21
MyDate.MUSECOND=1069
dayOfYear=0L
r = BRATHL_DAYOFYEAR(MyDate, dayOfYear)
print, r, dayOfYear
BRATHL_DIFFDSM
Computes the difference between two dates (date1 - date2)
the result is expressed in a decimal number of seconds
BRATHL_DIFFDSM(BRATHL_DATEDSM date1, BRATHL_DATEDSM date2, DOUBLE diff)
[in] date1
[in] date2
[out] diff: difference in seconds (date1 - date2)
return 0 or error code (see Date error codes in brathl general documentation)
Example:
d1={BRATHL_DATEDSM}
d1.REFDATE=3
d1.DAYS=423
d1.SECONDS=5
d1.MUSECONDS=0
d2={BRATHL_DATEDSM}
d2.REFDATE=2
d2.DAYS=36
d2.SECONDS=54
d2.MUSECONDS=2536
diff = 0.0D
r = BRATHL_DIFFYMDHMSM(d1, d2, diff)
print, r, diff
BRATHL_DIFFJULIAN
Computes the difference between two dates (date1 - date2)
the result is expressed in a decimal number of seconds
BRATHL_DIFFJULIAN (BRATHL_DIFFJULIAN date1, BRATHL_DIFFJULIAN date2, DOUBLE diff)
```

[in] date1 [in] date2

[out] diff : difference in seconds (date1 - date2)

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DIFFDSM

BRATHL_DIFFYMDHMSM

Computes the difference between two dates (date1 - date2) the result is expressed in a decimal number of seconds

BRATHL_DIFFYMDHMSM(BRATHL_DIFFYMDHMSM date1, BRATHL_DIFFYMDHMSM date2, DOUBLE diff)

[in] date1 [in] date2

[out] diff: difference in seconds (date1 - date2)

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DIFFDSM

BRATHL_DSM2JULIAN

Converts a days-seconds-microseconds date into a decimal julian date, according to refDate parameter

BRATHL_DSM2JULIAN(BRATHL_DATEDSM dateDSM, INT refDate, BRATHL_DATEJULIAN dateJulian);

[in] dateDSM: date to convert

[in] refDate : date reference conversion [out] dateJulian : result of the conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example:

dIn={BRATHL_DATEDSM}

dln.REFDATE=3 dln.DAYS=423 dln.SECONDS=5 dln.MUSECONDS=0

dOut={BRATHL_DATEJULIAN}

refDateDestination = 0

r = BRATHL_DSM2JULIAN(dln, refDateDestination, dOut) print, r, dOut.REFDATE, dOut.JULIAN

BRATHL_DSM2SECONDS

Converts a days-seconds-microseconds date into secnods, according to refDate parameter

BRATHL_DSM2SECONDS(BRATHL_DATEDSM dateDSM, INT refDate, BRATHL_DATESECOND dateSeconds);

[in] dateDSM: date to convert

[in] refDate : date reference conversion [out] dateSeconds : result of the conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DSM2JULIAN

BRATHL_DSM2YMDHMSM

Converts a days-seconds-microseconds date into a year, month, day, hour, minute, second, microsecond date

BRATHL_DSM2YMDHMSM(BRATHL_DATEDSM dateDSM, BRATHL_DATEYMDHMSM dateYMDHMSM);

[in] dateDSM: date to convert

[in] refDate : date reference conversion

[out] dateYMDHMSM: result of the conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example:

dIn={BRATHL_DATEDSM}

dIn.REFDATE=3 dIn.DAYS=423 dIn.SECONDS=5 dIn.MUSECONDS=0

dOut={BRATHL_DATEYMDHMSM}

refDateDestination = 0

r = BRATHL_DSM2YMDHMSM(dln, dOut)

print, r, dOut.YEAR, dOut.JULIAN, dOut.MONTH, dOut.DAY, dOut.HOUR, dOut.MINUTE, dOut.SECOND, dOut.MUSECOND

BRATHL_JULIAN2DSM

Converts a decimal julian date into a days-seconds-microseconds date, according to refDate parameter

BRATHL_JULIAN2DSM(BRATHL_DATEJULIAN dateJulian, INT refDate, BRATHL_DATEDSM dateDSM);

[in] dateJulian : date to convert

[in] refDate : date reference conversion [out] dateDSM : result of conversion

return 0 or error code (see Date error codes in brathl general documentation)

BRATHL_DSM2YMDHMSM(BRATHL_DATEDSM dateDSM, BRATHL_DATEYMDHMSM dateYMDHMSM);

[in] dateDSM : date to convert

[in] refDate : date reference conversion [out] dateYMDHMSM : result of the conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DSM2JULIAN

BRATHL_JULIAN2SECONDS

Converts a decimal julian date into seconds, according to refDate parameter

BRATHL_JULIAN2SECONDS(BRATHL_DATEJULIAN dateJulian, INT refDate, BRATHL_DATESECOND dateSeconds)

[in] dateJulian : date to convert

[in] refDate : date reference conversion [out] dateSeconds : result of conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DSM2JULIAN

BRATHL_JULIAN2YMDHMSM

Converts a decimal julian date into a year, month, day, hour, minute, second, microsecond date

BRATHL_JULIAN2YMDHMSM(BRATHL_DATEJULIAN dateJulian, BRATHL_DATEYMDHMSM);

[in] dateJulian : date to convert

[in] refDate : date reference conversion [out] dateYMDHMSM : result of conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DSM2YMDHMSM

BRATHL_SECONDS2DSM

Converts seconds into a days-seconds-microseconds date, according to refDate parameter

BRATHL_SECONDS2DSM(BRATHL_DATESECOND dateSeconds, INT refDate, BRATHL_DATEDSM dateDSM);

[in] dateSeconds : date to convert [in] refDate : date reference conversion [out] dateDSM : result of the conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DSM2JULIAN

BRATHL_SECONDS2JULIAN

Converts seconds into a decimal julian date, according to refDate parameter

BRATHL_SECONDS2JULIAN(BRATHL_DATESECOND dateSeconds, INT refDate, BRATHL_DATEJULIAN dateJulian)

[in] dateSeconds : date to convert [in] refDate : date reference conversion [out] dateJulian : result of the conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DSM2JULIAN

BRATHL_SECONDS2YMDHMSM

Converts seconds into a a decimal julian date, according to refDate parameter

BRATHL_SECONDS2YMDHMSM(BRATHL_DATESECOND dateSeconds, INT refDate, BRATHL_DATEJULIAN dateJulian)

[in] dateSeconds : date to convert [in] refDate : date reference conversion

[out] dateJulian: result of the conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DSM2JULIAN

BRATHL_NOWYMDHMSM

Gets the current date/time,

LIBRATHL_API int32_t brathl_NowYMDHMSM(brathl_DateYMDHMSM *dateYMDHMSM);

[out] dateYMDHMSM : current date/time

BRATHL_NOWYMDHMSM(BRATHL_DATEYMDHMSM dateYMDHMSM)

Example: see BRATHL_DSM2JULIAN

 $\begin{aligned} & dOut = & \{BRATHL_DATEYMDHMSM\} \\ & r = BRATHL_NOWYMDHMSM(dOut) \end{aligned}$

print, r, dOut.YEAR, dOut.JULIAN, dOut.MONTH, dOut.DAY, dOut.HOUR, dOut.MINUTE, dOut.SECOND, dOut.MUSECOND

BRATHL_YMDHMSM2DSM

Converts a year, month, day, hour, minute, second, microsecond date into a days-seconds-microseconds date, according to refDate parameter

BRATHL_YMDHMSM2DSM(BRATHL_DATEYMDHMSM dateYMDHMSM, INT refDate, BRATHL_DATEDSM dateDSM)

[in] dateYMDHMSM: date to convert [in] refDate: date reference conversion [out] dateDSM: result of the conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DSM2JULIAN

BRATHL_YMDHMSM2JULIAN

_

Converts a year, month, day, hour, minute, second, microsecond date into a decimal julian date, according to refDate parameter

BRATHL_YMDHMSM2JULIAN(BRATHL_DATEYMDHMSM dateYMDHMSM, INT refDate, BRATHL_DATEJULIAN dateJulian)

[in] dateYMDHMSM: date to convert [in] refDate: date reference conversion [out] dateJulian: result of the conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DSM2JULIAN

BRATHL_YMDHMSM2SECONDS

Converts a year, month, day, hour, minute, second, microsecond date into a seconds, according to refDate parameter

BRATHL_YMDHMSM2SECONDS(BRATHL_DATEYMDHMSM dateYMDHMSM, INT refDate, BRATHL_DATESECOND dateSeconds)

[in] dateYMDHMSM : date to convert [in] refDate : date reference conversion [out] dateSeconds : result of the conversion

return 0 or error code (see Date error codes in brathl general documentation)

Example: see BRATHL_DSM2JULIAN

BRATHL_SETREFUSER1 BRATHL_SETREFUSER2

Set user-defined reference dates

BRATHL_SETREFUSER1(STRING dateRef)

[in] dateRef: date to set - format: YYYY-MM-DD HH:MN:SS.MS

return 0 or error code (see Date error codes in brathl general documentation)

Example:

dateRefUser1 = '2001 01 12 14:57:23:1456' dateRefUser2 = '2005 11 14'

brathl_setrefuser1(dateRefUser1) brathl_setrefuser2(dateRefUser2)

MyDate={BRATHL_DATEDSM}

. Set user-defined ref. date 2001 01 12 14:57:23:1456 MyDate.REFDATE=5 MyDate.DAYS=423 MyDate.SECONDS=5 MyDate.MUSECONDS=0

AnotherDate={BRATHL_DATEDSM}

. Set user-defined ref. date 2005 11 14 AnotherDate.REFDATE=6 AnotherDate.DAYS=423 AnotherDate.SECONDS=5 AnotherDate.MUSECONDS=0

117 **Basic Radar Altimetry Toolbox User Manual** ; ref. date for MyDate is now 2005 11 14 MyDate.REFDATE=6 brathl_setrefuser2('2005 05 18 13:08:00') ; ref. date for MyDate and AnotherDate is now 2005 05 18 13:08:00 BRATHL_CYCLE2YMDHMSM Converts a cyle/pass into a date BRATHL_CYCLE2YMDHMSM(INT mission, ULONG cycle, ULONG pass, BRATHL_DATEYMDHMSM dateYMDHMSM) [in] mission : mission type : 0: Topex/Poseidon 1 : Jason-1 2: ERS2 3: Envisat 4: ERS1-A 5: ERS1-B 6: GFO [in] cycle: number of cycle to convert [in] pass: number of pass in the cycle to cinvert [out] dateYMDHMSM: date corresponding to the cycle/pass return 0 or error code (see Cycle/date conversion error codes in brathl general documentation) Example: cycle=120L pass=153L mission=3 dOut={BRATHL_DATEYMDHMSM} $\label{eq:result} \begin{array}{ll} r = BRATHL_CYCLE2YMDHMSM(mission,\,cycle,\,pass,\,dOut) \\ print,\,"result\,",\,r \end{array}$ print, "mission ", mission , " cycle ", cycle, " pass ", pass print, "Y", dOut.year, " M ", dOut.month, " D ", dOut.day, " H ", dOut.hour, " MN ", dOut.minute, " S ", dOut.second, " MS ", dOut.muSecond BRATHL_YMDHMSM2CYCLE Converts a date into a cycle/pass BRATHL_YMDHMSM2CYCLE(INT mission, BRATHL_DATEYMDHMSM dateYMDHMSM, ULONG cycle, ULONG pass) [in] mission : mission type :

0: Topex/Poseidon

1 : Jason-1

2: ERS2

3: Envisat

4: ERS1-A

5: ERS1-B

6: GFO

[in] dateYMDHMSM : date to convert

[out] cycle: number of cycle

[out] pass : number of pass in the cycle
return 0 or error code (see Cycle/date conversion error codes in brathl general documentation)

Example:

cycle=0L
pass=0L
mission=1

dln={BRATHL_DATEYMDHMSM}
dln.YEAR=2003
dln.MONTH=12
dln.DAY=5
dln.HOUR=18
dln.HOUR=18
dln.MINUTE=0
dln.SECOND=21
dln.MUSECOND=1069

r = BRATHL_YMDHMSM2CYCLE(mission, dln, cycle, pass)
print, "result", r

print, "Y", dOut.year, " M ", dOut.month, " D ", dOut.day, " H ", dOut.hour, " MN ", dOut.minute, " S ", dOut.second, " MS ", dOut.muSecond print, "mission ", mission , " cycle ", cycle, " pass ", pass

Annex G. BRATHL-Fortran API

The BRATHL-C API consists of just a handful of Fortran functions.

Below is the list of Fortran APIs functions.

A description of each function is detailed in the BRATHL documentation in html or latex format (search for refman-html or refman-latext sub-directories in your BRATHL directories installation). Note: When installing BRAT Toolbox, you have to selected 'Documentations' component.

Date conversion/computation functions

============

brathl_DayOfYear

brathl_DiffDSM brathl_DiffJULIAN brathl_DiffYMDHMSM

brathl_DSM2Julian brathl_DSM2Seconds brathl_DSM2YMDHMSM

brathl_JULIAN2DSM brathl_JULIAN2Seconds brathl_JULIAN2YMDHMSM

brathl_SECONDS2DSM brathl_SECONDS2Julian brathl_SECONDS2YMDHMSM

brathl_NowYMDHMSM

brathl_YMDHMSM2DSM brathl_YMDHMSM2Julian brathl_YMDHMSM2Seconds

Date conversion/computation example:

PROGRAM TESTDATE F

IMPLICIT NONE

INCLUDE "brathlf.inc"
INTEGER IREFDATESRC
DOUBLE PRECISION ISECONDS
INTEGER IREFDATEDEST
INTEGER ODAYS
INTEGER OSECONDS
INTEGER OMUSECONDS

INTEGER Y
INTEGER M
INTEGER D

INTEGER H INTEGER MN INTEGER SEC INTEGER MS INTEGER RESULT CHARACTER*128 ERRSTR CHARACTER*28 REFUSER INTEGER TMP REFUSER = '1952 02 18' CALL BRATHLF SETREFUSER1 (REFUSER) IREFDATESRC = REF20000101 С IREFDATEDEST = REF19500101 IREFDATEDEST = REFUSER1 ISECONDS = 86460.16936D0ODAYS = 0OSECONDS = 0OMUSECONDS = 0RESULT = BRATHLF SECONDS2DSM(IREFDATESRC, ISECONDS, IREFDATEDEST, & ODAYS, OSECONDS, OMUSECONDS) IF (RESULT .NE. BRATHL SUCCESS) THEN CALL BRATHLF ERRNO2STRING (RESULT, ERRSTR) WRITE(*,*) 'ERROR: ' // ERRSTR STOP END IF WRITE(*,*) ' IREFDATESRC:', IREFDATESRC,' ISECONDS:', ISECONDS, ' IREFDATEDEST:', IREFDATEDEST, ' ODAYS:', ODAYS, ' OSECONDS:', & OSECONDS, ' OMUSECONDS:', OMUSECONDS δ RESULT = BRATHLF DSM2SECONDS (IREFDATESRC, ODAYS, OSECONDS, & OMUSECONDS, IREFDATEDEST, ISECONDS) IF (RESULT .NE. BRATHL SUCCESS) THEN CALL BRATHLF ERRNO2STRING(RESULT, ERRSTR) WRITE(*,*) 'ERROR: ' // ERRSTR STOP END IF WRITE(*,*) ' IREFDATESRC:', IREFDATESRC,' ISECONDS:', ISECONDS, ' IREFDATEDEST:', IREFDATEDEST, ' ODAYS:', ODAYS, ' OSECONDS:', & OSECONDS, ' OMUSECONDS:', OMUSECONDS ______ RESULT = brathlf DSM2YMDHMSM(IREFDATESRC, ODAYS, OSECONDS, OMUSECONDS, Y, M, D, H, MN, SEC, MS) IF (RESULT .NE. BRATHL SUCCESS) THEN CALL BRATHLF ERRNO2STRING (RESULT, ERRSTR) WRITE(*,*) 'ERROR: ' // ERRSTR STOP END IF WRITE(*,*) ' IREFDATESRC:', IREFDATESRC,' Y:', Y,

```
'M:', M, 'D:', D, 'H:', H, 'MN:', MN, 'SEC:', SEC, 'MS:', MS,
δ
       ' ODAYS:', ODAYS, ' OSECONDS:',
&
&
       OSECONDS, ' OMUSECONDS:', OMUSECONDS
       RESULT = brathlf YMDHMSM2DSM( Y, M, D, H, MN, SEC, MS,
       IREFDATEDEST, ODAYS, OSECONDS, OMUSECONDS,)
&
       IF (RESULT .NE. BRATHL SUCCESS) THEN
         CALL BRATHLF ERRNO2STRING (RESULT, ERRSTR)
         WRITE(*,*) 'ERROR: ' // ERRSTR
         STOP
       END IF
     \label{eq:write} \texttt{WRITE}\,(\,{}^\star,\,{}^\star) \quad {}^\prime \quad \texttt{IREFDATESRC:', IREFDATESRC,' Y:', Y,}
&
       ' M:', M, ' D:', D, ' H:', H,' MN:', MN,' SEC:', SEC,' MS:', MS,
       ' ODAYS:', ODAYS, ' OSECONDS:',
OSECONDS, ' OMUSECONDS:', OMUSECONDS
&
&
       END
```

Cycle/date conversion functions

To convert cycle <-> date, these functions use an asci parameter file (ascii file) with records:

field 1 : Name of the mission

field 2 : Cycle reference

field 3: Pass reference

field 4: Reference date in decimal julian day

Each field has to be separated by, at least, a non-numeric character

The file can contained several records for a same mission. Only the field with the greatest date is taken into account

You can add records.

You can add comments, commented lines start by '#' character.

If the file doesn't exist, default values are:

Name	Cycle	Pass	Refere	nce date
Jason-1	99		230	19987.9081795
Topex/Poseidon	442		230	19987.9127535
ERS2	66		598	18831.768334
ERS1-A	15		1	15636.938955
ERS1-B	42		108	16538.6732895
ENVISAT	30		579	19986.106016

brathl_Cycle2YMDHMSM brathl_YMDHMSM2Cycle

Cycle/date conversion example:

```
PROGRAM TESTCYCLE_F
IMPLICIT NONE
```

INCLUDE "brathlf.inc" INTEGER C INTEGER P INTEGER MISSION INTEGER Y INTEGER M INTEGER D INTEGER H INTEGER MN INTEGER SEC INTEGER MS INTEGER RESULT CHARACTER*128 ERRSTR MISSION = ENVISAT C = 120P = 153RESULT = BRATHLF CYCLE2YMDHMSM(MISSION, C, P, Y, M, D, H, MN, SEC, MS) & IF (RESULT .NE. BRATHL SUCCESS) THEN CALL BRATHLF ERRNO2STRING (RESULT, ERRSTR) WRITE(*,*) 'ERROR: ' // ERRSTR STOP END IF WRITE(*,*) ' MISSION:', MISSION,' CYCLE:', C, ' PASS:', P, & & ' Y:', Y, 'M:', M, 'D:', D, 'H:', H, 'MN:', MN, 'SEC:', SEC, 'MS:', MS & RESULT = BRATHLF YMDHMSM2CYCLE (MISSION, Y, M, D, H, MN, SEC, MS, C, P) & IF (RESULT .NE. BRATHL SUCCESS) THEN CALL BRATHLF ERRNO2STRING (RESULT, ERRSTR) WRITE(*,*) 'ERROR: ' // ERRSTR STOP END IF WRITE(*,*) ' MISSION:', MISSION,' CYCLE:', C, ' PASS:', P, & ' Y:', Y, ۶ ' M:', M, ' D:', D, ' H:', H,' MN:', MN,' SEC:', SEC,' MS:', MS ۶ END _____

Data reading function

============

brathl_ReadData

Example:

```
PROGRAM P
 IMPLICIT NONE
 CHARACTER* (100) NAMES (10)
 CHARACTER* (10)
                    Record
 CHARACTER* (120) Selection
 CHARACTER* (200) Expressions (20)
CHARACTER*(20) Units(20)
REAL*8 Result(1000,20)
 LOGICAL*4 Ignore
 LOGICAL*4 Statistics
 REAL*8
                    Default
 INTEGER*4 NbValues
 INTEGER*4 NbResults
 INTEGER*4 ReturnCode
 INCLUDE "brathlf.inc"
NAMES(1) = 'JA1_GDR_2PaP124_001.CNES'
NAMES(2) = 'JA1_GDR_2PaP124_002.CNES'
NAMES(3) = 'JA1_GDR_2PaP124_003.CNES'
Record = 'data'
 Selection = 'latitude > 20'
 Expressions(1)
                  = 'latitude + longitude'
 Units(1) = 'radians'
 Expressions(2) = 'swh ku'
Units(2) = 'm'
NbValues = 1000
NbResults = -1
 Ignore
                    = .false.
 Statistics = .false.
 Default
                     = 1.0E100
ReturnCode = brathlf_ReadData(3,
$
                                       NAMES,
$
                                       Record,
$
                                       Selection,
$
                                       2,
$
                                       Expressions,
                                       Units,
$
$
                                       Result,
$
                                       NbValues,
$
                                       NbResults,
$
                                       Ignore,
$
                                       Statistics,
                                       Default)
print *, NbResults
print *, ReturnCode
 END
```

Annex H. BRATHL-C API

The BRATHL-C API consists of just a handful of C structures and functions.

Below is the list of C APIs functions.

A description of each function is detailed in the BRATHL documentation in html or latex format (search for refman-html or refman-latext sub-directories in your BRATHL directories installation). Note: When installing BRAT Toolbox, you have to selected 'Documentations' component.

```
Date conversion/computation functions
_____
brathl_DayOfYear
brathl_DiffDSM
brathl_DiffJULIAN
brathl_DiffYMDHMSM
brathl_DSM2Julian
brathl_DSM2Seconds
brathl_DSM2YMDHMSM
brathl_JULIAN2DSM
brathl_JULIAN2Seconds
brathl_JULIAN2YMDHMSM
brathl_SECONDS2DSM
brathl SECONDS2Julian
brathl_SECONDS2YMDHMSM
brathl_NowYMDHMSM
brathl_YMDHMSM2DSM
brathl_YMDHMSM2Julian
brathl_YMDHMSM2Seconds
```

Date conversion/computation example:

```
#include <brathl.h>
#include <brathl error.h>
void PrintfDateDSM(brathl_DateDSM *d);
void PrintfDateSecond(brathl_DateSecond *d);
void PrintfDateJulian(brathl DateJulian *d);
void PrintfDateYMDHMSM(brathl DateYMDHMSM *d);
int main (int argc, char *argv[])
{
  double diff = 0;
  brathl_DateSecond dateSeconds;
  brathl_DateDSM dateDSM;
  brathl_DateDSM dateDSM2;
  brathl DateJulian dateJulian;
  brathl DateJulian dateJulian2;
  brathl DateYMDHMSM dateYMDHMSM;
  brathl DateYMDHMSM dateYMDHMSM2;
```

brathl_refDate refDate = REF19500101; brathl_refDate refDateDest = REF19500101; char Buff[1024]; memset(brathl refDateUser1, '\0', BRATHL REF DATE USER LEN - 1); memset(&dateSeconds, '\0', sizeof(dateSeconds)); memset(&dateDSM, '\0', sizeof(dateDSM)); memset(&dateDSM2, '\0', sizeof(dateDSM2)); memset(&dateJulian, '\0', sizeof(dateJulian)); memset(&dateJulian2, '\0', sizeof(dateJulian2)); memset(&dateYMDHMSM, '\0', sizeof(dateYMDHMSM)); memset(&dateYMDHMSM2, '\0', sizeof(dateYMDHMSM2)); puts ("saisir Référentiel Source : \n" "1 --> 1950\n" "2 --> 1958\n" "3 --> 1990\n" "4 --> 2000\n" "5 --> user 1\n" "x Exit\n"); c = getchar(); getchar(); switch (c) case 'X' : case 'x' : return 0; case '1' : refDate = REF19500101; break; case '2' : refDate = REF19580101; break; case '3' : refDate = REF19900101; break; case '4' : refDate = REF20000101; break; case '5' : refDate = REFUSER1; puts ("saisir la date du réfétentiel au format YYYY MM DD hh:mn:s:ms "); gets (Buff); strncpy (brathl_refDateUser1, Buff, BRATHL REF DATE USER LEN - 1); break; default : refDate = REF19500101; puts ("saisir Référentiel Destination : \n" "1 --> 1950\n" "2 --> 1958\n" "3 --> 1990\n" "4 --> 2000\n" "5 --> user 1\n" "x Exit\n"); c = getchar(); getchar(); switch (c)

```
case 'X':
  case 'x':
   return 0;
  case '1' : refDateDest = REF19500101; break;
  case '2' : refDateDest = REF19580101; break;
  case '3' : refDateDest = REF19900101; break;
  case '4' : refDateDest = REF20000101; break;
 case '5' :
   refDateDest = REFUSER1;
   puts ("saisir la date du réfétentiel au format YYYY MM DD hh:mn:s:ms ");
   //fgets (brathl_refDateUser1, strlen(refDateUser), stdin);
   gets (Buff);
    strncpy (brathl refDateUser1, Buff, BRATHL REF DATE USER LEN - 1);
   break;
  default : refDateDest = REF19500101;
printf("ref. dest %d %s\n", refDateDest, brathl refDateUser1 );
do
  puts ("\nConversion : \n"
    "1 - Seconds --> DSM\n"
    "2 - DSM -->Seconds\n"
    "3 - Julian --> DSM\n"
    "4 - DSM -->Julian\n"
    "5 - YMDHMSM --> DSM\n"
    "6 - DSM -->YMDHMSM\n"
    "7 - Seconds --> Julian\n"
    "8 - Julian --> Seconds\n"
    "9 - Seconds --> YMDHMSM\n"
    "A - YMDHMSM --> Seconds\n"
    "B - Julian --> YMDHMSM\n"
    "C - YMDHMSM -->Julian\n"
    "D - diff Date1 - Date2 (YMDHMSM)\n"
    "E - diff Date1 (ref. src) - Date2 (ref. dest) (DSM) \n"
    "F - diff Date1 (ref. src) - Date2 (ref. dest) (Julian) \n"
    "N - Now --> YMDHMSM\n"
    "Q - YMDHMSM --> Quantieme\n"
    "x Exit\n");
  c = getchar();
  getchar();
  switch (c)
    case '1' : // Seconds --> DSM
      memset(&dateSeconds, '\0', sizeof(dateSeconds));
         memset(&dateDSM, '\0', sizeof(dateDSM));
   dateSeconds.refDate = refDate;
    puts ("nbSeconds :");
      gets (Buff);
         sscanf(Buff, "%lf", &dateSeconds.nbSeconds);
```

```
result = brathl Seconds2DSM(&dateSeconds, refDateDest, &dateDSM);
printf("result %d %s\n", result, brathl_Errno2String(result));
  PrintfDateSecond(&dateSeconds);
      PrintfDateDSM(&dateDSM);
break;
case '2' : // DSM -->Seconds
  memset(&dateSeconds, '\0', sizeof(dateSeconds));
      memset(&dateDSM, '\0', sizeof(dateDSM));
dateDSM.refDate = refDate;
puts ("D S M :");
  gets (Buff);
      sscanf(Buff, "%ld%*c%ld%*c%ld ",
                &dateDSM.days,
                &dateDSM.seconds,
                &dateDSM.muSeconds );
      result = brathl DSM2Seconds(&dateDSM, refDateDest, &dateSeconds);
printf("result %d %s\n", result, brathl Errno2String(result));
  PrintfDateSecond(&dateSeconds);
      PrintfDateDSM(&dateDSM);
break;
case '3' : // Julian --> DSM
      memset(&dateDSM, '\0', sizeof(dateDSM));
      memset(&dateJulian, '\0', sizeof(dateJulian));
dateJulian.refDate = refDate;
puts ("julian :");
  gets (Buff);
      sscanf(Buff, "%lf", &dateJulian.julian);
result = brathl Julian2DSM(&dateJulian, refDateDest, &dateDSM);
printf("result %d %s\n", result, brathl Errno2String(result));
  PrintfDateJulian(&dateJulian);
      PrintfDateDSM(&dateDSM);
break;
case '4' : // DSM -->Julian
  memset(&dateJulian, '\0', sizeof(dateJulian));
    memset(&dateDSM, '\0', sizeof(dateDSM));
dateDSM.refDate = refDate;
puts ("D S M :");
  gets (Buff);
      sscanf(Buff, "%ld%*c%ld%*c%ld ",
                &dateDSM.days,
                &dateDSM.seconds,
                &dateDSM.muSeconds );
      result = brathl_DSM2Julian(&dateDSM, refDateDest, &dateJulian);
printf("result %d %s\n", result, brathl_Errno2String(result));
  PrintfDateJulian(&dateJulian);
      PrintfDateDSM(&dateDSM);
break:
```

case '5' : // YMDHMSM --> DSM memset(&dateDSM, '\0', sizeof(dateDSM)); memset(&dateYMDHMSM, '\0', sizeof(dateYMDHMSM)); puts ("YYYY MM DD hh:mn:s:ms :"); gets (Buff); sscanf(Buff, "%4d%*c%2d%*c%2d%*c" "%2d%*c%2d%*c%2d%*c%6d", &dateYMDHMSM.year, &dateYMDHMSM.month, &dateYMDHMSM.day, &dateYMDHMSM.hour, &dateYMDHMSM.minute, &dateYMDHMSM.second, &dateYMDHMSM.muSecond); result = brathl YMDHMSM2DSM(&dateYMDHMSM, refDateDest, &dateDSM); printf("result %d %s\n", result, brathl Errno2String(result)); PrintfDateYMDHMSM(&dateYMDHMSM); PrintfDateDSM(&dateDSM); break; case '6' : // DSM -->YMDHMSM ${\tt memset(\&dateYMDHMSM, '\0', sizeof(dateYMDHMSM));}$ memset(&dateDSM, '\0', sizeof(dateDSM)); puts ("D S M :"); gets (Buff); sscanf(Buff, "%ld%*c%ld%*c%ld ", &dateDSM.days, &dateDSM.seconds, &dateDSM.muSeconds); result = brathl DSM2YMDHMSM(&dateDSM, &dateYMDHMSM); printf("result %d %s\n", result, brathl Errno2String(result)); PrintfDateYMDHMSM(&dateYMDHMSM); PrintfDateDSM(&dateDSM); break; case '7' : // Seconds --> Julian memset(&dateSeconds, '\0', sizeof(dateSeconds)); memset(&dateJulian, '\0', sizeof(dateJulian)); dateSeconds.refDate = refDate; puts ("nbSeconds :"); gets (Buff); sscanf(Buff, "%lf", &dateSeconds.nbSeconds); result = brathl Seconds2Julian(&dateSeconds, refDateDest, &dateJulian); printf("result %d %s\n", result, brathl Errno2String(result)); PrintfDateSecond(&dateSeconds); PrintfDateJulian(&dateJulian); break; case '8' : // Julian --> Seconds
 memset(&dateSeconds, '\0', sizeof(dateSeconds));

memset(&dateJulian, '\0', sizeof(dateJulian));

dateJulian.refDate = refDate;

puts ("julian :"); gets (Buff); sscanf(Buff, "%lf", &dateJulian.julian); result = brathl Julian2Seconds(&dateJulian, refDateDest, &dateSeconds); printf("result %d %s\n", result, brathl Errno2String(result)); PrintfDateSecond(&dateSeconds); PrintfDateJulian(&dateJulian); break; case '9' : // Seconds --> YMDHMSM memset(&dateSeconds, '\0', sizeof(dateSeconds)); memset(&dateYMDHMSM, '\0', sizeof(dateYMDHMSM)); dateSeconds.refDate = refDate; puts ("nbSeconds :"); gets (Buff); sscanf(Buff, "%lf", &dateSeconds.nbSeconds); result = brathl Seconds2YMDHMSM(&dateSeconds, &dateYMDHMSM); printf("result %d %s\n", result, brathl Errno2String(result)); PrintfDateSecond(&dateSeconds); PrintfDateYMDHMSM(&dateYMDHMSM); break: case 'A' : // YMDHMSM --> Seconds case 'a' : // YMDHMSM --> Seconds memset(&dateSeconds, '\0', sizeof(dateSeconds)); memset(&dateYMDHMSM, '\0', sizeof(dateYMDHMSM)); puts ("YYYY MM DD hh:mn:s:ms :"); gets (Buff); sscanf(Buff, "%4d%*c%2d%*c%2d%*c" "%2d%*c%2d%*c%2d%*c%6d", &dateYMDHMSM.year, &dateYMDHMSM.month, &dateYMDHMSM.day, &dateYMDHMSM.hour, &dateYMDHMSM.minute, &dateYMDHMSM.second, &dateYMDHMSM.muSecond); result = brathl YMDHMSM2Seconds(&dateYMDHMSM, refDateDest, &dateSeconds); printf("result \(\frac{1}{2} d \) %s\n", result, brathl Errno2String(result)); PrintfDateSecond(&dateSeconds); PrintfDateYMDHMSM(&dateYMDHMSM); break; case 'B' : // Julian --> YMDHMSM case 'b' : // Julian --> YMDHMSM $\verb|memset(&dateYMDHMSM, '\0', sizeof(dateYMDHMSM));|\\$ memset(&dateJulian, '\0', sizeof(dateJulian)); dateJulian.refDate = refDate; puts ("julian :"); gets (Buff); sscanf(Buff, "%lf", &dateJulian.julian); result = brathl Julian2YMDHMSM(&dateJulian, &dateYMDHMSM); printf("result %d %s\n", result, brathl Errno2String(result));

PrintfDateJulian(&dateJulian); PrintfDateYMDHMSM(&dateYMDHMSM); break: case 'C' : // YMDHMSM --> Julian case 'c' : // YMDHMSM --> Julian memset(&dateJulian, '\0', sizeof(dateJulian)); memset(&dateYMDHMSM, '\0', sizeof(dateYMDHMSM)); puts ("YYYY MM DD hh:mn:s:ms :"); gets (Buff); sscanf(Buff, "%4d%*c%2d%*c%2d%*c" "%2d%*c%2d%*c%2d%*c%6d", &dateYMDHMSM.year, &dateYMDHMSM.month, &dateYMDHMSM.day, &dateYMDHMSM.hour, &dateYMDHMSM.minute, &dateYMDHMSM.second, &dateYMDHMSM.muSecond); result = brathl YMDHMSM2Julian(&dateYMDHMSM, refDateDest, &dateJulian); printf("result %d %s\n", result, brathl Errno2String(result)); PrintfDateJulian(&dateJulian); PrintfDateYMDHMSM(&dateYMDHMSM); break; case 'D' : // diff Date1 (ref. src) - Date2 (ref. dest) (YMDHMSM) case 'd' : // diff Date1 (ref. src) - Date2 (ref. dest) (YMDHMSM) $\verb|memset(&dateYMDHMSM, '\0', sizeof(dateYMDHMSM));|\\$ memset(&dateYMDHMSM2, '\0', sizeof(dateYMDHMSM2)); puts ("Date 1 YYYY MM DD hh:mn:s:ms :"); gets (Buff); sscanf(Buff, "%4d%*c%2d%*c%2d%*c" "%2d%*c%2d%*c%2d%*c%6d", &dateYMDHMSM.year, &dateYMDHMSM.month, &dateYMDHMSM.day, &dateYMDHMSM.hour, &dateYMDHMSM.minute, &dateYMDHMSM.second, &dateYMDHMSM.muSecond); puts ("Date 2 YYYY MM DD hh:mn:s:ms :"); gets (Buff); sscanf(Buff, "%4d%*c%2d%*c%2d%*c" "%2d%*c%2d%*c%2d%*c%6d", &dateYMDHMSM2.year, &dateYMDHMSM2.month, &dateYMDHMSM2.day, &dateYMDHMSM2.hour, &dateYMDHMSM2.minute, &dateYMDHMSM2.second, &dateYMDHMSM2.muSecond); diff = 0;result = brathl DiffYMDHMSM(&dateYMDHMSM, &dateYMDHMSM2, &diff); printf("result %d %s\n", result, brathl Errno2String(result)); PrintfDateYMDHMSM(&dateYMDHMSM); PrintfDateYMDHMSM(&dateYMDHMSM2); printf("\t---> Difference : %lf \n", diff); break; case 'E' : // diff Date1 (ref. src) - Date2 (ref. dest) (DSM) case 'e' : // diff Date1 (ref. src) - Date2 (ref. dest) (DSM) memset(&dateDSM, ' $\0$ ', sizeof(dateDSM)); memset(&dateDSM2, '\0', sizeof(dateDSM2));

```
dateDSM.refDate = refDate;
dateDSM2.refDate = refDateDest;
puts (" Date 1 D S M :");
  gets (Buff);
     sscanf(Buff, "%ld%*c%ld%*c%ld ",
                &dateDSM.days,
                &dateDSM.seconds,
                &dateDSM.muSeconds );
puts (" Date 2 D S M :");
  gets (Buff);
     sscanf(Buff, "%ld%*c%ld%*c%ld ",
                &dateDSM2.days,
                &dateDSM2.seconds,
                &dateDSM2.muSeconds );
  diff = 0;
result = brathl DiffDSM(&dateDSM, &dateDSM2, &diff);
printf("result %d %s\n", result, brathl Errno2String(result));
      PrintfDateDSM(&dateDSM);
      PrintfDateDSM(&dateDSM2);
  printf("\t---> Difference : %lf \n", diff);
break;
 case 'F' : // diff Date1 (ref. src) - Date2 (ref. dest) (Julian)
 case 'f' : // diff Date1 (ref. src) - Date2 (ref. dest) (Julian)
     memset(&dateDSM, '\0', sizeof(dateDSM));
memset(&dateDSM2, '\0', sizeof(dateDSM2));
dateJulian.refDate = refDate;
dateJulian2.refDate = refDateDest;
puts ("Date 1 julian :");
  gets (Buff);
      sscanf(Buff, "%lf", &dateJulian.julian);
puts ("Date 2 julian :");
  gets (Buff);
      sscanf(Buff, "%lf", &dateJulian2.julian);
  diff = 0;
result = brathl DiffJulian(&dateJulian, &dateJulian2, &diff);
printf("result %d %s\n", result, brathl Errno2String(result));
      PrintfDateJulian(&dateJulian);
      PrintfDateJulian(&dateJulian2);
  printf("\t---> Difference : %lf \n", diff);
break;
 case 'N' : // Now --> YMDHMSM
 case 'n' : // Now --> YMDHMSM
      memset(&dateYMDHMSM, '\0', sizeof(dateYMDHMSM));
result = brathl NowYMDHMSM(&dateYMDHMSM);
```

printf("result %d %s\n", result, brathl_Errno2String(result)); PrintfDateYMDHMSM(&dateYMDHMSM); break: case 'Q' : // YMDHMSM --> Quantième case 'q' : // YMDHMSM --> Quantième memset(&dateYMDHMSM, '\0', sizeof(dateYMDHMSM)); puts ("YYYY MM DD hh:mn:s:ms :"); gets (Buff); sscanf(Buff, "%4d%*c%2d%*c%2d%*c" "%2d%*c%2d%*c%2d%*c%6d", &dateYMDHMSM.year, &dateYMDHMSM.month, &dateYMDHMSM.day, &dateYMDHMSM.hour, &dateYMDHMSM.minute, &dateYMDHMSM.second, &dateYMDHMSM.muSecond); uint32_t quantieme; result = brathl Quantieme(&dateYMDHMSM, &quantieme); printf("result %d %s\n", result, brathl Errno2String(result)); PrintfDateYMDHMSM(&dateYMDHMSM); printf("\t---> Quantieme : %ld \n", quantieme); break; default : break; if ((c != 'X') && (c != 'x')) puts("Press enter key to continue"); getchar(); } $\}$ while ((c != 'X') && (c != 'x')); return 0; } //----void PrintfDateDSM(brathl DateDSM *d) printf("\tbrathl DateDSM days %ld seconds %ld museconds %ld ref. %d %s\n", d->days, d->seconds, d->muSeconds, d->refDate, brathl refDateUser1); //---void PrintfDateSecond(brathl DateSecond *d) printf("\tbrathl DateSecond nbSeconds %lf ref. %d %s\n", d->nbSeconds, d->refDate, brathl refDateUser1); //---void PrintfDateJulian(brathl DateJulian *d) printf("\tbrathl DateJulian julian %lf ref. %d %s\n", d->julian, d->refDate, brathl refDateUser1);

Cycle/date conversion functions

===========

To convert cycle <-> date, these functions use an asci parameter file (ascii file) with records :

field 1 : Name of the mission field 2 : Cycle reference field 3 : Pass reference

field 4: Reference date in decimal julian day

Each field has to be separated by, at least, a non-numeric character

The file can contained several records for a same mission. Only the field with the greatest date is taken into account

You can add records.

You can add comments, commented lines start by '#' character.

If the file doesn't exist, default values are:

Name	Cycle	Pass	Reference date
Jason-1	99	230	19987.9081795
Topex/Poseidon	442	230	19987.9127535
ERS2	66	598	18831.768334
ERS1-A	15	1	15636.938955
ERS1-B	42	108	16538.6732895
ENVISAT	30	579	19986.106016

brathl_Cycle2YMDHMSM brathl_YMDHMSM2Cycle

Cycle/date conversion example

```
#include <brathl.h>
#include <brathl_error.h>

void PrintfDateDSM(brathl_DateDSM *d);
void PrintfDateSecond(brathl_DateSecond *d);
void PrintfDateJulian(brathl_DateJulian *d);
void PrintfDateYMDHMSM(brathl_DateYMDHMSM *d);
int main (int argc, char *argv[])
{
```

uint32_t cycle = 0;

```
uint32 t pass = 0;
int32 t result = BRATHL SUCCESS;
char c;
double diff = 0;
brathl mission mission;
brathl DateYMDHMSM dateYMDHMSM;
char Buff[1024];
memset(&dateYMDHMSM, '\0', sizeof(dateYMDHMSM));
puts ("saisir la mission : \n"
          "1 --> TOPEX\n"
          "2 --> JASON1\n"
          "3 --> ERS2\n"
          "4 --> ENVISAT\n"
          "5 --> ERS1 A\n"
          "6 --> ERS1 B\n"
          "7 --> GFO\n"
          "x Exit\n");
c = getchar();
getchar();
switch (c)
  case 'X' :
  case 'x' :
   return 0;
  case '1' : mission = TOPEX; break;
  case '2' : mission = JASON1; break;
  case '3' : mission = ERS2; break;
  case '4' : mission = ENVISAT; break;
  case '5' : mission = ERS1_A; break;
  case '6' : mission = ERS1 B; break;
  case '7' : mission = GFO; break;
   break;
  default : mission = TOPEX;
}
do
 puts ("\nConversion Cycle <--> Date: \n"
   "1 - Cycle --> Date YMDHMSM\n"
    "2 - Date YMDHMSM -->Cycle\n"
    "x Exit\n");
  c = getchar();
  getchar();
  switch (c)
  {
```

//----

case '1' : // Cycle --> Date YMDHMSM memset(&dateYMDHMSM, '\0', sizeof(dateYMDHMSM)); cycle = pass = 0;puts ("Cycle Pass:"); gets (Buff); sscanf(Buff, "%ld%*c%ld ", &cycle, &pass); result = brathl Cycle2YMDHMSM(mission, cycle, pass, &dateYMDHMSM); printf("result %d %s\n", result, brathl Errno2String(result)); printf("\tcycle %d pass %d\n", cycle, pass); PrintfDateYMDHMSM(&dateYMDHMSM); break; case '2' : // Date YMDHMSM -->Cycle memset(&dateYMDHMSM, '\0', sizeof(dateYMDHMSM)); cycle = pass = 0; puts ("YYYY MM DD hh:mn:s:ms :"); gets (Buff); sscanf(Buff, "%4d%*c%2d%*c%2d%*c" "%2d%*c%2d%*c%2d%*c%6d", &dateYMDHMSM.year, &dateYMDHMSM.month, &dateYMDHMSM.day, &dateYMDHMSM.hour, &dateYMDHMSM.minute, &dateYMDHMSM.second, &dateYMDHMSM.muSecond); result = brathl YMDHMSM2Cycle(mission, &dateYMDHMSM, &cycle, &pass); printf("result %d %s\n", result, brathl_Errno2String(result)); printf("\tcycle %d pass %d\n", cycle, pass); PrintfDateYMDHMSM(&dateYMDHMSM); break; default : break; if ((c != 'X') && (c != 'x')) puts("Press enter key to continue"); getchar(); $\}$ while ((c != 'X') && (c != 'x')); return 0; } void PrintfDateDSM(brathl DateDSM *d) { printf("\tbrathl_DateDSM days %ld seconds %ld museconds %ld ref. %d %s\n", d->days, d->seconds, d->muSeconds, d->refDate, brathl_refDateUser1);

void PrintfDateSecond(brathl DateSecond *d) printf("\tbrathl_DateSecond nbSeconds %lf ref. %d %s\n", d->nbSeconds, d->refDate, brathl refDateUser1); //---void PrintfDateJulian(brathl DateJulian *d) { printf("\tbrathl DateJulian julian %lf ref. %d %s\n", d->julian, d->refDate, brathl refDateUser1); } //---void PrintfDateYMDHMSM(brathl DateYMDHMSM *d) printf("\tbrathl DateYMDHMSM year %ld month %ld day %ld hour %ld minute %ld second %ld musecond %ld ref. %s\n", d->year, d->month, d->day, d->hour, d->minute, d->second, d->muSecond, brathl refDateUser1); }

Data reading function

brathl ReadData

Example:

```
#include <stdio.h>
#include <stdlib.h>
#include "brathl.h"
#include "brathl error.h"
int main(int argc, char **argv)
  char
                  *Names[10];
  int32 t ReturnCode;
  double *Data[2] = {NULL, NULL};
  int32 t Sizes[2]
                        = \{-1, -1\};
        *Expressions[2];
  char
                   *Units[2];
  char
  int32 t ActualSize;
  Names[0] = "JA1_GDR_2PaP124_001.CNES";
Names[1] = "JA1_GDR_2PaP124_002.CNES";
  Names[2] = "JA1_GDR_2PaP124_003.CNES";
 Expressions[0] = "latitude + longitude";
Units[0] = "radians";
```

BRATHL-PYTHON API

The BRATHL-Python API consists of a handful of Python structures and functions. ______ BRATHL-Python API: Structures _____ - brathl DateYMDHMSM - brathl_DateDSM - brathl_DateSecond - brathl DateJulian brathl DateYMDHMSM data structure: This structure represents a YYYY-MM-DD HH:MN:SS:MS date structure. => Example - Defining date 2000-01-01 12:25:20.1: MyDate = brathl DateYMDHMSM (2000, 1, 1, 12, 25, 20, 100000) => Example - Retrieving information: MyDate.YEAR : numbers of years MyDate.MONTH : numbers of months MyDate.MONTH

MyDate.DAY

inumbers of days

MyDate.HOUR

MyDate.MINUTE

MyDate.SECOND

inumbers of minutes

myDate.Seconds MyDate.MUSECOND : numbers of microseconds brathl DateDSM data structure: _____ This structure represents day/seconds/microseconds date structure. => Example - Defining date 1 day, 62 seconds and 100000 microseconds: MyDate = brathl DateDSM(brathl refDate.REF19500101, 1, 62, 100000) => Example - Retrieving information: MyDate.REFDATE : date reference number
MyDate.DAY : numbers of days
MyDate.SECOND : numbers of seconds MyDate.MUSECOND : numbers of microseconds REFDATE is the reference date i.e:

0: brathl_refDate.REF19500101 : reference to 1950-01-01 00:00:00.0
1: brathl_refDate.REF19580101 : reference to 1958-01-01 00:00:00.0
2: brathl_refDate.REF19850101 : reference to 1985-01-01 00:00:00.0
3: brathl_refDate.REF19900101 : reference to 1990-01-01 00:00:00.0
4: brathl_refDate.REF20000101 : reference to 2000-01-01 00:00:00.0
5: brathl_refDate.REFUSER1 : user reference 1

6: brathl refDate.REFUSER2 : user reference 2

-> NOTE: REFUSER1 and REFUSER2 allow the user to set two specifics reference dates of his choice

```
(see brathl SetRefDateUser1 and brathl SetRefDateUser1 functions)
 brathl DateSecond data structure:
 This structure represents a decimal seconds date structure.
  => Example - Defining 86401.01 seconds (starting reference date: 1950-01-01
00:00:00.0):
      MyDate = brathl DateSecond (brathl refDate.REF19500101, 86401.01)
  => Example - Retrieving information:
      MyDate.REFDATE : date reference number
      MyDate.SECOND : numbers of seconds
 brathl DateJulian data structure:
 This structure represents a decimal Julian date structure.
  => Example - Defining 1.5 days (starting reference date: 2000-01-01 00:00:00.0):
      MyDate = brathl_DateJulian (brathl_refDate.REF20000101, 1.5)
  => Example - Retrieving information:
      MyDate.REFDATE : date reference number
MyDate.JULIAN : decimal julian day
_____
BRATHL-Python API: Functions
Date conversion/computation functions
_____
- brathl DayOfYear
- brathl_DiffDSM
- brathl_DiffJulian
- brathl DiffYMDHMSM
- brathl_DSM2Julian
- brathl_DSM2Seconds
- brathl DSM2YMDHMSM
- brathl_Julian2DSM
- brathl_Julian2Seconds
- brathl_Julian2YMDHMSM
- brathl_Seconds2DSM
- brathl_Seconds2Julian
- brathl Seconds2YMDHMSM
- brathl NowYMDHMSM
```

Basic Radar Altimetry Toolbox User Manual - brathl_YMDHMSM2DSM - brathl_YMDHMSM2Julian - brathl YMDHMSM2Seconds - brathl SetRefDateUser1 - brathl SetRefDateUser2 Cycle/Date Conversion functions - brathl Cycle2YMDHMSM - brathl YMDHMSM2Cycle _____ Data Reading functions - brathl ReadData brathl_DayOfYear function: Retrieves the day of the year of a date. brathl DayOfYear(date) [in] date : date object (Type: brathl DateYMDHMSM) return dayOfYear : day of year (Type: Python integer) brathl DiffDSM function: _____ Computes the difference between two dates (date1 - date2). brathl DiffDSM(dateDSM1, dateDSM2) [in] dateDSM1 : date object (Type: brathl_DateDSM)
[in] dateDSM2 : date object (Type: brathl_DateDSM)
return diff : difference in seconds (Type: Pytho return diff : difference in seconds (Type: Python float) brathl DiffJulian function: Computes the difference between two dates (date1 - date2).

brathl_DiffJulian(dateJulian1, dateJulian2)

```
dateJulian1 : date object (Type: brathl_DateJulian)
dateJulian2 : date object (Type: brathl_DateJulian)
[in]
[in]
```

return diff : difference in seconds (Type: Python float)

brathl DiffYMDHMSM function:

Computes the difference, in seconds, between two dates (date1 - date2).

brathl DiffYMDHMSM(date1, date2)

[in] dateYMDHMSM1 : date object (Type: brathl_DateYMDHMSM)
[in] dateYMDHMSM2 : date object (Type: brathl_DateYMDHMSM)
return diff : difference in seconds (Type: Python fl : difference in seconds (Type: Python float)

brathl DSM2Julian function:

Converts a days-seconds-microseconds date into a decimal julian date, according to refDate parameter.

brathl DSM2Julian(dateDSM, refDate)

: date to convert (Type: brathl_DateDSM) [in] dateDSM

[in] uateDSM refDate : date reference conversion (see REFDATE on brathl Dat-

eDSM data structure example)

return dateJulian : result of the conversion (Type: brathl_DateJulian)

brathl DSM2Seconds function:

Converts a days-seconds-microseconds date into seconds, according to refDate parameter.

brathl DSM2Seconds(dateDSM, refDate)

[in] dateDSM
[in] refDate : date to convert (Type: brathl DateDSM)

: date reference conversion (see REFDATE on brathl Dat-

eDSM data structure example)

return dateSeconds : result of the conversion (Type: brathl_DateSecond)

brathl DSM2YMDHMSM function:

Converts a days-seconds-microseconds date into a year, month, day, hour, minute, second, microsecond date.

brathl DSM2YMDHMSM(dateDSM)

[in] dateDSM : date to convert (Type: brathl_DateDSM)
return dateYMDHMSM : result of the conversion (Type: brathl_DateYMDHMSM)

```
brathl_Julian2DSM function:
```

Converts a decimal julian date into a days-seconds-microseconds date, according to refDate parameter.

brathl Julian2DSM(dateJulian, refDate)

[in]

dateJulian : date to convert (Type: brathl_DateJulian)
refDate : date reference conversion (see REFDATE on : date reference conversion (see REFDATE on brathl Dat-

eDSM data structure example)

return dateDSM : result of the conversion (Type: brathl DateDSM)

brathl Julian2Seconds function:

Converts a decimal julian date into seconds, according to refDate parameter.

brathl Julian2Seconds(dateJulian, refDate)

[in] dateJulian : date to convert (Type: brathl DateJulian)

refDate [in] : date reference conversion (see REFDATE on brathl Dat-

eDSM data structure example)

return dateSeconds : result of the conversion (Type: brathl_DateSecond)

brathl Julian2YMDHMSM function:

Converts a decimal julian date into a year, month, day, hour, minute, second, microsecond date.

brathl Julian2YMDHMSM(dateJulian)

: date to convert (Type: brathl DateJulian) [in] dateJulian

return dateYMDHMSM : date to convert (Type: pratni_pateJulian)
: result of the conversion (Type: brathl_DateYMDHMSM)

brathl Seconds2DSM function:

Converts seconds into a days-seconds-microseconds date, according to refDate parameter.

brathl Seconds2DSM(dateSeconds, refDate)

[in] dateSeconds : date to convert (Type: brathl_DateSecond)
[in] refDate : date reference conversion (see REFDATE on : date reference conversion (see REFDATE on brathl Dat-

eDSM data structure example)

: result of the conversion (Type: brathl_DateDSM) return dateDSM

brathl Seconds2Julian function:

Converts seconds into a decimal julian date, according to refDate parameter.

brathl Seconds2Julian(dateSeconds, refDate)

[in] dateSeconds : date to convert (Type: brathl_DateSecond)
[in] refDate : date reference conversion (see REFDATE on : date reference conversion (see REFDATE on brathl Dat-

eDSM data structure example)

return dateJulian : result of the conversion (Type: brathl_DateJulian)

brathl Seconds2YMDHMSM function:

Converts seconds into a year, month, day, hour, minute, second, microsecond date.

brathl Seconds2YMDHMSM(dateSeconds)

: date to convert (Type: brathl DateSecond) [in] dateSeconds

return dateYMDHMSM : result of the conversion (Type: brathl DateYMDHMSM)

brathl NowYMDHMSM function:

Gets the current year, month, day, hour, minute, second, microsecond date.

brathl NowYMDHMSM()

return dateYMDHMSM : current date/time (Type: brathl DateYMDHMSM)

brathl YMDHMSM2DSM function:

Converts a year, month, day, hour, minute, second, microsecond date into a daysseconds-microseconds date.

brathl YMDHMSM2DSM(dateYMDHMSM, refDate)

[in] dateYMDHMSM
[in] refDate : date to convert (Type: brathl DateYMDHMSM)

: date reference conversion (see REFDATE on brathl Dat-

eDSM data structure example)

: result of the conversion (Type: brathl DateDSM) return dateDSM

brathl_YMDHMSM2Julian function:

Converts a year, month, day, hour, minute, second, microsecond date into a decimal julian date, according to refDate parameter.

brathl YMDHMSM2Julian(dateYMDHMSM, refDate)

brathl DateYMDHMSM)

```
[in] dateYMDHMSM : date to convert (Type: brathl_DateYMDHMSM)
[in] refDate : date reference conversion (see REFDATE on
                             : date reference conversion (see REFDATE on brathl Dat-
eDSM data structure example)
 return dateJulian : result of the conversion (Type: brathl DateJulian)
  brathl YMDHMSM2Seconds function:
  _____
  Converts a year, month, day, hour, minute, second, microsecond date into seconds,
according to refDate parameter.
  brathl YMDHMSM2Seconds(dateYMDHMSM, refDate)
         dateYMDHMSM : date to convert (Type: brathl_DateYMDHMSM) refDate : date reference conversion (see REFDATE on
  [in]
                             : date reference conversion (see REFDATE on brathl Dat-
eDSM data structure example)
  return dateSeconds : result of the conversion (Type: brathl_DateSecond)
  brathl SetRefDateUser1 function:
  Set first user defined reference date: REFUSER1.
  brathl SetRefDateUser1(dateRef)
  [in]
         dateRef
                       : date to set in format: YYYY MM DD HH:MN:SS.MS (Type:
Python string).
  brathl SetRefDateUser2 function:
  Set first user defined reference date: REFUSER2.
  brathl SetRefDateUser2(dateRef)
                       : date to set in format: YYYY MM DD HH:MN:SS.MS (Type:
  [in] dateRef
Python string).
  brathl_Cycle2YMDHMSM function:
  _____
  Converts a cyle/pass into a date.
  brathl Cycle2YMDHMSM(mission, cycle, nbPass)
  [in]
                              : mission type (Type: brathl_mission)
         mission
  [in] cycle
[in] nbPass
                              : number of cycle to convert (Type: Python int/long)
                             : number of pass in the cycle to convert (Type: Python
int/long)
```

return dateYMDHMSM : date/time corresponding to the cycle/pass (Type:

```
'mission' is the Satellite/mission reference i.e:
   0: brathl mission.TOPEX : Topex/Poseidon mission
   1: brathl_mission.JASON2 : Jason-2 mission 2: brathl_mission.JASON1 : Jason-1 mission 3: brathl_mission.ERS2 : ERS2 mission
   4: brathl_mission.ERS1_A
6: brathl_mission.ERS1_B
7: brathl_mission.GFO

ERS2 mission
ERS2 mission
ERS2 mission
ERS2 mission
ERS2 mission
ERS1_B
ERS1-A mission
ERS1_B
GFO mission
   => Example:
       cycle = 1
       nbPass = 2
       dateYMDHMSM = brathl Cycle2YMDHMSM(brathl mission.JASON1, cycle, nbPass)
  brathl YMDHMSM2Cycle function:
  Converts a date into a cyle/pass.
  brathl YMDHMSM2Cycle(mission, dateYMDHMSM)
  [in]
            mission
                                : mission type (Type: brathl_mission)
           dateYMDHMSM
  [in]
                                : date/time to convert (Type: brathl DateYMDHMSM)
                                : number of cycle (Type: Python int/long)
  return cycle
  return nbPass
                                : number of pass in the cycle (Type: Python int/long)
   => Example:
       dateYMDHMSM = brathl DateYMDHMSM (2002, 1, 15, 6, 35, 43, 261871)
       cycle, nbPass = brathl YMDHMSM2Cycle(brathl mission.JASON1, dateYMDHMSM)
  brathl ReadData function:
  Reads data from a set of files.
  brathl ReadData(fileNames, recordName, selection, expressions, units, ignore-
OutOfRange, statistics, defaultValue):
  [in] fileNames : File name list. Empty strings are ignored (Type: Python
list of strings).
  [in] recordName
                          : Name of the fields record. For netCDF files is 'data'
(Type: Python string).
                            : Expression for selecting data fields. If empty string,
  [in] selection
all data are selected
                              (Type: Python string).
  [in] expressions : Expressions applyed to data fields to build wanted value.
If empty string, the returned
                             data are always default values (Type: Python list of
strings).
                            : Wanted unit for each expression. Must be None or of 'ex-
  [in] units
pressions' size. If None, no unit
                             conversion is done. If an entry is None or an empty
string, no unit conversion is applyed
```

to the data of the corresponding expression (Type: Python list of strings). [in] ignoreOutOfRange : Skip excess data. If there are too much values to store they are ignored (case is set True). Must be False if statistics is True (Type: Python bool). [in] statistics : Returns statistics on data instead of data themselves (Type: Python bool). The returned values for each expression are: - Count of valid data taken into account; - Mean of the valid data; - Standard deviation of the valid data; - Minimum value of the valid data; - Maximum value of the valid data. : Value to use for default/missing values (Type: Python [in] defaultValue float or int). return dataResults : Data read. Must contain a number of entries to values to read equal to expressions size (Type: Python list). => Example: fileNames = ['example.nc']
recordName = 'data' = '' selection expressions ignoreOutOfRange = False statistics = False = 0 defaultValue dataResults = brathl ReadData(fileNames, recordName, selection, expressions, units, ignoreOutOfRange, statistics, defaultValue)

```
print ("-----")
for i in range(len(dataResults)):
    print (expressions[i], "(", len(dataResults[i]), " values) =",
dataResults[i])
    print ("-----")
```