Brocade SDN Controller

Compatibility Matrix with Apps and Extensions

Supporting Brocade SDN Controller v2.0.1



© 2015, Brocade Communications Systems, Inc. All Rights Reserved.

ADX, Brocade, Brocade Assurance, the B-wing symbol, DCX, Fabric OS, HyperEdge, ICX, MLX, MyBrocade, OpenScript, The Effortless Network, VCS, VDX, Vplane, and Vyatta are registered trademarks, and Fabric Vision and vADX are trademarks of Brocade Communications Systems, Inc., in the United States and/or in other countries. Other brands, products, or service names mentioned may be trademarks of others.

Notice: This document is for informational purposes only and does not set forth any warranty, expressed or implied, concerning any equipment, equipment feature, or service offered or to be offered by Brocade. Brocade reserves the right to make changes to this document at any time, without notice, and assumes no responsibility for its use. This informational document describes features that may not be currently available. Contact a Brocade sales office for information on feature and product availability. Export of technical data contained in this document may require an export license from the United States government.

The authors and Brocade Communications Systems, Inc. assume no liability or responsibility to any person or entity with respect to the accuracy of this document or any loss, cost, liability, or damages arising from the information contained herein or the computer programs that accompany it.

The product described by this document may contain open source software covered by the GNU General Public License or other open source license agreements. To find out which open source software is included in Brocade products, view the licensing terms applicable to the open source software, and obtain a copy of the programming source code, please visit http://www.brocade.com/support/oscd.

Contents

Brocade SDN Controller Overview	5
About the controller	
About the base controller	
About the extensions	
Brocade SDN Controller Compatibility with Apps	7
About the apps	
History of app compatibility	
Compatibility with Brocade Flow Manager app versions	
Compatibility with Brocade Topology Manager app versions	
Compatibility with Brocade Flow Optimizer app versions	
Contacting Brocade	g

Brocade SDN Controller Overview

About the controller

Brocade SDN Controller is a software-defined networking (SDN) controller that is based on the OpenDaylight project.

The controller consists of packages that form a platform on which you can install or build apps. Packages that provide a common functionality and are essential for running the controller are part of the base controller. Packages that are optional are extensions that can be installed to enable additional functionality. The controller is built on a modular design that allows apps and extensions to be updated while maintaining a stable platform, which helps to improve the delivery time of apps and extensions and reduce risk to users.

Unless mentioned otherwise in this guide, the controller refers to Brocade SDN Controller.

About the base controller

The base controller is a platform on which various apps and extensions can be installed or built to provide additional functionality. Apps and extensions sometimes depend on a specific version of the controller.

The following list presents the current components of the base controller:

- · bvc-version.zip—Contains the base controller packages
- · bvc-dependencies-version.zip—Contains the dependencies packages for the base controller
- · bvc-core-ux-version.zip—Contains the user interface packages for the base controller

About the extensions

The Brocade SDN extensions add functionality to the controller and change the way you can configure the controller or other extensions. The extensions are optional but may be required for other extensions or apps to work as expected.

The following list presents the currently available extensions:

- bvc-ext-openflow-packaging-version.zip—Contains the OpenFlow packages
- bvc-ext-bgp-pcep-packaging-version.zip—Contains the Border Gateway Protocol (BGP) and Path Computation Element Protocol (PCEP) packages
- bvc-ext-hosttracker-noflood-packaging-version.zip—Contains the Host Tracker No Flood Mode packages.
- bvc-ext-ovsdb-packaging-version.zip—Contains the Open vSwitch Database Management protocol (OVSDB) packages
- bvc-ext-l2switch-packaging-version.zip—Contains the Layer 2 (L2) switch packages
- bvc-ext-utilities-packaging-version.zip—Contains the controller utilities packages

When you run the controller ./installbsc installation script command with the -y argument, all the extensions are installed by default. If you do not use the -y argument, you are prompted to install each extension.

Brocade SDN Controller Compatibility with Apps

About the apps	
History of app compatibility	٠

About the apps

The controller provides additional apps as add-on packages. You can access the apps by using the controller user interface.

Brocade Topology Manager is installed by default when you install the controller user interface. Most apps are not installed as part of the controller installation script. Some apps may require additional licensing rights. The following list provides some of the available apps:

- · Brocade Topology Manager
- · Brocade Flow Manager

For more information about the apps, refer to the specific app User Guide.

History of app compatibility

The following sections list the history of app compatibility with the controller.

Compatibility with Brocade Flow Manager app versions

The following table lists compatibility between Brocade SDN Controller and Brocade Flow Manager app versions.

Brocade Flow	Brocade SDN Controller version
Manager app version	2.0.1
1.0.0	Supported

Compatibility with Brocade Topology Manager app versions

The following table lists compatibility between Brocade SDN Controller and Brocade Topology Manager app versions.

Brocade	Brocade SDN Controller version
Topology Manager app version	2.0.1
1.0.0	Supported

Compatibility with Brocade Flow Optimizer app versions

For information about compatibility between Brocade SDN Controller and Brocade Flow Optimizer app versions, refer to the release notes for the Brocade Flow Optimizer.

Contacting Brocade

To provide document feedback use the online feedback form in the HTML documents posted on www.brocade.com or contact documentation@brocade.com.

For product support information and the latest information on contacting the Technical Assistance Center, go to http://www.brocade.com/services-support/index.html.

If you have purchased Brocade product support directly from Brocade, use one of the following methods to contact the Brocade Technical Assistance Center 24x7. Brocade OEM customers contact their OEM/ Solutions provider.

Online	Telephone	E-mail
Preferred method of contact for non-urgent issues: My Cases through MyBrocade Software downloads and licensing tools Knowledge Base	Required for Sev 1-Critical and Sev 2-High issues: Continental US: 1-800-752-8061 Europe, Middle East, Africa, and Asia Pacific: +800-AT FIBREE (+800 28 34 27 33) For areas unable to access toll free number: +1-408-333-6061 Toll-free numbers are available in many countries.	support@brocade.com Please include: Problem summary Serial number Installation details Environment description

Contacting Brocade