APPLICATION Technology

Semiconductors


When electrons can move freely through a material, the material is a conductor. The electrons in metals are loosely held and require little additional energy to move from one vacant orbital to the next. A set of overlapping orbitals is called a *conduction band*. Because electrons can easily jump to the conduction band, metals conduct electricity when only a very small voltage is applied.

Semiconductors conduct a current if the voltage applied is large enough to excite the outer-level electrons of their atoms into the higher energy levels. With semiconductors, more energy, and thus a higher voltage, is required to cause conduction. By contrast, nonmetals are insulators because they do not conduct at ordinary voltages. Too much energy is needed to raise their outer electrons into conduction bands.

Semiconductor devices include transistors; diodes, including light-emitting diodes (LEDs); some lasers;

and photovoltaic cells ("solar" cells). Though silicon is the basis of most semiconductor devices in the computer industry, pure silicon has little use as a semiconductor. Instead, small amounts of impurities are added to increase its conductive properties. Adding impurities to silicon is called *doping*, and the substances added are *dopants*. The dopant is usually incorporated into just the surface layer of a silicon chip. Typical dopants include the Group 15 elements phosphorus and arsenic and the Group 13 elements boron, aluminum, gallium, and indium.

A silicon atom has four electrons in its outer energy level whereas Group 13 atoms have three and Group 15 atoms have five. Adding boron to silicon creates a mix of atoms having four valence electrons and atoms having three valence electrons. Boron atoms form only three bonds with silicon, whereas silicon forms four bonds with other silicon atoms. The unbonded spot between a silicon atom



This model shows the difference in the levels of energy required to excite electrons into the conduction band in metals, semiconductors, and insulators. The forbidden zone is too great an energy gap in insulators for these elements to function as conductors. The energy gap for semiconductors is small enough that it can be crossed under certain conditions.