Broadspeed OfficeSuite Quick Start Guide for Users

	Connect and Activate Your Phone	Customize Your Phone and User Features	Change Your Password	Set Up Your Call Coverage	Set Up Your Voice Mail	Access Voice Mail Remotely
Need:	• Phone and Power Cord • Ethernet Cable • Your Extension and PIN	• A Web browser • Web Interface URL • Your Extension and PIN	• Access to the Web Interface	• Access to the Web Interface	• Access to your activated phone.	• Your phone number or extension • Voice mail password
Steps:	1. Disconnect your computer from the LAN. 2. Connect the Ethernet cable to the LAN, and to the phone port labeled: 3. Connect the computer to the phone port labeled **PC**. 4. Connect the power cord to the phone, and plug into a power outlet. 5. When the phone boots up, press the button below the word "Activate." 6. Enter your extension and PIN. 7. Press the button below the word "Enter." *Your phone is now active.*	1. In a browser, enter Web Interface URL. 2. When the Login screen appears, enter your extension and PIN. 3. The User window appears. 4. Select **My Settings** on the left-hand frame to see the user actions available to you. *You may now customize your personal settings.*	1. Select **My Settings.** 2. From the menu appearing in the main frame, select **Change my PIN**. 3. A window will pop up. Follow the on-screen instructions. 4. **Save** your changes. *Your new PIN is now active for both web access and phone login.*	1. Select **My Settings.** 2. From the menu appearing in the main frame, select **View and edit call coverage options**. 3. The main frame will present you with the call coverage options. Follow the on-screen instructions. 4. **Save** your changes. *Your Call Coverage is now set.*	1. Press the **Message** button on your set. 2. Follow the spoken instructions to set up your voice mail password and your greetings. *Your Voicemail is now set up.* *See other side for additional details.*	1. Call your own phone and wait to be transferred to voice mail. 2. Wait for your greeting to start, then press the * key. 3. When prompted, enter your password. 4. Follow the voice prompts to retrieve messages.
Notes:	Extension and PIN supplied by email or by your local Administrator. Or use your phone's default PIN, which is 1234.	Your local Administrator will provide the URL to the Office Suite Web Interface.	Use this new PIN the next time you access the web interface.	Call Coverage tells the system how your unanswered calls are to be routed.	Your voice mail box default password is 1234..	Voicemail messages can also be retrieved online at https://voicemail.broadviewnet.com

BOS-QSG-11-06

For additional instructions, go to **https://officesuite.broadviewnet.net/webadmin**, log in, and click Help; or visit the OfficeSuite Customer Information Center at www.broadviewnet.com/customers_center/voiceoverip.asp. If you still have questions, email us at OfficeSuiteSupport@BroadviewNet.com or call 1.888.623 VOIP (8647).

OfficeSuite™ Voicemail Quick Reference Guide

To Initialize Your Voice Mailbox

1. Dial your own telephone number. (OfficeSuite users press the message button on the phone.)
2. At the prompt, enter your passcode, optionally terminated by #.

To Access Your Voicemail Remotely*

1. Dial your own telephone number and wait for the call to cover to voicemail.
2. Interrupt the voicemail greeting with "*".
3. At the prompt, enter your pass code, optionally terminated by #.

For First Time Users Who Need to Initialize their Voice Mailbox

1. Access your voicemail as described above.
2. The default pass code is 1234 and should be changed immediately.
3. The voice prompts guide you through setting up your mailbox and changing your pass code.
4. Terminate the recording of your name and your greetings using #.

Voicemail Menu

After calling into your Voicemail you will be presented with the following options:

Press 1 Listen to Messages
Press 2 Send a Message
Press 3 Place a Call
Press 9 User Options
Press * Disconnect/Hang-up
Press 0 Help

Mailbox Options

1. From the Main Menu, press 9.
2. You can then select one of these options:

Press 1 Review and Record Your Name and Greetings
Press 2 Change Your Pass Code or Login Options
Press 3 Change What Information is Played at the Start of Each Message
Press 4 Change Call Answering Options and Select Active Greeting
Press * Main Menu
Press 0 Help

Listening to Messages

1. From the Main Menu, press 1.
2. You can then select one of these options:

Press 1 Replay Current Message
Press 2 Save Current Message
Press 3 Delete Current Message
Press 4 Reply to Current Message
Press 5 Forward a Copy of Current Message
Press 6 Message Information
Press 7 Play Previous Message
Press 9 Play Next Message
Press # Message Menu
Press * Main Menu
Press 0 Help

Message Navigation

To be used while a message is playing.

Press 7 Rewind
Press 8 Pause
Press 9 Fast Forward
Press # Message Menu

Send a Message

1. From the Main Menu, press 2.
2. At the prompt, dial an extension or a Voicemail group number, or dial by name.
3. Press # after each destination number. Add as many destinations as you wish. After the last destination number and #, Press # again to begin recording your message.
4. When you have finished recording your message, press #.

Press 1 Send Message
Press 2 Re-Record Message
Press 3 Review Message
Press 4 Mark Message Urgent
Press 5 Add Recipients
Press 6 Mark Message Private
Press # Send
Press * Cancel, Return to Main Menu
Press 0 Help

Forwarding a Message

1. While listening to messages, press 5 to forward to another recipient.
2. At the prompt, dial the extension number of the message recipient(s) terminated by #.
3. After the tone, record an introductory message. When you are finished, press #.
4. Press #1 and the message will be forwarded to the recipients.

*Once your OfficeSuite voice mailbox is set up for the first time, messages can also be listened to and managed online at https://voicemail.broadviewnet.com.

Broadview NETWORKS®

Customer Service 1.800.BROADVIEW

©2011 Broadview Networks Inc. All rights reserved.