We acknowledge and pay our respects to the Kaurna people, the traditional custodians whose ancestral lands we gather on.

We acknowledge the deep feelings of attachment and relationship of the Kaurna people to country and we respect and value their past, present and ongoing connection to the land and cultural beliefs.




# Computer Systems

Lecture 11: Signals and Caching



## Review: The whole system






# Signals & Caching



# The Hack Computer


### The HACK machine is very simple

it has 64KB of separate read only instruction memory
it has 48KB + 2B of separate read / write data memory
the entire machine runs off a **single clock signal**all instructions take exactly the same amount of time to execute
a lot of embedded systems may be structured like this








### The Hack Computer





## Signal Propagation – Clock Tick












### Signal Propagation – Clock Tick



# **Signal Propagation**

The clock must not tick again until propagation completes

the output of every gate needs time to get to the next gate every gate needs time to respond to its inputs the longest path through the machine must be able to complete

### The longest path is very long

the PC must send a new address to instruction memory only then can a new instruction be used to change control signals only then can the correct inputs reach the ALU only then can the correct output leave the ALU only then can a Jump be evaluated only then is the new value of the PC known



# **Signal Propagation**

Until propagation completes bad things appear to happen

wrong data being read from memory

wrong data being written to the wrong memory address

the wrong values flowing through muxes

the wrong address being written to the PC

the wrong values being written to the A and D registers

Why does the computer still work?

because the wrong values are never saved

Memory, PC, A and D do not change until the next clock tick



### **The Power Wall**

### Switching consumes power

if the outputs of chips change power is consumed even if externally there is no change, internal changes can occur careful routing of wires to minimise changes can save power

The overall power consumption of a processor approximates

Capacitive Load x Voltage<sup>2</sup> x Frequency

### **Power Consumption Performance Challenges**

There is a practical limit to how much power can be used
Capacitive Load reduction requires new manufacturing processes
Voltage reductions may be nearing their limits
Removing the generated heat can be expensive
We want lower power consumption



### What Can Be Done?

#### Shorten the longest path

more efficient adders

- our 16-bit adder requires a signal to traverse 32 gates
- carry look ahead could reduce this to 5 gates
- a 16-bit multiplier could be implemented with a 20 gate delay a shorter longest path may allow a shorter clock cycle / faster clock but a faster clock means more power consumption?

#### Split the processor into smaller parts linked by registers

pipelining

#### Use separate clocks for different components

- processor\*
- memory\*
- I/O devices



# **Slow Memory**

Assume that the RAM in our Hack computer is changed the new memory takes 500 clock cycles to read or write anything it is not good at remembering data but it is very cheap !!! Assume that the RAM has a ready signal it is cleared when addressM changes or writeM changes it is set when the input has been saved and / or the output is correct How do we stop the Hack processor while we wait? we could and the ready signal with the load signal for A, D and PC if these registers cannot change the Hack processor is stalled Instructions using RAM are now 500 times slower other instructions still complete in a single clock cycle instruction using RAM are stalled for 500 clock cycles but our Hack computer still works ... sort of ... Pong is too slow ...



# Very Slow Memory in Real Life?

### The HACK machine is very simple

it has separate instruction memory and data memory

the entire machine runs off a single clock signal

all instructions take exactly the same amount of time to execute

The usual Von-Neumann architecture is more complex

there is only one memory

all instructions and data live in the same memory

reading instructions interferes with reading / writing data

real memories can be very large but much slower than the CPU

taking anywhere from 2 to more than 500 clock cycles to access

How do we make a computer fast when memory is slow?




# **Memory Hierarchies**

#### The usual Von-Neumann architecture is more complex

there is only one memory
all instructions and data live in the same memory
reading instructions interferes with reading / writing data
real memories can be very large but much slower than the CPU

- taking anywhere from 2 to more than 500 clock cycles to access how do we make this work?
- keep local copies of what is being used?

#### What the programmer sees on a modern CPU:






# Memory Caching – Hardware Implemented

#### A memory cache

it may appear to behave like memory from the outside internally it keeps copies of blocks of memory that were accessed it has a lookup table recording the addresses of the copies access to data in the cache is very fast access to data not in the cache must wait for the memory access to data not in the cache may be slower than without one






# Memory Caching – Hardware Implemented

#### **Instruction Caching**

when an instruction is required, copy it and others around it instructions already in the cache can be read very quickly

#### **Data Caching**

when data is required, copy it and data around it data already in the cache can be read very quickly when data is written, keep a copy of it\*





# Why Instruction Caching Usually Works

#### **Instruction Caching**

instructions do not change


the same instructions are used over and over again

loops and frequently called functions benefit most

if the cache is full you can safely overwrite anything you like

the wrong choices can have a catastrophic impact on performance

the choices are implemented in hardware, change may be impossible






## Why Data Caching Sometimes Works

#### **Data Caching**

caching data is a more complex problem
if data is frequently accessed you want it to stay in the cache
if the cache is full what do you overwrite?
you cannot overwrite new data that has not been written to memory
the wrong choices can have a catastrophic impact on performance

the choices are implemented in hardware, change may be impossible






# The Memory Hierarchy

#### There can be many levels of cache

every cache has a table recording it contents





## **Memory Hierarchies**

#### The caches are mostly hidden from the programmer

in some cases virtual memory can be manipulated directly memory mapped files are a good example virtual memory is partly implemented in software hardware exceptions run page fault handlers to move data caches work to hide themselves from the programmer

What the programmer sees on a modern CPU

CPU

16 Exabytes of Memory



### **Real World Effects**

### **Instruction Caching**

it calls the function

consider a simple interpreter for a virtual machine a loop is responsible for reading the next instruction from memory it then looks up the address of a function to simulate the instruction

on return it goes around the loop again

### I tried to make one of these really fast

I made gcc put the simulated program counter in a physical register I had optimized the loop reducing it from 28 to 4 instructions

### What was the speed difference?

5 to 1, 7 to 1, 10 to 1, 20 to 1, 100 to 1, 500 to 1, ...?

### Can you explain why?



### **Real World Effects**

#### **Data Caching**

consider a simple loop that reads all the elements in an array can you tell how long it will take to run?

```
// sum length elements of data in the order specified by indices
int iterate(int *data,int *indices,int length)
{
    int x;
    for ( int i = 0 ; i < length ; i++ )
    {
        x += data[indices[i]] ;
    }
    return x;
}</pre>
```

### Can the time taken vary?

if yes, why and by how much? if no, why not?



### **Real World Effects**

### How can you avoid or minimise these problems?

- buy a more expensive processor with a more intelligent cache
- try to keep data close together
- try to avoid unnecessary random access to data
- try to take advantage of temporal and spatial locality

### **Temporal Locality**

- instructions and data tend to get used again in the near future
- caches that replace the least recently used content may work well

### **Spatial Locality**

- instructions and data tend to be near something that was just used
- caches usually copy an enclosing block of instructions or data
- cache line size can vary a lot, the best size depends on the program



# Summary

#### Caching is used just about everywhere in a computer

#### Instruction caching is usually very effective

- instructions do not change\* during execution
- most instructions get used over and over again

#### Data caching can be very effective

- data changes during execution
- when data is accessed, it may well be used again soon
- when data is accessed, near by data may well be used soon

#### **Virtual Memory (VM)**

- main memory can be a cache for a much larger virtual memory
- every program can view its entire 16 exabytes of VM
- it works so long as the programs do not use too much of it
- physical resources still need to be available





### This Week

- Review Chapter 11 of the Text Book (if you haven't already)
- Prac 6 Available, due end of semester
- Prac 7 (second part of prac 6) available this week.

