

Level 4 — Joint bridge: EPOS2 BridgeState

Owner: epos2_bridge / epos2_joint_bridge.py · state: self.bridge_state (BridgeState enum), one node per joint
Runtime path: FollowJointTrajectory goals, config joints/j2-j6.yaml (legacy IPM paths off) · source-derived, not runtime-verified

- state
- composite (bridge node)
- legacy-only state, disabled
- context / interface
- transition in code
- transition via call chain*
- from any state (on border)
- * body not fully read

