


BCM(左前门锁、右前门锁)




BCM(左后门锁、右后门锁、背门锁)



BCM(背门锁、主驾带扣开关、前舱盖锁、制动液位开关、引擎模拟器)



BCM(制动灯开关、光照传感器、防盗指示灯、脚刹开关)



BCM(小探头)

