### MKS TFT pictures&logos Customization Manual

#### V1.1

#### **Contract**

If customers want to customize the picture and logo showing in the touch screen, the rules should be followed.

- 1. Customization range:
- a. Button pictures (such as show at red number 1 in figure 1),
   text above the picture (such as show at red number 2 in figure 1) can be customized when you design your own pictures;
- b. Background color of screen(see Figure 3, default Black);
- c. Color of the text in title(see Figure 4, default white);
- d. Background color for status such as temperature (see figure1 red number "5", default dark blue);
- e. Color of the text for status such as temperature , etc. (see Figure 1 red number 6, default white);
- f. Color of the text in the button of "select the file" interface, (see Figure 2, showing at red number7, default white);
- g. Background color of the button in "select the file" interface, we suggest you choose the same color with picture;

Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building , Runnong Business center, No. 2, Huangcun avenue, Tianhe district ,

h. Background color of the print status information text in "printing" interface (see figure3,showing at red number "8", default white);

- i. Color of the print status information text in "printing" interface, we suggest you choose the same color with picture;
- j. Button defaults 3D effect , then there will turn up white border around the button picture.



Figure 1

Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building, Runnong Business center, No. 2, Huangcun avenue, Tianhe district,



Figure 2



Figure 3

- 2.Customizable button picture, 16bpp, wide =78 pixels, high =104 pixels;
- 3.Customizable logo images, 16bpp, wide =320 pixels, high =240 pixels;
- 4. The name of the custom image must be named after the appendix (see Appendix 1).

5. The color value is 16 binary, according to the 3 primary colors

Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building, Runnong Business center, No. 2, Huangcun avenue, Tianhe district,

of blue, green, red order (see Appendix 2);

6.Customizable function button, can customize 7 buttons at most.

# Step:

- 1. Picture customization
- a. Install the "Image2Lcd" tool that we provide;
- b. Follow the following operation for each picture:

Open the Image2Lcd software and set as below:



Prepare .Bmp format picture, using the Image2Lcd to open:


Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building, Runnong Business center, No. 2, Huangcun avenue, Tianhe district,



Click save bottom, save the file with the name we specified.



Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building, Runnong Business center, No. 2, Huangcun avenue, Tianhe district,

c. Create a folder "mks\_pic" in the root directory of your SD card, and put all the .Bin files generated by the previous step to the folder "mks\_pic";

- 2. Screen background color customization
  Modify the color value in configuration file "MKS config.txt"
  field "CFG background color" colon, and then save;
- 3. Color of title text customization
  Modify the color value in configuration file " mks\_config.txt " field " cfg\_title\_color " colon, and then save;
- 4. Background color for display statues such as temperature customization

Modify the color value in configuration file " mks\_config.txt " field " cfg\_state\_background\_color " colon, and then save;

5. Color of text such as temperature customization
Modify the color value in configuration file " mks\_config.txt " field " cfg\_state\_text\_color " colon, and then save;

Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building, Runnong Business center, No. 2, Huangcun avenue, Tianhe district,

6. Customize the color of filename button in "select file" interface

Modify the color value in configuration file " mks\_config.txt " field " cfg\_filename\_color " colon, and then save;

7. Customize the background color of filename button in "select file" interface

Modify the color value in configuration file " mks\_config.txt " field " cfg\_filename\_background\_color " colon, and then save;

8. Customize the background color of text for printing status in "printing" interface

Modify the color value in configuration file " mks\_config.txt " field " cfg\_printingstat\_word\_background\_color " colon, and then save;

9. Customize the color of text for printing status in "printing" interface

Modify the color value in configuration file " mks\_config.txt " field " cfg printingstat word color " colon, and then save;

Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@gg.com;529442067@gg.com;4164049@gg.com;

Address: Room 2110, No2 Building, Runnong Business center, No. 2, Huangcun avenue, Tianhe district,

10. Function button settings for the "more" menu;

a. Modify the value in configuration file " mks config.txt " field

" moreitem pic cnt " colon, and then save (maximum value is

7)

b. Change the command line after the colon of

"moreitem\_button1\_cmd" in configuration file, and take it as

your first function button. Each command with a semicolon ";"

as the interval, the whole button command line use wrap for

the end. The total number of character for the entire function

keys is no more than 200.

c. Others 6 buttons are the same way.

11. Wheather button needs 3D effect

Modify value after the colon of "mks config.txt"

"cfg BUTTON 3D effects" in configuration files. 1 is yes, 0 is

no.

12. Copy file "mks config.txt" and "mks pic" to SD card

root directory, insert SD card into MKS TFT, and restart , then

the system will upgrade automatically.

**Appendix 1** 

Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;


Address: Room 2110, No2 Building, Runnong Business center, No. 2, Huangcun avenue, Tianhe district,

Photo naming (note that some pictures are duplicated, you need only provide one ).

1. logo: bmp\_logo.bin



2. "ready to print" interface:



Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building, Runnong Business center, No. 2, Huangcun avenue, Tianhe district,

	移 动	回 零	tTff(nuinting)
预热 (preHeat):	(Move):	(Home):	打印(printing):
bmp_preHeat.bin	bmp_mov.bi	bmp_zero.bi	bmp_printing.bi
	n	n	n
挤出(extrusion):	风扇 (Fan):	设置(Set):	更多 (More):
bmp_extruct.bin	bmp_fan.bin	bmp_set.bin	bmp_more.bin

### 3.PreHeat interface:



Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building, Runnong Business center, No. 2, Huangcun avenue, Tianhe district,

增加(Add):			减少(Dec):
bmp_Add.bi			bmp_Dec.bi
n			n
预热对象 (target): 热床: bmp_bed.bi n 喷头 1: bmp_extru1. bin 喷头 2: bmp_extru2.	步进(step):  1 度 : bmp_step1_degree .bin  5 度 : bmp_step5_degree .bin  10 度 : bmp_step10_degre e.bin	关 闭(Close): bmp_speed0 .bin	返回(Back): bmp_return. bin

# 3. Extrusion interface:

Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building , Runnong Business center, No. 2, Huangcun avenue, Tianhe district ,



进料(In):			退料
			(Out):
bmp_in.bi			bmp_out
n			.bin
喷头 (E):	步进(Step):	速率(speed):	返 回
E1 :	1mm :	slow :	(Back):
bmp_extru	bmp_step1_mm.bi	bmp_speed_slow.	bmp_ret


Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building, Runnong Business center, No. 2, Huangcun avenue, Tianhe district,

1.bin	n	bin	urn.bin
E2 :	5mm :	normal :	
bmp_extru	bmp_step5_mm.bi	bmp_speed_norm	
2.bin	n	al.bin	
	10mm :	high :	
	bmp_step10_mm.	bmp_speed_high.	
	bin	bin	

### 4. Move interface:



Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building , Runnong Business center, No. 2, Huangcun avenue, Tianhe district ,

			步进(Step):
			0.1mm :
X+:	Y+:	Z+:	bmp_step_move0_1.bin
bmp_xAdd.	bmp_yAd	bmp_zA	1mm :
bin	d.bin	dd.bin	bmp_step_move1.bin
			10mm :
			bmp_step_move10.bin
X-:	Y-:	Z-:	返回(Back):
bmp_xDec.	bmp_yDe	bmp_zD	bmp return.bin
bin	c.bin	ec.bin	binp_return.bin

### 5. Home interface:



Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building , Runnong Business center, No. 2, Huangcun avenue, Tianhe district ,

全部(Home): bmp_zeroA.bin	X: bmp_zeroX.b in	Y: bmp_zeroY.bi n	Z: bmp_zeroZ.bin
			返回 (Back): bmp_return.bi n

### 7. Fan interface:



Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building, Runnong Business center, No. 2, Huangcun avenue, Tianhe district,

增加			减少
(Add):			(Dec):
bmp_Add.			bmp_Dec
bin			.bin
全 速	半速(Half):		返回
(Full):	一元 (Hall):   bmp_speed127.bi	关闭(close):	(Back):
bmp_spee		bmp_speed0.bin	bmp_ret
d255.bin	n		urn.bin

## 8. Setting interface:



Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building, Runnong Business center, No. 2, Huangcun avenue, Tianhe district,

文件系统			连接
《File Sys):	触 摸 校 正	机型 (Machine):	( connect
,	(Calibration):	bmp_machine.bi	) :
bmp_fileSys	bmp_adj.bin	n	bmp_conn
.bin			ect.bin
wifi:			返 回
	语言(language):	关于 (about):	(Back):
bmp_wifi.bi	bmp_lang.bin	bmp_about.bin	bmp_retu
n	A		rn.bin

# 9. File system interface:



Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building , Runnong Business center, No. 2, Huangcun avenue, Tianhe district ,

SD:	U 盘(udisk):	
未选择:	未选择:	
bmp_sd.bin	bmp_usb.bin	
被选择:	被选择:	
bmp_sd_sel.b	bmp_usb_sel.b	
in	in	
		返回
		(Back):
		bmp_retu
	A	rn.bin

# 10. Machine type interface



Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building , Runnong Business center, No. 2, Huangcun avenue, Tianhe district ,

普通 (normal):	三角洲(delta):	
未选择:	未选择:	
bmp_norm.bin	bmp_delta.bin	
被选择:	被选择:	
bmp_norm_sel.	bmp_delta_sel.bi	
bin	n	
		返 回
		(Back):
		bmp_retu
		rn.bin

# 11. Connecting interface



Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building , Runnong Business center, No. 2, Huangcun avenue, Tianhe district ,

9600:	115200:	250000:	
未选择:	未选择:	未选择:	
bmp_baud9600.bi	bmp_baud115	bmp_baud250	
n	200.bin	000.bin	
被选择:	被选择:	被选择:	
bmp_baud9600_s	bmp_baud115	bmp_baud250	
el.bin	200 _sel.bin	000_sel.bin	
			返 回
			(Back):
			bmp_ret
			urn.bin

### 12. Language interface



Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building , Runnong Business center, No. 2, Huangcun avenue, Tianhe district ,

简 体 中 文			
(simple	英文(English):		
Chinese):	未选择:		
未选择:	bmp_en.bin		
bmp_simple.bin	被 选 择 :		
被选择:	bmp_en_sel.bin		
bmp_simple_sel	5p_ess	- 0	
.bin			
			返 回
	A		(Back):
			bmp_ret
A			urn.bin

## 13. More interface

自 定 义	自 定 义	自定义	自 定 义
1(custom1):	2(custom2):	3(custom3):	4(custom4)
	,	,	:
bmp_custom	bmp_custom2	bmp_custom	bmp_custo
1.bin	.bin	3.bin	m4.bin

Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building , Runnong Business center, No. 2, Huangcun avenue, Tianhe district ,

自	定	义	自	定	义	自	定	义	返	回
5(cu	stom5	):	6(cu	stom6	):	7(cu	stom	7):	(Bacl	k):
bmp	_custo	om	bmp	_custo	om6	bmp	_cust	om	bmp_r	etur
5.bir	า		.bin			7.bi	n		n.bin	

### 14. "Choose file" interface



文件 (file):				
bmp_file.bin				
目录 (dir):				
bmp_dir.bin				
	上一页 (page	下一页 (page	返	口

Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building, Runnong Business center, No. 2, Huangcun avenue, Tianhe district,

up):	down):	(Back):
bmp_pageUp.b	bmp_pageDo	bmp_return.
in	wn.bin	bin

### 15. Printing interface



			操作(option):
			bmp_menu.bin
喷头 1(E1):	喷头 2(E2):	热床(bed):	风扇(fan):
bmp_extru	bmp_extru2	bmp_bed_no_	bmp_fan_no_word

Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building , Runnong Business center, No. 2, Huangcun avenue, Tianhe district ,

1_no_word	_no_words.	words.bin	s.bin
s.bin	bin		风扇转动:
			bmp_fan_move.bi
			n

# 16. Option interface



		停 止
暂停 (pause):		(stop):
bmp_pause.bin		bmp_stop.bi
		n

Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building, Runnong Business center, No. 2, Huangcun avenue, Tianhe district,

温度			返 回
( temperature	变速(speed):	风扇(fan):	(Back):
) :	bmp_speed.bin	bmp_fan.bin	bmp_return.
bmp_temp.bin			bin

### 17. Pause interface



恢复		停 」	1
(resume):		(stop):	
bmp_resume.b		bmp_stop.b	i
in		n	

Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building, Runnong Business center, No. 2, Huangcun avenue, Tianhe district,

			温	度
挤出(Extruct):	移动(move):	図島(fan)。	( temp	erat
bmp_extruct.bi		bmp_fan.bin	ure )	:
n	bmp_mov.bin	Dilip_lall.bill	bmp_ten	np.
			bin	> /

# 18. Speed interface



		减 少
增加(Add):		( Dec ):
bmp_Add.bin		bmp_Dec.bi
		n

Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building, Runnong Business center, No. 2, Huangcun avenue, Tianhe district,

		步进(Step):	
移动	  挤出(Extruct):	1mm :	
(Move):	未选择:	bmp_step1_mm	
未选择:	bmp extruct.bi	.bin	返回
bmp_mov.bin	n '-	5mm :	(Back):
'-  被选择:	  被 选 择 <b>:</b>	bmp_step5_mm	bmp_return
bmp mov se	bmp extruct s	.bin	.bin
l.bin	el.bin	10mm :	
		bmp_step10_m	
		m.bin	

# 2 Appendix 2

Hexadecimal value for the common color

Blue	0xFF0000
Green	0x00FF00
Red	0x0000FF
yellow	0x00FFFF
Light blue	0xFF8080
Light green	0x80FF80
Light red	0x8080FF

Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building , Runnong Business center, No. 2, Huangcun avenue, Tianhe district ,

Cyan	0xFFFF00
Light Cyan	0xFFFF80
Light yellow	0x80FFFF
Deep green	0x008000
Deep red	0x000080
Deep blue	0x800000
Deep yellow	0x008080
Black	0x000000
White	OxFFFFF

Website: www.makerbase.com.cn Database: https://github.com/makerbase-mks

E-mail: 2228481602@qq.com;529442067@qq.com;4164049@qq.com;

Address: Room 2110, No2 Building , Runnong Business center, No. 2, Huangcun avenue, Tianhe district ,