



Target Customization and Tool Integration

Tutorial @ FPT Conference 2017 – Melbourne– Australia

Marco Lattuada

Politecnico di Milano Dipartimento di Elettronica, Informazione e Bioingegneria marco.lattuada@polimi.it

- Target Selection
- Integration with Simulator and Synthesis tools

- □ Target = FPGA device(+synthesis tool) + clock period
 - ▶ Different delays of FPGA elements (i.e., delay of a DSP)
 - ▶ Different sizes of FPGA elements (i.e., size of LUTs)
 - ▶ Different HDL description of memory elements
- □ Target device + target clock period can be specified
 - Default is
 - Target device: xc7z020-1clg484-VVD
 - Target clock period: 10ns

- ☐ Target information is embedded in XML files
 - ► Supported devices → included in bambu executable
 - New devices → must be passed to the tool
- XML file mainly contains characterization of functional units
 - Area
 - Delay
- XML files are automatically generated by means of eucalyptus (distributed in PandA)
 - ▶ New devices can be easily added

Intel

- Cyclone II: EP2C70F896C6, EP2C70F896C6-R
- Cyclone V: 5CSEMA5F31C6
- Stratix IV: EP4SGX530KH40C2
- Stratix V: 5SGXEA7N2F45C1

Lattice

ECP3: LFE335EA8FN484C

■ Xilinx

- Virtex 4: xc4vlx100-10ff1513
- Virtex 5: xc5vlx110t-1ff1136 xc5vlx330t-2ff1738 xc5vlx50-3ff1153
- Virtex 6: xc6vlx240t-1ff1156
- Artix 7: xc7a100t-1csg324-VVD
- Virtex 7: xc7vx330t-1ffg1157 xc7vx485t-2ffg1761-VVD xc7vx690t-3ffg1930-VVD
- Zynq: xc7z020-1clg484-VVD (default), xc7z020-1clg484, xc7z020-1clg484-YOSYS-VVD

```
--device-name=<value>
```

Specify the name of the device (see previous slide) Default is xc7z020-1clg484 (Xilinx Zynq)

```
--clock-period=<value>
```

Specify the period of the clock signal (in nanoseconds)

Default is 10

Example:

--device-name=5SGXEA7N2F45C1 --clock-period=5

- Bambu can directly interface synthesis tools:
 - Quartus / Quartus Prime
 - ▶ ISE
 - ▶ Vivado
 - Diamond
- Bambu
 - generates synthesis scripts
 - collects information about generated solutions

--evaluation

- User can provide
 - VHDL/Verilog implementation of custom module
 - Constraint files
- Customization of design flow
 - User can provide XML files containing custom TCL scripts

- Bambu can directly interface simulation tools
- Support to single tools must be enabled during configuration
 - ▶ isim
 - xsim
 - modelsim
 - ▶ icarus
 - verilator (enabled in VM)
- Bambu can
 - generate testbench + simulation scripts
 - collect data

- Testbench is automatically generated in Verilog by bambu starting from:
 - Randomly generated values
 - ► XML file | --generate-tb=<file.xml>

 - Annotated C file
 - Support to open, read, write of files
- Result of the simulation is compared with
 - ▶ C input or
 - ▶ C generated from bambu IR
- ☐ Maximum allowed ULP can be set

- Synthesize a module which takes as input an array of integer with arbitrary size and returns the minimum and maximum value
 - ▶ Do not use structure

Solution Hint

Example: Code returning the maximum of array of 10 elements

```
void max(int input[10], int * max)
   int local max = input[0];
   int i = 0;
   for (i = 0; i < 10; i++)
      if(input[i] > local max)
         local max = input[i];
   *max = local max;
```

Possible Solution

```
void min max(int * input, int num elements, int * max, int * min)
   int local max = input[0];
   int local min = input[0];
   int i = 0;
   for (i = 0; i < num elements; i++)
   {
      if(input[i] > local max)
         local max = input[i];
      else if(input[i] < local min)</pre>
         local min = input[i];
   *min = local min;
   *max = local max;
```

- Write testbench for the module designed in the previous activity
 - ► Test arrays with different elements and different sizes

```
--generate-tb=<xml_file>
```

```
<?xml version="1.0"?>
<function>
     <testbench input="0,1,2,3,4" num_elements="5"/>
</function>
```

Possible Solution

Third example – Select target device and clock target period

- Compare the number of cycles required by a function executing 64 bit multiplication on the following target
 - ► xc4vlx100-10ff1513 66MHz
 - ► 5SGXEA7N2F45C1 200MHz
 - ► xc7vx690t-3ffg1930-VVD 100MHz
 - ► xc7vx690t-3ffg1930-VVD 333MHz
 - ► xc7vx690t-3ffg1930-VVD 400MHz

bambu module.c --device-name=xc4vlx100-10ff1513 --clock-period=15 --simulate

Solution

bambu module.c --device-name=xc4vlx100-10ff1513 --clock-period=15 --simulate

bambu module.c --device-name=5SGXEA7N2F45C1 --clock-period=5 --simulate

bambu module.c --device-name=xc7vx690t-3ffg1930-VVD --clock-period=10 --simulate

bambu module.c --device-name=xc7vx690t-3ffg1930-VVD --clock-period=3.3 --simulate

bambu module.c --device-name=xc7vx690t-3ffg1930-VVD --clock-period=2.5 --simulate