DISPLAYS & IND LIGHTS DRIVER CONNECTORS						BUTTONS / SWITCHES / KNOBS CONNECTORS							
EWMU / CMDS DSUB1			EWPI DSUB2				EWMU / CMDS	EWPI					
							CN1 (IDC 2X13 PIN HEADER)	CN2 (IDC 2X5 PIN HEADER)					
DC-37 FEMALE			DB-25 FEMALE				B-25 MALE (PARALLEL PORT TYPE)	TO DB-9 MALE (STRAIGHT THRU)					
USE 24 AWG CABLE			USE 24 AWG CABLE				b 23 MALL (I AMALLEL I GM I I I L)	,					
SOURCE	DC37	FUNCTION	SOURCE	DB25	FUNCTION	SOURCE	IDC	DB	FUNCTION	SOURCE	IDC	DB	FUNCTION
	PIN			PIN			26	25			10	9	
								PIN			PIN	PIN	
5V PS +	1	+5V	5V PS +	1	+5V	TEENSY DGND	1	_	ROTARY SWITCH COMMON	TEENSY DGND	1		BUTTON COMMON
5V PS GND	2	GND	5V PS GND	2	GND	TEENSY PIN 28	2	14	EWMU/CMDS MODE SWITCH - OFF	TEENSY PIN 19	2	2	PRI BUTTON
5V PS GND	3	GND	5V PS GND	3	GND	TEENSY PIN 29		2	EWMU/CMDS MODE SWITCH - STBY	TEENSY PIN 21	3	3	SEP BUTTON
5V PS GND	4	GND	N/C	4	N/C	TEENSY PIN 30	4		EWMU/CMDS MODE SWITCH - MAN	TEENSY PIN 20	4	4	UNK BUTTON
5V PS GND	5	GND	N/C		N/C	TEENSY PIN 31	5	3	EWMU/CMDS MODE SWITCH - SEMI	TEENSY PIN 18	5	5	MD BUTTON
TEENSY PIN 12	6	DATA IN	TEENSY PIN 15	6	DATA IN	TEENSY PIN 32	6	16	EWMU/CMDS MODE SWITCH - AUTO	N/C	6	6	N/C
TEENSY PIN 10	7	CLK	TEENSY PIN 10	7	CLK	TEENSY PIN 27	7	4	EWMU DISP SWITCH - MENU   CMDS FL SWITCH - ON/OFF	TEENSY 3V3	7	7	BRIGHTNESS POT (+)
TEENSY PIN 8	8	BLANKING	TEENSY PIN 17	8	BLANKING	TEENSY PIN 11	8	17	EWMU DISP SWITCH - ON/OFF	TEENSY PIN 16	8	8	BRIGHTNESS POT - WIPER
5V PS GND	9	CASE GND	5V PS GND	9	CASE GND	TEENSY PIN 26	9	5	EWMU RWR SWITCH - MENU   CMDS CH SWITCH - ON/OFF	TEENSY AGND	9	9	BRIGHTNESS POT (-)
5V PS +	10	CMDS IND LGHT +5V	5V PS +	10	EWPI IND LEDS +5V	TEENSY PIN 8	10	18	EWMU/CMDS RWR SWITCH - ON/OFF	N/C	10	N/C	N/C
5V PS GND	11	CMDS DISP RDY LAMPS (-)	5V PS GND	11	PRI LED (-)	TEENSY PIN 25	11	6	EWMU JMR SWITCH - MENU   CMDS O2 SWITCH - ON/OFF				
5V PS GND	12	CMDS NO GO LAMPS (-)	5V PS GND	12	UNK LED (-)	TEENSY PIN 7	12	19	EWMU/CMDS JMR SWITCH - ON/OFF				
5V PS GND	13	CMDS GO LAMPS (-)	5V PS GND	13	ML LED (-)	TEENSY PIN 24	13	7	EWMU MWS - MENU   CMDS O1 SWITCH - ON/OFF				
BL GND	14	BACKLIGHTING GND	BL GND	14	BACKLIGHTING GND	TEENSY PIN 6	14	20	EWMU/CMDS MWS SWITCH - ON/OFF				
BL GND	15	BACKLIGHTING GND	BL+	15	BACKLIGHTING +	TEENSY PIN 0	15	8	EWMU/CMDS JETTISON SWITCH - ON/OFF				
BL+	16	BACKLIGHTING +	TEENSY PIN 1	16	COL1	TEENSY DGND	16	21	TOGGLE SWITCH COMMON				
BL+	17	BACKLIGHTING +	TEENSY PIN 1	17	COL1	TEENSY PIN 36	17	9	EWMU BUTTON MATRIX COL1   CMDS PRGM - 1				
TEENSY PIN 1	18	COL1	TEENSY PIN 2	18	COL2	TEENSY PIN 37	18	22	EWMU BUTTON MATRIX COL2   CMDS PRGM - 2				
TEENSY PIN 1	19	COL1	TEENSY PIN 2	19	COL2	TEENSY PIN 38	19	10	EWMU BUTTON MATRIX COL3   CMDS PRGM - 3				
TEENSY PIN 1	20	COL1	TEENSY PIN 3	20	COL3	TEENSY PIN 39	20	23	EWMU BUTTON MATRIX COL4   CMDS PRGM - 4				
TEENSY PIN 1	21	COL1	TEENSY PIN 3	21	COL3	TEENSY PIN 33	21	11	EWMU BUTTON MATRIX ROW1   CMDS MODE - BYP				
TEENSY PIN 2		COL2	TEENSY PIN 4	22	COL4	TEENSY PIN 34	22	24	EWMU BUTTON MATRIX ROW2   CMDS PRGM - BIT				
TEENSY PIN 2		COL2	TEENSY PIN 4	23	COL4	TEENSY 3V3	23		BRIGHTNESS POT (+)				
TEENSY PIN 2		COL2	TEENSY PIN 5	24	COL5	TEENSY PIN 14			BRIGHTNESS POT - WIPER				
TEENSY PIN 2		COL2	TEENSY PIN 5	25	COL5				BRIGHTNESS POT (-)				
TEENSY PIN 3	26	COL3				N/C	26	N/C	N/C				
TEENSY PIN 3		COL3											
TEENSY PIN 3		COL3											
TEENSY PIN 3	29	COL3											
TEENSY PIN 4		COL4											
TEENSY PIN 4		COL4											
TEENSY PIN 4		COL4											
TEENSY PIN 4		COL4											
TEENSY PIN 5	34	COL5								-			
TEENSY PIN 5	-	COL5		REV: 1.01									
TEENSY PIN 5		COL5							D-4 2024 OF 24	Sheet:	1: -1	. <b>.</b> •	1/1
TEENSY PIN 5	37	COL5							Date: 2021-05-24	Drawn By:	ııgr	itnii	ng