



TRIDIUM NIAGARA 4 BACNET PICS

BACnet Protocol Implementation Conformance Statement

Date: 10 April 2019

Vendor Name: <u>Tridium, Inc.</u> Product Name: <u>JACE-8000</u> Product Model Number: 12977

Application Software Version: Tridium 4.7.110.26

Firmware Revision: 4.7.110.26 BACnet Protocol Revision: 14

Product Description:

Niagara 4 provides the ability to view, monitor, and control BACnet devices over IP, raw Ethernet, or MS/TP media. Devices, points, schedules, alarms, and logs can be learned and managed from Niagara 4.

Niagara points, schedules, histories, and alarming can be exposed to BACnet for monitor and control by foreign BACnet clients. In addition, BACnet objects like trendlog, schedule, calendar and event enrollment can be dynamically created, deleted and modified in Niagara by foreign BACnet clients.

BACnet Standardized Device Profile (Annex L):

\square BA	ACnet Advanced Operator Workstation (B-AWS)
\square BA	ACnet Operator Workstation (B-OWS)
\square BA	ACnet Operator Display (B-OD)
$\boxtimes \mathbf{B}$	ACnet Building Controller (B-BC)
\square BA	ACnet Advanced Application Controller (B-AAC)
\square BA	ACnet Application Specific Controller (B-ASC)
\square BA	ACnet Smart Sensor (B-SS)
\square BA	ACnet Smart Actuator (B-SA)





Additional BACnet Interoperability Building Blocks Supported (Annex K):

Data Sharing Device & No DS-RP-A, B DM-DDB-A DS-RPM-A, B DM-DOB-B DS-WP-A, B DM-ADM-A DS-WPM-A, B DM-ANM-A DS-COV-A, B DM-TS-A, B DS-COVP-B DM-UTC-A DS-V-A DM-ATS-A DS-M-A DM-MTS-A DM-DCC-B	A A B , B
DS-RPM-A, B DS-WP-A, B DS-WPM-A, B DS-COV-A, B DS-COVP-B DS-V-A DS-W-A DM-DOB-B DM-ADM-A DM-ANM-A DM-ANM-A DM-ATS-A DM-ATS-A DM-MTS-A	A A B , B
DS-WP-A, B DS-WPM-A, B DS-COV-A, B DS-COVP-B DS-V-A DS-WPM-A, B DM-ANM-A DM-TS-A, E DM-UTC-A DM-ATS-A DM-MTS-A	A A B , B
DS-WPM-A, B DS-COV-A, B DS-COVP-B DS-V-A DS-M-A DS-M-A DS-M-A DM-ANM-A DM-TS-A, E DM-UTC-A DM-ATS-A DM-MTS-A	A 3 , B
DS-COV-A, B DS-COVP-B DS-V-A DS-M-A DM-TS-A, E DM-UTC-A DM-ATS-A DM-ATS-A	3 , B
DS-COVP-B DS-V-A DS-M-A DM-UTC-A DM-ATS-A DM-MTS-A	, B
DS-V-A DS-M-A DM-ATS-A DM-MTS-A	
DS-M-A DM-MTS-A	
DM-DCC-R	ı
BM BEE B	
DM-RD-B	
DM-BR-B	
DM-R-B	
DM-OCD-B	
DM-LM-A,	В
Alarm & Event Management Trending	
AE-N-A T-V-A	
AE-N-I-B T-VMT-I-B	Г-VMТ-Е-В
AE-N-E-B T-ATR-A, B	.
AE-ACK-A, B	
AE-ASUM-B	
AE-ESUM-B	
AE-INFO-B	
AE-VN-A	
AE-VM-A	
Scheduling Network Ma	anagement
SCHED-VM-A NM-RC-B	-
SCHED-I-B	
SCHED-E-B	





Segmentation Capability:

Feature	Supported	Window size
Transmit Segmented Messages	yes	10
Receive Segmented Messages	yes	any

Standard Object Types Supported:

- Calendar, Event-Enrollment, Notification-Class, Schedule, and Trend-Log Object types can be dynamically created and deleted
- No general range restrictions exist; however, certain specific applications may have specific range restrictions.
- All potentially available properties are listed for each object type.
- Optional properties are listed in *italics*. Not all instances support all optional properties.
- Writable properties are listed in **bold**. Any range limitations are expressed in parentheses following the property name.

Object Type	Properties	
Analog Input	Object_Identifier Object_Name Object_Type Present_Value Description Device_Type Status_Flags Event_State Reliability Out_Of_Service Update_Interval Units Min_Pres_Value Max_Pres_Value	Resolution COV_Increment Time_Delay (O) Notification_Class (O) High_Limit (O) Low_Limit (O) Deadband (O) Limit_Enable (O) Event_Enable (O) Acked_Transitions (O) Notify_Type (O) Event_Time_Stamps (O) Event-message-texts(O) Event-Detection-Enable (O) Property List





Object Type	Properties	
Analog Output	Object_Identifier Object_Name Object_Type Present_Value Description Device_Type Status_Flags Event_State Reliability Out_Of_Service Units Min_Pres_Value Max_Pres_Value Resolution Priority_Array Relinquish_Default	COV_Increment Time_Delay (O) Notification_Class (O) High_Limit (O) Low_Limit (O) Deadband (O) Limit_Enable (O) Event_Enable (O) Acked_Transitions (O) Notify_Type (O) Event_Time_Stamps (O) Event-message-texts(O) Event-Detection-Enable (O) Property List
Analog Value	Object_Identifier Object_Name Object_Type Present_Value Description Status_Flags Event_State Reliability Out_Of_Service Units Priority_Array Relinquish_Default Min_Pres_Value Max_Pres_Value Resolution	COV_Increment (O) Time_Delay (O) Notification_Class (O) High_Limit (O) Low_Limit (O) Deadband (O) Limit_Enable (O) Event_Enable (O) Acked_Transitions (O) Notify_Type (O) Event_Time_Stamps (O) Event-message-texts(O) Event-Detection-Enable (O) Property List





Object Type	Properties	
		Change_Of_State_Time (O)
	Object_Identifier	Change_Of_State_Count (0)
	Object_Name	Time_Of_State_Count_Reset (O)
	Object_Type	Elapsed_Active_Time (0)
	Present_Value	Time_Of_Active_Time_Reset (O)
	Description	Time_Delay (O)
	Device_Type	Notification_Class (O)
Binary Input	Status_Flags	Alarm_Value (O)
	Event_State	Event_Enable (O)
	Reliability	$Acked_Transitions(O)$
	Out_Of_Service	Notify_Type (O)
	Polarity	Event_Time_Stamps (O)
	Inactive_Text	Event-message-texts(O)
	Active_Text	Event-Detection-Enable (O)
		Property List
		Time_Of_State_Count_Reset (O)
	Object_Identifier	Elapsed_Active_Time (0)
	Object_Name	Time_Of_Active_Time_Reset (O)
	Object_Type	Minimum_Off_Time
	Present_Value	Minimum_On_Time
	Description	Priority_Array
	Device_Type	Relinquish_Default
	Status_Flags	Time_Delay (O)
Binary Output	Event_State	Notification_Class (O)
	Reliability	$Feedback_Value\left(O\right)$
	Out_Of_Service	Event_Enable (O)
	Polarity	$Acked_Transitions(O)$
	Inactive_Text	Notify_Type (O)
	Active_Text	Event_Time_Stamps (O)
	Change_Of_State_Time (O)	Event-message-texts(O)
	Change_Of_State_Count (0)	Event-Detection-Enable (O)
		Property List





Object Type	Properties	
		Elapsed_Active_Time (0)
	Object_Identifier	Time_Of_Active_Time_Reset (O)
	Object_Name	Minimum_Off_Time
	Object_Type	Minimum_On_Time
	Present_Value	Priority_Array
	Description	Relinquish_Default
	Status_Flags	Time_Delay (O)
Pinory Volue	Event_State	Notification_Class (O)
Binary Value	Reliability	Alarm_Value (O)
	Out_Of_Service	Event_Enable (O)
	Inactive_Text	Acked_Transitions (O)
	Active_Text	Notify_Type (O)
	Change_Of_State_Time (O)	Event_Time_Stamps (O)
	Change_Of_State_Count (0)	Event-message-texts(O)
	Time_Of_State_Count_Reset (O)	Event-Detection-Enable (O)
		Property List
	Object_Identifier Object_Name	Description
Calendar		Present_Value
Calelluar		Date_List
	Object_Type	Property List





Object Type	Properties	
3 3 1		Segmentation_Supported
		Max_Segments_Accepted
		Local_Time
		Local_Date
		UTC_Offset
		Daylight_Savings_Status
		APDU_Segment_Timeout
	Object_Identifier	APDU_Timeout
	Object_Name	Number_Of_APDU_Retries
	Object_Type	Time Synchronization Recipients
	System_Status	Max_Master
	Vendor_Name	Max_Info_Frames
	Vendor_Identifier	Device_Address_Binding
	Model_Name	Database_Revision
	Firmware_Revision	Configuration_Files
Device	Application_Software_Revision	Last_Restore_Time
	Location	Backup_Failure_Timeout
	Description	Backup Preparation Time
	Protocol_Version	Restore Preparation Time
	Protocol_Revision	Restore Completion Time
	Protocol_Services_Supported	Backup and Restore State
	Protocol_Object_Types_Supported	Active_COV_Subsriptions
	Object_List	Last Restart Reason
	Max_APDU_Length_Accepted	Time of Device Restart
		Restart Notification Recipients
		UTC Time Synchronization Recipients
		Time Synchronization Interval
		Align Interval
		Interval Offset
		Serial Number
		Property List
	Object_Identifier	File_Size
	Object_Name	Modification_Date
File	Object_Type	Archive
(Stream Access Only)	Description	Read_Only
	File_Type	File_Access_Method
	The_Type	Property List





Object Type	Properties		
	Object_Identifier	Object-Property-reference	
	Object_Name	Event-State	
	Object_Type	Event-Enable	
	Description	Acked_Transitions (O)	
Event Enrollment	Event-Type	Notification-Class	
	Notify-Type	Event_Time_Stamps (O)	
	Event-Parameters	Event-message-texts(O)	
	Status_Flags	Event-Detection-Enable (O)	
	Reliability	Property List	
	į.	Proportional_Constant_Units	
	Object_Identifier	Integral_Constant	
	Object_Name	Integral_Constant_Units	
	Object_Type	Derivative_Constant	
	Present_Value	Derivative_Constant_Units	
		Bias	
	Status_Flags	Maximum_Output	
	Event_State	Minimum_Output	
	Reliability	Priority_For_Writing	
	Out_Of_Service	COV_Increment	
Loop	Update_interval	Time_Delay	
1	Output_Units	Notification_Class	
	Manipulated_Variable_Reference	Error_Limit	
	Controlled_Variable_Reference	Deadband	
	Controlled_Variable_Value	Event_Enable	
	Controlled_Variable_Units	Acked_Transitions	
	Setpoint_Reference	Notify_Type	
	Setpoint	Event_Time_Stamps	
	Action	Event Message Texts	
	Proportional_Constant	Event Detection Enable	
		Property List	
		Number_Of_States	
		State_Text	
	Object_Identifier	Time_Delay (O)	
	Object_Name	Notification_Class (O)	
	Object_Type	Alarm_Values (O)	
	Present_Value	Fault_Values (O)	
Multi-state Input	Description Description	Event_Enable (O)	
ī	Device_Type Status_Floors	Acked_Transitions (O)	
	Status_Flags	Notify_Type (O)	
	Event_State	Event_Time_Stamps (O)	
	Reliability	Event Message Texts	
	Out_Of_Service	Event Detection Enable	
		Property List	





Object Type	Properties	
Multi-state Output	Object_Identifier Object_Name Object_Type Present_Value Description Device_Type Status_Flags Event_State Reliability Out_Of_Service Number_Of_States	Properties State_Text Priority_Array Relinquish_Default Time_Delay (O) Notification_Class (O) Feedback_Value (O) Event_Enable (O) Acked_Transitions (O) Notify_Type (O) Event_Time_Stamps (O) Event Message Texts Event Detection Enable Property List
Multi-state Value	Object_Identifier Object_Name Object_Type Present_Value Description Status_Flags Event_State Reliability Out_Of_Service Number_Of_States	State_Text Priority_Array Relinquish_Default Time_Delay (O) Notification_Class (O) Alarm_Values (O) Fault_Values (O) Event_Enable (O) Acked_Transitions (O) Notify_Type (O) Event_Time_Stamps (O) Event Message Texts Event Detection Enable Propery List
Notification Class	Object_Identifier Object_Name Object_Type Description	Notification_Class Priority Ack_Required Recipient_List Property List
Schedule	Object_Identifier Object_Name Object_Type Description Present Value Effective_Period Weekly_Schedule Exception_Schedule	Schedule_Default List_Of_Object_Property_References Priority_For_Writing Status_Flags Reliability Out_Of_Service Property List





Object Type	Properties	
Trend Log	Object_Identifier Object_Name Object_Type Description Enable Start_Time Stop_Time Log_DeviceObjectProperty Log_Interval COV_Resubscription_Interval Client_COV_Increment Stop_When_Full Buffer_Size	Log_Buffer Record_Count Total_Record_Count Logging Type Trigger Status Flags Notification_Threshold Records_Since_Notification Last_Notify_Record Event_State Notification_Class Event_Enable Acked_Transitions Notify_Type Event_Time_Stamps Event Message Texts Event Detection Enable Property List
Large Analog Value	Object_Identifier Object_Name Object_Type Present_Value Description Status_Flags Event_State Reliability Out_Of_Service Units Priority_Array Relinquish_Default Min_Pres_Value Max_Pres_Value Resolution	COV_Increment (O) Time_Delay (O) Notification_Class (O) High_Limit (O) Low_Limit (O) Deadband (O) Limit_Enable (O) Event_Enable (O) Acked_Transitions (O) Notify_Type (O) Event_Time_Stamps (O) Event-message-texts(O) Event-Detection-Enable (O) Property List





Object Type	Properties	
Integer Value	Object_Identifier Object_Name Object_Type Present_Value Description Status_Flags Event_State Reliability Out_Of_Service Units Priority_Array Relinquish_Default Min_Pres_Value Max_Pres_Value Resolution	COV_Increment (O) Time_Delay (O) Notification_Class (O) High_Limit (O) Low_Limit (O) Deadband (O) Limit_Enable (O) Event_Enable (O) Acked_Transitions (O) Notify_Type (O) Event_Time_Stamps (O) Event-message-texts(O) Event-Detection-Enable (O) Property List
Positive Integer Value	Object_Identifier Object_Name Object_Type Present_Value Description Status_Flags Event_State Reliability Out_Of_Service Units Priority_Array Relinquish_Default Min_Pres_Value Max_Pres_Value Resolution	COV_Increment (O) Time_Delay (O) Notification_Class (O) High_Limit (O) Low_Limit (O) Deadband (O) Limit_Enable (O) Event_Enable (O) Acked_Transitions (O) Notify_Type (O) Event_Time_Stamps (O) Event-message-texts(O) Event-Detection-Enable (O) Property List
Characterstring Value	Object_Identifier Object_Name Object_Type Present_Value Description Status_Flags Event_State Reliability Out_Of_Service Units Priority_Array Relinquish_Default Property List	





Object Type	Properties	
	Object_Identifier	
	Object_Name	
	Object_Type	
Structured-View	Description	
	Node-type	
	Node-Subtype	
	Subordinate-List	
	Subordinate-annotations	
	Property-List	





Data Link Layer Options:
 ☑ BACnet IP, (Annex J) ☑ BACnet IP, (Annex J), Foreign Device ☑ ISO 8802-3, Ethernet (Clause 7) ☐ ANSI/ATA 878.1, 2.5 Mb. ARCNET (Clause 8) ☐ ANSI/ATA 878.1, RS-485 ARCNET (Clause 8), baud rate(s) ☑ MS/TP master (Clause 9), baud rate(s): 9600, 19200, 38400, 76800, 115200 ☐ MS/TP slave (Clause 9), baud rate(s): ☐ Point-To-Point, EIA 232 (Clause 10), baud rate(s): ☐ Point-To-Point, modem, (Clause 10), baud rate(s): ☐ LonTalk, (Clause 11), medium: ☐ Other:
Device Address Binding:
Is static device binding supported? (This is currently necessary for two-way communication with MS/TP slaves and certain other devices.)
Networking Options:
 ⊠ Router, Clause 6 – Routing configurations: Ethernet-IP, Ethernet-MS/TP, IP-MS/TP □ Annex H, BACnet Tunneling Router over IP □ BACnet/IP Broadcast Management Device (BBMD) □ Does the BBMD support registrations by Foreign Devices? □ No □ No
Character Sets Supported:
Indicating support for multiple character sets does not imply that they can all be supported simultaneously.
 ISO 10646 (UTF-8) □ IBM[™]/Microsoft[™] DBCS □ ISO 8859-1 □ ISO 10646 (UCS-2) □ ISO 10646 (UCS-4) □ JIS X 0208