

Ê PHASOR TEMPLATES (Air: ε_r=μ_r=1)

Wavenumber per medium *nonmag.*
 $k_i = \frac{\omega\sqrt{\epsilon_{r,i}}}{c}$ (rad/m) $\Rightarrow k_2 = k_1\sqrt{\epsilon_{r,2}/\epsilon_{r,1}}$

Direction table *u* ∈ {x, y, z} = axis perp. to boundary

Inc dir	Inc	Refl	Trans
+û	e^{-jk_1u}	e^{+jk_1u}	e^{-jk_2u}
-û	e^{+jk_1u}	e^{-jk_1u}	e^{+jk_2u}

+û direction ⇔ Med 2 at u ≥ 0. Reflected sign flips, transmitted matches incident.

General template (incident has pol. ê, amplitude a₀):
Êⁱ = a₀ê e^{±jk₁u} (V/m) (incident wave, Med 1)
Ê^r = Γ a₀ê e^{±jk₁u} (V/m) (reflected wave, Med 1)
Ê^t = τ a₀ê e^{±jk₂u} (V/m) (transmitted wave, Med 2)
(lossy med 2: replace e^{±jk₂u} with e^{∓α₂u} e^{±jβ₂u})
Total in medium 1: Ê₁ = Êⁱ + Ê^r.
ê by polarization *plug into templates above*

Pol.	ê	Note
Lin. x̂	x̂	E _y = 0
Lin. ŷ	ŷ	E _x = 0
Lin. at 45°	(x̂ + ŷ)/√2	in phase
RHC	x̂ - jŷ	δ = -π/2
LHC	x̂ + jŷ	δ = +π/2
General	a _x x̂ + a _y e ^{jδ} ŷ	elliptical

Γ, τ act on ê unchanged. Only swap the polarization, not the formulas.

TABLE 8-2 — Γ, τ, R, T SUMMARY

Med. 1 (z < 0) incident side; Med. 2 (z ≥ 0) transmitted.

	Normal ⊥ pol (θ _i = 0)	pol
Γ refl. wav	$\frac{\eta_2 - \eta_1}{\eta_2 + \eta_1}$	$\frac{\eta_2 \cos \theta_i - \eta_1 \cos \theta_t}{\eta_2 \cos \theta_i + \eta_1 \cos \theta_t}$
τ trans. wav	$\frac{2\eta_2}{\eta_2 + \eta_1}$	$\frac{2\eta_2 \cos \theta_i}{\eta_2 \cos \theta_i + \eta_1 \cos \theta_t}$
τ rel.	τ = 1 + Γ	τ = (1 + Γ) $\frac{\cos \theta_i}{\cos \theta_t}$
R refl. pwr	Γ ²	Γ ²
T trans. pwr	τ ² $\frac{\eta_1}{\eta_2}$	τ ² $\frac{\eta_1 \cos \theta_t}{\eta_2 \cos \theta_i}$
R + T total	T = 1 - R	T = 1 - R

Notes: sin θ_t = √μ₁ε₁/μ₂ε₂ sin θ_i; nonmag. ⇒ η₂/η₁ = n₁/n₂.

Intrinsic impedance η_i *plug into table above*
η_i = √ $\frac{\mu_r}{\epsilon_r}$ η₀ $\xrightarrow{\mu_r=1}$ $\frac{\eta_0}{\sqrt{\epsilon_{r,i}}}$ (Ω) η₀ = 120π ≈ 377 Ω

Default μ_r = 1 (air, dielectric). Use μ_r ≠ 1 only if problem says “ferromagnetic”/iron/ferrite/etc.

Low-loss correction η_c σ/(ωε) ≪ 1
η_c ≈ √ $\frac{\mu}{\epsilon'}$ (1 + j $\frac{\sigma}{2\omega\epsilon'}$) $\xrightarrow{\text{drop } j}$ $\frac{\eta_0}{\sqrt{\epsilon_r}}$

For Γ/τ just use η₀/√ε_r. The j term is for |η_c|, θ_η. See LOSSY MEDIA — 5 CASES for all regimes.

POWER REFLECTION & TRANSMISSION

% reflected *always*
%P_r = 100 |Γ|²

% transmitted *η-ratio matters!*
%P_t = 100 |τ|² $\frac{\eta_1}{\eta_2}$

Check: %P_r + %P_t = 100.

SNELL'S LAW — OBLIQUE INCIDENCE

Single boundary *angles from normal*
sin θ₂ = sin θ₁ √ $\frac{\epsilon_{r,1}}{\epsilon_{r,2}}$ = sin θ₁ $\frac{n_1}{n_2}$

Multilayer chain *stack of slabs 1 → 2 → 3 → 4*
sin θ_{i+1} = sin θ_i √ $\frac{\epsilon_{r,i}}{\epsilon_{r,i+1}}$

Air-slabs-air shortcut *outer media identical*
θ_{exit} = θ_{incident}

Snell only sets angles. Reflection/transmission magnitudes need Fresnel coefficients (parallel vs perpendicular).

LATERAL DISPLACEMENT

Beam offset through N slabs thickness t_i, refracted angle inside slab i
Slab-indexed θ_i = angle inside slab i; t_i = slab thickness (m)

$$d = \sum_{i=1}^N t_i \tan \theta_i$$

The angle (θ_i) in the formula is always the one the ray makes inside that slab of height (t_i).

LOSSY MEDIA — 5 CASES

Loss tangent ε' = ε_rε₀; ε₀ = 8.854 × 10⁻¹² F/m
 $\frac{\epsilon''}{\epsilon'} = \frac{\sigma}{\omega \epsilon_r \epsilon_0}$

Type	σ/ωε	η _c , α, β
Lossless (σ = 0)	0	η = η ₀ /√ε _r exact α = 0, β = ω√ε _r /c
Low-loss	< 10 ⁻²	η _c ≈ $\frac{\eta_0}{\sqrt{\epsilon_r}}$ (1 + j $\frac{\sigma}{2\omega\epsilon'}$)
Quasi-cond.	10 ⁻² –10 ²	exact: (η/√X) e ^{jθ} η see below
Good cond.	> 10 ²	η _c ≈ (1 + j) √ $\pi f \mu / \sigma$ α ≈ β ≈ √ $\pi f \mu \sigma$
Magnetic	any	keep full √μ _r /ε _r η ₀

For Γ/τ: drop j correction; use η₀/√ε_r. Magnetic: keep μ_r.

Low-loss quick params σ/(ωε) ≪ 1, μ_r = 1
α ≈ $\frac{\sigma \eta_0}{2\sqrt{\epsilon_r}}$ (Np/m), β ≈ $\frac{\omega\sqrt{\epsilon_r}}{c}$ (rad/m), η_c ≈ $\frac{\eta_0}{\sqrt{\epsilon_r}}$ (Ω)

Exact (quasi-cond) X = √(1 + (ε''/ε')²)
α = ω √ $\frac{\mu\epsilon'}{2}$ √X - 1, β = ω √ $\frac{\mu\epsilon'}{2}$ √X + 1
θ_η = $\frac{1}{2} \arctan \frac{\sigma}{\omega\epsilon'}$

RECTANGULAR WAVEGUIDE — MODES

TE mode E_z = 0, H_z ≠ 0
TM mode H_z = 0, E_z ≠ 0
Dimensions a × b with a > b along x̂, ŷ; wave in ẑ.
E_x form (TE) *read m, n from arguments*
E_x ∝ cos($\frac{m\pi x}{a}$) sin($\frac{n\pi y}{b}$) sin(ωt - βz)
coef. on x = mπ/a; coef. on y = nπ/b.

Identify TE_{m,n} vs TM_{m,n} *cos/sin pattern of E_x is identical for both!*
1. Read the problem statement (e.g. “a TE wave” → TE).
2. If m = 0 or n = 0 in the mode label ⇒ must be TE (TM forbids 0).
3. Source field H_z(x, y) given ⇒ TE. Source field E_z(x, y) given ⇒ TM.
TE allows at least one of m, n ≥ 1 (other can be 0). TM needs both m, n ≥ 1. That's why TE₁₀ exists but TM₁₀ doesn't.

TABLE 8-3 — FULL FIELD COMPONENTS

All fields carry an e^{-jβz} factor (omitted below).
k_c² = (mπ/a)² + (nπ/b)².

TE mode *generator: Ê_z*
Ê_z = H₀ cos $\frac{m\pi x}{a}$ cos $\frac{n\pi y}{b}$
Ê_x = -j $\frac{\omega\mu}{k_c^2}$ ($\frac{n\pi}{b}$) H₀ cos $\frac{m\pi x}{a}$ sin $\frac{n\pi y}{b}$
Ê_y = -j $\frac{\omega\mu}{k_c^2}$ ($\frac{m\pi}{a}$) H₀ sin $\frac{m\pi x}{a}$ cos $\frac{n\pi y}{b}$
Ê_z = 0, Ê_x = -Ê_y/Z_{TE}, Ê_y = Ê_x/Z_{TE}

TM mode *generator: Ê_z*
Ê_z = E₀ sin $\frac{m\pi x}{a}$ sin $\frac{n\pi y}{b}$
Ê_x = -j $\frac{\beta}{k_c^2}$ ($\frac{m\pi}{a}$) E₀ cos $\frac{m\pi x}{a}$ sin $\frac{n\pi y}{b}$
Ê_y = -j $\frac{\beta}{k_c^2}$ ($\frac{n\pi}{b}$) E₀ sin $\frac{m\pi x}{a}$ cos $\frac{n\pi y}{b}$
Ê_z = 0, Ê_x = -Ê_y/Z_{TM}, Ê_y = Ê_x/Z_{TM}

TEM (plane wave) for reference: Ê_x = E₀e^{-jβz}, Ê_y = Ê_x/η, f_c N/A, k = ω√μ̵.

CUTOFF FREQUENCY

f_{mn} (a.k.a. f_c for that mode) *m, n integers ≥ 0 (not both zero)*

$$f_c \equiv f_{mn} = \frac{u_p^0}{2} \sqrt{\left(\frac{m}{a}\right)^2 + \left(\frac{n}{b}\right)^2} \text{ (Hz)}$$

Common cutoffs (a > b)

Mode	f _{mn}
u _{p0}	c/√ε _r (hollow: u _{p0} = c)
TE ₁₀	f ₁₀ = u _{p0} /(2a) (dominant)
TE ₀₁	f ₀₁ = u _{p0} /(2b)
TE ₂₀	f ₂₀ = u _{p0} /a = 2f ₁₀
TE ₁₁ , TM ₁₁	f ₁₁ = $\frac{u_{p0}}{2} \sqrt{1/a^2 + 1/b^2}$

Propagation requires f > f_{mn}. In Z_{TE}/Z_{TM} and u_g, f_c = f_{mn} of the excited mode.

ε_r, FROM DISPERSION

Given ω, β, mode (m, n) *result is unitless*
ε_r = $\frac{c^2}{\omega^2} \left[\beta^2 + \left(\frac{m\pi}{a}\right)^2 + \left(\frac{n\pi}{b}\right)^2 \right]$ (unitless)

Inputs: ω (rad/s), β (rad/m), a, b (m), c = 3 × 10⁸ (m/s), m, n (unitless).

WAVE IMPEDANCE & H_y

Z_{TE} = $\frac{\eta}{\sqrt{1 - (f_c/f)^2}}$ (Ω) Z_{TM} = η √(1 - (f_c/f)²)
η = $\frac{\eta_0}{\sqrt{\epsilon_r}}$ H_y = $\frac{E_x}{Z_{TE}}$ (TE mode)
Z_{TE} > η always (denominator < 1); Z_{TM} < η.

GROUP VELOCITY & TRAVEL TIME

u_g = u_{p0} √(1 - (f_{mn}/f)²) (m/s)
u_p = $\frac{u_{p0}}{\sqrt{1 - (f_{mn}/f)^2}}$ (m/s) ⇒ u_pu_g = u_{p0}² (m²/s²)
t = L/u_g (s) travel time through guide of length L
Higher modes have lower u_g ⇒ they arrive later. Group delay spread = sum over excited modes.

BOUNDARY

η₁, η₂ — imp. (Ω)
Γ, τ, R, T — coeffs (unitless)
τ = 1 + Γ; R = |Γ|²
k_i = ω√ε_{r,i}/c (rad/m)
α₂ (Np/m), β₂ (rad/m): lossy
z = 0 — boundary plane (m)
η₀ = 120π ≈ 377 Ω

SNELL / OBLIQUE

θ_i, θ_t — angles from normal
n_i = √ε_{r,i} — index of refr.
t_i — slab thickness (m)
d — lateral disp. (m)
plane of inc. = plane of k̂ + normal
⊥: Ê ⊥ this plane
||: Ê || this plane

WAVEGUIDE

a, b — wide, narrow dim. (m);
a > b
m, n — mode indices (int.)
f_{mn} — cutoff (Hz)
β — prop. const (rad/m)
Z_{TE}/Z_{TM} — wave imp. (Ω)
E_x, H_y — field comps (V/m, A/m)
η = η₀/√ε_r

VELOCITIES

u_{p0} = c/√ε_r — bulk phase vel.
u_p = u_{p0}/√(1 - (f_c/f)²)
u_g = u_{p0} √(1 - (f_c/f)²)
u_pu_g = u_{p0}²
t = L/u_g — travel time
c = 3 × 10⁸ m/s

POWER & UNITS

%P_r = 100 |Γ|²
%P_t = 100 |τ|² η₁/η₂
%P_r + %P_t = 100
σ (S/m), ε (F/m), μ (H/m)
ε₀ = 8.85 × 10⁻¹² F/m
μ₀ = 4π × 10⁻⁷ H/m
1/(36π) × 10⁻⁹ ≈ ε₀