

DIPOLE TYPE BY LENGTH
l = antenna rod length (m)

λ (wavelength) = $\frac{c}{f} = \frac{3 \times 10^8}{f}$ (m)		
<i>l</i> /λ	Type	Use formula
< 1/50	Hertzian (short)	HERTZIAN $S(R, \theta)$, $D=1.5$
= 1/4	Quarter-wave	ARB formula, $\pi l/\lambda = \pi/4$
= 1/2	Half-wave	half-wave shortcut, $D=1.64$, $R_{\text{rad}}=73 \Omega$
= 1	Full-wave	ARB, $D=2.41$, $R_{\text{rad}}=199 \Omega$
other	Arbitrary	ARB formula

HERTZIAN DIPOLE — $S(R, \theta)$

Far-field E,H phasors small $l \ll \lambda$ $\vec{E}_\theta = \frac{jI_0 k l \eta_0}{4\pi R} e^{-jkR} \sin \theta$, $\vec{H}_\phi = \vec{E}_\theta / \eta_0$ Power density formulas $l/\lambda < 1/50$; far field	
Power density	$S(R, \theta) = S_{\text{max}} \sin^2 \theta$ (W/m ²)
Max pwr density	$S_{\text{max}} = \frac{\eta_0 k^2 I_0^2 l^2}{32\pi^2 R^2}$ (W/m ²)
<i>l</i> : rod length (m) <i>R</i> : obs. distance (m)	I_0 : peak current (A) θ : angle from dipole axis (rad)
$k=2\pi/\lambda$ (rad/m)	$\eta_0=120\pi \approx 377 \Omega$
Total radiated power	$P_{\text{rad}} = \frac{\eta_0 \pi}{3} (I_0 l / \lambda)^2$ (W)

ARBITRARY-LENGTH DIPOLE — $S(\theta)$

Power density at <i>R</i> any l $S(\theta) = \frac{15 I_0^2}{\pi R^2} \left[\frac{\cos(\frac{\pi l}{\lambda} \cos \theta) - \cos(\frac{\pi l}{\lambda})}{\sin \theta} \right]^2$ <i>At $\theta=0, \pi$: bracket is 0/0. L'Hôpital $\Rightarrow S=0$ (no axial radiation). TI-36X Pro alt: evaluate bracket at $\theta=0.001$ rad $\rightarrow$ tiny $\rightarrow 0$.</i> Normalized pattern dimensionless $F(\theta)=S(\theta)/S_{\text{max}}$
--

COMMON ANGLES (deg $\leftrightarrow$ rad, trig values)

Conversion multiply by $\frac{\pi}{180}$ or $\frac{180}{\pi}$

$\theta_{\text{rad}} = \theta_{\text{deg}} \cdot \frac{\pi}{180}$ $\theta_{\text{deg}} = \theta_{\text{rad}} \cdot \frac{180}{\pi}$

°	rad	sin θ	cos θ	sin ² θ	cos ² θ
0	0	0	1	0	1
30	$\pi/6$	1/2	$\sqrt{3}/2$	1/4	3/4
45	$\pi/4$	$\sqrt{2}/2$	$\sqrt{2}/2$	1/2	1/2
60	$\pi/3$	$\sqrt{3}/2$	1/2	3/4	1/4
90	$\pi/2$	1	0	1	0
180	π	0	-1	0	1

Antenna formulas usually take θ in rad. RAD mode on calc.

LINEAR ANTENNA ARRAY

<i>N</i> identical elements along axis, spacing <i>d</i> , equal phase (broadside, $\theta_{\text{max}} = \pi/2$). Total pattern $S = S_e \cdot F_a$ (S_e = single elem).
Array factor (uniform, broadside) $k = 2\pi/\lambda$, $\gamma = kd \cos \theta$ $F_a(\theta) = \frac{\sin^2(N\gamma/2)}{\sin^2(\gamma/2)}$; $F_a^{\text{max}} = N^2$ at $\theta = \pi/2$
Normalize $F_a^{\text{norm}} = F_a/N^2$
HPBW (broadside, uniform) use Nd, not $(N-1)d$ $\beta \approx 0.88 \frac{\lambda}{Nd}$ (rad) = $50.8^\circ \cdot \frac{\lambda}{Nd}$ <i>Grating lobes appear if $d > \lambda$. Avoid.</i>

BEAM PARAMETERS — β , Ω_p , *D*

Normalize always start here $F(\theta) = S(\theta)/S_{\text{max}}$ (unitless) Beamwidth β at threshold <i>X</i> Set $F(\theta_X) = X$, solve for θ_X ; $\beta = 2\theta_X$ (symmetric)		
Threshold	$X=10^{\text{dB}/10}$	θ_X (Gauss. short-cut)
HPBW (−3 dB)	0.5	$\sqrt{\frac{\ln 2}{a}}$
−6 dB	0.25	$\sqrt{\frac{\ln 4}{a}}$
−10 dB	0.1	$\sqrt{\frac{\ln 10}{a}}$
any $F(\theta_X)$	any <i>X</i>	$F(\theta_X) = X$
Pattern solid angle Ω_p recognize pattern, look up $\Omega_p = \int_0^{2\pi} \int_0^\pi F(\theta) \sin \theta \, d\theta \, d\phi$ (sr) <i>No ϕ dep.</i> : $\Omega_p = 2\pi \int_0^\pi F(\theta) \sin \theta \, d\theta$. <i>θ is the integration variable — DON'T plug in a number for θ (e.g. $\theta_{1/2}$). Integrate over $\theta \in [0, \pi]$.</i>		
Pattern $F(\theta)$	Ω_p (sr)	
Isotropic ($F=1$)	$4\pi \approx 12.57$	
Hertzian sin ² θ	$8\pi/3 \approx 8.38$	
Half-wave dipole	≈ 7.66	
Narrow Gauss $e^{-a\theta^2}$	$\pi/a = \pi\theta_{1/2}^2 / \ln 2$	
2-axis HPBW (aperture)	$\beta_{xz} \cdot \beta_{yz}$	
Other (use integral)	numerical	

TI-36X Pro: [2nd] [d/dx] for $\int_{\square}^{\square}$, RAD mode, multiply by 2 π .

Directivity <i>D</i> always $D=4\pi/\Omega_p$; common shortcuts below $D = \frac{4\pi}{\Omega_p}$ (unitless) $D_{\text{dB}} = 10 \log_{10} D$
WORD TRAP: “direction” = θ_{max} (rad); “directivity” = <i>D</i> (unitless). Dipoles $\rightarrow$ COMMON DIPOLE PARAMS table. Aperture: $D \approx 4\pi A_p / \lambda^2$. 2-axis HPBW: $D \approx 4\pi / (\beta_{xz} \beta_{yz})$. Circular: $D \approx 4\pi / \beta^2$. Gain (if asked) $\xi = \text{rad. eff.}$, $0 < \xi \leq 1$ $G = \xi D$ $G_{\text{dB}} = 10 \log_{10} G$
Lossless / ideal antenna $\Rightarrow G = D$.

COMMON DIPOLE PARAMETERS

Lossless ($\xi=1$): $G=D$.				
Type	<i>l</i>	<i>D</i>	<i>D</i> _{dB}	<i>R</i> _{rad} (Ω)
Isotropic	N/A	1	0	—
Hertzian	< $\lambda/50$	1.5	1.76	$80\pi^2(l/\lambda)^2$
Half-wave	$\lambda/2$	1.64	2.15	73.2
Monopole	$\lambda/4$ (gnd)	1.64	2.15	36.6
Full-wave	λ	2.41	3.82	199

Half-wave: $P_{\text{rad}} = 36.6 I_0^2 W$. Monopole ($\lambda/4$ above ground): same patt. as half-wave but P_{rad} , R_{rad} halved.

ANTENNA AREAS (A_e , A_p)

Effective area antenna's RX cross section; <i>D</i> from BEAM PARAMS or table above $A_e = \frac{\lambda^2 D}{4\pi}$ (m ²)
Physical cross section wire dipole, diameter <i>d</i>; <i>l</i> see table above $A_p = l d$ (m ² , any dipole)
Inverse: <i>D</i> from A_e $D = \frac{4\pi A_e}{\lambda^2}$ (unitless)
Thin wire: $A_e \gg A_p$ (e.g., Hertzian $A_e = 3\lambda^2/8\pi \approx 0.119\lambda^2$).

FRISIS TRANSMISSION FORMULA

For each antenna's *G*: if given by NAME (“half-wave dipole” etc.) $\rightarrow$ COMMON DIPOLE PARAMS ($G=D$, lossless). Else (dB/linear value given) $\rightarrow$ use as given (convert dB $\rightarrow$ linear).

Pwr density at RX, then RX pwr G_t, G_r linear gains; $\lambda = c/f$

$$S_r = \frac{G_t P_t}{4\pi R^2} \text{ (W/m}^2\text{); } P_r = G_t G_r \left(\frac{\lambda}{4\pi R} \right)^2 P_t \text{ (W)}$$

Equivalent: $P_r = S_r A_{e,r}$.

Solve for *R* max range

$$R = \frac{\lambda}{4\pi} \sqrt{\frac{G_t G_r P_t}{P_r}}$$

Equivalent form using A_e recv. area form

$$P_r = \frac{G_t P_t A_{e,r}}{4\pi R^2}, \quad G_r = \frac{4\pi A_{e,r}}{\lambda^2}$$

Free-space path loss: $L_{fs} = (4\pi R/\lambda)^2$, so $P_r = G_t G_r P_t / L_{fs}$.

Off-axis (patterns not aligned): multiply by $F_t(\theta_t, \phi_t) F_r(\theta_r, \phi_r)$, both = 1 when aligned.

Recipe 1. $\lambda = c/f$. 2. Convert any dB gain $\rightarrow$ linear: $G=10^{G_{\text{dB}}/10}$.

3. Get G_t, G_r by antenna type: dipole $\rightarrow$ COMMON DIPOLE PARAMS; aperture $\rightarrow$ APERTURE box; arbitrary *F* $\rightarrow$ BEAM PARAMS. 4. Plug into Friis.

Use linear *G*, not dB. Convert FIRST.

dB $\leftrightarrow$ LINEAR

Works for any power-like quantity (*G*, *D*, P_r/P_t , SNR, ...):

$$X_{\text{dB}} = 10 \log_{10} X_{\text{lin}} \quad X_{\text{lin}} = 10^{X_{\text{dB}}/10}$$

dB	linear	dB	linear
0	1	10	10
3	2	13	20
6	4	20	100
7	5	30	1000
−3	0.5	−10	0.1

Memorize: 3 dB $\Leftrightarrow \times 2$, 10 dB $\Leftrightarrow \times 10$. Add dB = multiply linear.

For E-field / amplitude use 20 log not 10 log (power $\propto E^2$).

NOISE & SNR

Noise power thermal noise into matched receiver

$$P_N = k_B T_{\text{sys}} B \text{ (W)}$$

$k_B = 1.38 \times 10^{-23}$ J/K; T_{sys} system noise temp (K); *B* receiver bandwidth (Hz).

Signal-to-noise ratio

$$\text{SNR} = \frac{P_{\text{rec}}}{P_N} \text{ (unitless)} \quad \text{SNR}_{\text{dB}} = 10 \log_{10} \frac{P_{\text{rec}}}{P_N}$$

Typical comm. link needs SNR > 10 dB for usable signal.

APERTURE ANTENNAS (horn, dish)

A_p physical aperture area (m²); *A_e* effective area (m², = $\lambda^2 D/4\pi$); β_{xz}, β_{yz} HPBW's in two planes (rad); ℓ , *d* aperture side / diameter (m).

Directivity (any shape, uniform illum.)

$$D \approx \frac{4\pi A_p}{\lambda^2} \text{ (unitless)} \Rightarrow A_e \approx A_p$$

Directivity from beamwidths any aperture

$$D \approx \frac{4\pi}{\beta_{xz} \beta_{yz}} \text{ (use rad); circular: } D \approx 4\pi/\beta^2$$

HPBW and <i>D</i> by aperture shape uniform illum.; β in rad			
Shape	<i>A_p</i>	HPBW (rad)	<i>D</i> (unitless)
Rect. $\ell_x \times \ell_y$	$\ell_x \ell_y$	$\beta_x \approx 0.88\lambda/\ell_x$ $\beta_y \approx 0.88\lambda/\ell_y$	$D \approx 4\pi/(\beta_x \beta_y)$ $= 4\pi \ell_x \ell_y / \lambda^2$
Square ℓ	ℓ^2	$\beta \approx 0.88\lambda/\ell$	$D \approx 4\pi/\beta^2 = 4\pi \ell^2 / \lambda^2$
Circular (diam. <i>d</i>)	$\pi d^2/4$	$\beta \approx 1.02\lambda/d$	$D \approx 4\pi/\beta^2 = \pi^2 d^2 / \lambda^2$

Scaling (any ratio) $D \propto A_p/\lambda^2$; $\beta \propto \lambda/\sqrt{A_p}$

$$D_{\text{new}} = D_{\text{old}} \cdot \frac{A_{p,\text{new}}}{A_{p,\text{old}}} \cdot \left(\frac{f_{\text{new}}}{f_{\text{old}}} \right)^2$$

$$\beta_{\text{new}} = \beta_{\text{old}} \cdot \sqrt{\frac{A_{p,\text{old}}}{A_{p,\text{new}}}} \cdot \frac{f_{\text{old}}}{f_{\text{new}}}$$

If a parameter is unchanged, its ratio = 1. Examples: double area $\rightarrow D \times 2$, $\beta \times 1/\sqrt{2}$; double freq $\rightarrow D \times 4$, $\beta \times 1/2$.

DIPOLE

<i>l</i> — antenna length (m) $\lambda = c/f$ (m); $c = 3 \times 10^8$ m/s I_0 — peak current (A) $k = 2\pi/\lambda$ (rad/m) <i>R</i> — obs. dist. (m); θ from axis $\eta_0 = 120\pi \approx 377 \Omega$ $S(R, \theta)$ — pwr density (W/m ²)
--

BEAM

$F(\theta) = S/S_{\text{max}}$ (unitless) <i>a</i> — coef. on θ^2 in Gaussian β — HPBW (rad or °) Ω_p — pattern solid angle (sr) <i>D</i> — $4\pi/\Omega_p$ — directivity ξ rad. eff.; $G = \xi D$ $D_{\text{dB}} = 10 \log_{10} D$; $D = 10^{D_{\text{dB}}/10}$

FRISIS / dB

<i>P_t</i> — power transmitted (W) <i>P_r</i> — power received (W) <i>G_t</i> — transmit gain (linear) <i>G_r</i> — receive gain (linear) $S_r = G_t P_t / (4\pi R^2)$ (W/m ²) $P_r = G_t G_r (\lambda/4\pi R)^2 P_t$ $G = 10^{G_{\text{dB}}/10}$ 3 dB = $\times 2$, 10 dB = $\times 10$ $P_N = k_B T_{\text{sys}} B$ (W)
--

APERTURE

<i>A_p</i> — physical area (m ²) $A_e = \lambda^2 D / (4\pi)$ (m ²) $A_e \approx A_p$ for aperture $D \approx 4\pi A_p / \lambda^2$ (unitless) $\beta \approx 0.88\lambda/\ell$ (rect/sq.) $\beta \approx 1.02\lambda/d$ (circular) $2A_p \Rightarrow 2D$, $\beta/\sqrt{2}$
--

ARRAY

<i>N</i> — number of elements <i>d</i> — spacing (m) $\gamma = kd \cos \theta$ $F_a = \sin^2(N\gamma/2) / \sin^2(\gamma/2)$ $F_a^{\text{max}} = N^2$ at $\theta = \pi/2$ $F_a^{\text{norm}} = F_a/N^2$ $F_a \approx 0.88\lambda/(Nd)$ (broadside)
