HOW TO: Printer Calibration	Version: 1.0.0
Printer Name: Zebra	Printer Model: TLP2844
Author: Yamija Munthali	Date Issued: 2 November, 2017



Step 1:

Make sure the printer is off (If the printer is on please turn it off)



Step 2:

Press and hold the spooler button



Step 3:

Without releasing the spooler button Switch on the printer, wait until the light around the spooler button flashes three times, then release the spooler button

The printer will start printing, wait until it finishes printing.

Step 4:

Press the spooler button once to exit the dump mode

The printer will print out of dump signaling the end calibration