search blog...

- Home
- Forum
- Wiki
- Code
 - o <u>RSS</u>
 - o <u>Twitter</u>
 - o <u>Facebook</u>

Search Wiki Search Forum Search Blog

Search

Login / Register


• About





Sensing Humidity With The SHT15 + Arduino

Tuesday, November 27 th, 2012



The SHT15 is a digital humidity sensor that outputs a fully calibrated humidity reading. And... because what we are measuring is actually relative humidity, and relative humidity being relative to temperature, the SHT15 has a builtin digital thermometer. This makes things much easier to work with than sensors without a thermometer onboard. You can pick one up from sparkFun here.

Hooking it up

The SHT15 uses a two-wire connection for communication that is similar to, but not, I2C. So we wont be able to use the Arduino's dedicated lines for this. The down side is it is a bit slower to get readings from, the plus side is that you can connect it to any 2 digital pins you want. We are using pins 2 and 3 on our arduino.

BEFORE YOU SOLDER IT UP... Note that this board can not be washed! So if you are using flux, or solder that you normally clean up, don't (They actually recommend to use "no-clean" solder just so you don't have to worry about it). And be extremely careful not to get it wet at all.

AFTER YOU SOLDER IT UP... To get a clean reading, the sensor needs to be stored at >75% humidity for at least 12 hours to allow the polymer to re-hydrate (just what the doc says). If you don't, your SHT15 may read an offset that slowly disappears if exposed to ambient conditions. Alternatively the re-hydration process may be performed at ambient conditions (>40% Humidity) for 5 + days.


Im not exactly sure how you do that... But someone noted that they put it in a ziplock with a wet towel (not touching) for 12H.

Code

The code for this is a bit wacky (as with most digital sensors), but it is split up pretty nicely, and is as easy to read as it can be.

Note that the readings are a bit slow to return a value (100+ ms).

1 de 4 26/02/2017 12:03



Copy Code

```
//Based of the wiring code at http://wiring.org.co/learning/basics/humiditytemperaturesht15.html
int SHT_clockPin = 3; // pin used for clock
int SHT_dataPin = 2; // pin used for data
void setup(){
  Serial.begin(9600); // open serial at 9600 bps
void loop(){
  //these can take a bit to get the values (100ms or so)
  float temperature = getTemperature();
  float humidity = getHumidity();
  Serial.print(temperature);
Serial.print(" | ");
  Serial.println(humidity);
}
float getTemperature(){
  //Return Temperature in Celsius
  SHT_sendCommand(B00000011, SHT_dataPin, SHT_clockPin);
  SHT_waitForResult(SHT_dataPin);
  int val = SHT_getData(SHT_dataPin, SHT_clockPin);
  SHT_skipCrc(SHT_dataPin, SHT_clockPin);
  return (float)val * 0.01 - 40; //convert to celsius
float getHumidity(){
  //Return Relative Humidity
  SHT_sendCommand(B00000101, SHT_dataPin, SHT_clockPin);
  SHT_waitForResult(SHT_dataPin);
  int val = SHT_getData(SHT_dataPin, SHT_clockPin);
  SHT_skipCrc(SHT_dataPin, SHT_clockPin);
  return -4.0 + 0.0405 * val + -0.0000028 * val * val;
```

2 de 4 26/02/2017 12:03

```
void SHT_sendCommand(int command, int dataPin, int clockPin){
 // send a command to the SHTx sensor
  // transmission start
 pinMode(dataPin, OUTPUT);
 pinMode(clockPin, OUTPUT);
 digitalWrite(dataPin, HIGH);
 digitalWrite(clockPin, HIGH);
 digitalWrite(dataPin, LOW);
 digitalWrite(clockPin, LOW);
 digitalWrite(clockPin, HIGH);
 digitalWrite(dataPin, HIGH);
 digitalWrite(clockPin, LOW);
  // shift out the command (the 3 MSB are address and must be 000, the last 5 bits are the command)
 shiftOut(dataPin, clockPin, MSBFIRST, command);
  // verify we get the right ACK \,
 digitalWrite(clockPin, HIGH);
 pinMode(dataPin, INPUT);
 if (digitalRead(dataPin)) Serial.println("ACK error 0");
 digitalWrite(clockPin, LOW);
 if (!digitalRead(dataPin)) Serial.println("ACK error 1");
void SHT_waitForResult(int dataPin){
 // wait for the SHTx answer
 pinMode(dataPin, INPUT);
 int ack; //acknowledgement
  //need to wait up to 2 seconds for the value
 for (int i = 0; i < 1000; ++i) \{
   delay(2);
    ack = digitalRead(dataPin);
   if (ack == LOW) break;
 if (ack == HIGH) Serial.println("ACK error 2");
int SHT_getData(int dataPin, int clockPin){
  // get data from the SHTx sensor
 // get the MSB (most significant bits)
 pinMode(dataPin, INPUT);
 pinMode(clockPin, OUTPUT);
 byte MSB = shiftIn(dataPin, clockPin, MSBFIRST);
  // send the required ACK
 pinMode(dataPin, OUTPUT);
 digitalWrite(dataPin, HIGH);
 digitalWrite(dataPin, LOW);
 digitalWrite(clockPin, HIGH);
 digitalWrite(clockPin, LOW);
  // get the LSB (less significant bits)
 pinMode(dataPin, INPUT);
 byte LSB = shiftIn(dataPin, clockPin, MSBFIRST);
 return ((MSB << 8) | LSB); //combine bits
void SHT_skipCrc(int dataPin, int clockPin) {
 // skip CRC data from the SHTx sensor
 pinMode(dataPin, OUTPUT);
 pinMode(clockPin, OUTPUT);
 digitalWrite(dataPin, HIGH);
 digitalWrite(clockPin, HIGH);
 digitalWrite(clockPin, LOW);
```

Unless otherwise stated, this code is released under the MIT License - Please use, change and share it.

Tweet Me gusta $\frac{29}{No Comments}$

Archives

- October 2013
- November 2012
- August 2012
- April 2012
- March 2012
- February 2012
- January 2012
- October 2011
- September 2011

3 de 4 26/02/2017 12:03

- August 2011
- <u>July 2011</u>
- June 2011
- May 2011
- April 2011March 2011
- February 2011
- January 2011
- December 2010
- November 2010
- October 2010
- September 2010

Categories

- <u>funded projects</u>
- Promotions
- Review
- <u>Site</u>
- Tutorials
- <u>User Contributed Articles</u>
- User Project

about

- Content available under: Attribution-Share Alike 3.0 Unported
- Proudly powered by WordPress, Free WordPress Themes, and Search Marketing

26/02/2017 12:03 4 de 4