Virtual Clinical Trail (VCT) Open Source User Guide

By Barco, Healthcare Division

March 31, 2015

Table of Contents

1	Acknowledgement		2	
2	Bacro VCT Research License			
3	Introduction			
4	Software and Hardware Requirements			
5	Source Code Location			
6	Build VCT			
7	Test units			
8	Contribute			
8	3.1	Add a new module	7	
8	3.2	Add new dependencies, changing the core part of VCT, adding new functionalities to the XML	8	
8	3.3	Documentation	8	

1 Acknowledgement

This work is supported in part by the US National Institutes of Health (grant 1R01CA154444).

2 Bacro VCT Research License

0 "Software" shall mean VCT as originally published by Barco, as well as any subsequent Modifications, made by Barco or a third party, to the originally published software.

1 This Software License is between you and BARCO NV, a corporation organized and existing under the laws of Belgium registered under number BE 0473.191.041, Commercial Companies' Register of Kortrijk, having its registered office President Kennedypark, 35 at B-8500 Kortrijk, Belgium ("Barco").

By installing, executing, downloading, reviewing, modifying, enhancing and/or otherwise using the Software, either as initial version or as an upgrade, update, patch or enhancement of a prior release, the present terms and conditions shall apply.

2 Barco grants you a limited, royalty free, non-exclusive, non-assignable, non-transferable license (without the right to grant sublicenses) to:

- Use the Software for internal testing and/or research purposes;
- Make Modifications to the Software;
- Use the modified Software for internal testing and/or research purposes.

In any case, you shall refrain from using the Software for or in support of any commercial product or activity.

All modifications, derivatives, enhancements and/or alterations (the "Modifications"), and the underlying IPR related thereto will be the property of Barco, and all right, title and interest therein will vest in Barco. Accordingly, Supplier hereby assigns and agrees to assign to Barco all right, title, and interest in and to the Modifications, together with all underlying IPR that may be obtained on such Modifications. To the extent that title to the Modifications or related IPR may not, by operation of law, vest in Barco, you hereby transfer and assign, and agree to transfer and assign, to Barco all of its rights, title and interests in and to all Modifications, including all IPR related thereto. Barco will have the right to obtain and to hold in its own name all IPR at its sole discretion. You will provide, and will cause your employees, agents, consultants and contractors to provide, all cooperation that Barco reasonably determines necessary to accomplish to complete transfer of the Modifications and all IPR related thereto, including without limitation executing further assignments, consents, releases and other commercially reasonable documentation, and at Barco's expense, will provide and will cause any necessary third party to provide good faith testimony by affidavit, declaration, in-person or other proper means in support of any effort by Barco to establish, perfect or defend its rights acquired pursuant to this Agreement through the prosecution of patents or other governmental recordings, registrations or filings, and through regulatory proceedings, litigation, or other means. You further waive any "moral" rights, or other rights with respect to attribution of authorship or integrity of the Modifications as you may have under any applicable law.

Except in case where Barco is providing you with the source code of the (respective parts) of the Software, Neither you nor any Authorized User may, whether in whole or in part, reverse engineer, derive source code from, disassemble, decompile, or create derivative works based on the Software, without the prior consent, in writing, of Barco.

You warrant that the Modifications are "original" and are able to be subject to the provisions of this license. To the extent you are contemplating making "non-original" Modifications, including Modifications which consist of code which is directly or indirectly subject to (i) a third party proprietary license or (ii) GPL 2, GPL 3 or any other open source license which requires license that the (source code of the) Software is to be:

- generally disclosed or distributed in source code form, licensed for the purpose of making derivatives of such Software, or be redistributed free of charge, contrary to the terms and conditions of this Agreement;
- otherwise used or distributed in a manner contrary to the terms and conditions of this Agreement. you NEED to obtain prior written approval from Barco BEFORE making such Modification.

- 3 Barco (and Barco's licensors, as appropriate) retain ownership of all intellectual property rights in the Software, the Modifications, and any copies you or any authorized user may make of such Software.
- 4 The duration of this Software License will be from the date of your acceptance (as set forth above) of the Software (with no termination date, unless otherwise specified.

You may terminate this Software License at any time by destroying all copies of the Software then in your possession and returning all associated materials and documentation, to Barco. Barco may terminate this Software License forthwith by informing you at any time if you and/or any of your authorized users is in breach of any of the Software License's terms.

5 YOU UNDERSTAND THAT THE SOFTWARE IS BEING PROVIDED TO YOU "AS IS". BARCO DOES NOT MAKE NOR INTENDS TO MAKE ANY WARRANTIES OR REPRESENTATIONS, EXPRESS OR IMPLIED AND SPECIFICALLY DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY FITNESS, FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT OF INTELLECTUAL PROPERTY AND DOES NOT WARRANT THAT THE SOFTWARE WILL BE FREE FROM ERRORS OR THAT SUCH ERRORS WILL BE CORRECTED BY BARCO AND YOU ARE SOLELY RESPONSIBLE FOR ALL COSTS AND EXPENSES ASSOCIATED WITH RECTIFICATION, REPAIR OR DAMAGE CAUSED BY SUCH ERRORS.

6 BARCO ACCEPTS NO LIABILITY FOR ANY DAMAGES, LOSSES OR CLAIMS YOU OR ANY THIRD PARTY MAY SUFFER AS A RESULT OF YOUR USE OF THE SOFTWARE. IN JURISDICTIONS WHERE BARCO'S LIABILITY CANNOT BE EXCLUDED, BARCO'S LIABILITY FOR DIRECT DAMAGES SHALL BE LIMITED TO AN AMOUNT OF 50 EURO IN THE AGREGATE (OR TO THE MAXIMUM EXTENT PERMITTED BY LAW WHERE NO FURTHER EXCLUSION IS LEGALLY ALLOWED). TO THE MAXIMUM EXTENT PERMITTED BY LAW, IN NO EVENT WILL BARCO BE LIABLE FOR ANY INDIRECT, SPECIAL, PUNITIVE, INCIDENTAL OR CONSEQUENTIAL LOSS OR DAMAGES OF ANY KIND WHICH MAY ARISE OUT OF OR IN CONNECTION WITH THE SOFTWARE, THIS SOFTWARE LICENSE OR THE PERFORMANCE OR PURPORTED PERFORMANCE OF OR FAILURE IN THE PERFORMANCE OF BARCO'S OBLIGATIONS UNDER THIS SOFTWARE LICENSE OR FOR ANY ECONOMIC LOSS, LOSS OF BUSINESS, CONTRACTS, DATA, GOODWILL, PROFITS, TURNOVER, REVENUE, REPUTATION OR ANY LOSS ARISING FROM WORK STOPPAGE, COMPUTER FAILURE OR MALFUNCTION OF THE SOFTWARE AND ANY AND ALL OTHER COMMERCIAL DAMAGES OR LOSSES WHICH MAY ARISE IN RESPECT OF USE OF THE SOFTWARE, EVEN IF BARCO HAS BEEN ADVISED OF THE POSSIBILITY OF THEIR OCCURRENCE. YOU HEREBY AGREE TO INDEMNIFY. KEEP INDEMNIFIED, DEFEND AND HOLD HARMLESS BARCO AND BARCO'S AFFILIATES AND SUBSIDIARIES FROM AND AGAINST ANY AND ALL ACTIONS, PROCEEDINGS, LIABILITY, LOSS, DAMAGES, FEES AND COSTS (INCLUDING ATTORNEY FEES), AND OTHER EXPENSES INCURRED OR SUFFERED BY BARCO ARISING OUT OF OR IN CONNECTION WITH ANY BREACH BY YOU OF THE TERMS OF THIS SOFTWARE LICENSE.

7 This Software License is the only understanding and agreement between you and Barco for use of the Software by you and/or Authorized Users. The Software License supersedes all other communications, understandings or agreements we had prior to this Software License (with the exception of any continuing confidentiality agreement) although nothing in this Software License purports to exclude liability for fraudulent misrepresentation. You may not export or re-export the Software or any copy or adaptation in violation of any applicable laws or regulations. This Software License shall not be altered, amended or varied. If any provision of this Software License is determined to be illegal, void or unenforceable, or if any court of competent jurisdiction in any final decision so determines, this Software License shall continue in full force save that such provision shall be deemed to be deleted with effect from the date of such decision, or such earlier date, and shall be replaced by a provision which is acceptable by law and which embodies the intention of this Software License a close as possible.

8 The construction, validity and performance of this Software License shall be governed in all respects by the laws of Belgium without recourse to its conflict of law principles. All disputes arising in any way out of or affecting this Software License shall be subject to the exclusive jurisdiction of the courts of Kortrijk, without prejudice to enforcement of any judgment or order thereof in any other jurisdiction. The United Nations Convention on Contracts for the International Sale of Goods (the "Convention") shall not apply to this Software License, however, if the Convention is deemed by a court of competent jurisdiction to apply to this Software

License, Barco shall not be liable for any claimed non-conformance of the Software under Article 35(2) of the Convention.

Open Source Software provisions:

This product contains software components released under an Open Source license, as follows:

Name	Version	License type
EasyBMP	1.06	BSD - revised/modified
Boost	1.40.0	BSD Like
Glew		BSD Like
OpenCV	2.0.0	BSD - revised/modified
Meschach	1.2b	BSD Like
MTGP	2009-2011	BSD Like
OpenCL	1.1	
xml/xmlParser		BSD - revised/modified
zlib	in 2005	BSD Like

Copyright on each Open Source Software component belongs to the respective initial copyright holder, each additional contributor and/or their respective assignee(s), as may be identified in the respective Open Source Software documentation, source code, README file, or otherwise. You shall not remove or obscure or otherwise alter the respective copyrights

EACH SEPARATE OPEN SOURCE SOFTWARE COMPONENT AND ANY RELATED DOCUMENTATION ARE PROVIDED "AS IS" WITHOUT EXPRESS OR IMPLIED WARRANTY INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IN NO EVENT SHALL THE COPYRIGHTHOLDER OR ANY OTHER CONTRIBUTOR BE LIABLE FOR DIRECT, INCIDENTAL, SPECIAL, EXEMPLARY OR CONSEQUENTIAL DAMAGES, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY. MORE INFORMATION/DETAILS IS TO BE FOUND IN EACH SPECIFIC OPEN SOURCE LICENSE.

3 Introduction

This document describes how to get and compile the open source code for Virtual Clinical Trials (VCT). VCT is a framework made of different modules.

This document describes the software and hardware requirements you need to run VCT, how to get the code, how to build it, and how to add to it.

4 Software and Hardware Requirements

To compile and run VCT, you must have the following configuration:

- Windows XP SP3 or 7
- Vistual Studio 2008 SP1 Note: Other versions of Visual Studio (2005, 2010, 2012, etc) are not currently supported.
- CMake 2.8.10.2 or higher: http://www.cmake.org/
- OpenCL, from the AMD.

Note: Once you have installed the SDK, make sure the environment variable AMDAPPSDKROOT has been created. Otherwise, create it.

Regarding hardware:

- Make sure you have at least 2 GB of free space on your Hard drive.
- If you plan to use OpenCL / CUDA, make sure you have a compatible graphics card.

5 Source Code Location

All source code is located at github:

https://github.com/Barco-VCT/VirtualClinicalTrials

Documentation is available at on github to download and clone the software.

6 Build VCT

From the root directory:

build opensrc

The build script creates the .sln file for use with VisualStudio. Go to the Win32 directory and open file in Visual Studio

Build_VCT.sln

To compile VCT, in Visual Studio, go to:

Build > Build Solution.

Following the number of modules to compile, the compilation can take a few minutes.

The VCT executable is added in a subdirectory of the win32 directory, named Debug or Release according to the compilation configuration you selected.

7 Test units

Some test units are available for running and testing the VCT simulation platform in the folder "test_units".

There are 6 available test units. For running them a folder "vct" must be created and the vct executable must be copied as well as all necessary dlls (from OpenCV). Then for each test units, the run_simulation.bat file can be executed. In the folder "doc", documentation can be found describing the different test units. Then the files in the output folder of each test unit will be overwritten.

8 Contribute

8.1 Add a new module

VCT uses CMake to build the Visual Studio solution. <u>Consequently, to add a new module, we strongly advise you to do the following:</u>

- Organize the files on your working copy (see illustration on figure 5.1):
 - Create, in the <root>/vct/src/Modules directory, a sub-directory with a name ending with "Module". The system is case sensitive.
 - For instance: FourierTransformModule.
 - The header and source file must have the same name than the directory name.
 - For instance: FourierTransformModule.cpp and FourierTransformModule.h.
 - The source file must be located in a sub-directory named cpp.
 - If additional files are required, then their names do not matter. You can locate all of them just like the previous ones: headers in module directory, and sources cpp directory.
 - For instance: FourierTransformInternalProcess.h and cpp/FourierTransformInternalProcess.cpp.
 - The folder cpp must contain a file named BuildFull.cmake. To make this file properly, you can go with your command prompt to the directory vct/src/Modules and type makeBuildFull.bat and give it in argument the name of the main class of the module(For example HistogramModule). It will create the file BuildFull.cmake and fill it with the name of the main header file and the main source file. If your module contains some other sources and header files, add them manually.
- Develop the module:
 - The module must inherit the class Module. You can include the file with #include <Module.h>.
 - The Module class is an abstract class, and the following methods must be implemented:
 - * SetParameter
 - * Simulate

Note: For more information about implementation details, please refer to the VCT tutorial.




Figure 5.1: File organization for a new module

8.2 Add new dependencies, changing the core part of VCT, adding new functionalities to the XML ...

If you have to modify the core part of VCT, or if you need to add new dependencies, to change the functionalities of the XML ... please first contact us.

8.3 Documentation

Please document your code following the dOxygen style. If relevant, please provide as well a technical report describing the technical choices made for the developed algorithm. Templates can be provided on request.