Detailed Design (DD) External Interrupt

Authors: Burners Team (Ahmed Salah, Basem Moufreh, Hassan El Gabass, Hazem El

Morshedi, Mohamed Safwat).

Customer: NTI

Instructor: Mahmoud Ali, Ahmed Abd El Reheem.

APIs

- 1. Initialization API
- 2. Get the interrupt flag API
- 3. Interrupt call back API



1 Initializing API

Name	Initialization Function
Prototype	STD EXTI_void_init(EXTI_init_config_struct* EXTI_config);
Parameter in	EXTI_config: Pointer to Configuration struct that contains Enable
	values of INT0, INT1, INT2, Besides the sense level of each
Parameter	-
out	
Parameter	-
in-out	
Return Type	STD E_OK \ STD E_NOT_OK
Description	Function Initiate the External interrupt peripheral using the given
	configurations.
Covered	[SRS_EXINT_1]
Requirement	

2 Get the interrupt flag API

Name	Get the interrupt flag Function
Prototype	u8 EXTI_get_INT_flag(u8 copy_INT_id);
Parameter in	copy_INT_id: Interrupt id of the selected interrupt.
Parameter	-
out	
Parameter	-
in-out	
Return Type	u8
Description	Function return value of the INT flag in case of Polling not
	interrupting
Covered	[SRS_EXINT_2]
Requirement	

3 Interrupt call back API

Name	Interrupt call back
Prototype	STD EXTI_void_INT_callback(u8 copy_INT_id, void
	(*ptr_callback_function)(void));
Parameter in	copy_INT_id: Interrupt id of the selected interrupt
	ptr_callback_function: Pointer to the callback function that needs to
	be executed when the flag is raised.
Parameter	-
out	
Parameter	-
in-out	
Return Type	STD E_OK \ STD E_NOT_OK
Description	Function address the call back functions to be called by the ISR of
	each Interrupt.
Covered	[SRS_EXINT_3]
Requirement	