Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany

 Postal address:
 36035 Fulda, Germany

 Phone:
 +49 661 6003-0

 Fax:
 +49 661 6003-607

 E-mail:
 mail@jumo.net

 Internet:
 www.jumo.net

#### JUMO Instrument Co. Ltd.

JUMO House Temple Bank, Riverway Harlow, Essex CM20 2DY, UK Phone: +44 1279 635533

Fax: +44 1279 635355 Fax: +44 1279 635262 E-mail: sales@jumo.co.uk Internet: www.jumo.co.uk

#### JUMO Process Control, Inc.

8 Technology Boulevard Canastota, NY 13032, USA Phone: 315-697-5866 1-800-554-JUMO Fax: 315-697-5867

1-800-554-JUMO Fax: 315-697-5867 E-mail: info.us@jumo.net Internet: www.jumousa.com



Data Sheet 706585

Page 1/21




# Secure Data Management and FDA-Compliant Measured Data Recording

### **Brief description**

The LOGOSCREEN fd by JUMO is a paperless recorder for the electronic recording, archiving, and evaluation of process data that fully meets FDA requirements according to 21 CFR Part 11. The LOGOSCREEN fd has a maximum of 18 universal measurement inputs and is especially designed for the recording of security-related data. Up to 50 different users can log in to the device with their personal password and provide their respective signature if needed. Efficient PC programs are available to evaluate archived data and to configure the LOGO-SCREEN fd.

#### **Block structure**




## Approvals/marks of conformity (see Technical data)







Type 706585/...



(Stainless steel front (Ex))

Key features

## Conforms to FDA CFR Part 11

- Up to 50 users
- Electronic signature
- Comfortable security management
- Easy operation by control knob or touchpad
- Measurement data storage on CompactFlash memory card or USB memory stick
- Automatic read-out of data through the PCA Communications Software (PCC)
- Integrated web server
- Simultaneous recording of up to 3 batch reports
- Batch control (start, stop, texts) through barcode reader
- Modbus master function
- ATEX approval with stainless steel front



⟨Ex⟩ II 2D Ex pD 21 IP65

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany Postal address: 36035 Fulda, Germany Phone: +49 661 6003-0

Fax: +49 661 6003-607 E-mail: mail@jumo.net Internet: www.jumo.net

#### JUMO Instrument Co. Ltd.

JUMO House Temple Bank, Riverway Harlow, Essex CM20 2DY, UK Phone: +44 1279 635533 +44 1279 635262 E-mail: sales@jumo.co.uk

Internet: www.jumo.co.uk

**JUMO Process Control, Inc.** 8 Technology Boulevard Canastota, NY 13032, USA Phone: 315-697-5866 1-800-554-JUMO Fax: 315-697-5867 E-mail: info.us@jumo.net

Internet: www.jumousa.com



Data Sheet 706585

#### **Technical data**

#### **Analog inputs**

#### Thermocouple

Designation	Measuring range	Accuracy <sup>a</sup>
Fe-CuNi L DIN 43710	-200 to +900 °C	±0.1 %
Fe-CuNi J EN 60584	-200 to +1200 °C	±0.1 % from -100 °C
Cu-CuNi U DIN 43710	-200 to +600 °C	±0.1 % from -150 °C
Cu-CuNi T EN 60584	-270 to +400 °C	±0.1 % from -150 °C
NiCr-Ni K EN 60584	-200 to +1372 °C	±0.1 % from -80 °C
NiCr-CuNi E EN 60584	-200 to +1000 °C	±0.1 % from -80 °C
NiCrSi-NiSi N EN 60584	-100 to +1300 °C	±0.1 % from -80 °C
Pt10Rh-Pt S EN 60584	0 to 1768 °C	±0.15 %
Pt13Rh-Pt R EN 60584	0 to 1768 °C	±0.15 %
Pt30Rh-Pt6Rh B EN 60584	0 to 1820 °C	±0.15 % from 400 °C
W3Re/W25Re D	0 to 2495 °C	±0.15 % from 500 °C
W5Re/W26Re C	0 to 2320 °C	±0.15 % from 500 °C
W3Re/W26Re	0 to 2400 °C	±0.15 % from 500 °C
Chromel-copel GOST R 8.585-2001	-200 to +800 °C	±0.15 % from -80 °C
Chromel-alumel GOST R 8.585-2001	-200 to +1372 °C	±0.1 % from -80 °C
PLII (Platinel II)	0 to 1395 °C	±0.15 %
Shortest span	Type L, J, U, T, K, E, N, chromel-alumel, PLII: 1	
	Type S, R, B, D, C, W3Re/W26Re, chromel-cop	oel: 500 °C
Range start/end	freely programmable within the limits, in 0.1 °C	steps
Cold junction	Pt100 internal or thermostat external constant	
Cold junction accuracy (internal)	±1 °C	
Cold junction temperature (external)	-50 to +150 °C adjustable	
Sampling cycle	Channel 1 to 18: 125 ms in total	
Input filter	2nd order digital filter; filter constant adjustable from 0 to 10.0 sec	
Electrical isolation	see "Electrical data" on page 5 and	
	"Overview of the electrical isolation" on page 1	8
Resolution	> 14 bit	
Features	also programmable in °F	

<sup>&</sup>lt;sup>a</sup> The linearization accuracy refers to the maximum measuring range. The linearization accuracy is reduced with short spans.

#### Resistance thermometer

Designation	Connection circuit	Measuring range	Accuracya	Measurement current
Pt100 EN 60751 (TC = 3.85*10 <sup>-3</sup> 1/°C)	2/3-wire 2/3-wire 4-wire	-200 to +100 °C -200 to +850 °C -200 to +850 °C	±0.5 °C ±0.8 °C ±0.5 °C	≈ 250 µA ≈ 250 µA ≈ 250 µA
Pt100 JIS 1604 (TC = 3.917*10 <sup>-3</sup> 1/°C)	2/3-wire 2/3-wire 4-wire	-200 to +100 °C -200 to +650 °C -200 to +650 °C	±0.5 °C ±0.8 °C ±0.5 °C	≈ 250 µA ≈ 250 µA ≈ 250 µA
Pt100 GOST 6651-94 A.1 (TC = 3.91*10 <sup>-3</sup> 1/°C)	2/3-wire, 4-wire 2/3-wire, 4-wire	-200 to +100 °C -200 to +850 °C	±0.5 °C ±0.8 °C	≈ 250 µA ≈ 250 µA
Pt500 EN 60751 (TC = 3.85*10 <sup>-3</sup> 1/°C)	2/3-wire, 4-wire 2/3-wire, 4-wire	-200 to +100 °C -200 to +850 °C	±0.5 °C ±0.9 °C	≈ 100 µA ≈ 100 µA
Pt1000 EN 60751 (TC = 3.85*10 <sup>-3</sup> 1/°C)	2/3-wire 2/3-wire 4-wire	-200 to +100 °C -200 to +850 °C -200 to +850 °C	±0.5 °C ±0.8 °C ±0.5 °C	≈ 100 μA ≈ 100 μA ≈ 100 μA
Ni100 DIN 43760 (TC = 6.18*10 <sup>-3</sup> 1/°C)	2/3-wire, 4-wire	-60 to +180 °C	±0.4 °C	≈ 250 µA
Pt50 ST RGW 1057 1985 (TC = 3.91*10 <sup>-3</sup> 1/°C)	2/3-wire 2/3-wire 4-wire 4-wire	-200 to +100 °C -200 to +1100 °C -200 to +100 °C -200 to +1100 °C	±0.5 °C ±0.9 °C ±0.5 °C ±0.6 °C	≈ 250 μA ≈ 250 μA ≈ 250 μA ≈ 250 μA

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany Postal address: 36035 Fulda, Germany

Phone: +49 661 6003-0 Fax: +49 661 6003-607 E-mail: mail@jumo.net Internet: www.jumo.net

#### JUMO Instrument Co. Ltd.

JUMO House Temple Bank, Riverway Harlow, Essex CM20 2DY, UK Phone: +44 1279 635533 Fax: +44 1279 635262 E-mail: sales@jumo.co.uk

Internet: www.jumo.co.uk

**JUMO Process Control, Inc.** 8 Technology Boulevard Canastota, NY 13032, USA Phone: 315-697-5866 1-800-554-JUMO Fax: 315-697-5867 E-mail: info.us@jumo.net

Internet: www.jumousa.com



Data Sheet 706585

Designation	Connection circuit	Measuring range	Accuracya	Measurement current
Cu50	2/3-wire	-50 to +100 °C	±0.5 °C	≈ 250 µA
$(TC = 4.26*10^{-3} 1/^{\circ}C)$	2/3-wire	-50 to +200 °C	±0.9 °C	≈ 250 µA
	4-wire	-50 to +100 °C	±0.5 °C	≈ 250 µA
	4-wire	-50 to +200 °C	±0.7 °C	≈ 250µA
Cu100 GOST 6651-94 A.4	2/3-wire	-50 to +100 °C	±0.5 °C	≈ 250 µA
$(TC = 4.26*10^{-3} 1/^{\circ}C)$	2/3-wire	-50 to +200 °C	±0.9 °C	≈ 250 µA
	4-wire	-50 to +100 °C	±0.5 °C	≈ 250 µA
	4-wire	-50 to +200 °C	±0.6 °C	≈ 250 µA
Connection circuit	2-, 3-, or 4-wire circu	iit		
Shortest span	15 °C			
Sensor lead resistance	max. 30 per conduc max. 10 per conduc	tor for 3-wire/4-wire circ tor for 2-wire circuit	uit	
Range start/end	freely programmable	within the limits, in 0.1	°C steps	
Sampling cycle	Channel 1 to 18: 125	ms in total		
Input filter	2nd order digital filte	r; filter constant adjustal	ole from 0 to 10 sec	
Electrical isolation	see "Electrical data"	on page 5 and		
	"Overview of the elec	ctrical isolation" on page	: 18	
Resolution	> 14 bit			
Features	also programmable i	n °F		

<sup>&</sup>lt;sup>a</sup> The linearization accuracy refers to the maximum measuring range. The linearization accuracy is reduced with short spans.

#### Resistance transmitter and potentiometer

Designation	Measuring range	Accuracy <sup>1a</sup>	Measurement current
Resistance transmitter	up to 4000 Ω	±4 Ω	≈ 100 µA
Potentiometer	$< 400 \Omega$ $\ge 400 \Omega$ to $4000 \Omega$	$\pm 400 \text{ m}\Omega$ $\pm 4 \Omega$	≈ 250 µA ≈ 100 µA
Connection circuit	resistance transmitter: 3-potentiometer: 2-/3-/4-w	wire circuit	~ 100 μΛ
Shortest span	60Ω		
Sensor lead resistance		max. 30 per conductor for 4-wire circuit max. 10 per conductor for 2-/3-wire circuit	
Resistance values	freely programmable with	freely programmable within the limits, in 0.1 steps	
Sampling cycle	Channel 1 to 18: 125 ms	Channel 1 to 18: 125 ms in total	
Input filter	2nd order digital filter; filt	er constant adjustable from 0 to	o 10.0 sec
Electrical isolation		see "Electrical data" on page 5 and "Overview of the electrical isolation" on page 18	
Resolution	> 14 bit		

<sup>&</sup>lt;sup>a</sup> The linearization accuracy refers to the maximum measuring range. The linearization accuracy is reduced with short spans.

#### Input for DC voltage, DC current

Basic range	Accuracy <sup>a</sup>	Input resistance
-12 to +112 mV	±100 μV	$R_E \ge 1 M\Omega$
-10 to +210 mV	±240 μV	$R_{E} \ge 470 \text{ k}\Omega$
-1.5 to +11.5 V	±6 mV	$R_E \ge 470 \text{ k}\Omega$
-0.12 to +1.12 V	±1 mV	$R_E \ge 470 \text{ k}\Omega$
-1.2 to +1.2 V	±2 mV	$R_E \ge 470 \text{ k}\Omega$
-11.2 to +11.2 V	±12 mV	$R_E \ge 470 \text{ k}\Omega$
Shortest span	5mV	
Range start/end	freely programmable within the limits in 0.01 mV steps	
-1.3 to +22 mA	±20 μA	burden voltage ≤ 3 V
-22 to +22 mA	±44 μA	burden voltage ≤ 3 V
Shortest span	0.5mA	
Range start/end	freely programmable within the limits in 0.01 mA steps	
Overrange/underrange	according to NAMUR NE 43	
Sampling cycle	Channel 1 to 18: 125 ms in total	

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany

Postal address: 36035 Fulda, Germany
Phone: +49 661 6003-0
Fax: +49 661 6003-607
E-mail: mail@jumo.net
Internet: www.jumo.net

#### JUMO Instrument Co. Ltd.

JUMO House Temple Bank, Riverway Harlow, Essex CM20 2DY, UK Phone: +44 1279 635533 Fax: +44 1279 635262 E-mail: sales@jumo.co.uk

Internet: www.jumo.co.uk

#### JUMO Process Control, Inc.

8 Technology Boulevard Canastota, NY 13032, USA Phone: 315-697-5866 1-800-554-JUMO Fax: 315-697-5867 E-mail: info.us@jumo.net

Internet: www.jumousa.com



Data Sheet 706585

Page 4/21

Basic range	Accuracy <sup>a</sup>	Input resistance
Input filter	2nd order digital filter; filter constant adjustable from 0 to 10.0 sec	
Electrical isolation	see "Electrical data" on page 5 and "Overview of the electrical isolation" on page 18	
Resolution	>14 bit	

<sup>&</sup>lt;sup>a</sup> The linearization accuracy refers to the maximum measuring range. The linearization accuracy is reduced with short spans.

#### Transducer short circuit/break

	Short-circuit <sup>a</sup>	Break <sup>a</sup>
Thermocouple	not detected	detected
Resistance thermometer	detected	detected
Resistance transmitter	not detected	detected
Potentiometer	not detected	detected
Voltage ≤ ±210 mV	not detected	detected
Voltage > ±210 mV	not detected	not detected
Current	not detected	not detected

<sup>&</sup>lt;sup>a</sup> Programmable reaction of device, e.g. triggering alarm

#### Binary inputs/outputs (option)

Input or output	configurable as input or output
Number	8, 16 or 24, depending on the device version, to DIN VDE 0411, Part 500; max. 25 Hz, max. 32 V
Input	
• level	logic "0": -3 to +5 V (input current max. $\pm 1$ mA), logic "1": 12 to 30 V (2.5 mA $\leq$ input current $\leq$ 5 mA)
counting frequency	8Hz
High-speed input	the first two binary inputs of each module (B1, B2, B9, B10, B17, B18), if the module is not fitted with relays or 6 analog inputs
task	count function, e.g. for flow measurement
counting frequency	10 kHz
Output	
• type	open-collector output, switches relative to positive voltage
• level	logic "0": transistor is inhibited (max. permissible voltage across switching transistor 30 V, max. leakage current 0.1 mA) logic "1": transistor is switched on (max. voltage across switching transistor 1.6 V, max. current 50 mA)
sampling cycle	at least 1 sec (1 Hz)

#### **Outputs**

1 relay (ex-factory)	changeover (SPDT), 3 A, 230 V AC <sup>a</sup>
6 relays (option)	changeover (SPDT), 3 A, 230 V AC <sup>a, b</sup>

<sup>&</sup>lt;sup>a</sup> With resistive load.

#### **Interfaces**

RS232/RS485 (connector 7)	Qty. 1, switchable between RS232 and RS485
• protocol	Modbus master, Modbus slave and barcode reader
baud rate	9600, 19200, 38400
• modem	can be connected
• connector	SUB-D
external inputs	via the Modbus master/slave function, 24 analog and 24 binary

b It is not permissible to mix SELV circuits and supply circuits.

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany Postal address: 36035 Fulda, Germany

Postal address: 36035 Fulda, Germany
Phone: +49 661 6003-0
Fax: +49 661 6003-607
E-mail: mail@jumo.net
Internet: www.jumo.net

#### JUMO Instrument Co. Ltd.

JUMO House
Temple Bank, Riverway
Harlow, Essex CM20 2DY, UK
Phone: +44 1279 635533
Fax: +44 1279 635262
E-mail: sales@jumo.co.uk

Internet: www.jumo.co.uk

Phone: 315-697-5866 1-800-554-JUMO Fax: 315-697-5867 E-mail: info.us@jumo.net Internet: www.jumousa.com

**JUMO Process Control, Inc.** 8 Technology Boulevard Canastota, NY 13032, USA



Data Sheet 706585

Page 5/21

RS232 for barcode reader (connector 2)	Qty. 1
• protocol	Modbus master, Modbus slave and barcode reader
baud rate	9600, 19200, 38400
• connector	SUB-D
external inputs	via the Modbus master/slave function, 24 analog and 24 binary
Ethernet (connector 6)	
quantity	max. 1
• protocols	TCP, IP, HTTP, DHCP, SMTP, ModbusTCP
baud rate	10 Mbits/sec, 100 Mbits/sec
• connector	RJ45
data format	HTML
USB host (connector 5)	
quantity	2 (or 1 with stainless steel front), connector 5 and front connector (not with stainless steel front); no parallel operation
• use	for connecting a memory stick
max. current	100 mA
USB device (connector 15)	
• quantity	2 (or 1 with stainless steel front), connector 15 and front connector (not with stainless steel front); no parallel operation)
• use	for connecting to the (master) computer

#### Screen

Resolution/size	320 × 240 pixels/5.5"
Type/number of colors	TFT color screen/256 colors
Screen refresh rate	> 150 Hz
Brightness setting	adjustable on instrument
Screen saver (switch-off)	through waiting time or control signal

#### **Electrical data**

Supply voltage (switch-mode PSU)	AC 100 to 240 V +10/-15%, 48 to 63Hz or AC/DC 20 to 30 V, 48 to 63Hz (ELV)
Electrical safety	to EN 61010, Part 1, August 2002 overvoltage category II, pollution degree 2
Protection class I	terminal for PE conductor
Test voltages (type test)	
mains supply circuit to meas. circuit	with AC supply: 2.3 kV/50 Hz, 1 min, with AC/DC supply: 2.3 kV/50 Hz, 1 min
<ul> <li>mains supply circuit to housing (protective conductor)</li> </ul>	with AC supply: 2.3 kV/50 Hz, 1 min, with AC/DC supply: 2.3 kV/50 Hz, 1 min
<ul> <li>measuring current circuits to measuring current circuit and housing</li> </ul>	500 V/50 Hz, 1 min
electrical isolation between analog inputs	up to 30 V AC and 50 V DC
Supply voltage error	< 0.1 % of range span
Power consumption	approx. 40 VA
Data backup	CompactFlash memory card
Electrical connection	
mains supply and relays	at rear through pluggable screw terminals, 5.08 mm raster, max. conductor cross-section $\leq$ 2.5 mm <sup>2</sup> or 2× 1.5 mm <sup>2</sup> with ferrules
analog and binary inputs	at rear through pluggable screw terminals, 3.81 mm raster, max. conductor cross-section $\leq$ 1.5 mm <sup>2</sup>

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany

Postal address: 36035 Fulda, Germany Phone: +49 661 6003-0 Fax: +49 661 6003-607 E-mail: mail@jumo.net Internet: www.jumo.net

#### JUMO Instrument Co. Ltd.

JUMO House Temple Bank, Riverway Harlow, Essex CM20 2DY, UK Phone: +44 1279 635533 +44 1279 635262

Phone: 315-697-5866 1-800-554-JUMO Fax: 315-697-5867 E-mail: sales@jumo.co.uk E-mail: info.us@jumo.net Internet: www.jumo.co.uk Internet: www.jumousa.com

**JUMO Process Control, Inc.** 8 Technology Boulevard Canastota, NY 13032, USA



Data Sheet 706585

#### **Environmental influences**

Ambient temperature range	0 to +50 °C						
Ambient temperature effect	0.03 %/°C						
Storage temperature range	0 to +60 °C						
Climatic conditions	≤75 % relative humidity, no condensation						
EMC	EN 61326-1						
interference emission	Class A - only for industrial use -						
immunity to interference	to industrial requirements						

#### Housing

Housing front	zinc die-casting, optionally in stainless steel (extra code)
Housing type	housing for flush-panel mounting to IEC 61554, in stainless steel
Bezel size	144 mm × 144 mm to IEC 61554
Depth behind panel	193 mm (incl. terminals)
Panel cut-out	138 <sup>+1.0</sup> mm × 138 <sup>+1.0</sup> mm to IEC 61554
Panel thickness	2 to 40 mm
Housing mounting	in panel to DIN 43834
Operating position	unrestricted, but taking into account the viewing angle of the screen, horizontally ±65°, vertically +40° to -65°
Enclosure protection	to EN 60529 Category 2, front IP65, rear IP20
Weight	approx. 3.5 kg

#### Approvals/marks of conformity

Mark of conformity	Testing laboratory	Certificates / certification numbers	Test basis	valid for
c UL us	Underwriters Laboratories	E 201387	UL 61010-1 CAN/CSA-C22.2 No. 61010-1	the flush-mounted instrument; not in conjunction with extra code 350
II 2G Ex px IIC II 2D Ex pD 21 IP65	electrosuisse	SEV 08 ATEX 0155 U	EN 1127-1:2007 EN 60079-0:2006 EN 60079-2:2007 EN 61241-0:2006 EN 61241-4:2006	the flush-mounted instrument; only in conjunction with extra code 444 and without extra code 350

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany

 Postal address:
 36035 Fulda, Germany

 Phone:
 +49 661 6003-0

 Fax:
 +49 661 6003-607

 E-mail:
 mail@jumo.net

 Internet:
 www.jumo.net

#### JUMO Instrument Co. Ltd.

JUMO House Temple Bank, Riverway Harlow, Essex CM20 2DY, UK Phone: +44 1279 635533

Fax: +44 1279 635362 E-mail: sales@jumo.co.uk Internet: www.jumo.co.uk

#### JUMO Process Control, Inc.

8 Technology Boulevard Canastota, NY 13032, USA Phone: 315-697-5866 1-800-554-JUMO Fax: 315-697-5867 E-mail: info.us@jumo.net

Internet: www.jumousa.com



Data Sheet 706585

Page 7/21



### **Instrument description**

housing door.

#### Hardware

The paperless recorder is built to a modular design. The basic type consists of a PSU board (incl. relays) and a CPU board (incl. Ethernet and RS232/RS485 interfaces and an RS232 interface for barcode reader and USB interface connection).

Module slots 1, 2 and 3 can be fitted with input modules, each with 6 analog inputs or 3 analog inputs and 8 binary inputs/outputs. Alternatively, module slot 3 can be fitted with a relay module that has 6 relays.

Optionally, the PSU board can be equipped with a PROFIBUS-DP interface.

#### **Data recording**

Measurements are acquired continuously in a 125msec sampling cycle. Based on these measurements, reports are compiled and limits checked.

The measurements are transferred to the main memory of the instrument, according to the programmable storage cycle and stored value (maximum, minimum, average, min&max, instantaneous value or economy mode).

The paperless recorder saves the data in groups, and an input can be assigned to several groups (maximum 9).

#### Main memory (SRAM)

The data stored in the SRAM are regularly copied to the internal memory in 20 kbyte blocks.

#### Internal memory

When a block in the main memory has been filled, it is copied to the internal memory. The internal memory has a capacity of max. 256 Mbytes.

Every write action is monitored, so that any errors in saving the data can be immediately identified.

The instrument monitors the capacity of the internal memory and activates one of the "memory alarm" signals when the capacity falls below the configurable residual capacity level. These signals can be used, for instance, to operate the alarm relay.

The memory is written as a ring memory, i. e. when the memory is full, the oldest data are automatically overwritten by the new data. Data from the internal memory can be shown as a history presentation on the recorder. The

size of the history memory can be configured.

#### Data transfer to the PC

Data transfer from the paperless recorder to a PC is made by means of the external CompactFlash memory card (not available with stainless steel front), the USB memory stick or via one of the interfaces (USB device, RS232, RS485, Ethernet).

#### Data security

The data are stored in coded form in a proprietary format. This ensures a high level of data security.

If the paperless recorder is disconnected from the supply, then:

- RAM and clock time are buffered by a lithium battery (ex-factory) ≥ 10 years or with a storage capacitor ≥ 2 days (ambient temperature -40 to +45 °C),
- measurement and configuration data in the internal memory will not be lost.

#### Recording duration

Depending on the configuration of the instrument, the duration of the recording can vary over a considerable range (from a few days up to several months).

#### Report

For each channel of a group, a report (maximum/minimum/average or integrator) can be run over defined periods.

#### **Batch reports**

Up to three batch reports can be created simultaneously in the recorder. The measurement data, start, end and duration of each batch can be displayed together with a batch counter and freely definable texts, both on the recorder and within the PC Evaluation Software PCA3000.

On request, a barcode reader can be used to start batches and read in batch texts.

## Limit checkline changeover of operating mode

Over/underlimit conditions trigger alarms. An alarm can be used, for instance, as a control signal for changing over the operating mode. The storage cycle and stored value can be configured separately for all three operating modes.

With the help of the alarm delay function, brief occurrences or over/underlimit conditions can be filtered out, with the result that no alarm is generated.

#### Normal operation

If the instrument is **not** in timed or event operation, normal operation is active.

#### **Event operation**

Event operation is activated/deactivated by a control signal (binary input, group/combination alarm, ...). As long as the control signal is active, the instrument is in event operation.

#### Timed operation

Timed operation is active on a daily basis within a programmable time period. The operating modes have different priorities.

#### **Counters/integrators**

27 additional internal channels are available for use as counters, integrators, operating time counters or for flow measurements.

These counters are controlled through the binary inputs, the alarms, or via the logic channels. The analog channels can be used for the integrators.

The numerical indication is shown in a separate window, with a maximum of 9 digits. The acquisition period can be selected as: periodic, daily, weekly, monthly, yearly as well as external, total (overall count) or daily from to

A maximum of 6 binary inputs are available as high-speed counters with a 10 kHz sampling cycle rate.

## Math/logic module (extra code)

The module for math and logic (18 channels each) enables, for instance, the combination of analog channels with one another, and also the combination of analog channels with counters and binary inputs. The operators available for formulae are: +, -, \*, /, SQRT(), MIN(), MAX(), SIN(), COS(), TAN(), \*\*, EXP(), ABS(), INT(), FRC(), LOG(), LN(), humidity, moving average or !, &, |, ^, as well as ( and ). The math and logic module can only be configured through the setup program.

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany

Postal address: 36035 Fulda, Germany Phone: +49 661 6003-0 Fax: +49 661 6003-607 E-mail: mail@jumo.net Internet: www.jumo.net

#### JUMO Instrument Co. Ltd.

JUMO House Temple Bank, Riverway Harlow, Essex CM20 2DY, UK Phone: +44 1279 635533

Fax: +44 1279 635355 Fax: +44 1279 635262 E-mail: sales@jumo.co.uk Internet: www.jumo.co.uk

#### JUMO Process Control, Inc.

8 Technology Boulevard Canastota, NY 13032, USA Phone: 315-697-5866 1-800-554-JUMO Fax: 315-697-5867 E-mail: info.us@jumo.net

Internet: www.jumousa.com



Data Sheet 706585

Page 8/21

## Operation and configuration

#### On the recorder

The instrument is configured from the control knob (or with stainless steel front, from the touchpad) on the front panel under menu guidance.



Shift current menu position (cursor) to the left or upwards.



Shift current menu position (cursor) to the right or downwards.



When the control knob is pressed, the current function is executed.

#### Example:




Rotate control knob to the left.



Press control knob.

Result: The menu for the alarm and event list is called up.



Rotate control knob to the left.



( • ) Press control knob.

Result: The menu for the alarm and event list is closed again.



Integrated user lists (different users with different authorizations) protect the recorder against unauthorized access.

#### Through the setup program

As an alternative to the configuration from the control knob on the recorder, the instrument can also be configured through the setup program.

Communication between the setup program and the paperless recorder is made through the:

- USB device interface
- serial interface
- Ethernet interface
- · CompactFlash memory card or
- USB memory stick



The configuration data can be archived on a data storage medium and output to the printer

## **Operating language**

Two languages (see order details) are integrated in the instrument ex-factory. The setup program is used to exchange the operator language.

The languages available at the moment are: English, French, German, Russian, Japanese, Chinese, Italian, Romanian, Czech, Hungarian, Polish and Greek.

Other language versions (with Unicode capability) can be created.

#### Web server

The web server is integrated in the paperless recorder as standard. Four different modes of presentation are available:


- online visualization
- three freely programmable HTML pages
- current batch reports
- 4-way view (1 to 4 recorders or different visualizations)



On the PC side, the web server can be addressed with the (Microsoft®) Internet Explorer. For visualizing graphics, an SVG Viewer (from Adobe®, for instance) must be installed on the PC in addition to the Internet Explorer.

## **Process images (editor)**

The setup program can create process images and transfer them to the paperless recorder for display. Up to 25 objects (images, analog channels, binary channels, texts, ...) can be used in a process image.



One process image is integrated in the paperless recorder ex-factory.

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany

36035 Fulda, Germany Postal address: +49 661 6003-0 Phone: Fax: +49 661 6003-607 E-mail: mail@jumo.net Internet: www.jumo.net

#### JUMO Instrument Co. Ltd.

JUMO House

Temple Bank, Riverway Harlow, Essex CM20 2DY, UK Phone: +44 1279 635533 Fax: +44 1279 635262 E-mail: sales@jumo.co.uk

Internet: www.jumo.co.uk

#### JUMO Process Control, Inc.

8 Technology Boulevard Canastota, NY 13032, USA Phone: 315-697-5866 1-800-554-JUMO


Fax: 315-697-5867 E-mail: info.us@jumo.net Internet: www.jumousa.com



Data Sheet 706585


#### Visualization on the instrument

#### **Operator level**



Selection of visualization

#### Vertical diagram



- Recorder chart presentation of analog and binary channels
- Display of scaling and limit markers of a channel (can be switched on/off)
- Numerical display of current analog channels

#### Bar graph presentation




- Bar graph presentation of analog channels
- On/Off presentation of binary channels
- Display of current analog channels with scaling and limit markers
- Color change of bar graph to red when limits are infringed

#### **Numerical presentation**




- Large numerical presentation of analog channels, including the channel name and description
- Each analog channel can be switched to the foreground
- On/Off presentation of binary channels

#### **Numerical 1-channel presentation**



- Clear presentation of an analog channel
- An analog input is shown simultaneously as a bar graph and a number
- Display of channel name and description
- Display of scaling and limit markers

#### **Process image**



- Freely configurable presentation (through the setup program) of analog and binary signals with background pictures
- One process image for each group

Delivery address: Mackenrodtstraße 14

36039 Fulda, Germany 36035 Fulda, Germany Postal address: Phone: +49 661 6003-0 Fax: +49 661 6003-607 E-mail: mail@jumo.net Internet: www.jumo.net

#### JUMO Instrument Co. Ltd.

JUMO House Temple Bank, Riverway Harlow, Essex CM20 2DY, UK Phone: +44 1279 635533

Fax: +44 1279 635262 E-mail: sales@jumo.co.uk Internet: www.jumo.co.uk

#### JUMO Process Control, Inc.

8 Technology Boulevard Canastota, NY 13032, USA Phone: 315-697-5866 1-800-554-JUMO


Fax: 315-697-5867 E-mail: info.us@jumo.net Internet: www.jumousa.com



Data Sheet 706585


Page 10/21

#### **Binary presentation**




On/Off presentation of binary channels

#### Report



- Display of different reports for the analog channels of a group
- Details of minimum, maximum, average/ integral values and time period
- Display of the previous report

#### **Batch reports**




- 3 batches documented simultaneously
- Changeover between current and completed batch reports
- Electronic signature is possible
- Batch texts via interface and barcode reader, among others

#### Counter/integrator presentation



- Presentation of up to 27 counters or integrators
- Changeover between individual and overall display
- Display of the current and the most recently completed count

#### **Group selection**



- Up to 9 groups are configurable
- Up to 6 analog and 6 binary channels can be shown for each group
- Measurement signals can be used in several groups

#### **History presentation**



- All stored measurement data are shown as curves at different zoom levels
- Display of scaling and limit markers of a channel
- Numerical display of the measurements of the analog channels at the cursor position
- Shifting of the visible section within the stored measurement data

Delivery address: Mackenrodtstraße 14

36039 Fulda, Germany 36035 Fulda, Germany Postal address: Phone: +49 661 6003-0 Fax: +49 661 6003-607 E-mail: mail@jumo.net Internet: www.jumo.net

#### JUMO Instrument Co. Ltd.

JUMO House

Temple Bank, Riverway Harlow, Essex CM20 2DY, UK Phone: +44 1279 635533 Fax: +44 1279 635262 E-mail: sales@jumo.co.uk

Internet: www.jumo.co.uk

#### JUMO Process Control, Inc.

8 Technology Boulevard Canastota, NY 13032, USA 315-697-5866 Phone: 1-800-554-JUMO

Fax: 315-697-5867 E-mail: info.us@jumo.net Internet: www.jumousa.com



Data Sheet 706585


Page 11/21

#### Presentation of alarm lists




- Display of current alarms
- For the instrument as a whole or batch-related
- Up to 150 entries visible on the recorder

#### Presentation of event lists




- Display and storage of events and alarms
- For the instrument as a whole or batch-related
- Up to 150 entries visible on the recorder

#### Configuration



- Configuration on the recorder itself, by rotating and pressing the control knob
- Configuration through the setup program

### Visualization through the web browser



- Recorder Online JUMO
- Quad View

- Online visualization of a recorder
- Selection of (max.) three customized HTML pages (created on request)
- Navigation through the different recorder visualizations (curves, bar graph, text, process, ...)
- Max. four recorders or four different visualizations simultaneously

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany

Postal address: 36035 Fulda, Germany +49 661 6003-0 Phone: Fax: +49 661 6003-607 E-mail: mail@jumo.net Internet www.jumo.net

#### JUMO Instrument Co. Ltd.

JUMO House Temple Bank, Riverway Harlow, Essex CM20 2DY, UK +44 1279 635533 Phone:

+44 1279 635262 Fax: E-mail: sales@jumo.co.uk Internet: www.jumo.co.uk

#### JUMO Process Control, Inc.

8 Technology Boulevard Canastota, NY 13032, USA Phone: 315-697-5866 1-800-554-JUMO Fax: 315-697-5867 E-mail: info.us@jumo.net

Internet: www.jumousa.com




Data Sheet 706585

### PC programs


#### PC Evaluation Software (PCA3000)

The PC Evaluation Software (PCA3000) is a program which runs under Windows 2000/XP, and is used to manage, archive, visualize and evaluate the recorder data.



- The data from differently configured instruments are recognized by the PC Evaluation Software and stored in an archive database. All management is fully automatic. The user only has to manually allocate an identifier (supplementary description).
- The user can at any time gain access to certain data sets which can be distinguished by the identifier. It is also possible to restrict the time periods to be evaluated.
- Any analog or binary channels of a paperless recorder (even from different groups) can subsequently be combined into PCA groups in PCA3000.
- Since each group is displayed in a separate window, several groups can be shown simultaneously on the screen and compared.
- Operation by mouse or keys.
- Using the export filter, it is possible to export the stored data, so that they can be processed in other programs such as Excel.
- The PC Evaluation Software PCA3000 has network capability, i.e. several users can obtain data from the same archive file (\*.177) in a network directory, independently of each other.

#### **PCA Communications Software (PCC)**



- · Data can be read out from the recorder via the USB device interface, the serial interface (RS232/RS485) or via the Ethernet interface; the data can be read manually or automatically (e.g. daily at 23.00 hrs)
- Data can also be retrieved via remote control, through a modem

- The print template is selected within PCC
- 4. Read the print template. Print templates are created within PCA3000.
- 5. Data transfer from archive
- 6. Determine the content defined in the print template
- 7. Use the determined content in the defined design. 8. Output the completed design in the defined formats.

#### PC Security Manager (PCS)

Software for the administration of access control. This software is only accessible to administrators.

#### PC Audit-Trail Manager (PCAT)

Software for the documentation of PC operational actions that could lead to alterations in data recording.

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany

Postal address: 36035 Fulda, Germany +49 661 6003-0 Fax: +49 661 6003-607 E-mail: mail@jumo.net Internet: www.jumo.net

#### JUMO Instrument Co. Ltd.

JUMO House Temple Bank, Riverway Harlow, Essex CM20 2DY, UK Phone: +44 1279 635533

+44 1279 635262 Fax: E-mail: sales@jumo.co.uk Internet: www.jumo.co.uk

#### JUMO Process Control, Inc.

8 Technology Boulevard Canastota, NY 13032, USA Phone: 315-697-5866 1-800-554-JUMO Fax: 315-697-5867 E-mail: info.us@jumo.net

Internet: www.jumousa.com



Data Sheet 706585

Page 13/21

#### Interfaces

- **USB** interfaces (standard)
- RS232/RS485 interface (standard)
- RS232 interface for barcode reader (standard)
- Ethernet interface (standard)
- PROFIBUS-DP interface (extra code)

USB Interraces	<b>USB</b>	interfaces
----------------	------------	------------

With USB interfaces, a distinction is made between the host and the device interface. A USB memory stick can be attached to the host interface. The device interface, in conjunction with a standard commercial USB cable, is used to operate the setup program. The paperless recorder without stainless steel front has host and device interfaces connected in parallel on both the front and back panels, of which only one of each type can ever be used. The paperless recorder with stainless steel front has only one host and one device interface at the rear panel.

#### RS232/RS485 interface

Current process data, as well as specific device data, can be read out via the RS232 or RS485 interface.

Data saved to the internal memory can also be read out in conjunction with the PC Evaluation Software PCA3000 and the PCA Communications Software (PCC).

The RS232 interface permits a maximum lead length of 15 m, the RS485 interface 1.2 km. Connection is by a 9-pin SUB-D connector on the back of the instrument. Modbus (master and slave) protocols are available, and the transmission mode used is RTU (Remote Terminal Unit).

#### RS232 for barcode reader

A barcode reader can be attached to the interface. The barcode reader can be used to start or stop batch reporting, and to set batch texts (customer information, batch number...).

The barcode reader can also be operated via the RS232/RS485 interface, and the RS232 interface for the barcode reader can also be used as a Modbus master or slave.

	USB Host/Device	RS232 RS485	Ethernet	PROFIBUS- DP	External CF card
Read current measurement data	yes (device only)	yes	yes	yes	no
Write current measurement data	no	yes	yes	yes	no
Read out stored measurement data	yes	yes	yes	no	yes
Read/write configuration	yes	yes	yes	no	yes
Write user list	yes	yes	yes	no	yes

#### **Ethernet interface**

The Ethernet interface can be used in local networks for the communication between the recorder and the setup program and the PCA Communications Software. The IP address is set permanently through the configuration on the instrument or in the setup program, or can be automatically received from a DHCP server.

server allows The integrated web simultaneous access by several PCs to 3 HTML and 3 batch pages.

Transmission protocol: TCP/IP Network type: 10BaseT, 100BaseT

#### **PROFIBUS-DP** interface

The recorder can be integrated into a fieldbus system according to the PROFIBUS-DP standard via the PROFIBUS-DP interface. This PROFIBUS version is especially designed for communication between automation and distributed systems peripheral devices at the field level.

Data are transmitted serially according to the RS485 standard, with a maximum 12 Mbits/

Using the project design tool that is included in the delivery (GSD generator; GSD = device master file), an application-specific GSD file is created, which is used to integrate the recorder into the fieldbus system.

#### **External CompactFlash** memory card (CF)

For paperless recorders without stainless steel front, the external CompactFlash memory card (CF) is used to transfer the data from the internal memory to the PC. Configuration data can be created on the PC and then transferred to the recorder by means of the memory card.

On the PC side, data on the card is accessed using a read/write device (CompactFlash reader/writer).

#### External inputs via interface

The paperless recorder can acquire and store up to 24 external analog inputs and 24 binary

Furthermore, the interfaces can be used to enter comments in the event list of the recorder

## Stainless steel front (£x) (extra code 444)



The paperless recorder with extra code 444 (without extra code 350) may be installed in switch cabinets with at least a simplified Under pressurized enclosure. conditions, use in a potentially explosive athmosphere (max. zones 1 and 21) is authorized from the front.

Notes installation on Installation Instructions B 706585.4.1 must be complied with and followed.

Paperless recorders with authorization for explosion hazard areas, carry the following mark on the nameplate attached to the instrument.

⟨£x⟩ II 2G Ex px IIC

⟨€x⟩ II 2D Ex pD 21 IP65

Caution: If extra code 444 is present, the CompactFlash memory card can no longer be used for external storage. Measurement data can be read out via one of the interfaces or via a USB memory stick (from the back).

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany

Postal address: 36035 Fulda, Germany
Phone: +49 661 6003-0
Fax: +49 661 6003-607
E-mail: mail@jumo.net
Internet: www.jumo.net

#### JUMO Instrument Co. Ltd.

JUMO House Temple Bank, Riverway Harlow, Essex CM20 2DY, UK Phone: +44 1279 635533

Fax: +44 1279 635353 Fax: +44 1279 635262 E-mail: sales@jumo.co.uk Internet: www.jumo.co.uk

#### JUMO Process Control, Inc.

8 Technology Boulevard Canastota, NY 13032, USA Phone: 315-697-5866 1-800-554-JUMO

Fax: 315-697-5867 E-mail: info.us@jumo.net Internet: www.jumousa.com




Data Sheet 706585

Page 14/21

### **Connection diagram**

#### Rear view with pluggable screw terminals

#### Instrument variant 1



#### Module slot 3 (top)

fitted with one relay card


#### Module slot 2 (middle)

fitted with 6 analog channels or 3 analog channels and 8 binary inputs/outputs

#### Module slot 1 (bottom)

fitted with 6 analog channels or 3 analog channels and 8 binary inputs/outputs

#### Instrument variant 2



#### Module slot 3 (top)

fitted with 6 analog channels or 3 analog channels and 8 binary inputs/outputs

#### Module slot 2 (middle)

fitted with 6 analog channels or 3 analog channels and 8 binary inputs/outputs

#### Module slot 1 (bottom)

fitted with 6 analog channels or 3 analog channels and 8 binary inputs/outputs

Delivery address: Mackenrodtstraße 14

36039 Fulda, Germany Postal address: 36035 Fulda, Germany Phone: +49 661 6003-0 Fax: +49 661 6003-607 E-mail: mail@jumo.net Internet: www.jumo.net

JUMO Instrument Co. Ltd. JUMO House Temple Bank, Riverway Harlow, Essex CM20 2DY, UK Phone: +44 1279 635533 +44 1279 635262 Fax: E-mail: sales@jumo.co.uk

Internet: www.jumo.co.uk

**JUMO Process Control, Inc.** 8 Technology Boulevard Canastota, NY 13032, USA Phone: 315-697-5866 1-800-554-JUMO

Fax: 315-697-5867 E-mail: info.us@jumo.net Internet: www.jumousa.com



Data Sheet 706585

Page 15/21

Terminal assignment	Connector	Diagram
Supply	1	
Supply as on nameplate	Connector 4 L1 (L+) N (L-) PE	L1 N PE O O O O O L1 N PE
Analog inputs		
Thermocouple		1 2 3 4
RTD in 2-wire circuit		1 2 3 4
RTD in 3-wire circuit	Connectors 8 to 11 (input 1 to 12) for instrument variant 1	1 2 3 4
RTD in 4-wire circuit		1 2 3 4
Resistance transmitter		1 2 3 4 E = End S S A S = Slider A = Start
Potentiometer in 2-wire circuit	or Connectors 8 to 13	1 2 3 4
Potentiometer in 3-wire circuit	(input 1to18) for instrument variant 2	1 2 3 4
Potentiometer in 4-wire circuit	* conditions of control of contro	1 2 3 4
Voltage input 0 to 1 V	· · · · · · · · · · · · · · · · · · ·	1 2 3 4 0 0 0 0 1 U <sub>x</sub> = 0 to 1 V
Voltage input 0 to 10 V		1 2 3 4 U <sub>x</sub> = 0 to 10 V
Current input		1 2 3 4 0 0 0 0 0 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1

Delivery address: Mackenrodtstraße 14

36039 Fulda, Germany
Postal address: 36035 Fulda, Germany
Phone: +49 661 6003-0
Fax: +49 661 6003-607
E-mail: mail@jumo.net
Internet: www.jumo.net

#### JUMO Instrument Co. Ltd.

JUMO House Temple Bank, Riverway Harlow, Essex CM20 2DY, UK Phone: +44 1279 635533

Fax: +44 1279 635262 E-mail: sales@jumo.co.uk Internet: www.jumo.co.uk

#### JUMO Process Control, Inc.

8 Technology Boulevard Canastota, NY 13032, USA Phone: 315-697-5866 1-800-554-JUMO Fax: 315-697-5867

Internet: www.jumousa.com


info.us@jumo.net

E-mail:



Data Sheet 706585

Page 16/2



Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany

Postal address: 36035 Fulda, Germany Phone: +49 661 6003-0 Fax: +49 661 6003-607 E-mail: mail@jumo.net Internet: www.jumo.net

JUMO Instrument Co. Ltd. JUMO House Temple Bank, Riverway Harlow, Essex CM20 2DY, UK Phone: +44 1279 635533

+44 1279 635262 Fax: E-mail: sales@jumo.co.uk Internet: www.jumo.co.uk

**JUMO Process Control, Inc.** 8 Technology Boulevard Canastota, NY 13032, USA Phone: 315-697-5866 1-800-554-JUMO Fax: 315-697-5867 E-mail: info.us@jumo.net

Internet: www.jumousa.com



Data Sheet 706585

Page 17/21

Terminal assignment	Connector	Diagram
Relay outputs	1	
Relay 1 changeover (SPDT)	Connector 1	12 11 13
Relay 2 changeover (SPDT)		22 21 23
Relay 3 changeover (SPDT)	Connector 14	32 31 33
Relay 4 changeover (SPDT)	only for instrument variant 1	42 41 43
Relay 5 changeover (SPDT)	*(2000000000000000000000000000000000000	52 51 53
Relay 6 changeover (SPDT)		62 61 63
Relay 7 changeover (SPDT)		72 71 73
Interfaces		
RS232 for barcode reader 9-pin SUB-D socket connector	Connector 2	2 RxD Receive Data 3 TxD Transmit Data 5 GND Ground
PROFIBUS-DP 9-pin SUB-D socket connector (extra code)	Connector 3	3 RxD/TxD-P Receive/Transmit Data-Pos. B conductor 5 DGND Ground for data transmission 6 VP Supply voltage-Pos. 8 RxD/TxD-P Receive/Transmit Data-Neg. A conductor
USB host interface for connecting memory sticks	Connector 5	The recorder without stainless steel front also has a USB host interface on the front panel, connected in parallel. The two interfaces cannot both be operated at the same time.
Ethernet RJ45 socket connector	Connector 6	1 TX+ Transmit Data + 2 TX- Transmit Data - 3 RX+ Receive Data + 6 RX- Receive Data -
RS232 9-pin SUB-D socket connector (switchable to RS485)	Connector 7	2 RxD Receive Data 3 TxD Transmit Data 5 GND Ground
RS485 9-pin SUB-D socket connector (switchable to RS232)	Connector 7	3 TxD+/RxD+ Transmit/Receive Data + 5 GND Ground 8 TxD-/RxD- Transmit/Receive Data -
USB host interface for connecting a PC	Connector 15	The recorder without stainless steel front also has a USB device interface on the front panel, connected in parallel. The two interfaces cannot both be operated at the same time.

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany Postal address: 36035 Fulda, Germany

Phone: +49 661 6003-0 Fax: +49 661 6003-607 E-mail: mail@jumo.net Internet: www.jumo.net

#### JUMO Instrument Co. Ltd.

JUMO House Temple Bank, Riverway Harlow, Essex CM20 2DY, UK Phone: +44 1279 635533

+44 1279 635262 E-mail: sales@jumo.co.uk Internet: www.jumo.co.uk

**JUMO Process Control, Inc.** 8 Technology Boulevard Canastota, NY 13032, USA Phone: 315-697-5866 1-800-554-JUMO 315-697-5867 Fax:


E-mail: info.us@jumo.net

Internet: www.jumousa.com



Data Sheet 706585

### Overview of the electrical isolation



Delivery address: Mackenrodtstraße 14

#### JUMO Instrument Co. Ltd.

JUMO House

Temple Bank, Riverway Harlow, Essex CM20 2DY, UK Phone: +44 1279 635533 Fax: +44 1279 635262

Fax: +44 1279 635262 E-mail: sales@jumo.co.uk Internet: www.jumo.co.uk

#### JUMO Process Control, Inc.

8 Technology Boulevard Canastota, NY 13032, USA Phone: 315-697-5866

1-800-554-JUMO
Fax: 315-697-5867
E-mail: info.us@jumo.net
Internet: www.jumousa.com





Data Sheet 706585

Page 19/21


#### **Dimensions**


Recorder with die-cast zinc front






Recorder with stainless steel front (extra code 444)







Panel cut-out



## Universal carrying case option - TG-35





Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany Postal address: 36035 Fulda, Germany

Phone: +49 661 6003-0
Fax: +49 661 6003-607
E-mail: mail@jumo.net www.jumo.net

#### JUMO Instrument Co. Ltd.

JUMO House Temple Bank, Riverway Harlow, Essex CM20 2DY, UK Phone: +44 1279 635533 Fax: +44 1279 635262 E-mail: sales@jumo.co.uk

Internet: www.jumo.co.uk

#### JUMO Process Control, Inc.

8 Technology Boulevard
Canastota, NY 13032, USA
Phone: 315-697-5866
1-800-554-JUMO
Fax: 315-697-5867
E-mail: info.us@jumo.net
Internet: www.jumousa.com



Data Sheet 706585

Page 20/21

#### **Order details**

	(1)	Basic type
706585		Paperless recorder with Ethernet, USB and RS232/RS485 interfaces and
		RS232 interface (to connect a barcode reader) and one relay
	(2)	Software
0		No software package
1		With software package
	(0)	(setup program incl. USB cable, PCA3000, PCC, PCS, PCAT)
	(3)	Language for instrument texts
8		Factory setting (German/English)
9	/4\	Set to customer specification
	(4)	Module slot 1
0		not used
2		3 analog inputs and 8 binary inputs/outputs
3	<b>(5)</b>	6 analog inputs
	(5)	Module slot 2
0		not used
2		3 analog inputs and 8 binary inputs/outputs
3	(0)	6 analog inputs
	(6)	Module slot 3
0		not used
1		6 relay outputs
2		3 analog inputs and 8 binary inputs/outputs
3	(=)	6 analog inputs
	(7)	Supply
25		AC/DC 20 to 30 V, 48 to 63 Hz
33	(0)	AC 100 to 240 V +10/-15 %, 48 to 63 Hz
000	(8)	Extra codes memory
020		Lithium battery for memory buffering (ex-factory)
021	(0)	Storage capacitor
	(9)	Extra codes
		not used
260	(4.0)	Math and logic module
	(10)	Extra codes housing
		not used
350		Universal carrying case TG-35 <sup>a</sup>
444	/4.4\	Stainless steel front with touchpad &
	(11)	
		without extra codes
267		PROFIBUS-DP interface

<sup>&</sup>lt;sup>a</sup> This extra code is available in combination with voltage supply AC 100 to 240 V, not with low supply voltage. UL and ATEX approvals not applicable. The protection type in the carrying case corresponds to IP20, outside IP20D.

Order code	(1)		(2)	(3)		(4)	(5)	(6)		(7)		(8)		(9)		(10)		(11)
Order example	706585	/			-				] -		/		,		,		,	

List extra codes in sequence, separated by commas.

Delivery address: Mackenrodtstraße 14 36039 Fulda, Germany Postal address: 36035 Fulda, Germany

Phone: +49 661 6003-0
Fax: +49 661 6003-607
E-mail: mail@jumo.net
Internet: www.jumo.net

JUMO Instrument Co. Ltd.

JUMO House Temple Bank, Riverway Harlow, Essex CM20 2DY, UK Phone: +44 1279 635533 Fax: +44 1279 635262 E-mail: sales@jumo.co.uk

Internet: www.jumo.co.uk

Phone: 315-697-5866 1-800-554-JUMO Fax: 315-697-5867 E-mail: info.us@jumo.net Internet: www.jumousa.com

JUMO Process Control, Inc.

8 Technology Boulevard Canastota, NY 13032, USA



Data Sheet 706585

Page 21/21

#### Standard accessories

- 1 Installation instructions B706585.4 (B706585.4.1 with extra code 444) and
   1 Operating instructions B706585.1
- · 4 mounting brackets
- 1 control panel seal
- 1 CD with detailed operating instructions and additional documentation

#### Accessories - data sheet 709700

- PC software package consisting of: Setup program, PC Evaluation Software (PCA3000), PCA Communications Software (PCC), PC Security Manager (PCS), and PC Audit-Trail Manager (PCAT). Please specify all version numbers when placing repeat orders.
- CompactFlash memory cards and USB memory sticks
   The CF cards and memory sticks specified by JUMO are tested and designed for industrial applications.
   The correct use with other brands cannot be guaranteed.
- · For further accessories see data sheet 709700