FRAME ASSEMBLY

Required tools; - screwdriver

- 3mm allen head hexagonal key
- hammer

	,
PART NUMBER	QTY.
0601_038	1
sigma 20x20	2
0601_014_02	6
0601_030	1
0601_067	1
0601_032	1
0601_033	2
0601_034	1
0601_068	1
EN ISO 4762 M4 x 10 - 10N	8
Tapping screw DIN 7049-ST2.9x6.5	6
NUT - M4	3
Tapping screw DIN 7049-ST2.2x9.5	4



