

LIF Image Previewing

As part of the process of finishing the acquisition of cortical explant images, all of the captured images should be previewed to assess for imaging issues or artefacts which may make analysis challenging. A **Python** script has been written to streamline this process. This script is called *PreviewLIFFiles.py*.

Running the Script

The preview script can be run from the command-line, like other scripts. You can either provide the path to the folder containing the LIF files you want to preview on the command-line, or you can copy the script from the desktop into the folder and double-click on it to run it.

This script will search through the provided folder (or the one it's run from) for all LIF files. For each file it finds, it will display to you the number of image series contained, as well as the number of colour channels for each series. In addition to displaying a printout of the details of the images within the file, it will also display to the screen both a Minimum- and Maximum-Intensity Projection of each colour channel for each series. These projections are intended to provide a visualization for the fluorescent and bright-field/transmitted light modalities to assess the images for artefacts or errors.