
TcEventVideoPlayback Service

To use the Event Video Playback feature, you must first install the TcEventVideoPlayback service. This service will run in the background of the IPC and convert TwinCAT Vision images to video files when called from the PLC.


Install the service via the supplied MSI installer file, and you can verify with the Windows Services.



PLC Project - Quick Start Sample

For quick start purposes, a PLC sample project and the SPT_Vision library is supplied. To run the sample, follow these steps.

- 2. To open the .tszip select open project in Visual Studio or XAE Shell
- 3. Load the included sample images into the TC Vision File Source
- 4. Activate the TwinCAT project
- 5. Put the PLC into Run state
- 6. Open the Visu project and press the Run Vision button to start the vision process



- 7. Check images are streaming via the TwinCAT -> Windows-> ADS Image Watch
- 8. To generate a video, press the Trigger Video button on the Visu
- 9. Check that a video was created in the default directory C:\TcAlarmvideos


Notes on PLC Project

- The SPT_Vision component FB_ImageAquire and the base Tc3 Vision components are supported. For the sample, the SPT_Vision component FB_ImageAquire is used. The FB_ImageToVideo function does not require FB_ImageAquire to work, and it can also be supplied with standard image pointers from the Tc3 Vision base library.
- The FB_ImageToVideo is configurable. You can set the directory of where the video will be recorded, as well as the Camera name and Event Logger name.


Common issues running the sample

Build Error

The first known common issue is when loading the PLC project on a brand new install. If nothing has been loaded on the system before, you will get some Tc2_System library errors like below.




To fix this, you will need to right-click the top XAE project node and select -> Unload Project, and then right-click Reload Project.




Binaries Error

The second known common issue is the TcVision binaries error when trying to activate the project, as seen below. This is due to a mismatch of the publishing system TcVision version and the one you are using.



To fix this, you must reload the tmc files for each of the FileSource TcCom objects under Vision. Make sure to do it for both.




HMI Project - Quick Start Sample

Included in the package is a NuGet Package for the EventVision component. This package should be installed properly if selected. To install manually, copy the EventVision.'version'.nupkg file to the directory C:\TwinCAT\Functions\TE2000-HMI-Engineering\References.

To configure the project:


- 1. Install the Beckhoff.TwinCAT.HMI.EventLogger package with the NuGet Package Manager
- 2. On the Browse window of the NuGet Package Manager, add the **EventVision** package to the project




♀ Tip

If the package does not appear, double check Package source has TwinCAT HMI Customer profile selected

3. Set a virtual directory of where the video files exist. Go to Server -> TcHmiSrv -> Virtual directories and add the following entry.



- 4. On your HMI view, add a new EventVideo Control grid
- 5. Modify the top 3 properties and make sure the Virtual Drive matched the Virtual Directory created in Step 3



6. Launch the HMI in a browser

The EventVideoPlayback control will only work in browser launch or fully deployed environment. HMI Live View will not allow you to play video files due to the virtual directory usage.

7. Double click the Video event to play



Note

- If you only see a blank playback window, try adjusting the codec that was used to record the video
- If you get a "Waiting For Video" in place of "Play Video", try the following:
 - Re-adding the EventVideo Control
 - o Completely remove the virtual directory and re-add
 - Make sure Check Retires and Check Delay is set in the properties window of the control