Getting Started

Installer Requirements

- Windows 10 or higher (x64 only)
- TwinCAT XAR 4024.4x or higher (Service Only)
- TwinCAT XAE 4024.4x or higher (PLC and HMI components)
- TE2000 v1.12.760 or higher
- TF2000 v1.12.760 or higher

Build Project Source Requirements

These requirements are only if you are looking to build the source code located inside GitHub.

- VS 2022 Pro with .Net components (System Service)
- VS 2019 Pro (TcHMI Control Extension)
- TwinCAT XAR 4024.4x
- TE2000 v1.12.760 or higher
- Advanced Installer 21.9 (Building MSI)
- Python
- mkdocs
- mkdocs-material