6502.org: Source: Porting Sweet 16

[Return to Main Page]

Porting Sweet 16 by Carsten Strotmann (carsten@strotmann.de)

[<u>Up to Source Code Repository</u>]

Sweet 16 is a metaprocessor or "pseudo microprocessor" implemented in 6502 assembly language. Originally written by Steve Wozniak and used in the Apple II, Sweet 16 can also be ported to other 6502-based systems to provide useful 16-bit functionality. This article includes the source code for Sweet 16, along with a brief history, programming instructions, and notes to help port it.

This material was provided by Carsten Strotmann, who has built a working Atari Port of Sweet 16, <u>for BIBO</u> and <u>for Mac/65</u> assemblers. See also <u>the appendix</u> for material added later, after <u>a discussion on the 6502 forum</u>.

- Porting Sweet 16
- The Story of Sweet 16 (as told by Woz)
- Source code (Sweet 16)
- Sweet 16 Introduction
- Sweet 16: A Pseudo 16-bit Microprocessor
 - <u>Description</u>
 - Instruction Descriptions
 - o Sweet 16 Opcode Summary
 - Register Instructions
 - Theory of Operation
 - When is an RTS really a JSR?
 - o Opcode Subroutines
 - o Memory Allocation
 - <u>User Modifications</u>
 - Notes from Apple II System Description
- Sweet 16 S-C Macro Assembler Text
 - o Programming Model
 - Sweet 16 Opcodes
- Appendix: Additional Material

Porting Sweet 16

Sweet 16 is not a teen-magazine, nor is it a brand name for candy. It is a really tricky und useful extension to a 6502 computer. It was originally written by Apple's Steve "Woz" Wozniak and can be found in the ROM of some APPLE [[Computers. Sweet 16 is a kind of virtual machine that gives the 6502 programmer a 16 bit extension to the CPU. Sweet 16 creates sixteen 16-bit registers/pointers (in zero page) and new opcodes to use this registers. Although Sweet 16 is not as fast as standard 6502 code, it can reduce the code size of your programms and ease programming.

This text focuses only on the task of porting Sweet 16 to another 6502 based computer. Information on the useage and the interals of Sweet 16 can be found in the documentation by Steve Wozniak and the article by Dick Sedgewick.

Porting Sweet 16 is easy, if you know what to take into account. There are three main issues:

- 1. the location of the zero page registers
- 2. the base address of the code in memory
- 3. the save and restore routines

Let's start with the zero page registers

Sweet 16 needs 32 zero page addresses for the 16 registers (R0-R15). In the original Apple Version this registers are from \$0 to \$1F,in the ATARI Version the locations \$E0-\$FF are used. You can place this registers anywhere in the zeropage, but it have to be a contiguous range.

The base address of the code

Sweet 16 uses a tricky indirect 8-Bit jump to access the routines for each opcode. This saves some space in the code. But for this hack to work, some precaution have to be taken for the code. All code from the label "SET" to the label "RTN" have to be assembled in one 6502 Page (\$100/256 Bytes). If you mind this, everything should work fine.

The "save" and "restore" routines

The Apple][Version of Sweet 16 uses the ROM-internal "save" and "restore" routines to save and restore all processor registers and flags. If your system has such routines in ROM, fine, just use them. If not, you have to add these routines to your programm. Here is a template:

Thats all. Porting Sweet 16 is easy and straightforward. I hope to see some Sweet 16 enhanced 6502 source in the future. If someone is searching for a nice project, extending an open-source 6502 Assembler (like CA65 from CC65) with the Sweet 16 opcodes would be one:)

The Story of Sweet 16 (as told by Woz)

While writing Apple BASIC, I ran into the problem of manipulating the 16 bit pointer data and its arithmetic in an 8 bit machine.

My solution to this problem of handling 16 bit data, notably pointers, with an 8 bit microprocessor was to implement a non-existent 16 bit processor in software, interpreter fashion, which I refer to as SWEET16. SWEET16 contains sixteen internal 16 bit registers, actually the first 32 bytes in main memory, labelled R0 through R15. R0 is defined as the accumulator, R15 as the program counter, and R14 as a status register. R13 stores the result of all COMPARE operations for branch testing. The user acceses SWEET16 with a subroutine call to hexadecimal address F689. Bytes stored after the subroutine call are thereafter interpreted and executed by SWEET16. One of SWEET16's commands returns the user back to 6502 mode, even restoring the original register contents.

Implemented in only 300 bytes of code, SWEET16 has a very simple instruction set tailored to operations such as memory moves and stack manipulation. Most opcodes are only one byte long, but since she runs approximately ten times slower than equivalent 6502 code, SWEET16 should be employed only when code is at a premium or execution is not. As an example of her usefulness, I have estimated that about 1K byte could be weeded out of my 5K byte Apple-II BASIC interpreter with no observable performance degradation by selectively applying SWEET16. [Full article in BYTE magazine here.]

Source code (Sweet 16)

INC R15H

IDA >SET

SW16D

The following is from a 1994 post to Usenet group comp.sys.apple2.programmer by Sheldon Simms.

```
Article 1684 of comp.sys.apple2.programmer:
Newsgroups: comp.sys.apple2.programmer
Path: amdahl.uts.amdahl.com!amdahl!amd!decwrl!sdd.hp.com!elroy.jpl.nasa.gov!swrinde!ihnp4.ucsd.edu!library.ucla.edu!csulb.edu!csus.edu!netcom.com!sheldon
From: sheldon@netcom.com (Sheldon Simms)
Subject: Source code (Sweet 16)
Message-ID: <sheldonCLz3qM.85r@netcom.com>
Organization: NETCOM On-line Communication Services (408 241-9760 quest)
Date: Tue, 1 Mar 1994 06:37:33 GMT
Well maybe this should go to comp.sources.apple2 but it's not too long
and in my mind it's part of the thread on learning assembly language
programming. It's an opportunity to learn from Woz himself.
-Sheldon
******
    APPLE-TT PSEUDO MACHINE
         INTERPRETER
      COPYRIGHT (C) 1977
     APPLE COMPUTER, INC
     ALL RIGHTS RESERVED
         S. WOZNIAK
* TITLE: SWEET 16 INTERPRETER
******
RØL
       EQU
           $0
       EOU
R14H
       EQU
            $1D
R15I
       EOU
           $1E
R15H
       FOU
            $1F
            $FF4A
SAVE
       EQU
RESTORE EQU
            $FF3F
       ORG $F689
       AST
        ISR
            SAVE
                           ; PRESERVE 6502 REG CONTENTS
       PLA
       STA
           R15L
                           ; INIT SWEET16 PC
       PLA
                           ;FROM RETURN
            R15H
                           ; ADDRESS
        STA
                           :INTERPRET AND EXECUTE
SW16B
       JSR
            SW16C
        JMP
            SW16B
                           :ONE SWEET16 INSTR.
SW16C
       TNC
            R15L
       BNE
                           ;INCR SWEET16 PC FOR FETCH
```

2 of 16 13/03/2024, 16:26

· COMMON HIGH BYTE FOR ALL ROUTINES

```
; PUSH ON STACK FOR RTS
        PHA
             (R15L),Y
                              ;FETCH INSTR
        AND
                              ; MASK REG SPECIFICATION
                              :DOUBLE FOR TWO BYTE REGISTERS
        ASL
        TAX
                              ;TO X REG FOR INDEXING
        EOR
              (R15L),Y
                              ; NOW HAVE OPCODE
                              ;IF ZERO THEN NON-REG OP ;INDICATE "PRIOR RESULT REG"
        BEQ
             TOBR
        STX
             R14H
        LSR
        LSR
                              ;OPCODE*2 TO LSB'S
        LSR
                              :TO Y REG FOR INDEXING
        TAY
                              ;LOW ORDER ADR BYTE
        LDA
            OPTBL-2,Y
        PHA
                              ;ONTO STACK
        RTS
                              ;GOTO REG-OP ROUTINE
TOBR
        INC
             R15L
             TOBR2
                              ;INCR PC
        BNE
        INC
             R15H
TOBR2
             BRTBL,X
                              ;LOW ORDER ADR BYTE
                              ;ONTO STACK FOR NON-REG OP ;"PRIOR RESULT REG" INDEX
        PHA
             R14H
        LDA
                              ;PREPARE CARRY FOR BC, BNC.
        LSR
        RTS
                              ;GOTO NON-REG OP ROUTINE
RTNZ
        PLA
                              ;POP RETURN ADDRESS
        PLA
             RESTORE
                              ;RESTORE 6502 REG CONTENTS
        JSR
              (R15L)
                              ;RETURN TO 6502 CODE VIA PC
SETZ
              (R15L),Y
                              ;HIGH ORDER BYTE OF CONSTANT
        STA
             RØH,X
        DEY
                              ;LOW ORDER BYTE OF CONSTANT
             (R15L),Y
        LDA
        STA
             RØL,X
        \mathsf{TYA}
                              :Y REG CONTAINS 1
        SEC
             R15L
                              :ADD 2 TO PC
        ADC
        STA
             R15L
        INC
             R15H
SET2
        RTS
OPTBL
             SET-1
        DFB
                              :1X
        DFB
             RTN-1
                              ;0
        DFB
             LD-1
                              ;2X
        DFB
             BR-1
             ST-1
        DFB
                              :3X
        DFB
             BNC-1
                              ;2
             LDAT-1
        DFB
                              ;4X
        DFB
             BC-1
        DFB
DFB
             STAT-1
                              ;5X
             BP-1
                              :4
             LDDAT-1
        DFB
                              ;6X
        DFB
        DFB
             STDAT-1
                              ;7X
        DFB
             BZ-1
                              ;6
        DFB
             POP-1
                              :8X
        DFB
             BNZ-1
        DFB
             STPAT-1
                              ;9X
        DFB
             BM1-1
                              ;8
        DFB
             ADD-1
                              :AX
        DFB
             BNM1-1
                              ;9
        DFB
             SUB-1
                              ;BX
        DFB
             BK-1
        DFB
             POPD-1
                              :CX
        DFB
             RS-1
                              ;B
        DFB
             CPR-1
                              ;DX
        DFB
             BS-1
        DFB
             INR-1
                              ;EX
        DFB
             NUL - 1
                              ;D
        DFB
             DCR-1
                              ;FX
        DFB
             NUL-1
        DFB
             NUL-1
                              ;UNUSED
        DFB NUL-1
* FOLLOWING CODE MUST BE
* CONTAINED ON A SINGLE PAGE!
SET
        BPL SETZ
                              :ALWAYS TAKEN
        LDA
LD
             RØL,X
ВК
        EQU
             RØL
        LDA
             RØH,X
                              ; MOVE RX TO R0
        STA
             RØH
        RTS
ST
        LDA
             RØL
        STA
             RØL,X
                              ;MOVE RØ TO RX
        LDA
             RØH
        STA
             RØH,X
        RTS
STAT
        LDA
             RØL
STAT2
        STA
              (R0L,X)
                              ;STORE BYTE INDIRECT
        LDY
             $0
             R14H
                              ;INDICATE RØ IS RESULT NEG
STAT3
        STY
             RØL,X
INR
        INC
        BNE
             INR2
                              :INCR RX
        TNC
             RØH,X
INR2
        RTS
                              ;LOAD INDIRECT (RX)
LDAT
        LDA
             (RØL,X)
```

		RØL	;TO RØ
	LDY	\$0 R0H	;ZERO HIGH ORDER RØ BYTE
		STAT3	;ALWAYS TAKEN
POP	LDY		;HIGH ORDER BYTE = 0
POPD		POP2 DCR	;ALWAYS TAKEN ;DECR RX
		(RØL,X)	;POP HIGH ORDER BYTE @RX
2022	TAY	0.00	;SAVE IN Y REG
POP2	JSR	DCR (R0L,X)	;DECR RX ;LOW ORDER BYTE
	STA	RØL	;TO RØ
POP3	STY		;INDICATE RØ AS LAST RESULT REG
PUPS	LDY STY	\$0 R14H	, INDICATE RW AS LAST RESULT REG
	RTS		
LDDAT		LDAT	;LOW ORDER BYTE TO R0, INCR RX ;HIGH ORDER BYTE TO R0
	STA	(RØL,X) RØH	, HIGH ORDER BITE TO RE
		INR	;INCR RX
STDAT		STAT RØH	;STORE INDIRECT LOW ORDER ;BYTE AND INCR RX. THEN
	STA	(RØL,X)	;STORE HIGH ORDER BYTE.
STRAT	JMP	INR	;INCR RX AND RETURN
STPAT	LDA	DCR RØL	;DECR RX
	STA	(R0L,X)	;STORE RØ LOW BYTE @RX
DCR	JMP	POP3 RØL,X	;INDICATE R0 AS LAST RESULT REG
DCK		DCR2	;DECR RX
		RØH,X	
DCR2	DEC RTS	RØL,X	
SUB	LDY	\$0	;RESULT TO R0
		SEC	;NOTE Y REG = 13*2 FOR CPR
	LDA SBC	RØL RØL,X	
		RØL,Y	;R0-RX TO RY
	LDA SBC	R0H R0H,X	
SUB2		RØH,Y	
	TYA	**	;LAST RESULT REG*2
	ADC STA		;CARRY TO LSB
	RTS		
ADD		RØL RØL,X	
		RØL	;R0+RX TO R0
	LDA		
	LDY	R0H,X \$0	;R0 FOR RESULT
		SUB2	;FINISH ADD
BS		R15L STAT2	;NOTE X REG IS 12*2! ;PUSH LOW PC BYTE VIA R12
		R15H	7. 03 2011 10 31.12 11 11.2
BR	JSR CLC	STAT2	;PUSH HIGH ORDER PC BYTE
BNC	BCS	BNC2	;NO CARRY TEST
BR1		(R15L),Y	;DISPLACEMENT BYTE
	DEA	BR2	
BR2	ADC	R15L	;ADD TO PC
	STA TYA	R15L	
		R15H	
		R15H	
BNC2 BC	RTS BCS	BR	
	RTS		
BP	ASL TAX		;DOUBLE RESULT-REG INDEX ;TO X REG FOR INDEXING
		RØH,X	;TEST FOR PLUS
		BR1	;BRANCH IF SO
ВМ	RTS ASL		;DOUBLE RESULT-REG INDEX
	TAX		
		R0H,X BR1	;TEST FOR MINUS
	RTS	5112	
BZ	ASL TAX		;DOUBLE RESULT-REG INDEX
		RØL,X	;TEST FOR ZERO
		RØH,X	;(BOTH BYTES)
	BEQ RTS	BR1	;BRANCH IF SO
BNZ	ASL		;DOUBLE RESULT-REG INDEX
	TAX	RØL,X	;TEST FOR NON-ZERO
		RØH,X	;(BOTH BYTES)
	BNE	BR1	;BRANCH IF SO
BM1	RTS ASL		;DOUBLE RESULT-REG INDEX
	TAX		
		RØL,X RØH,X	;CHECK BOTH BYTES ;FOR \$FF (MINUS 1)
	EOR	\$FF	, on wit (minus i)
		BR1	;BRANCH IF SO
	RTS		

```
BNM1
                            ;DOUBLE RESULT-REG INDEX
       ASL
        TAX
             RØL,X
        LDA
        AND
             RØH,X
                            :CHECK BOTH BYTES FOR NO $FF
       EOR
            $FF
                            :BRANCH IF NOT MINUS 1
        BNE
             BR1
        LDX $18
                            ;12*2 FOR R12 AS STACK POINTER
RS
        JSR
            DCR
                            :DECR STACK POINTER
                            :POP HIGH RETURN ADDRESS TO PC
        LDA
             (RØL,X)
        STA
            R15H
        JSR
                            ;SAME FOR LOW ORDER BYTE
             DCR
             (RØL,X)
        I DA
        STA R15L
        RTS
RTN
        JMP
             RTNZ
 W. Sheldon Simms
                           Newt's Friend / Jack Kemp for President
                         | Freedom implies responsibility
sheldon@netcom.com
Article 1685 of comp.sys.apple2.programmer:
Newsgroups: comp.sys.apple2.programmer
Path: amdahl.uts.amdahl.com!amdahl!amd!decwrl!sdd.hp.com!elroy.jpl.nasa.gov!swrinde!ihnp4.ucsd.edu!library.ucla.edu!csulb.edu!csus.edu!netcom.com!sheldon
From: sheldon@netcom.com (Sheldon Simms)
Subject: Sweet 16 description
Message-ID: <sheldonCLz3tB.8C4@netcom.com>
Organization: NETCOM On-line Communication Services (408 241-9760 quest)
Date: Tue, 1 Mar 1994 06:39:11 GMT
Lines: 992
Well since I posted the source, here's what it does for anyone who
-Sheldon
```

Sweet 16 - Introduction

by Dick Sedgewick (from Merlin Users Manual)

Sweet 16 is probably the least used and least understood seed in the Apple][.

In exactly the same sense that Integer and Applesoft Basics are languages, SWEET 16 is a language. Compared to the Basics, however, it would be classed as low level with a strong likeness to conventional 6502 Assembly language.

To use SWEET 16, you must learn the language - and to quote "WOZ", "The opcode list is short and uncomplicated". "WOZ" (Steve Wozniak), of course is Mr. Apple, and the creator of SWEET 16.

SWEET 16 is ROM based in every Apple J[from \$F689 to \$F7FC. It has it's own set of opcodes and instruction sets, and uses the SAVE and RESTORE routines from the Apple Monitor to preserve the 6502 registers when in use, allowing SWEET 16 to be used as a subroutine.

It uses the first 32 locations on zero page to set up its 16 double byte registers, and is therefore not compatible with Applesoft Basic without some additional efforts.

The original article, "SWEET 16: The 6502 Dream Machine", first appeared in Byte Magazine, November 1977 and later in the original "WOZ PAK". The article is included here and again as test material to help understand the use and implementation of SWEET 16.

Examples of the use of SWEET 16 are found in the Programmer's Aid #1, in the Renumber, Append, and Relocate programs. The Programmer's Aid Operating Manual contains complete source assembly listings, indexed on page 65.

The demonstration program is written to be introductory and simple, consisting of three parts:

- 1. Integer Basic Program
- 2. Machine Language Subroutine
- 3. SWEET 16 Subroutine

The task of the program will be to move data. Parameters of the move will be entered in the Integer Basic Program.

The "CALL 768" (\$300) at line 120, enters a 6502 machine language subroutine having the single purpose of entering SWEET 16 and subsequently returning to BASIC (addresses \$300, \$301, \$302, and \$312 respectively). The SWEET 16 subroutine of course performs the move, and is entered at Hex locations \$303 to \$311 (see listing Number 3).

After the move, the screen will display three lines of data, each 8 bytes long, and await entry of a new set of parameters. The three lines of data displayed on the screen are as follows:

- Line 1: The first 8 bytes of data starting at \$800, which is the fixed source data to be moved (in this case, the string A\$).
- Line 2: The first 8 bytes of data starting at the hex address entered as the destination of the move (high order byte only).
- Line 3: The first 8 bytes of data starting at \$0000 (the first four SWEET 16 registers).

The display of 8 bytes of data was chosen to simplify the illustration of what goes on.

Integer Basic has its own way of recording the string A\$. Because the name chosen for the string "A\$" is stored in 2 bytes, a total of five housekeeping bytes precede the data entered as A\$, leaving only three additional bytes available for display. Integer Basic also adds a

6502.org: Source: Porting Sweet 16

housekeeping byte at the end of a string, known as the "string terminator".

Consequently, for convenience purposes of the display, and to see the string terminator as the 8th byte, the string data entered via the keyboard should be limited to two characters, and will appear as the 6th and 7th bytes. Additionally, parameters to be entered include the number of bytes to be moved. A useful range for this demonstration would be 1-8 inclusive, but of course 1-255 will work.

Finally, the starting address of the destination of the move must be entered. Again, for simplicity, only the high-order byte is entered, and the program allows a choice between Decimal 9 and high-order byte of program pointer 1, to avoid unnecessary problems (in this demonstration enter a decimal number between 9 and 144 for a 48K APPLE).

The 8 bytes of data displayed starting at \$00 will enable one to observe the condition of the SWEET 16 registers after a move has been accomplished, and thereby understand how the SWEET 16 program works.

From the article "SWEET 16: A 6502 Dream Machine", remember that SWEET 16 can establish 16 double byte registers starting at \$00. This means that SWEET 16 can use the first 32 addresses on zero page.

The "events" occurring in this demonstration program can be studied in the first four SWEET 16 registers. Therefore, the 8 byte display starting at \$0000 is large enough for this purpose.

These four registers are established as R0, R1, R2, R3:

```
$0000
                         0001
                                     -SWEET 16 accumulator
R0
                     &
R1
          $0002
                     &
                         0003
                                     -Source address
           $0004
                         0005
                                      -Destination address
                     &
R3
           $0006
                         0007
                                      -Number of bytes to move
R14
           $001C
                     &
                         001D
                                      -Prior result register
R15
                     &
                                     -SWEET 16 Program counter
          $001E
                         001F
```

Additionally, an examination of registers R14 and R15 will extend and understanding of SWEET 16, as fully explained in the "WOZ" text. Notice that the high order byte of R14, (located at \$1D) contains \$06, and is the doubled register specification (3X2=\$06). R15, the SWEET 16 program counter contains the address of the next operation as it did for each step during execution of the program, which was \$0312 when execution ended and the 6502 code resumed.

To try a sample run, enter the Integer Basic program as shown in Listing #1. Of course, REM statements can be omitted, and line 10 is only helpful if the machine code is to be stored on disk. Listing #2 must also be entered starting at \$300.

NOTE: A 6502 disassembly does not look like listing #3, but the SOURCEROR disassembler would create a correct disassembly.

```
Enter "RUN" and hit RETURN
Enter "12" and hit RETURN (A$ - A$ string data)
Enter "18" and hit RETURN (high-order byte of destination)
```

The display should appear as follows:

```
$0800-C1 40 00 10 08 B1 B2 1E (SOURCE)
$0A00-C1 40 00 10 08 B1 B2 1E (Dest.)
$0000-1E 00 08 08 08 0A 00 00 (SWEET 16)
```

NOTE: The 8 bytes stored at \$0A00 are identical to the 8 bytes starting at \$0800, indicating that an accurate move of 8 bytes length has been made. They are moved one byte at a time starting with token C1 and ending with token 1E. If moving less than 8 bytes, the data following the moved data would be whatever existed at those locations before the move.

The bytes have the following significance:

A Token\$



The SWEET 16 registers are as shown:

```
low
           hiah
                          high
                                          high
                                                   low
                                                         high
$0000 1E
           00
                     08
                           08
                                    08
                                           0A
                                                    00
                                                          00
      register
                     register
                                     register
                                                    register
         R0
                        R1
                                        R2
                                                       R3
                                                    (#bytes)
                     (source)
                                      (dest)
       (acc)
```

The low order byte of R0, the SWEET 16 accumulator, has \$1E in it, the last byte moved (the 8th).

The low order byte of the source register R1 started as \$00 and was incremented eight times, once for each byte of moved data.

The high order byte of the destination register R2 contains \$0A, which was entered at 10 (the variable) and poked into the SWEET 16 code. The low-order byte of R2 was incremented exactly like R1.

Finally, register R3, the register that stores the number of bytes to be moved, has been poked to 8 (the variable B) and decremented eight times as each byte got moved, ending up \$0000.

By entering character strings and varying the number of bytes to be moved, the SWEET 16 registers can be observed and the contents predicted.

Working with this demonstration program, and study of the text material will enable you to write SWEET 16 programs that perform additional 16 bit manipulations. The unassigned opcodes mentioned in the "WOZ Dream Machine" article should present a most interesting opportunity to "play".

SWEET 16 as a language - or tool - opens a new direction to Apple][owners without spending a dime, and it's been there all the time.

"Apple-ites" who desire to learn machine language programming, can use SWEET 16 as a starting point. With this text material to use, and less opcodes to learn, a user can quickly be effective.

Listing #1

```
>List
     10
            PRINT "[D]BLOAD SWEET": REM CTRL D
            CALL - 936: DIM A $ (10)
     20
            INPUT "ENTER STRING A $ "
     30
            INPUT "ENTER # BYTES " , B
     40
            IF NOT B THEN 40 : REM AT LEAST 1
    50
            POKE 778 , B : REM POKE LENGTH
    60
            INPUT "ENTER DESTINATION "
     80
            IF A > PEEK (203) - 1 THEN 70
            IF A < PEEK (205) + 1 THEN 70
     90
            POKE 776 , A : REM POKE DESTINATION
     100
            M = 8 : GOSUB 160 : REM DISPLAY
     110
     120
            CALL 768 : REM GOTO $0300
     130
            M = A : GOSUB 160 : REM DISPLAY
            M = 0 : GOSUB 160 : REM DISPLAY
     140
            PRINT : PRINT : GOTO 30
     150
     160
            POKE 60 , 0 : POKE 61 , M
            CALL -605 : RETURN : REM XAM8 IN MONITOR
     170
Listina #2
     300:20 89 F6 11 00 08 12 00 00 13 00 00 41 52
         F3 07 FB 00 60
Listing #3
SWEET 16
     $300 20 89 F6
                        ISR
                               $F689
     $303
           11
              00
                   08
                        SET
                               R1 source address
    $306
          12 00 00
                        SET
                               R2 destination address
     $309 13 00
                        SET
                               R3 length
     $30C
          41
                        LD
                               @R1
     $30D
          52
                        ST
                               @R2
     $30E
          F3
                        DCR
                               R3
     $30F
          07
                        BNZ
                               $30C
                        RTN
    $312 60
                        RTS
Data will be poked from the Integer Basic program:
                    from Line 100
                    from Line 60
```

SWEET 16: A Pseudo 16 Bit Microprocessor

by Steve Wozniak

Description:

While writing APPLE BASIC for a 6502 microprocessor, I repeatedly encountered a variant of MURPHY'S LAW. Briefly stated, any routine operating on 16-bit data will require at least twice the code that it should. Programs making extensive use of 16-bit pointers (such as compilers, editors, and assemblers) are included in this category. In my case, even the addition of a few double-byte instructions to the 6502 would have only slightly alleviated the problem. What I really needed was a 6502/RCA 1800 hybrid - an abundance of 16-bit registers and excellent pointer capability.

My solution was to implement a non-existant (meta) 16-bit processor in software, interpreter style, which I call SWEET 16.

SWEET 16 is based on sixteen 16-bit registers (R0-15), which are actually 32 memory locations. R0 doubles as the SWEET 16 accumulator (ACC), R15 as the program counter (PC), and R14 as the status register. R13 holds compare instruction results and R12 is the subroutine return stack pointer if SWEET 16 subroutines are used. All other SWEET 16 registers are at the user's unrestricted disposal.

SWEET 16 instructions fall into register and non-register categories. The register ops specify one of the sixteen registers to be used as either a data element or a pointer to data in memory, depending on the specific instruction. For example INR R5 uses R5 as data and ST @R7 uses R7 as a pointer to data in memory. Except for the SET instruction, register ops take one byte of code each. The non-register ops are primarily 6502 style branches with the second byte specifying a +/-127 byte displacement relative to the address of the following instruction. Providing that the prior register op result meets a specified branch condition, the displacement is added to the SWEET 16 PC, effecting a branch.

SWEET 16 is intended as a 6502 enhancement package, not a stand alone processor. A 6502 program switches to SWEET 16 mode with a subroutine call and subsequent code is interpreted as SWEET 16 instructions. The nonregister op RTN returns the user program to 6502 mode after restoring the internal register contents (A, X, Y, P, and S). The following example illustrates how to use SWEET 16.

```
300
    B9 00 02
                         LDA
                               IN,Y
                                         ;get a char
303
    C9 CD
                                         ;"M" for move
305
    DØ 09
                         BNE
                               NOMOVE
                                         ;No. Skip move
307
    20 89 F6
                         JSR
                               SW16
                                         ;Yes, call SWEET 16
                MLOOP
30A 41
                         LD
                               @R1
                                         :R1 holds source
30B
    52
                               @R2
                         ST
                                         ;R2 holds dest. addr.
                         DCR
30C
                                         ;Decr. length
30D
    07 FB
                         BNZ
                               ML00P
                                         ;Loop until done
30F
     00
                         RTN
                                         ;Return to 6502 mode.
    C9 C5
                               #"F"
                NOMOVE
310
                        CMP
                                         :"E" char?
                         BEQ
                                         ;Yes, exit
312
    DØ 13
                               EXIT
```

NOTE: Registers A, X, Y, P, and S are not disturbed by SWEET 16.

Instruction Descriptions:

The SWEET 16 opcode listing is short and uncomplicated. Excepting relative branch displacements, hand assembly is trivial. All register opcodes are formed by combining two Hex digits, one for the opcode and one to specify a register. For example, opcodes 15 and 45 both specify register R5 while codes 23, 27, and 29 are all ST ops. Most register ops are assigned in complementary pairs to facilitate remembering them. Therefore, LD ans ST are opcodes 2N and 3N respectively, while LD @ and ST @ are codes 4N and 5N.

Opcodes 0 to C (Hex) are assigned to the thirteen non-register ops. Except for RTN (opcode 0), BK (0A), and RS (0B), the non register ops are 6502 style branches. The second byte of a branch instruction contains a +/-127 byte displacement value (in two's complement form) relative to the address of the instruction immediately following the branch.

If a specified branch condition is met by the prior register op result, the displacement is added to the PC effecting a branch. Except for the BR (Branch always) and BS (Branch to a Subroutine), the branch opcodes are assigned in complementary pairs, rendering them easily remembered for hand coding. For example, Branch if Plus and Branch if Minus are opcodes 4 and 5 while Branch if Zero and Branch if NonZero? are opcodes 6 and 7.

SWEET 16 Opcode Summary:

Register OPS-

1n	SET	Rn	Constant (Set)
2n	LD	Rn	(Load)
3n	ST	Rn	(Store)
4n	LD	@Rn	(Load Indirect)
5n	ST	@Rn	(Store Indirect)
6n	LDD	@Rn	(Load Double Indirect)
7n	STD	@Rn	(Store Double Indirect)
8n	POP	@Rn	(Pop Indirect)
9n	STP	@Rn	(Store POP Indirect)
An	ADD	Rn	(Add)
Bn	SUB	Rn	(Sub)
Cn	POPD	@Rn	(Pop Double Indirect)
Dn	CPR	Rn	(Compare)
En	INR	Rn	(Increment)
Fn	DCR	Rn	(Decrement)
6n 7n 8n 9n An Bn Cn Dn	LDD STD POP STP ADD SUB POPD CPR INR	@Rn @Rn @Rn @Rn Rn Rn @Rn Rn	(Load Double Indirect (Store Double Indirect (Pop Indirect) (Store POP Indirect) (Add) (Sub) (Pop Double Indirect) (Compare) (Increment)

Non-register OPS-

00	RTN		(Return to 6502 mode)
01	BR	ea	(Branch always)
02	BNC	ea	(Branch if No Carry)
03	BC	ea	(Branch if Carry)
04	BP	ea	(Branch if Plus)
05	BM	ea	(Branch if Minus)
06	BZ	ea	(Branch if Zero)
07	BNZ	ea	(Branch if NonZero)
08	BM1	ea	(Branch if Minus 1)
09	BNM1	ea	(Branch if Not Minus 1)
0A	BK		(Break)
0B	RS		(Return from Subroutine)
0C	BS	ea	(Branch to Subroutine)
0D			(Unassigned)
0E			(Unassigned)
0F			(Unassigned)

Register Instructions:

SET:

SET Rn, Constant [1n Low High]

The 2-byte constant is loaded into Rn (n=0 to F, Hex) and branch conditions set accordingly. The carry is cleared.

EXAMPLE:

```
15 34 A0 SET R5 $A034 ;R5 now contains $A034 LOAD: LD Rn [ 2n ]
```

The ACC (R0) is loaded from Rn and branch conditions set according to the data transferred. The carry is cleared and contents of Rn are not disturbed.

EXAMPLE:

```
15 34 A0 SET R5 $A034
25 LD R5 :ACC now contains $A034
```

STORE:

ST Rn [3n]

The ACC is stored into Rn and branch conditions set according to the data transferred. The carry is cleared and the ACC contents are not disturbed.

EXAMPLE:

```
25 LD R5 ;Copy the contents
36 ST R6 ;of R5 to R6
```

LOAD INDIRECT:

LD @Rn [4n]

The low-order ACC byte is loaded from the memory location whose address resides in Rn and the high-order ACC byte is cleared. Branch conditions reflect the final ACC contents which will always be positive and never minus 1. The carry is cleared. After the transfer, Rn is incremented by 1.

EXAMPLE

```
15 34 A0 SET R5 $A034
45 LD @R5 ;ACC is loaded from memory
;location $A034
;R5 is incr to $A035
```

STORE INDIRECT:

ST @Rn [5n]

The low-order ACC byte is stored into the memory location whose address resides in Rn. Branch conditions reflect the 2-byte ACC contents. The carry is cleared. After the transfer Rn is incremented by 1.

EXAMPLE:

```
15 34 A0 SET R5 $A034 ;Load pointers R5, R6 with 16 22 90 SET R6 $9022 ;$A034 and $9022 
45 LD @R5 ;Move byte from $A034 to $9022 
56 ST @R6 ;Both ptrs are incremented
```

LOAD DOUBLE-BYTE INDIRECT:

LDD @Rn [6n]

The low order ACC byte is loaded from memory location whose address resides in Rn, and Rn is then incremented by 1. The high order ACC byte is loaded from the memory location whose address resides in the incremented Rn, and Rn is again incremented by 1. Branch conditions reflect the final ACC contents. The carry is cleared.

EXAMPLE:

```
15 34 A0 SET R5 $A034 ;The low-order ACC byte is loaded
65 LDD @R6 ;from $A034, high-order from
;$A035, R5 is incr to $A036
```

STORE DOUBLE-BYTE INDIRECT:

STD @Rn [7n]

The low-order ACC byte is stored into memory location whose address resides in Rn, and Rn is the incremented by 1. The high-order ACC byte is stored into the memory location whose address resides in the incremented Rn, and Rn is again incremented by 1. Branch conditions reflect the ACC contents which are not disturbed. The carry is cleared.

EXAMPLE:

```
15 34 A0 SET R5 $A034 ;Load pointers R5, R6
16 22 90 SET R6 $9022 ;with $A034 and $9022
65 LDD @R5 ;Move double byte from
76 STD @R6 ;$A034-35 to $9022-23.
;Both pointers incremented by 2.
```

POP INDIRECT:

POP @Rn [8n]

The low-order ACC byte is loaded from the memory location whose address resides in Rn after Rn is decremented by 1, and the high order ACC byte is cleared. Branch conditions reflect the final 2-byte ACC contents which will always be positive and never minus one. The carry is cleared. Because Rn is decremented prior to loading the ACC, single byte stacks may be implemented with the ST @Rn and POP @Rn ops (Rn is the stack pointer).

EXAMPLE:

```
15 34 A0
          SET R5
                    $A034
                              ;Init stack pointer
10 04 00
          SET R0
                   4
                              ;Load 4 into ACC
               @R5
                              ;Push 4 onto stack
10 05 00
          SET RØ 5
                              ;Load 5 into ACC
55
          ST
               @R5
                              :Push 5 onto stack
10 06 00
          SET RØ 6
                              ;Load 6 into ACC
               @R5
                              ;Push 6 onto stack
85
          POP
               @R5
                              ;Pop 6 off stack into ACC
85
          POP
               @R5
                              ;Pop 5 off stack
                              ;Pop 4 off stack
85
          POP
               @R5
```

STORE POP INDIRECT:

STP @Rn [9n]

The low-order ACC byte is stored into the memory location whose address resides in Rn after Rn is decremented by 1. Branch conditions will reflect the 2-byte ACC contents which are not modified. STP @Rn and POP @Rn are used together to move data blocks beginning at the greatest address and working down. Additionally, single-byte stacks may be implemented with the STP @Rn ops.

EXAMPLE:

```
14 34 A0
           SET R4
                    $A034
                              ;Init pointers
15 22 90
          SET R5
                    $9022
           POP
               @R4
                              ;Move byte from
           STP @R5
95
                              ;$A033 to $9021
84
           POP @R4
                              ;Move byte from
95
           STP @R5
                              :$A032 to $9020
```

ADD:

ADD Rn [An]

The contents of Rn are added to the contents of ACC (R0), and the low-order 16 bits of the sum restored in ACC. the 17th sum bit becomes the carry and the other branch conditions reflect the final ACC contents.

EXAMPLE:

```
10 34 76 SET R0 $7634 ;Init R0 (ACC) and R1
11 27 42 SET R1 $4227
A1 ADD R1 ;Add R1 (sum=B85B, C clear)
A0 ADD R0 ;Double ACC (R0) to $7086 ;with carry set.
```

SUBTRACT:

SUB Rn [Bn]

The contents of Rn are subtracted from the ACC contents by performing a two's complement addition:

```
ACC = ACC + Rn + 1
```

The low order 16 bits of the subtraction are restored in the ACC, the 17th sum bit becomes the carry and other branch conditions reflect the final ACC contents. If the 16-bit unsigned ACC contents are greater than or equal to the 16-bit unsigned Rn contents, then the carry is set, otherwise it is cleared. Rn is not disturbed.

EXAMPLE:

```
10 34 76 SET R0 $7634 ;Init R0 (ACC)
11 27 42 SET R1 $4227 ;and R1
B1 SUB R1 ;subtract R1 ;(diff=$340D with c set)
B0 SUB R0 ;clears ACC. (R0)
```

POP DOUBLE-BYTE INDIRECT:

POPD @Rn [Cn]

Rn is decremented by 1 and the high-order ACC byte is loaded from the memory location whose address now resides in Rn. Rn is again decremented by 1 and the low-order ACC byte is loaded from the corresponding memory location. Branch conditions reflect the final ACC contents. The carry is cleared. Because Rn is decremented prior to loading each of the ACC halves, double-byte stacks may be implemented with the STD @Rn and POPD @Rn ops (Rn is the stack pointer).

EXAMPLE:

```
15 34 A0
           SET R5
                    $A034
                               ;Init stack pointer
                               ;Load $AA12 into ACC
10 12 AA
           SET RØ
                    $AA12
           STD @R5
                               ;Push $AA12 onto stack
10 34 BB
           SET RØ $BB34
                               ;Load $BB34 into ACC
75
           STD @R5
                               ;Push $BB34 onto stack
           POPD @R5
                               :Pop $BB34 off stack
C5
           POPD @R5
                               ;Pop $AA12 off stack
C5
```

COMPARE:

CPR Rn [Dn]

The ACC (R0) contents are compared to Rn by performing the 16 bit binary subtraction ACC-Rn and storing the low order 16 difference bits in

10 of 16 13/03/2024, 16:26

R13 for subsequent branch tests. If the 16 bit unsigned ACC contents are greater than or equal to the 16 bit unsigned Rn contents, then the carry is set, otherwise it is cleared. No other registers, including ACC and Rn, are disturbed.

EXAMPLE:

```
15 34 A0
                    SFT
                        R5
                              $A034
                                        ;Pointer to memory
16 BF A0
                   SET
                        R6
                             $A0BF
                                        :Limit address
В0
           L00P1
                   SUB
                        RØ
                                        ;Zero data
                                        ;clear 2 locations
                   STD
                                        ;increment R5 by 2
25
                   LD
                        R5
                                        ;Compare pointer R5
                   CPR
D6
                        R6
                                        :to limit R6
02 FA
                   BNC LOOP1
                                        ;loop if C clear
```

INCREMENT:

INR Rn [En]

The contents of Rn are incremented by 1. The carry is cleared and other branch conditions reflect the incremented value.

EXAMPLE:

```
15 34 A0
           SET R5
                               ;(Pointer)
RØ
           SUB RØ
                               ;Zero to R0
55
           ST
               @R5
                               ;Clr Location $A034
           INR R5
E5
                               :Incr R5 to $A036
               @R5
                               ;Clrs location $A036
55
           ST
                               ;(not $A035)
```

DECREMENT:

DCR Rn [Fn]

The contents of Rn are decremented by 1. The carry is cleared and other branch conditions reflect the decremented value.

EXAMPLE: (Clear 9 bytes beginning at location A034)

```
15 34 A0
                   SFT R5
                             $A034
                                        ;Init pointer
14 09 00
                   SET
                        R4
                                        ;Init counter
                                        ;Zero ACC
B0
                   SUB
                       RØ
55
           L00P2
                   ST
                        @R5
                                        ;Clear a mem byte
                   DCR
                                        ;Decrement count
                        R4
07 FC
                   BNZ
                        L00P2
                                        :Loop until Zero
```

Non-Register Instructions:

RETURN TO 6502 MODE:

RTN 00

Control is returned to the 6502 and program execution continues at the location immediately following the RTN instruction. the 6502 registers and status conditions are restored to their original contents (prior to entering SWEET 16 mode).

BRANCH ALWAYS:

BR ea [01 d]

An effective address (ea) is calculated by adding the signed displacement byte (d) to the PC. The PC contains the address of the instruction immediately following the BR, or the address of the BR op plus 2. The displacement is a signed two's complement value from -128 to +127. Branch conditions are not changed.

NOTE: The effective address calculation is identical to that for 6502 relative branches. The Hex add & Subtract features of the APPLE J[monitor may be used to calculate displacements.

```
d = $80 ea = PC + 2 - 128
d = $81 ea = PC + 2 - 127
d = $FF ea = PC + 2 - 1
d = $00 ea = PC + 2 + 0
d = $01 ea = PC + 2 + 1
d = $7E ea = PC + 2 + 126
d = $7F ea = PC + 2 + 127
```

EXAMPLE:

```
$300: 01 50 BR $352
```

BRANCH IF NO CARRY:

BNC ea [02 d]

A branch to the effective address is taken only is the carry is clear, otherwise execution resumes as normal with the next instruction. Branch conditions are not changed.

BRANCH IF CARRY SET:

BC ea [03 d]

11 of 16 13/03/2024, 16:26

A branch is effected only if the carry is set. Branch conditions are not changed.

BRANCH IF PLUS:

BP ea [04 d]

A branch is effected only if the prior 'result' (or most recently transferred dat) was positive. Branch conditions are not changed.

EXAMPLE: (Clear mem from A034 to A03F)

```
15 34 A0
                    SET R5
                              $A034
                                        ;Init pointer
                    SET
                        R4
                                        ;Init limit
14 3F A0
В0
           L00P3
                   SUB RØ
55
                   ST
                        @R5
                                        :Clear mem byte
                                        ;Increment R5
24
                   LD
                        R4
                                        ;Compare limit
                   CPR
                        R5
                                        ;to pointer
D5
04 FA
                   RΡ
                        1.00P3
                                        ;Loop until done
```

BRANCH IF MINUS:

BM ea [05 d]

A branch is effected only if prior 'result' was minus (negative, MSB = 1). Branch conditions are not changed.

BRANCH IF ZERO:

BZ ea [06 d]

A Branch is effected only if the prior 'result' was zero. Branch conditions are not changed.

BRANCH IF NONZERO

BNZ ea [07 d]

A branch is effected only if the priot 'result' was non-zero Branch conditions are not changed.

BRANCH IF MINUS ONE

BM1 ea [08 d]

A branch is effected only if the prior 'result' was minus one (\$FFFF Hex). Branch conditions are not changed.

BRANCH IF NOT MINUS ONE

BNM1 ea [09 d]

A branch effected only if the prior 'result' was not minus 1. Branch conditions are not changed.

BREAK:

BK [0A]

A 6502 BRK (break) instruction is executed. SWEET 16 may be re-entered non destructively at SW16d after correcting the stack pointer to its value prior to executing the BRK.

RETURN FROM SWEET 16 SUBROUTINE:

RS [0B]

RS terminates execution of a SWEET 16 subroutine and returns to the SWEET 16 calling program which resumes execution (in SWEET 16 mode). R12, which is the SWEET 16 subroutine return stack pointer, is decremented twice. Branch conditions are not changed.

BRANCH TO SWEET 16 SUBROUTINE:

BS ea [0c d]

A branch to the effective address (PC + 2 + d) is taken and execution is resumed in SWEET 16 mode. The current PC is pushed onto a SWEET 16 subroutine return address stack whose pointer is R12, and R12 is incremented by 2. The carry is cleared and branch conditions set to indicate the current ACC contents.

EXAMPLE: (Calling a 'memory move' subroutine to move A034-A03B to 3000-3007)

```
15 34 A0
                   SET
                        R5
                             $A034
                                        ;Init pointer 1
14 3B A0
                   SET
                             $A03B
                                        ;Init limit 1
16 00 30
                   SET
                        R6
                             $3000
                                        ;Init pointer 2
                        MOVE
0C 15
                   RS
                                        :Call move subroutine
           MOVE
45
                        @R5
                                        ;Move one
                  LD
56
                        @R6
                   ST
                                        ;byte
24
                   LD
D5
                   CPR
                        R5
                                        ;Test if done
04 FA
                   ΒP
                        MOVE
                                        ;Return
```

Theory of Operation:

6502.org: Source: Porting Sweet 16

SWEET 16 execution mode begins with a subroutine call to SW16. All 6502 registers are saved at this time, to be restored when a SWEET 16 RTN instruction returns control to the 6502. If you can tolerate indefinate 6502 register contents upon exit, approximately 30 usec may be saved by entering at SW16 + 3. Because this might cause an inadvertant switch from Hex to Decimal mode, it is advisable to enter at SW16 the first time through.

After saving the 6502 registers, SWEET 16 initializes its PC (R15) with the subroutine return address off the 6502 stack. SWEET 16's PC points to the location preceding the next instruction to be executed. Following the subroutine call are 1-,2-, and 3-byte SWEET 16 instructions, stored in ascending memory like 6502 instructions. the main loop at SW16B repeatedly calls the 'execute instruction' routine to execute it.

Subroutine SW16C increments the PC (R15) and fetches the next opcode, which is either a register op of the form OP REG with OP between 1 and 15 or a non-register op of the form 0 OP with OP between 0 and 13. Assuming a register op, the register specification is doubled to account for the 3 byte SWEET 16 registers and placed in the X-reg for indexing. Then the instruction type is determined. Register ops place the doubled register specification in the high order byte of R14 indicating the 'prior result register' to subsequent branch instructions. Non-register ops treat the register specifcation (right-hand half-byte) as their opcode, increment the SWEET 16 PC to point at the displacement byte of branch instructions, load the A-reg with the 'prior result register' index for branch condition testing, and clear the Y-reg.

When is an RTS really a JSR?

Each instruction type has a corresponding subroutine. The subroutine entry points are stored in a table which is directly indexed into by the opcode. By assigning all the entries to a common page, only a single byte to address need be stored per routine. The 6502 indirect jump might have been used as follows to transfer control to the appropriate subroutine.

```
LDA
        #ADRH
                     ;High-order byte
STA
        IND+1
LDA
        OPTBL.X
                     :Low-order byte.
        IND
STA
```

To save code, the subroutine entry address (minus 1) is pushed onto the stack, high-order byte first. A 6502 RTS (return from subroutine) is used to pop the address off the stack and into the 6502 PC (after incrementing by 1). The net result is that the desired subroutine is reached by executing a subroutine return instruction!

Opcode Subroutines:

The register op routines make use of the 6502 'zero page indexed by X' and 'indexed by X direct' addressing modes to access the specified registers and indirect data. The 'result' of most register ops is left in the specified register and can be sensed by subsequent branch instructions, since the register specification is saved in the high-order byte of R14. This specification is changed to indicate R0 (ACC) for ADD and SUB instructions and R13 for the CPR (compare) instruction.

Normally the high-order R14 byte holds the 'prior result register' index times 2 to account for the 2-byte SWEET 16 registers and the LSB is zero. If ADD, SUB, or CPR instructions generate carries, then this index is incremented, setting the LSB.

The SET instruction increments the PC twice, picking up data bytes in the specified register. In accordance with 6502 convention, the low-order data byte precedes the high-order byte.

Most SWEET 16 non-register ops are relative branches. The corresponding subroutines determine whether or not the 'prior result' meets the specified branch condition and if so, update the SWEET 16 PC by adding the displacement value (-128 to +127 bytes).

The RTN op restores the 6502 register contents, pops the subroutine return stack and jumps indirect through the SWEET 16 PC. This transfers control to the 6502 at the instruction immediately following the RTN instruction.

The BK op actually executes a 6502 break instruction (BRK), transferring control to the interrupt handler.

Any number of subroutine levels may be implemented within SWEET 16 code via the BS (Branch to Subroutine) and RS (Return from Subroutine) instructions. The user must initialize and otherwise not disturb R12 if the SWEET 16 subroutine capability is used since it is utilized as the automatic return stack pointer.

Memory Allocation:

The only storage that must be allocated for SWEET 16 variables are 32 consecutive locations in page zero for the SWEET 16 registers, four locations to save the 6502 register contents, and a few levels of the 6502 subroutine return address stack. if you don't need to preserve the 6502 register contents, delete the SAVE and RESTORE subroutines and the corresponding subroutine calls. This will free the four page zero locations ASAV, XSAV, YSAV, and PSAV.

User Modifications:

You may wish to add some of your own instructions to this implementation of SWEET 16. If you use the unassigned opcodes \$0E and \$0F, remember that SWEET 16 treats these as 2-byte instructions. You may wish to handle the break instruction as a SWEET 16 call, saving two bytes of code each time you transfer into SWEET 16 mode. Or you may wish to use the SWEET 16 BK (break) op as a 'CHAROUT' call in the interrupt handler. You can perform absolute jumps within SWEET 16 by loading the ACC (R0) with the address you wish to jump to (minus 1) and executing a ST R15 instruction.

Notes from Apple II System Description

This is kind of old stuff, but I ran across the issue of Byte that had the Apple II system description by Steve Wozniak:

- Return to 6502 mode
- Branch Always 01
- 02 Branch no Carry
- Branch on Carry

```
Branch on Positive
         Branch on Negative
         Branch if equal
06
07
         Branch not equal
08
         Branch on negative 1
         Branch not negative 1
         Break to Monitor
0B-0F
        1 No operation
         R<-2 byte constant (load register immediate)
1R
    3
2R
         ACC<-R
         ACC->R
3R
         ACC<-@R, R<-R+1
4R
5R
         ACC->@R. R<-R+1
6R
         ACC<-@R double
         ACC->@R double
7R
         R<-R-1, ACC<-@R (pop)
         R<-R-1, ACC->@R
9R
         ACC<-@R(pop) double
AR
         compare ACC to R
BR
         ACC<-ACC+R
CR
         ACC<-ACC-R
         R<-R+1
ER
FR
         R<-R-1
```

notes

- 1. All braches are followed by a 1 byte relative displacement. Works identically to 6502 branches.
- 2. Only ADD, SUB, and COMPARE can set carry
- 3. Notation:
 - o R = a 16 bit "Register" operand designation, one of 16 labelled 0 to 15 (decimal), 0 to F (hexidecimal)
 - ACC = register operand R0
 - @R = indicrect reference, using the register R as the pointer
 - <-, -> = assignment of values
- 4. Length of instructions: Branches are always two bytes: opcodes followed by relative displacement. Load register immediate (1R) is three bytes: the hexadecimal opcode 10 to 1F followed by the 2 byte literal value of a 16 bit number. All other instructions are one byte in length.

And from that issue of Byte (Apr 1977, I think)...some words from the Woz himself. Retyped without permission.

Sweet 16 S-C Macro Assembler Text

SWEET-16 is a powerful programming tool developed by Steve Wozniak in the early days of Apple. Chances are that you do have this tool, whether you know it or not. The standard version is hidden away inside the Integer BASIC system. If you have Integer BASIC on your mother board, or in a firmware card, or in a 16K RAM card, then you have SWEET-16. I have included a commented source file of SWEET-16 on your S-C MACRO ASSEMBLER II disk, so you can assemble your own copy if you wish.

SWEET-16 is really a language, just like 6502 machine language, BASIC, Pascal, FORTRAN. It looks a lot like a machine language for a computer that does not really exist, so "Woz" has called it his "dream machine". You can read all about it in an old issue of BYTE Magazine (November, 1977, pages 150-159): "SWEET-16 -- The 6502 Dream Machine". Another article you may want to find is "SWEET-16 Revisited", by Charles F. Taylor. in MICRO--The 6502/6809 Journal. January, 1982, pages 25-42.

The beauty of SWEET-16 is in its ability to perform 16-bit arithmetic and data moves using automatically updated address pointers. And to add icing to the cake, most of the instructions are only one byte long! You can write extremely compact code, if you are willing to pay the price of slower execution. (A typical program will take half as many bytes, but ten times longer to execute.)

Does anyone really use SWEET-16? Yes, in a big way. I used it in several places inside the early versions of S-C Assembler II. The TED/ASM assembler, and all its descendants (including DOS Tool Kit, TED 11+, Big Mac, Merlin, and others) use SWEET-16 heavily. Several of the programs in the Apple Programmer's Aid ROM use SWEET-16. including the Integer BASIC Renumber/Append program.

The standard version of SWEET-16 is invoked by the 6502 instruction "JSR \$F689"; the bytes immediately following contain opcodes for SWEET-16 to process. SWEET-16 opcodes will be executed until the "RTN" opcode, which returns to 6502 mode.

Programming Model

The SWEET-16 "machine" has sixteen 16-bit registers (R0-R15). R0 is actually the two memory bytes at \$0000 and \$0001. The next two bytes are called R1; R15 is stored in \$001E and \$001F. Several of the registers have special functions: R0 is used as an accumulator (like the 6502's A-register); R12 is the subroutine return stack pointer; R13 receives the results of comparisons; R14 is a status register; R15 is the program address counter.

SWEET-16 REGISTERS

Register	6502 Address	Purpose
0	\$00,01	Accumulator
1	\$02,03	General
2	\$04,05	General
11	\$16,17	General
12	\$18,19	Subroutine Stack Pointer
13	\$1A,1B	Difference of comparands
14	\$1C,1D	Status
15	\$1E,1F	Program address

 $14 { of } 16$

There are two general types of opoodes recognized by SWEET-16: register and non-register opcodes. The non-register opcodes all have the form "0x", where x is a hexadecimal digit from 0 through C. (Opcodes 0D, 0E, and 0F are not used.) These opcodes are used for relative branches, subroutine call and return, and to leave SWEET-16. The register opcodes have the format "xR", where x is a hexadecimal digit from 0 through F, and R is a register number (0-F).

SWEET-16 OPCODES

Non-Register Opcodes: RTN, BK, and RS are one byte opcodes. The rest have a second byte which is a relative address, similar to the relative branch addresses used in 6502 opcodes. The conditional branches use status bits found in R14.

```
Return to 6502 code.
00
         RTN
01 ea
        BR
              addr
                       Unconditional Branch.
        BNC
                       Branch if Carry=0.
02 ea
              addr
03 ea
        BC
              addr
                       Branch if Carry=1.
                       Branch if last result positive.
Branch if last result negative.
04 ea
        BP
              addr
0S ea
        BM
              addr
                       Branch if last result zero.
06 ea
         ΒZ
              addr
                       Branch if last result non-zero.
07 ea
         BNZ
              addr
08 ea
        RM1
              addr
                       Branch if last result = -1.
09 ea
        BNM1 addr
                       Branch if last result not -1.
                       Execute 6502 BRK instruction.
ØA
         BK
0B
         RS
                       Return from SWEET-16 subroutine.
                       Call SWEET-16 subroutine.
        BS
              addr
```

Register Opcodes: The SET opcode uses three bytes, to load a 16-bit immediate value into a register. All the rest of the register opcodes only use one byte. ("MA" = memory address)

```
Rn <-- value.
1n lo hi
            SET
                 n,value
2n
            LD
                             R0 <-- (Rn).
3n
            ST
                             Rn <-- (R0)
4n
            LD
                 @n
                             MA = (Rn), ROL < -- (MA),
                             Rn <-- MA+1. R0H <-- 0.
                             MA = (Rn), MA < -- (R0L),
            ST
5n
                 @n
                             Rn <-- MA+1.
            LDD @n
                             MA = (Rn), R0 < -- (MA, MA+1),
6n
                             Rn <-- MA+2
                             MA = (Rn), MA, MA+1 < -- (R0),
7n
            STD @n
                             Rn <-- MA+2.
                             MA = (Rn)-1, ROL < -- (MA),
8n
                             R0H <-- 0, Rn <-- MA.
9n
            STP @n
                             MA <-- (Rn)-1, (MA) <-- ROL,
                             Rn <-- MA.
            ADD
                             R0 <-- (R0) + (Rn).
An
                 n
                             R0 <-- (R0) - (Rn)
Cn
            POPD @n
                             MA = (Rn)-2, MA, MA+1 < -- R0,
                             Rn <-- MA.
                             R13 <-- (R0) - (Rn),
            CPR n
Dn
                             R14 <-- status flags.
            TNR
                             Rn <-- (Rn) + 1.
Fn
            DCR
                 n
                             Rn <-- (Rn) - 1.
```

The S-C Assembler II includes all of the SWEET-16 opcodes, in the formats shown above. You can write programs which mix both 6502 code and SWEET-16 together in any combination.

Here are a few examples which illustrate programming in SWEET-16.

```
1010 * CLEAR A BLOCK OF MEMORY 1020 *-----
                1030 SWEET.16
F689-
                              .E0 $F689
                1040 BLOCK
                               .EQ $A00
0A00-
0234-
                               .EQ $234
                1060 *----
0800- 20 89 F6
               1070 CLEAR
                               JSR SWEET.16
                               SET 0.0
                                               0 FOR CLEARING WITH
0803- 10 00 00
               1080
0806- 11 00 0A
               1090
                               SET 1,BLOCK
                                               ADDRESS OF BLOCK
                                               # BYTES TO CLEAR
0809- 12 34 02
                1100
                               SET 2,N
080C- 51
                1110 .1
                               ST @1
                                               STORE IN BLOCK
                               DCR 2
080D- F2
               1120
                                               NOT FINISHED YET
080E- 07 FC
               1130
                               BNZ .1
0810- 00
SYMBOL TABLE
0A00- BLOCK
0800- CLEAR
. 1=080C
0234- N
F689- SWEET.16
0000 ERRORS IN ASSEMBLY
                1000 *-----
                1010 * MOVE A BLOCK OF MEMORY
                1020 *-----
                1030 SWEET.16
                              .E0 $F689
0A00-
                1040 SOURCE
                               .EQ $A00
0880-
                1050 DESTIN
                               .EQ $A80
0023-
               1060 N
                               .EQ $23
                1070 *-----
```

```
0800- 20 89 F6 1080 MOVE
                                JSR SWEET.16
0803- 11 00 0A 1090
                                SET 1,SOURCE
                                                ADDRESS OF SOURCE BLOCK
0806- 12 80 0A
                1100
                                SET 2,DESTIN
                                                ADDRESS OF DESTINATION BLOCK
0809- 13 23 00
               1110
                                SET 3,N
                                                # BYTES TO MOVE
                                LD @1
ST @2
                                                GET BYTE FROM SOURCE
080C- 41
                1120 .1
                                                STORE IN DESTINATION
080D- 52
                1130
                                DCR 3
080E- F3
080F- 07 FB
                1150
                                BNZ .1
                                                NOT FINISHED YET
0811- 00
                1160
                                RTN
SYMBOL TABLE
0A80- DESTIN
0800- MOVE
.01=08CC
0023- N
0A00- SOURCE
F689- SWEET.16
0000 ERRORS IN ASSEMBLY
                1000 *-----
                         RENUMBER S-C ASSEMBLER SOURCE CODE
                1020 *-----
F689-
                1030 SWEET.16 .EQ $F689
004C-
                1040 HIMEM
                                .EO $4C.4D
00CA-
                1050 PP
                                .EQ $CA,CB
                1060 *-----
                1070 RENUMBER
                            JSR SWEET.16
0800- 20 89 F6
               1080
0803- 11 CA 00
                            SET 1,PP
                                          PP HAS ADDRESS OF SOURCE CODE
                1090
0806- 61
                1100
                            LDD @1
                                          GET ADDRESS OF SOURCE CODE
0807- 31
                1110
                            ST 1
                                          ...IN R1
0808- 12 0A 00
               1120
                            SET 2,10
                                          INCREMENT = 10
                            SET 3.HIMEM
                                          HIMEM HAS ADDR OF END OF SOURCE
080B- 13 4C 00
               1130
080E- 63
                            LDD @3
                                          GET ADDRESS IN HIMEM
                1140
080F- 33
0810- 14 DE 03
               1160
                            SET 4,990
                                          START=990 (1ST LINE WILL BE 1000)
0813- 21
                1170 .1
                            LD 1
                                          TEST IF FINISHED
0814- D3
                            CPR 3
                1180
0815- 03 0E
                            BC .2
                1190
0817- 41
                1200
                            LD @1
                                          GET # BYTES IN THIS SOURCE LINE
                                          ... INTO R5
GET SEOUENCE NUMBER
0818- 35
                1210
                            ST 5
                            LD 4
0819- 24
                1220
081A- A2
                1230
                            ADD 2
                                          ADD INCREMENT
                                          ... INTO R4 AGAIN
081B- 34
                1240
                            ST 4
081C- 71
                1250
                            STD @1
                                             AND ALSO INTO SOURCE LINE
081D- F1
                1260
                            DCR 1
                                          BACK UP POINTER
081E- F1
                1270
                            DCR 1
081F- F1
                1280
                            DCR 1
0820- 21
                1290
                            LD 1
                                          ADD LENGTH OF LINE TO POINTER
0821- A5
                1300
                            ADD 5
                                          POINT AT NEXT SOURCE LINE
0822- 31
                1310
                            ST 1
0823- 01 EE
                1320
                            BR .1
0825- 00
                1330 .2
                            RTN
0826- 60
                1340
SYMBOL TABLE
004C- HIHEM
00CA- PP
0800- RENUMBER
.01-0813, .02-0825
F689- SWEET.16
0000 ERRORS IN ASSEMBLY
```

Appendix: Additional Material

A <u>discussion in August 2021</u> on the 6502 forum notes that some of this document is derived from <u>the file sweet16.txt</u>, possibly collated by W. Sheldon Simms and posted to Usenet, and in turn drawing from BYTE, and from the Merlin assembler documentation. Another source is <u>Call-A.P.P.L.E.</u> Woz Pak II from 1979.

Also noted in the discussion, the original listing from the BYTE article was captured by Paul R. Santa-Maria in SW16RB.TXT.

Last page update: August 24, 2021.