mini digital cassette recorder





**PHILIPS** 

This documentation is valid from serial number 3650 onwards e.g. fCO1 included. Data subjet to change without notice.	
2	LDB 4051

## Contents

#### GENERAL

- 1. Introduction
- 2. Technical Specification
- 3. Type Numbers

#### II USE OF THE MINI-DCR

- 1. Interfacing
- Survey of Interface Signals
- Timing Diagram 3.
- 4. Example of an interface Flow chart
- 5. Operating Instructions
- 6. Operator Maintenance

#### **III SERVICE INFORMATION**

- 1. Technical Description
- 2. Maintenance
- 3. Adjustments

#### **IV SPARE PARTS**

#### LIST OF ILLUSTRATIONS

- Physical Composition of the Mini-Fig. 1 Cassette
- Physical Composition of Tape Fig.
- **Data Block Composition** Fig. 3
- Fig. WDA-Signal
- 5 Fig. RDA-RDC Signal
- Fig. 6 **RDC** timing
- **Physical Dimensions** Fig. 7
- Fig. 8 Interface Connector
- Fig. 9 Fig. 10 Interface Diagram
- **Timing Diagram**
- Fig. 11 Flowchart example
- Fig. 12 **Block Diagram**
- Fig. 13 Circuit Diagram Fig. 14 **PCB Layout**
- Fig. 15 **RAS Signal**
- Fig. 16 Jitter Adjustment
- Fig. 17/18 Spare parts

## General

#### 1. INTRODUCTION

This manual provides the description, timing diagram, interfacing signals as well as operating and maintenance instructions for the Philips mini-digital cassette recorder.

The Philips Mini-DCR has been specially designed for O.E.M.'s and users that need a fast and lowcost serial memory device for data storage and interchange.

The Mini-DCR is available as a read-and-write version.

The recorder uses the Philips mini-cassettes. The whole system is based on Philips' extensive know-how gained in many years experience of digital cassette recording systems and their applications.

Advantages of economy, cassette convenience and high performance have made this technique internationally accepted and Philips quality and reliability have made them a major O.E.M. supplier of this type of equipment.

The Philips Mini-DCR is an ideal unit for microprocessor based systems, terminals, minicomputers and scientific calculators to be used in program loading, memory back-up and data capture applications.

#### 2. TECHNICAL SPECIFICATION

: two; a read/write head Number of heads

and an erase head

Recording head : single gap, single track,

half width, read/write

head

Number of tracks : two; A-side and B-side

Recording method : phase encoding

character/bit serial : approx. 35 m.

Tape length : 6000 bits per second Data transfer rate : 330-560 bpi (13-22 b/ Recording density

mm)

Irrecoverable error rate: 1 in 109 bits

: single motor hub driven Tape transport

338 rpm ± 5%

: 10.6-18 ips (270-450 Tape speed

mm/sec.)

Read/write time : <96 sec. for full tape

length

: <100 msec. (after Start time read/write

change in direction <150 msec.)

Stop time read/write

: 30-120 msec.

: 0.6-2.0 inch (15-50 mm) Start distance

(after change

in direction 1.2-2.6 inch

(30-65 mm)

Stop distance Rewind time Data capacity Medium

: 0.2-1.0 inch (5-25 mm)

: <96 sec.

: 64k octads per track : Philips 3.81 mm mini

cassette

**Electronics** 

Read/write electronics, tape transport

Control logic

: one printed circuit

board

Signal interface

: the signal interface is a MOS-compatible (HEF 4000p series)

interface

Signal levels/ output

signals

: logic "1" Vs minus

0.5V

logic "0" < 0.5V

Signal levels/input

signals

: logic "1" 9V to Vs logic "0" < 3V

Power interface

: DC-power Vs = 12 volt

± 5%

Power load

: 400 mA peak (100

msec.)

120 mA nominal 30 mA stand-by

Thermal dissipation Electrical connections

: 1.4 Watt nominal : via Amp. connector.

14 Pins cis serie Amp.

code

Housing 1-163690-3 Pin 163691-1 (loose

piece)

163618 (contact strips)

**Environmental conditions** 

Operating temperature

range Thermal shock Relative humidity : +5°C to +55°C : <11°C per hour : 10%-90% (no

condensation) : 780-1100 mbar

Air pressure Vibration (IEC 68-2-6): 5-200 Hz at 1g curve Heat radiation

: direct sunlight radiation on the cassette drive is

not allowed : see fig. 7

Physical dimensions Weight of Mini-DCR

: about 400 grams

3. TYPE NUMBERS

8920 405 10601 MDCR with front cover and

write enable switch (evaluation

unit inclusive 6 cassettes)

8920 405 10602 MDCR in normal shipping

package containing 20 units

without cassettes

8920 440 10101 Mini cassette in plastic cover.

# II Use of the Mini-DCR

#### 1. INTERFACING

The plug connections are given in fig. 8 and 9 and the interface signals and their function are listed in the following section.

The timing diagram in fig. 10 gives information about the various interface signals and commands.

- To guard against any fire hazard the following measures should be taken:
  - A. insert a fuse 0.5 A in the positive leads of the 12 Volt supply;
  - B. the supply leads and earth leads must each have a minimum cross-section of 0.38 mm<sup>2</sup>.
- It is recommended that cassettes be entirely (re-)wound before they are removed from the recorder.

This prevents the tape from being touched by the fingers during loading and unloading. Formation of unwanted loops is also avoided.

- If the direction of the tape movement is changed the start time will be about 50 msec. longer.
  - The start distance than will be between 30 and 65 mm.
- Each mini-cassette can be equipped with a write-enable plug in order to allow writing on the tape.

The position of the write-enable plug determines whether writing is enabled on track 1 or 2 (see fig. 1).

- Information written in the Forward direction cannot be recovered by reverse reading due to the variation in recording density and tape
- In order to avoid earth interference the signal ground and the power ground lines should be interconnected at the power supply.
- Figure 2 shows the physical composition of the tape.

Figure 3 shows the composition of the data blocks.

Initial gaps, interblock gaps and end of data gaps are all erased to the same polarity. This polarity is called the reference polarity. For this purpose the WDA-line should remain high.

A preamble at the beginning of each block is required to synchronise the read electronics. Data shall be Phase Encode (PE)

data bit value:



line transitions:

Additional line transitions (phase line transitions) shall be given at the nominal midpoints between bit line transitions if required, to establish the proper polarity for the successing bits.

The preamble is used to synchronise the Read Clock (RDC) Read data is TRUE at the positive pulse edge of the signal Read Clock (RDC).

#### 2. SURVEY OF INTERFACE SIGNALS

Contro	l lines	Description	If "O"	If "1"
FWD	Forward	Causes tape transport in forward direction.	Initiates tape transport.	Stops tape transport.
REV	Reverse	Causes tape transport in the reverse direction.	Initiates tape transport.	Stops tape transport.
WCD	Write Command	Enables information entering via WDA-line. Also causes erasure of the tape.	Gate is open.	Gate is closed.
Status	lines			
BET	Begin/end of tape	Indicates whether begin of tape or end of tape has been detected.	Begin or end of tape has been detected.	
CIP	Cassette in position	Indicates that a cassette is in position and the door has been closed.	Cassette is present.	No cassette.
WEN	Write enable	Indicates if a write enable plug is present in the cassette (file protection).	Allows writing on tape (plug is present).	Write action prohibited.
Data li	nes			
WDĀ	Write data	Input channel of the write amplifier accepting information in digital form to be recorded on tape.	PE-encoded data "O" is a neg. going signal. Data "1" is a positive going signal. In the gap WDA is at high level.	
RDC	Read clock	Separately generated clock to strobe read-data free of jitter.	Positive going e to clock read-da	dge should be used ita.
RDĀ	Read data	Output channel of the read amplifier, supplies digital data that has been read from the tape.	going signal. Data "1" is a po	a "O" is negative  ositive going signal, is at high level.

#### 3. TIMING DIAGRAM

See fig. 10

T1: The length depends on selected block-length and the relative position on the tape.

T2-T3-T4-T5: Depend on selected block-length, the total number of blocks and the start/stop, distances/times.

T6-T7: The pulses on the FWD line are necessary for clearing the Read Electronics.

#### How to use tape capacity efficiently

- 1. Required tape capacity: 32k-bytes per track (128 blocks of 256 bytes each).
  - T2 = 1/3 T1; T3 = 40 msec.;
  - T4 = 250 msec.; T5 = 0. In case of re-write one block T4 = 350 msec.
- 2. Required tape capacity; 24k-bytes per track (96 blocks of 256 bytes each).
  - T2 = 198 msec.; T3 = 40 msec.;
  - T4 = 450 msec.; T5 = 0.

3. Required tape capacity; 40k-bytes per track (40 blocs of 1024 bytes each).

T2 = 198 msec.; T3 = 40 msec.; T4 = 450 msec.; T5 = 0.

- 4. Required tape capacity; 64k-bytes per track (1 block of 64k-bytes).
  - T2 = Rewind time till BOT; T3 = time to write end of data gap; T4 is not applicable.

#### Remarks

- During a continuous write operation (no backspace or controll-read) T3 = 0 msec. in order to obtain optimum data capacity.
- Repeated updating of a data-block positioned between two other blocks, may cause overwriting of the first part of the next data block.
- The pre-amble is used to synchronise the Read-clock (see detail A of the timing diagram).
- Read data is TRUE at the positive pulse edge of the signal Read clock.
- To read two or more blocks of data continuously it is necessary to reset Read clock in the inter-block gaps. This can be achieved by a pulse on the FWD-line of:
   1 μs < T < 0.5 msec.</li>
- During Read operation signal WDA may not change level, because this causes cross-talk on RDA
- Signal BET indicates both begin and end of tape.
- In case of rewriting blocks, T4 should be at least 100 msec. longer as indicated.
- If the write enable switch is installed only cassette filled with the write enable plug can be recorded.
- The status signals CIP WEN BET can have some bounds on leading edges.

## 4. EXAMPLE OF AN INTERFACE FLOW CHART

In fig. 11 an example of a flow chart is given. The flow chart illustrates a program for writing and checking 128 blocks of 256 databytes each.

#### 5. OPERATING INSTRUCTIONS

Since the Mini-DCR is intended for use by O.E.M. customers, operation of the device will depend upon individual system requirements.

Cassette loading is accomplished by sliding up the button adjacent to the cassette cover and inserting the mini-cassette, open end first, into the cassette cover and closing the cover.

#### 6. OPERATORS MAINTENANCE

The only maintenance required for the user is cleaning of the read/write head every working week or 100 hours.

Use cotton wool buds moistened with ethanol.

# III Service Information

#### 1. TECHNICAL DESCRIPTION

(see fig. 12 block diagram and fig. 13 circuit diagram)

#### Write Data

The phase encoded (PE) WDA-signal is input at 15 IC1 and appears in-phase at 11 IC1 and antiphase at 9 IC1.

These two signals are applied across the read/write head when the WCD signal 9 IC6 is LOW and the WEN switch closed (8, 9 IC9-high). Enabling IC1 (4 IC1-low) also causes a low level; from 2 IC1, to be fed via R56 to the base of TS6 causing current to flow through the erase head.

#### Read Data

The read signal from the read/write head is amplified via 2, 1 IC2 and applied to the pulse-shaper and rectifier circuit. The negative pulses inverted and amplified via 6, 7 IC2 and recombined with the amplified positive pulses from 8 IC2. Further shaping and squaring is carried out via TS7 and IC6.

The square-wave read data signal is level-coded via 3, 1 IC7 and appears at output pin 12 (RDA). The read clock signal is derived from the read data signal via 2, 3 IC3 and appears at output pin 11 (RDC) to indicative a valid RDA output when positive.

The RDC signal is the strobe pulse for the RDA signal. The one shot-time of IC3 depends on the bit time of the RDA signal, to strobe this signal always at the right time. The phase bit is then ignored.

The Flip Flop 11 12 IC7 is introduced to start at the beginning of the data always with the shortest one shot time. The preamble will then synchronise the RDC circuit.

#### **Motor Control Logic**

A low signal on either the FWD or REV inputs will cause switch "on" of TS2, TS5 or TS3, TS4 respectively.

The amount of current flowing through these transistors (and the motor) is controlled by TS1. TS1 is driven by the servo loop formed by the motor, the tacho generator and IC's 4, 5 and 6.

#### **BET and Tape Stopped Detector**

A sample of the positive output from 8 IC5 is fed to 3 IC5 to hold the BET line high; should the tape jam or the motor stop, the output 8 IC5 goes negative causing a low on the BET line.

#### Clear Logic

When both REV and FWD lines are high the CLEAR signal output at 11 IC9 goes high causing the following:

- i) BET line high via 2 IC5.
- ii) TS1 cut-off via 12 IC5.
- iii) Preset of the RDA and RDC flip-flops IC7.

#### 2. MAINTENANCE

The only maintenance required for the Mini-DCR is cleaning of the read/write head every week or 100 working hours. Use cotton wool buds moistened with ethanol.

#### Note 1

The heads are adjusted in the factory and locked. Do not try to readjust them.

#### Note 2

The position of the motor bracket on the chassis is a factory adjustment. Do not loosen the mounting screws.

#### 3. ADJUSTEMENTS

#### 3.1 Electronics

- a. The motor speed has to be adjusted with R4:
  - Use the middle part of the total tape length.
  - Connect a frequency counter to testpoint 11.
  - Adjust with R4 to a frequency of 1075
     ± 10 Hz.
- b. The amplitude of the RAS-signal has to be adjusted with R29:
  - Use a reference amplitude cassette (code nr. 5322 297 34017).
  - Write a digital signal with a frequency of 3 KHz.
  - Rewind the recorded part of the tape and measure during the first forward readcycle the voltage on the RAS-test-point with an oscilloscope.
  - Adjust R29 to the voltage as mentioned on the reference amplitude cassette.

#### 3.2 Mechanical

The mechanical forward/reverse switching element has two stop screws that should be adjusted individually to give minimum jitter in each direction (see fig. 16):

 Use a continuous pre recorded cassette (i.e. 3 KHz. test cassette, code nr. 5322 297 34016).

- Use the special srewdriver\* that can be supplied under service code number 5322 395 54082.
- If the screw has not been turned in far enough a louder gear wheel noice is audible. (An oscilloscope connected to the RAS test-point shows that the amplitude of the signal is less stable (see fig. 15b).)
- Turn the screw clockwise until the stronger gear wheel noise just disappears, and then give the screw a further half-turn.
   (The oscilloscope shows a stable output voltage (see fig. 15a).)
- If the screw is turned in too far, the application of the gears is insufficient, and again a louder gear whell noise is audible.
   (The jitter is again visible on the oscilloscope in the envelope of the tape output.)

<sup>\*</sup> If a normal screwdriver is used, there is a great risk of it slipping out of the grove into the gears which could then be damaged. In this case the motor assembly has to be replaced.

# IV Spare parts Ersatzteile Pièces de rechance

Item Position Rep.	Description	Ordering Code Bestell kode No. de code	Beschreibung	Désignation
20 40	Stud Contactpin (100 pcs)	5322 466 94584 5322 268 14103	Stehbolzen Kontaktstift (100 Stk.)	Tige filetée Broche de contact (100 pcs.)
110	pcb connector (20 contacts)	5322 265 54006	Platinenstecker (20 Kontakte)	Connecteur imprimé (20 contacts)
120 1270	Keying plug CIP switch assy	5322 401 14191 5322 278 94079	Tastenstecker CIP-Schalter-Zus.	Fiche Ensemble commutateur CIP
FC01	CIP switch assy	5322 278 94088	CIP-Schalter-Zus.	Ensemble commutateur
1380	WEN switch assy	5322 278 94081	WEN-Schalter-Zus.	Ensemble commutateur WEN
1420	Front (without knob)	5322 443 34019	Frontplatte (ohne Knöpfe)	Face avant (sans bouton)
1430	Knob	5322 414 64109	Knopf	Bouton
1440	Washer for Knob	5322 466 94583	Unterlegscheibe für Knopf	Rondelle pour bouton
2040	Head housing assy	5322 249 14079	Kopfgehäuse-Zus.	Ensemble de logement de têts
2050	Contact housing (20 contacts)	5322 267 64007	Kontaktgehäuse (20 Kontakte)	Boîtier de contact (20 contacts)
2060	Spring (lock slide)	5322 492 34492	Feder (Verriegelungsschieber)	Ressort (verrou)
2070	Spring (head housing)	5322 492 34493	Feder (Kopfgehäuse)	Ressort (logement de tête)
2080	Guide block	5322 520 14257	Führungsblock	Bloc-guide
2090	Pressure bracket	5322 405 34065	Druckbügel	Etrier de compression
2100 2110	Brake (without Felt) Spring (pressbracket)	5322 405 24107 5322 492 34595	Bremse (ohne Filz) Feder (Druckbügel)	Frein (sans feutre) Ressort (étrier de
2110	Spring (pressuracker)	5522 452 54555	reder (Druckbuger)	compression)
FC01	Spring (pressbracket)	5322 492 34604	Feder (Druckbügel)	Ressort (étrier de compression)
2120	Spring (brake)	5322 492 34596	Feder (Bremse)	Ressort (frein)
2130	Motor assy	5322 361 24177	Motor-Zus.	Ensemble de moteur
2140	PCB assy	5322 214 34258	Platinen-Zus.	Ensemble de platine imprimée
FC01	PCB assy	5322 214 34267	Platinen-Zus.	Ensemble de platine imprimée
2150	Brake felt	5322 466 94585	Bremsfilz	Feutre de frein
2160	Lock slide	5322 466 85795	Verriegelungsschieber	Verrou
	Write Enable plug		Schreibfreigabestopfen	Fiche d'autorisation decriture
R1	C 47k.	4822 110 63152		
R2	C 100k.	4822 110 63161		
R3 R4	C 10k, P 100k,	4822 110 63134 5322 100 10116		
R5	M 301k.	5322 100 10116		
R6	C 680E	4822 110 53103		
R7	M 46k4	5322 116 50557		
R8	M 4k64	5322 116 50484		
R9	M 10k.	5322 116 54619		
R10	M 46k4	5322 116 50557		

Item Position Rep.	Description	Ordering Code Bestell kode No. de code
Position Rep. R11 R12 R13 R14 R15 R16 R17 R18 R20 R21 R22 R22 R226 R230 R31 R332 R334 R336 R340 R441 R450 R51 R526 R537 R546 R57	M 4k64 C 120k. C 330k. C 1M C 820k. C 560E C 270E C 100k. C 100k. C 100k. C 100k. C 47k. M 4k22 M 16k2 C 100k. C 47k. C 2M2 P 1k. C 680E C 1k5 M 10k. M 10k. M 10k. M 215k. C 4k7 C 22k. C 2k2 C 2k2 C 2k2 C 2k2 C 2k2 C 2k2 C 10k. C 10k. C 10k. C 10k. M 287k. C 22k. C 10k. C 10k. M 287k. C 20k. C 10k.	Bestell kode No. de code  5322 116 50484 4822 110 63163 4822 110 63187 4822 110 63185 4822 110 63101 4822 110 63101 4822 110 63161 4822 110 63161 4822 110 63161 4822 110 63161 4822 110 63161 4822 110 63161 4822 110 63161 4822 110 63161 4822 110 63161 4822 110 63161 4822 110 63161 4822 110 63152 5322 116 50593 4822 110 63161 4822 110 63152 5322 116 54619 5322 116 54619 5322 116 54743 5322 110 63118 4822 110 63118 4822 110 63116 4822 110 63116 4822 110 63116 4822 110 63134 4822 110 63134 4822 110 63134 4822 110 63134 4822 110 63134 4822 110 63134 4822 110 63134 4822 110 63134 4822 110 63134 4822 110 63134 4822 110 63134 4822 110 63134 4822 110 63134 4822 110 63134 4822 110 63134 4822 110 63134 4822 110 63134
R58	M 390E	5322 116 54401
R59	C 100E	4822 110 63081
R60	C 47k.	4822 110 63152
R61	C 2k2	4822 110 63116
R62	M 150k.	5322 116 54712
C1	470p	4822 122 31177
C2	2N2	4822 121 50415
C3	10N	5322 122 34041
C4	100p	4822 122 31081
C5	68N	5322 121 44137
C6	10N	5322 122 34041
C7	1M	5322 124 14075

Item Position Rep.	Description	Ordering Code Bestell kode No. de code
C8 C9 C10 C11 C12 C13 C14 C15 C16 C17 C18 C19 C20 L1 L2 D1-D2 D3 D4-D10 D11 D12-D16 TS1 TS2 TS3 TS4 TS5 TS6 TS7 IC1 IC2 IC3 IC4 IC5 IC6 IC7	BD204 BC327 BC337 BC327 BC337 BC558 BC547C HEF4502 BP LM324 N NE555 V NE555 V LM324 N HEF40106 BP HEF4013 P	4822 121 40334 4822 124 20477 4822 122 30103 4822 124 20697 5322 122 34041 4822 124 20697 4822 122 30098 4822 122 30126 4822 122 30126 4822 122 3013 4822 122 31178 5322 121 40323 4822 122 31164 4822 158 10224 4822 158 10224 4822 130 30613 4822 130 30613 4822 130 30613 4822 130 30613 4822 130 30613 4822 130 40855
IC8 IC9	HEF4050 P HEF4011 P	5322 209 14068 5322 209 14046

LDB 4051 23




Fig. 1





Fig. 2

A — Tape leader
B — Initial gap
C — Track 1
D — Track 2
E — Data block
F — Interblock gap
I — End of data gap

M - Preamble = 10101010



O - CRC character 16 bits







Fig. 3







T = ACTUAL BIT\_CEL TIME

t1= > 0,5 µSec. < 5 µSec.

t2= 40 µSec. = DATA VALID. TIME

t3= NOMINAL 0,75 T


MINIMUM 0,55T


MAXIMUM 0,95T

**ERE 6416** 

Fig. 6

25





Pin No.	Signal	Pin No.	Signal
1	12V	8	WCD
2	OV (Signal Ground)	9	REV
3	OV (Power)	10	FWD
4	Earth	11	RDC
	(Protective Ground)	12	RDA
6	WDA	13	CIP
7	BET	14	WEN

Fig. 8




Fig. 9





Fig. 10









Fig. 12



1.0








Fig. 15




Fig. 16




Fig. 17

LDB 4051 35




Fig. 18

36

3922 987 34261 3/80