





♦ Absolute MAX 200mA for entire package

When I/O Level is 3.3V



The input voltage to the board when it is running from external power.

Not USB bus power.





Arduino IDE

Serial Pin

| Analog Pin

|Control / INT

Power **GND**