Chapter 3 : Verilog Fundamentals

- Verilog HDL
- Language Basics



What is an HDL?



- A Hardware Description Language (HDL) is a software programming language used to model the intended operation of a piece of hardware.
- The difference between an HDL and "C"
 - Concurrency
 - Timing
- A powerful feature of the Verilog HDL is that we can use the same language for describing, testing and debugging the system.


History of Verilog


- Verilog was developed by Gateway Design Automation as a simulation language in 1983.
 Cadence purchased Gateway in 1989 and placed the Verilog language in the public domain. Open Verilog International (OVI) was created to develop the Verilog language as an IEEE standard. The definitive reference guide to the Verilog language is now the Verilog LRM, IEEE Std 1364-1995 [1995].
- Verilog is a fairly simple language to learn, especially if you are familiar with the C programming language.



Verilog Coding

Basic Verilog Concepts
Code Structure





Verilog Comments



- Single line comments:
 - Begin with "//" and end with a carriage return
 - . May begin anywhere on the line.
- Multiple line comments:
 - Begin with "/*" and end with a "*/"
 - . May begin and end anywhere on the line
 - Everything in between is commented out
- Coding style tip Use single line comments for comments. Reserve multi-line comments for commenting out a section of code.

An Example module pound one: reg [7:0] a,a\$b,b,c; // register declarations reg clk; initial begin clk=0; // initialize the clock forever #25 clk = !clk; /* This section of code implements a pipeline */ always @ (posedge clk) begin a = b: b = c;and endmodule

Identifiers



- Identifiers are names assigned by the user to Verilog objects such as modules, variables, tasks etc.
- An identifier may contain any sequence of letters, digits, a dollar sign '\$', and the underscore '_' symbol.
- The first character of an identifier must be a letter or underscore; it cannot be a dollar sign '\$', for example. We cannot use characters such as '-' (hyphen), brackets, or '#' in Verilog names (escaped identifiers are an exception).

Escaped Identifiers

- The use of escaped identifiers allow any character to be used in an identifier.
 - Escaped identifiers start with a backslash (\) and end with white space (White space characters are space, tabs, carriage returns).
 - Gate level netlists generated by EDA tools (like DC) often have escaped identifiers
- Examples:
 - Vclock = 0;
 - a*b = 0:
 - \5-6
 - \bus_a[0]
 - \bus_a[1]

•••• reg_OK,OK_,OK_\$,OK_123,CASE_SENSITIVE, case_sensitive; reg Vclock .\a*b : // Add white space after escaped identifier. //reg \$_BAD,123_BAD; // Bad names even if we declare them! initial begin legal_identifier = 0; // Embedded underscores are OK, two_underscores = 0; // even two underscores in a row. OK = 0; // Identifiers can start with underscore OK = 0; // and end with underscore. OK\$ = 0; // \$ sign is OK. OK 123 =0; // Embedded digits are OK. CASE SENSITIVE = 0; // Verilog is case-sensitive (unlike VHDL). case sensitive = 1: Vclock = 0; // An escaped identifier with \ breaks rules a*b = 0; // but be careful to watch the spaces! \$display("Variable CASE SENSITIVE= %d".CASE SENSITIVE): \$display("Variable case_sensitive= %d",case_sensitive);

module identifiers; /* Multiline comments in Verilog look like C comments

Simulation Result of the Example



....

Variable CASE_SENSITIVE= 0 Variable case sensitive= 1 Variable /clock = 0Variable a*b = 0

Logic values

end endmodule

and // is OK in here. */ // Single-line comment in Verilog.

reg legal_identifier, two_underscores;



An Example

Verilog has 4 logic Values:

\$display("Variable Vclock = %d", Vclock);

 $\frac{\a^b}{\a^b} = \a^b, \a^b;$

- '0' represents zero, low, false, not asserted.
- '1' represents one, high, true, asserted.
- 'z' or 'Z' represent a high-impedance value. which is usually treated as an 'x' value.
- 'x' or 'X' represent an uninitialized or an unknown logic value--an unknown value is either '1', '0', 'z', or a value that is in a state of change.

Data Types

....

- Three data type classes:
 - Nets
 - Physical connections between devices
 - Registers
 - Storage devices, variables.
 - Parameters
 - Constants

Registers

programming language.

- A register data type is declared using the keyword reg and is comparable to a variable in a
- A storage device. But a **reg** is not always equivalent to a hardware register, flip-flop, or latch.
- On the LHS of an assignment a register data type is updated immediately and holds its value until changed again.
- The default initial value for a reg is 'x'.

// scalar reg variable req a: reg [7:0] in_bus; // vectored reg variable

Nets



- Most common Net types
 - wire and tri (which are identical);
 - **supply1** and **supply0** (which are equivalent to the positive and negative power supplies respectively).
- The wire data type is analogous to a wire in an ASIC. A wire cannot store or hold a value. A wire must be continuously driven by an assignment statement. The default initial value for a wire is 'z'
- Coding style tip Use "tri" instead of "wire" as a visual indicator for more than one driver on a net.
- Other net types: wand, wor (synthesizable); trior, triand, trireg, tri1, tri0(not synthesizable).

example: wire a,b; // scalar wires

Parameters



- parameters:
 - run-time constant
 - used anywhere a literal may
 - for synthesis, must be integer and must be defined before being used

```
parameter <[msb:lsb]> identifier = value <, identifier = value ...>;
examples:
      parameter [2:0] a = 1;
                                      // 3-bit
      parameter
        depth = 32,
                                      // default depth
        width = 8;
                                      //default width
```

Numbers



- Constant numbers are integer or real constants.
- Integers may be sized or unsized.
 - Syntax: <size>'<base><value> where:
 - <size> is the number of bits
 - <base is b or B (binary), o or O (octal), d or D (decimal), h or H (hex)
 - <value> is 0-9 a-f A-F x X z Z ? _
 - Examples: 2'b01, 6'o243, 78, 4'ha,
- Default radix is decimal, i.e. 1=1'd1
- underscores (_) are ignored (use them as you would commas), e.g. 836_234_408_566_343
- a "?" is interpreted as Z (high impedance), 2'b??=2'bzz
- When <size> is less than <value> the upper bits are truncated, e.g. 2'b101->2'b01, 4'hfcba->4'ha

Points to Note



- When <size> is greater than <value>, and the left-most bit
 of <value> is 0 or 1, then zero's are extended to <size>
 bits.
 - 4'b01 -> 4'b0001, 16'h0 -> 16'h0000
 4'b11 -> 4'b0011, 16'h1 -> 16'h0001
- When <size> is greater than <value>, and the left-most bit
 of <value> is an x then the x value is extended to <size>
 bits
 - 4'bx1 -> 4'bxxx1, 16'hx -> 16'hxxxx
- When <size> is greater than <value>, and the left-most bit
 of <value> is a z then the z value is extended to <size>
 bits
 - 4'bz1 -> 4'bzzz1, 16'hz ->16'hzzzz
- Real numbers may be either in decimal or scientific notation
 - Syntax: <value>.<value> or <mantissa>e<exp>
 6.439 or 5.3e6

Examples



- 3.14 decimal notation
- 6.4e3 scientific notation for 6400.0
- 16'bz 16 bit z (z is extended to 16 bits)
- 83 unsized decimal
- 8'h0 8 bits with 0 extended to 8 bits
- 2'ha5 2 bits with upper 6 bits truncated
 - (binary equivalent = 01)
- 2_000_000 2 million
- 16'h0x0z 16'b0000xxxx0000zzzz
- Coding style tip don't use "?" in a number to indicate high impedance. It only adds confusion. If you want high impedance use "z"!!


Strings



- Strings are enclosed in double quotes and are specified on one line.
- Verilog recognizes normal C escape Characters (\t, \n, \\, \",%%).

examples:

```
parameter A_String = "abc";
// string constant, must be on one line
parameter Say = "Say \"Hey!\"";
// use escape quote \" for an embedded quote
parameter Tab = "\t"; // tab character
```




Design Entities




- The **module** is the basic unit of code in the Verilog language.
- Example

module holiday_1(sat, sun,weekend);

- input sat, sun;
- output weekend;
- assign weekend = sat | sun;
- endmodule





Module Port Declarations




- Scalar (1bit) port declarations:
 - port_direction port_name, port_name ...;
- Vector (Multiple bit) port declarations:
 - port_direction [port_size] port_name, port_name ...;
- port_direction: input, inout (bi-directional) or output
- port_name : legal identifier
- port_size: is a range from [msb:lsb]

input a, into_here, george;// scalar ports
input [7:0] in_bus, data; //vectored ports
output [31:0] out_bus; //vectored port
inout [maxsize-1:0] a bus;//parameterized port

Port Connection Rules

- Inputs:
 - Internally must be of net data type.
 - Externally the inputs may be connected to a reg or net data type.
- Inouts
 - Internally must be of net data type.
 - Externally must be connected to a net data type.
- Outputs
 - Internally may be of net or reg data type.
 - Externally must be connected to a net data type.

Using the ports of a module



Reading an input port

An input port can be used directly in

the code as Verilog infers a wire

by that name also

Module Instances

out = out +1:

endmodule



- A module may be instantiated within another module.
- There may be multiple instances of the same module.
- · Ports are either by order or by name.
- · Use by order unless there are lots of ports
- · Use by name for libraries and other peoples code
- . Can not mix the two syntax's in one instantiation

```
syntax for instantiation with port order:

module_name instance_name (signal, signal,...);

syntax for instantiation with port name:

module_name instance_name (.port_name(signal), .port_name (signal),...);

module example (a,b,c,d);
input a,b;
output c,d;
...
endmodule


example ex_inst_1(in_1, in_2, w, z);
example ex_inst_2(in_1, in_2, z); // skip a port
example ex_inst_3 (.a(w), .d(x), .c(y), .b(z));
```

Gate-level Primitives



. . . .

- Verilog has pre-defined primitives that implement basic logic functions.
- Structural modeling with the primitives is similar to schematic level design.



An Example



aBar

Module simple latch (q, qBar, set, clear); input set, clear; output q, qBar; nand #2 n1(q,qBar,set); nand #2 n2(qBar,q,clear); endmodule set n1

clear

User-Defined Primitives

- We can define primitive gates (a user-defined **primitive** or **UDP**) using a truth-table specification. The first port of a UDP must be an output port, and this must be the only output port (we may not use vector or inout ports).
- An example primitive Adder(Sum, InA, InB); output Sum; input InA, InB; table // inputs : output 00:0: 01:1; 10:1; 11:0; endtable

endprimitive

User-Defined Functions




syntax: function < | size or type |> name of function; input declarations local variable declarations statement or statement group endfunction

- size is optional and is of form [msb:lsb]
- type is optional and is either integer or real
- Returns the value assigned to the name of the function.
- Functions may not contain timing controls (incl. non-blocking procedural assignments).
- Functions must have at least one input.
- Looks local first then global to module for referenced variables.
- Functions may be called
 - within a continuous assignment
- e.g. assign b = func(a);
- indirectly within an instantiation
- e.g. mod U1 (one, func (a, b));

n2

- nested within another function

Function - Example define FALSE 0 define TRUE 1 module function ex (clk): input clk; reg r1,r2,r3; function error; // the function definition input[7:0] a,b,c; if ((a !=b) && (a !=c)) error = `FALSE; // assign value to the name of the function else error = `TRUE: endfunction always @ (posedge clk) if (error(r1,r2,r3)) // call of the function \$display ("error in reg compare"); // another example call below A function can be called where a always @ (posedge clk) d = error(r1.r2.r3): value may be placed in your code endmodule



Operators • Verilog operators (in increasing order of precedence) • ?: (conditional) • || (logical or) • && (logical and) • | (bitwise or) • ~| (bitwise nor) • ^((bitwise xor) • ^~ ~ ^ (bitwise xnor, equivalence) • & (bitwise and) • ~ & (bitwise nand) • == (logical) != (logical) === (case) !== (case)

Procedures

<= (It or equal)

>= (gt or equal)

<< (shift left)

>> (shift right) + (addition)

- (subtraction)

* (multiply)

/ (divide) % (modulus)

> (gt)



- A Verilog **procedure** is an **always** or **initial** statement, a task, or a function.
- The statements within a sequential block (statements that appear between a begin and an end) that is part of a procedure execute sequentially in the order in which they appear, but the procedure executes concurrently with other procedures.

Procedural Blocks

-
- There are two types of procedural blocks:
 - initial blocks executes only once
 - always blocks executes in a loop
- Multiple Procedural blocks may be used, if so the multiple blocks are concurrent.
- Procedural blocks may have:
 - Timing controls which delays when a statement may be executed
 - Procedural assignments
 - Programming statements

Procedural Statement Groups




- When there is more than one statement within a procedural block the statements must be grouped.
- Sequential grouping: statements are enclosed within the keywords begin and end.
- An example

```
always
 begin
           // executed 1st
    c = 4; // executed 2nd
    wake_up = 1; // executed 3rd
 end
```

Timing Controls (procedural delays)

- #delay simple delay
 - •Delays execution for a specific number of time steps. #5 req a = req b:
- @ (edge signal) edge-triggered timing control
 - •Delays execution until a transition on signal occurs.
 - edge is optional and can be specified as either posedge or negedge.
 - •Several signal arguments can be specified using the keyword or.
 - •An example : always @ (posedge clk) reg a = reg b;
- wait (expression) level-sensitive timing control
 - Delays execution until expression evaluates true.
 - •wait (cond is true) reg a = reg b;

Time & Event Queues





- Time can only advance forward.
- Time advances when every event scheduled at that time step is executed.
- Simulation completes when all event gueues are empty
- An event at time t may schedule another event at time t or any other time t+n

Procedural assignments

- Assignments made within procedural blocks are called procedural assignments.
 - Value of the RHS of the equal sign is transferred to the LHS
 - LHS must be a register data type (reg, integer, real). NO NETS!
 - RHS may be any valid expression or signal

```
always @ (posedge clk)
begin

a = 5; // procedural assignment
c = 4*32/6; // procedural assignment
wake_up =$time; // procedural assignment
end
```

Blocking Assignments



- · Blocking assignments.
 - RHS expression evaluated and assignment is scheduled.
- Delayed Blocking assignments.
 - Evaluation of the assignment is delayed by the timing control.
 - RHS expression evaluated and assignment is scheduled.

```
Blocking assignment:
initial
begin
a = b;
c = d;
end
```

```
Delayed Blocking assignments:
initial
begin
#1 a = b;
#1 c = d;
```

Blocking Assignments Example



- RHS expression evaluated.
- Assignment is scheduled in sequence.




Event Queues				Time
	e<-f(t)	c<-d(t)	a<-b(t)] t
				t+1
				t+2
				t+3
< Execution order				


Non Blocking Assignments





- The nonblocking procedural assignment statement allows execution in a sequential block to continue and registers are all updated together at the end of the current time step.
 - RHS expression evaluated.
 - Assignment is scheduled at the end of the queue .
 - Assignment is made at end of the time step.


```
initial
begin
a <= b;
end
```











Continuous Assignment



- Continuous assignment assigns a value to a wire in a similar way that a real logic gate drives a real wire.
- The main use for continuous assignments is to model combinatorial logic.

syntax: Explicit continuous assignment:
 assign net_name = expression;
 where net_name is a net that has been previously declared

module continuous (Ain, Aout);
input Ain;
output Aout;
assign Aout = ~Ain //continuous assignment.
endmodule

Ain

Illustration of Assignment Statements



module assignments

//... Continuous assignments go here.

always // beginning of a procedure

begin // beginning of sequential block

//... Procedural assignments go here.

end

endmodule

Control Statements



Aout

- Two types of programming statements:
 - Conditional
 - Looping
- Programming statements only used in procedural blocks

if and if-else

syntax:

if(expression) statement

If the expression evaluates to true then execute the statement (or statement group)

if(expression) statement1 else statement2

If the expression evaluates to true then execute statement1, if false, then execute statement2 (or corresponding statement groups).

```
module if_ex(clk);
  input clk;
  reg red,blue,pink,yellow,orange,color,green;
  always @ (posedge clk)
  if (red || (blue && pink))
  begin
    $display ("color is mixed up");
     color <= 0; // reset the color
  end
  else if (blue && yellow)
  $display ("color is greenish");
  else if (yellow && (green || orange))
  $display ("not sure what color is");
  else $display ("color is black");
endmodule
```

case

....

```
syntax:
case (expression)
   case_item_1:
                     statement or statement_group
   case item 2.
   case item 3:
                     statement or statement_group
   case item n:
                     statement or statement_group
   default:
              statement or statement_group
```


endcase

- · Does an identity comparison (But only simulation will match x, z)
- Compares expression with each case_item_(n) in turn.
- If none match, the default code is executed.
- default clause is ideal to catch unknown/unspecified values


```
reg [2:0] reg_a, reg_b;
always @ (posedge clk)
      case (reg_a)
          3'b000:
                     reg_b <= 0;
                     reg_b <= 1;
          3'b001:
          3'b010
          3'b011:
                     reg_b <= 3;
          default: reg_b <= 5;
      endcase
```

casez, casex

don't care).



• casex - special version of case that allows the Z or X logic value in the case-items (x or z or ? treated as don't cares).





Coding style tip - to save confusion use "?" as the don't care indicator.


Which to use: case or if-else?





. . . .


...

- Some general rules to remember:
 - Use if-else where you MUST have priority encoded logic
 - Use **case** for non-priority encoded logic
 - case items are mutually exclusive
 - Always specify a default clause in case statements










while

syntax:

while (expression) statement or statement_group

- statement or statement_group is continuously executed as long as expression evaluates true (or non zero).
- In synthesis, the loop must contain an edge-triggered timing control, i.e. @(posedge clk) or @ (negedge clk)



endmodule

•••

• • • •

for

syntax:


for (assignment_init; expression; assignment) statement or statement_group


 The assignment_init is executed once at the start of the loop.


- Loop executes as long as expression is true.
- The **assignment** is executed at the completion of each loop.


```
module for_ex1 (clk);
input clk;
reg [31:0] mem [0:9]; // 10x32 memory
integer i;
always @ (posedge clk)
for (i = 9; i >= 0; i = i-1)
mem[i] = 0; // init the memory to zeros
endmodule
```


Ever see a hardware for? HDL Compiler® simply unrolls the loop... module for_ex3(start_cnt,cnt); input start_cnt; module for_ex2(start_cnt,cnt); output[7:0] cnt; input start_cnt; integer i; output [7:0] cnt; reg [7:0] vec,cnt; integer i; reg start cnt; reg [7:0] vec,cnt; always @ (start_cnt) always @ (start_cnt) begin for $(i = 0; i \le 3; i = i+1)$ if (vec[0] == 1'b0)if (vec[i] == 1'b0)cnt = cnt + 1;cnt = cnt + 1;if (vec[1] == 1'b0)endmodule cnt = cnt + 1;if (vec[2] == 1'b0) You can't re-assign the loop variable from cnt = cnt + 1;within the for loop. It's supposed to be a constant! if (vec[3] == 1'b0)cnt = cnt + 1;· Beware using complex functions inside a for-loop. They end can easily be replicated unnecessarily by the unrolling. The example here generates 4 adders! endmodule • For synthesis you can't embed edge-triggered timing controls in for loops · Must use constants in expression limit.











Compiler directives

Compiler directives cause the Verilog compiler to take special actions

- · Indicated by the grave accent character (`)
- · Directive remains in effect until it is overridden or modified. It is active across modules and files.

macro

is substituted here

Conditional Compilation

List of most commonly used compiler directives:

`define macro text string

`include "file_name"

`ifdef macro verilog source

verilog source

`endif

Simulating the Verilog Code



Verilog code of NAND Latch

Module simple_latch (q, qBar, set, clear);


input set, clear;

output q, qBar;

nand #2 n1(q,qBar,set);

nand #2 n2(qBar,q,clear);

endmodule



Testbench



....

text substitution of text string for

file inclusion. Another source file

- A testbench generates a sequence of input values (we call these input vectors) that test or **exercise** the verilog code.
- It provides stimulus to the statement that will monitor the changes in their outputs.
- Testbenchs do not have a port declaration but must have an instantiation of the circuit to be tested.

A testbench for NAND Latch



```
Module test simple latch:
   wire q, qBar;
   reg set, clear;
   simple_latch SL1(q,qBar,set,clear);
           #10 \text{ set} = 0; clear = 1;
           #10 \text{ set} = 1;
           #10 clear = 0:
           #10 clear = 1;
           #10 $stop:
           #10 $finish:
          end
   initial
           $monitor ("%d set= %b clear= %b q=%b qBar=%b",$time
                      set,clear,q,qBar);
          end
endmodule
```