# **CG2271 Real Time Operating Systems**

## **Tutorial 5**

## Question 1

In a co-operative multitasking operating system, tasks surrender control to other tasks on their own accord. I.e. they are never pre-empted. How is such an OS similar to function queue scheduling, and how is different? List down and discuss as many points as possible.

## Question 2

C supports a special data type called "void \*", and this is commonly used in RTOS. For example in uC/OS-II and FreeRTOS, tasks are usually declared as:

```
void task1(void *param)
{
    !! task1 body
}

void task2(void *param)
{
    !! task2 body
}
```

- a. A variable that is declared of type int \* (e.g. int \*ptr) is essentially a pointer to an integer variable. By the same logic, a variable that is of type void \* (e.g. void \*ptr) is a pointer to void variable. However there is no such thing as a void variable in C. So what is a void \* variable?
- b. Discuss why void \* variables are useful.
- c. What are the pitfalls of using void \* variables?

## **Question 3**

In C, a pointer to a function with prototype *void fun(int \*)* is defined as:

```
int (*fpointer)(int);
```

So you can for example do this.

- a. Discuss, within the context of operating systems, the different ways that function pointers are useful.
- b. Using what you've just learnt about function pointers, implement a priority queue. Use the following structure:

```
typedef struct pq
{
     void (*fp)(void *);
     int priority;
     struct pq *next, *prev;
} TFuncQ;
```

Your priority queue has the following functions to queue and dequeue functions.

```
void enq(void (*fp)(void *), int priority);
TFuncQ *deq(); // Returns the structure at the head of the queue.
```

You can assume that priority=0 is for highest priority functions and priority=255 is for lowest.

c. Suppose that there are three handler functions adc\_func, timer0\_func and timer1\_func defined as:

```
void adc_func(void *ptr)
{
    !! Handle ADC stuff
}
```

```
void timer0_func(void *ptr)
{
    !! Handle timer 0 stuff
}
void timer1_func(void *ptr)
{
    !! Handle timer 1 stuff
}
```

Write the ISRs for the ADC, Timer 0 and Timer1 compare interrupts that insert the respective handler functions into the priority queue. You only need to show the ISR code, you do not need to show any initialization/startup code for the ADC or the timers. ADC has highest priority, Timer 0 next highest, and Timer 1 the lowest priority.

d. Continuing on with c., implement a full function-queue scheduling system, except for the code to initialize/startup the timers and ADC.