# Milestone 2: Simultaneous Localization And Mapping (SLAM)

# **Setting Up**

# Server (AlphaBot)

- Connect to the Pi through PuTTY, (i.e. open PuTTY, enter the IP address, and at the command prompt login as "pi" with the username "raspberrypi")
- cd into ECE4078\_MY\_Lab\_2022 and type git pull to get updates to the server/robot codes.
- Charge the batteries of the Alphabot.

## Client (Your PC)

- Open a command prompt (type "cmd")
- Install a few packages by running the command (these 2 lines are one single command): pip install machinevision-toolbox-python==0.5.5 spatialmath-python==0.8.9 matplotlib
- To confirm the required packages are installed, in a terminal type python, which opens python in command line, then type:

```
import cv2
from cv2 import aruco
from machinevisiontoolbox import Image, CentralCamera
```

If there is no error then everything is successfully installed and you can exit python by typing Ctrl+Z or exit().

```
If you encounter the error "cannot import name aruco from cv2", run: pip uninstall opencv-python opencv-contrib-python pip install opencv-contrib-python==4.6.0.66
```

- Download milestone2.zip and move the content to your working directory.
- Replace the keyboard control section in operate.py with the code you developed for M1. (do not simply replace the whole file, but copy-paste the code that you changed)

## **Activities**

## Calibration (Week 3)

#### Wheel calibration

In the calibration folder, please complete wheel\_calibration.py by filling in line 46 for computing the scale parameter, and line 89 for computing the baseline parameter. Open a command prompt in the calibration folder. Run the wheel calibration script using the command python wheel\_calibration.py --ip IPADDRESS --port 8000 . This script will set the robot driving forward, and then spinning at various velocities, for durations that you specify, in order to compute the scale and baseline parameters for wheel calibration.

You can mark a 1m long straight line with masking tape on the floor, and use it as a guide to check if the robot has traveled 1m (do not have to be exact). As Alphabot2-Pi does not have wheel encoders, it has trouble traveling straight due to wheel slip. To obtain the best calibration possible, you can perform some changes such as cleaning the tyres/tracks, using speed range that your Pibot usually operates (line 18 and line 61), using smaller range, or using distance less than 1m.

#### Camera calibration

For camera calibration on the physical robot, you are required to use a calibration method known as the checkerboard calibration.

Run the wheel calibration script using the command python calib\_pic.py --ip IPADDRESS --port 8000

For more details, see:

https://docs.opencv.org/4.x/dc/dbb/tutorial\_py\_calibration.html or https://learnopencv.com/camera-calibration-using-opencv/

## SLAM (Week 4-5)

operate.py makes use of the camera and wheels' calibrated parameters and the SLAM components to produce a map saved as "slam.txt" in the lab\_output folder. This SLAM map contains a list of identified ARUCO makers, their locations and the covariances of the estimation. Note: remember to replace the keyboard control section with your codes from M1.

ARUCO markers are square fiducial markers introduced by Rafael Muñoz and Sergio Garrido. OpenCV contains a trained function that detects the ARUCO markers, which will be used in this project (the dictionary we used to generate the markers was cv2.aruco.DICT\_4X4\_100). Alphabot will be using these ARUCO markers as road-signs to help it map the environment and locate itself.

SLAM computes the locations of the ARUCO markers using both camera-based estimation (slam/aruco\_detector.py) and motion model-based estimation (slam/robot.py). Please complete robot.py by filling in the computation of the derivatives and covariance of the motion model. Please also complete ekf.py by filling in the computation of the predicted robot state and the updated robot state to finish the extended Kalman filter function.

Once robot.py and ekf.py are completed, you can test the performance of your SLAM by running python operate.py.

## Marking

To be announced.

### FAQ M2

- The scale and baseline parameters are used in robot.py. Study how they are used in the codes to help you understand how to compute them.
- Take a close look at the units of the expected output when formulating your calculations. Referring to these equations may be helpful:

$$\dot{x} = r\omega \qquad \qquad \dot{\theta} = \frac{r}{L}(\omega_r - \omega_l)$$

- Beware of the sign error that can happen with calculating the difference between the measurement and estimate in the correction step
- The state vector x will be appended with the aruco-marker measurements. Take a note of the location of x that should be updated in the motion model.
- In the prediction step, we should update the mean belief by driving the robot.