



4.0 Tobacco Fixture

ASSEMBLY INSTRUCTIONS




**CAUTION!
ATTACH
ASSEMBLED
UNIT TO WALL**


For Video Instructions Visit:


<https://www.benchmarc.com/swedishinstructions/>





 **BENCHMARC®**
We Invent Displays


Uprights 	Display Length	Part Quantity
	1ft	2
	2ft	3
	3ft	4
	4ft	5


Top crossbar 	Display Length	Part Quantity
	1ft	1
	2ft	2
	3ft	3
	4ft	4

Bottom crossbar 	Display Length	Part Quantity
	1ft	3
	2ft	6
	3ft	9
	4ft	12


Foldable Header 	Display Length	Part Quantity
	1ft	1
	2ft	1
	3ft	1
	4ft	2

Base Panel 	Display Length	Part Quantity
	1ft	1
	2ft	2
	3ft	3
	4ft	4


Header Face 	Display Length	Part Quantity
	1ft	1
	2ft	1
	3ft	1
	4ft	2

Back Panel


Display Length	Part Quantity
1ft	1
2ft	2
3ft	3
4ft	4

Graphic


Display Length	Part Quantity
1ft	1
2ft	1
3ft	1
4ft	2

Upper Side Panel

Display Length	Part Quantity
1ft	2
2ft	2
3ft	2
4ft	2

Lower Side Panel


Display Length	Part Quantity
1ft	2
2ft	2
3ft	2
4ft	2

Light Panel

Display Length	Part Quantity
1ft	1
2ft	1
3ft	1
4ft	2


Christmas Tree Clip

Long



Display Length	Part Quantity
1ft	14
2ft	14
3ft	14
4ft	14

Short




Display Length	Part Quantity
1ft	4
2ft	8
3ft	12
4ft	16


1 Make sure the telescoping locks are **NOT** engaged.

Attach cross bars to leg uprights. **Have hole side face away from you.** Starting with lower cross bars. ①
Top cross bar last.


Top cross bars are marked with a “T” while the lower cross bars are blank.




2 Adjust leveler feet. Insert bases into leg slots.




3 Attach header bracket to front header face. Make sure bracket is oriented with the cross bar on the top.




4 Position as needed. Tighten thumb screws to secure position.




5 Attach header to uprights. Feed led light cable through the bracket.




6 Engage the Locks.




7 Attach backdrop to middle and bottom cross bars with short christmas tree clips.




8 Attach secondary backdrop to the top cross bar with short christmas tree clips.




- 9** Remove lock stoppers and pull up on the uprights to adjust the height. Push in locks to secure in place.




- 10** Attach lower side panels with long christmas tree clips.



11 Attach upper side panels with long christmas tree clips.



12 Add Shelves.



4.0 Attaching Header Panels


To secure two header panels, secure wing nut to bolt in the center of the two racks to complete assembly.



Nut (x2)



Bolt (x2)



2 Foot Rack (x2)

