


4.0 Tall Tobacco Rack

ASSEMBLY INSTRUCTIONS



**CAUTION!
ATTACH
ASSEMBLED
UNIT TO WALL**

For Instructions Visit:

<https://www.benchmarc.com/swedishinstructions/>



Original Push Lock

The original Push Lock system has two different types of legs a left and a right.



Opened Original Lock

Revised Universal Push Locks June 2022

The Revised Universal Push Locks are universal and have no right or left leg.



Opened Universal Lock



Closed Original Lock




Closed Universal Lock


4.0 Tall Tobacco Rack

2216


1 Attach cross bars to leg uprights. Cross bars are labeled accordingly. Make sure locks are not engaged. Use a mallet to secure fit.




2 Adjust leveler feet. Insert bases into leg slots.



3 Assemble header, attach arm braces to graphic channel with screws. Position as needed.




4 Attach header to back of uprights.




4.0 Tall Tobacco Rack

2216


5 Attach provided caps into uprights to secure header.




6 Attach backdrop to middle and bottom cross bars with push pins.



7 Attach secondary backdrop to the top cross bar.





8 Attach shelves.




Adjusting display height


2116



Pull out lock on all uprights.



Grab center upright and pull up.




Push lock back in to secure.

4.0 Attaching Header Panels


Items Needed:




Nut (1x)



Bolt (1x)



2 Foot Rack (1x)



1 Foot Rack (1x)

1 To secure two header panels, Secure wing nut to bolt in the center of the two racks to complete assembly.

