


USER MANUAL


PDP 12 - Jumper Machine


Florian BOULAY
Clara HEID
Virgile MARTY
Benoît VÉRAN
Bastien VINCENT





























This menu will execute the program to cut and strip jumpers with all the parameters set in the other menus.

This menu allow to set manually the position of the blade for stripping, the more the joystick is moved in a direction, the more steps the stepper will do.

The push allow to enter and exit the changing mode.


This menu allow to change the length of the jumpers by the numbers of pins it will cover, changing the number by an increment of 1 with the joystick from left to right, 3 being the minimum number and 20 the maximum.


The push allow to enter and exit the changing mode.

This menu allow to change the number of jumper the program will cut, changing the number by an increment of ten with the joystick from left to right, 1 being the minimum number. The push allow to enter and exit the changing mode.

This menu allow to extrude the wire from the extruder to the blade with one push.

Allow to change menu if the user is not executing a program or is changing values of a parameter.







More Instructions



1) connect the **power cable** to the **arduino board** 2) connect the 5A power supply to the emergency stop button 3) check that the emergency stop button is up 4) turn on the arduino board 5) turn on the switch