



OSIRIS VR VIEWER

Stereoscopic 3D & Desktop Viewer for OpenXR

Watch any game or your desktop on a giant curved screen in VR

USER MANUAL · Version 0.5.0

Contents

- 1 What is OSIRIS VR Viewer?**
- 2 System Requirements**
- 3 Getting Started & Usage**
- 4 Recommended Preset Setups**
- 5 Features in Detail**
 - 5.1 3D Mode & Stereo Formats
 - 5.2 Screen Shape & Geometry
 - 5.3 Head Tracking & Behaviour
 - 5.4 Image, Colour & Sharpening
 - 5.5 Edge Stretch — the five fill methods
 - 5.6 Experimental & Performance
 - 5.7 Motion Smoothing — Temporal Blend & Frame Extrapolation
 - 5.8 6DoF, Directional Tracking & VR-Data Output
 - 5.9 The Katanga Game Engine (auto-detect & recovery)
 - 5.10 Presets
 - 5.11 Interface, Themes & the In-VR Panel
- 6 VR Controller Hotkeys**
- 7 Head-Tracking Output & 6DoF Mods**
- 8 Links, Companion Tools & Hubs**
- 9 Tips, Troubleshooting & Glossary**

SECTION 1

What is OSIRIS VR Viewer?

OSIRIS VR Viewer turns your VR headset into a personal cinema and a 3D-gaming display. It takes an image source — a stereoscopic 3D game, a flat game, a movie, or your whole Windows desktop — and paints it onto a huge, curved virtual screen that wraps around you in VR.

Unlike a flat floating window, OSIRIS renders the source onto a configurable **sphere**, **fish-eye dome** or **box**, so the picture can fill your field of view and curve naturally around your head. It reads live 3D output from geo-11 / 3Dmigoto games (the **Katanga** shared-texture path) to give true per-eye stereoscopic depth, and it can just as easily mirror your desktop for productivity, media or non-3D games.

The project is built in Rust on top of **wgpu** and **OpenXR** (Vulkan backend), and is derived from the open-source VRScreenCap. It is designed to be light on its own GPU cost so the game keeps the frame budget, while still offering a deep toolbox of image, geometry, immersion and motion-smoothing controls.

At a glance

- **Two apps that talk to each other:** a tray runtime that renders in VR, and a desktop control panel — edits sync live, both ways.
- **Any source:** geo-11/Katanga 3D games, flat games, movies, or the full desktop (Desktop Duplication).
- **Any screen shape:** curved Sphere, Fisheye dome or Box, with full control of size, distance, curvature and offsets.
- **Real stereoscopy:** Mono, Half/Full SBS & TAB, Line-Interlaced and Checkerboard 3D, with swap-eyes and convergence.
- **Immersion tools:** five edge-fill methods, ambient glow, hybrid 360 immersion, concave back-wall and depth layers.
- **Performance & motion:** fixed foveated rendering, supersampling, temporal blend and adaptive frame extrapolation.

SECTION 2

System Requirements

Requirement	Details
Operating system	Windows 10 or 11 (64-bit).
VR runtime	An OpenXR runtime. Developed and tested against Pimax OpenXR (PimaxXR); other OpenXR runtimes such as SteamVR's should also work.
Headset	Any OpenXR-capable headset. Higher-refresh headsets (72/90/120 Hz) benefit most from the motion-smoothing features.
GPU	A modern Vulkan-capable GPU. Developed on an NVIDIA RTX 4080; mid-range and up recommended, since the game and the viewer share the GPU.
For 3D games	geo-11 or 3Dmigoto configured to output a Katanga-style shared stereo texture. Without it, games still display in 2D via the desktop path.
For desktop / 2D	Nothing extra — the desktop is captured with Windows Desktop Duplication automatically.

Note on foveated rendering: OSIRIS renders through Vulkan, so external D3D-only overlays (e.g. OpenXR Toolkit's VRS foveation) cannot hook it. Use the built-in shader foveation, or your headset runtime's own foveated rendering, instead.

SECTION 3

Getting Started & Usage

Getting into VR is a one-launch affair: you start the viewer, and everything else comes up automatically.

The two executables

Executable	Role
osiris-vr-viewer.exe	The runtime. It sits in the system tray and renders the virtual screen inside your headset. This is the only file you need to launch — start it with your headset on and its OpenXR runtime running.
osiris-gui.exe	The desktop control panel where you change every setting. You normally don't start this yourself: the viewer launches it automatically on startup. Edits you make here apply live in the headset.

Automatic control panel. When you open **osiris-vr-viewer.exe**, it spawns **osiris-gui.exe** for you as a companion window (a built-in recursion guard means it's never opened twice). So a single double-click gives you both the in-VR screen and the desktop controls — no need to hunt for the GUI separately. If the GUI ever closes, you can reopen it manually and it reconnects to the running viewer.

First run — step by step

- 1 Put your headset on and make sure its OpenXR runtime is active.
- 2 Launch **osiris-vr-viewer.exe**. A screen showing your desktop appears in VR, the app lands in the system tray, and the **control panel opens automatically** on your monitor.
- 3 In the control panel (which has already loaded your **default** preset), pick a **3D Mode** and **Screen shape**.
- 4 Use **Geometry** to size, curve and place the screen exactly where you want it. Optionally hit **Auto Adjust** to snap the height to the detected source aspect ratio.
- 5 To watch a 3D game, start it with geo-11 / 3Dmigoto. OSIRIS detects the shared 3D texture and switches to it automatically; when the game closes it returns to the desktop.
- 6 Save your tuned look as a preset — and make your everyday configuration the **default** so it loads on the next launch.

Tuning from inside VR

You never have to take the headset off to make changes. OSIRIS includes an **in-VR control panel** (an ImGui overlay) that mirrors the desktop GUI section-for-section. Edits made in either place reflect in the other in real time, so you can adjust curvature, edge-stretch, colour or immersion while actually looking at the result. The panel renders at your headset's refresh rate and is completely isolated from the capture path, so opening or dragging its sliders never interrupts the game feed or the desktop capture.

Good to know

- Launching the viewer is enough — the desktop control panel opens itself.
- The **default** preset loads automatically on startup; make it your comfortable baseline.
- Desktop ↔ game ↔ desktop transitions are automatic and seamless; a game exit returns you to the desktop rather than freezing.
- The desktop panel quietly throttles its own redraw when you're not interacting with it, so it never steals GPU from the game while you're immersed in VR.

SECTION 4

Recommended Preset Setups

These are good starting points — load or recreate them, then fine-tune to taste and save as your own presets. Values are directions, not exact numbers; every headset and game differs.

■ Cinema / Movies (flat 2D)

3D Mode: Mono. **Shape:** Sphere with low curvature (nearly flat).

Geometry: large size, comfortable distance, screen centred and head-locked.

Behaviour: Head-lock screen ON so the screen stays put as you relax.

Image: a touch of sharpening; keep colour neutral. Edge stretch OFF or subtle Ambient light for a soft glow around the frame.

■ Immersive 3D Game (stereoscopic)

3D Mode: match your game's output (Full-SBS / Half-SBS / TAB); use Swap-eyes if depth looks inverted.

Shape: Sphere with moderate–high curvature to wrap the image around you.

Edge Stretch: Hybrid Immersion (or Mirror/Expansion) to fill the periphery; add Ambient light for a 360 glow.

Geometry: tune Separation & Convergence until depth feels natural and comfortable.

■ Performance mode (GPU-bound games)

Supersampling: 1.0 (or lower) to hand GPU back to the game.

Experimental: Fixed Foveated Rendering ON — pull 'Foveation start' inward until fps is where you want it.

Motion: Temporal blend + Optical flow extrapolation ON for smoother motion up toward the headset refresh.

Image: turn off heavy sharpen/enhancement passes you don't need.

■ Desktop / Productivity

Source: desktop (automatic when no game is detected).

Shape: Box or a low-curve Sphere for a flat, readable panel.

Behaviour: Head-lock OFF if you want the screen fixed in the room; ON to carry it with you.

Image: full sharpness, no edge stretch — keep text crisp.

SECTION 5

Features in Detail

Everything OSIRIS can do, grouped by the panel section it lives in. Toggles that are off cost nothing; most effects are designed to be free until you enable them.

5.1 3D Mode & Stereo Formats

Chooses how the source image is split into left- and right-eye views. Match this to how your game or video encodes 3D.

■ Stereo format

Mono (single image, no depth), Half-SBS & Full-SBS (side-by-side), Half-TAB & Full-TAB (top-and-bottom), Line-Interlaced, and Checkerboard 3D. 'Full' formats use the whole source per eye; 'Half' formats squeeze both eyes into one frame.

■ Swap eyes

Flips left/right. Use it if close objects look far away — a sign the eyes are reversed.

■ Stereo corrections

Fine adjustments to line up the two eye images so depth is clean and comfortable.

5.2 Screen Shape & Geometry

Geometry defines the virtual surface the image is painted on and exactly where it floats around you. This is where you turn a flat rectangle into anything from a modest desktop monitor to a wrap-around dome that fills your vision.

■ Sphere (default)

An inside-out curved screen that bends around your head. Horizontal and vertical curvature are controlled independently, so you can go from an almost-flat cinema wall to a strongly enveloping curve that hugs your periphery. This is the recommended shape for both games and movies.

■ Fisheye

A dome-style projection that spreads the image over a very wide arc for maximum immersion — ideal for ultra-wide or 200°-style content where you want the picture to reach the edges of your vision.

■ Box

A flatter, panel-like surface with squared proportions. Best for desktop work, reading and crisp 2D where a curve would distort straight lines.

■ Distance & Size

How far away the screen sits and how large it is. Together they set the apparent field of view the picture occupies — a small screen far away for a focused monitor, or a huge one up close for a full-immersion cinema.

■ Offsets (X / Y / Z / Roll)

Slide the screen left/right (X), up/down (Y) and nearer/farther (Z), and tilt it (Roll), so the image lands precisely where you're looking. Handy for seated setups where your neutral gaze isn't dead-centre.

■ Curvature (Horizontal / Vertical)

Independent bend of the Sphere on each axis, from flat to cockpit-style wrap. A little horizontal curve adds presence without distortion; a lot turns the screen into a surround.

■ Auto Adjust

One click snaps the sphere/box height to match the **detected source aspect ratio** — with built-in presets for 16:9, 4:3 and 21:9 — so a new game or video fills the screen correctly without manual sizing.

■ Concave back-wall

Bows the surface into a shallow bowl so the centre appears gently recessed, adding real depth instead of a flat cut-out. You control the bowl **depth** and its **shape** (from parabolic to spherical) and where the recession begins.

■ Depth Layers

Splits the image into multiple stacked depth planes for a layered, diorama-like sense of three-dimensionality — especially effective on content with clear foreground/background separation.

■ **Dynamic Depth**

Drives the apparent depth from the image content itself, so brighter/closer areas pop forward — a content-aware 3D boost that works even on 2D sources.

5.3 Head Tracking & Behaviour

Controls how the screen responds to your head — from bolted-to-your-view to fixed in the room — and the smoothing that keeps the image rock-steady.

■ **Head-lock screen**

When on, the screen follows your head so it's always in front of you — perfect for lying back or moving around. When off, the screen stays anchored in world space so you can physically look around it, like a real monitor on a stand.

■ **Head-lock mode**

Chooses *how* the locked screen follows — from a rigid attachment that moves instantly with your head to a soft, delayed follow that trails slightly and feels more relaxed.

■ **Disable roll lock**

Lets the screen tilt with your head roll. Off keeps the screen horizon upright no matter how you cock your head (usually the more comfortable choice); on can add roll offset when head-lock is engaged.

■ **Head Lock Offsets**

Positions the locked screen relative to your head — height, distance and angle — so it sits comfortably in your natural gaze rather than dead-centre.

■ **DeJitter**

A vorpX-style soft-lock spring that gently damps the tiny involuntary tremors of your head. Movements smaller than a set dead-zone are ignored so a still head reads perfectly steady, while a stiffness control keeps larger turns from feeling sluggish. This is the key to a stable, fatigue-free image.

■ **Parallax Prediction**

Looks slightly ahead of your head motion and compensates, reducing the perceived latency and judder between moving your head and the image catching up.

5.4 Image, Colour & Sharpening

Everything that shapes how the picture looks before it reaches your eyes — from the core stereo comfort controls to optional clarity passes.

■ **Pose predict (ms) & Predict smooth**

How far ahead your head pose is predicted (in milliseconds) and how heavily that prediction is smoothed. More prediction cuts latency; more smoothing trades a little of that back for extra stability.

■ **IPD / Separation / Convergence**

The three core stereo-comfort controls. **Separation** sets how far apart the two eye views are (the overall strength of the 3D effect), **Convergence** moves the zero-parallax plane — the depth at which objects sit right on the screen — and **IPD** matches your eyes. Dial these in until depth looks natural and your eyes relax; getting them right is the single biggest factor in comfortable 3D.

■ **Brightness / Contrast / Saturation**

Straightforward colour grading of the displayed image, to match your headset's panel and your taste.

■ **Sharpness & Texture sharpen**

Restore crispness lost to upscaling and the curve of the screen. Two independent controls let you sharpen the overall image and the source texture separately.

■ **Filters (Bilinear / Bicubic / Lanczos)**

Selectable sampling kernels for scaling: **Bilinear** is smoothest, **Bicubic** is a sharper middle ground, and **Lanczos** is the crispest with controlled ringing. Pick per your source and taste.

■ CAS, Dehaze & Enhancement

Optional heavier passes: **Contrast-Adaptive Sharpening** for edge-aware bite, **Dehaze** to lift flat/washed-out images, and a multi-pass **Enhancement** clarity/upscale chain. These cost more GPU than the basic sharpen — leave them off when you're chasing frame-rate, and note the periphery skips them automatically when Fixed Foveated Rendering is on.

5.5 Edge Stretch — the five fill methods

When the source doesn't fill the whole curved screen, edge-stretch fills the periphery so there are no black borders. Five methods are available; each has its own collapsible slider group in both the desktop GUI and the in-VR panel.

■ Mirror

Reflects the boundary pixels outward — a clean, symmetric fill with adjustable softness, falloff and expand.

■ Repeated

Tiles the outer strip outward without a mirror flip; includes the Extend controls (edge stretch/expand, pull-blend, repeat depth/blend).

■ Ambient light

A content-aware peripheral glow that samples the image's edge colours and spreads them 360° around you — works in every mode and with Katanga. Great as a soft, immersive halo.

■ Expansion / Extrusion

Mesh-level deformation that pushes the screen geometry outward/forward, sharing one displacement — reach, seamlessness, smoothness and extrusion direction.

■ Hybrid Immersion

The most enveloping fill (Sphere mode): stretches the image toward a full wrap with independent horizontal/vertical centre and FOV-gain, stretch reach & direction, softness and ramp.

■ Rear fill (curve < 1)

When the sphere isn't fully closed, fills the black area behind you with a content-aware ambient wash so the world feels complete.

5.6 Experimental & Performance

Optional, cutting-edge features grouped under **Experimental Features**. All are off by default and safe to leave off.

■ Fixed Foveated Rendering (FFR)

Renders the periphery with progressively less work as the view angle leaves centre (full kernel → reduced → single tap), and skips the extra sharpen/CAS/dehaze passes out there. The screen centre stays full quality. A 'Foveation start' slider controls where the falloff begins. Portable shader-based approach — works on any headset.

■ Supersampling

Renders above native resolution for extra clarity (higher = sharper but heavier). Lower it to give the game more GPU. The single biggest quality-vs-performance lever.

■ Pimax planar depth reprojection

A Pimax-oriented planar depth submission path for reprojection.

■ Adaptive low-FPS prediction boost

Increases prediction strength when frame-rate drops, to keep motion steadier under load.

■ Frame pacing

Smooths frame delivery timing to reduce stutter.

■ Submit predicted pose to layer

Submits the predicted head pose to the compositor layer for lower perceived latency.

■ Stable per-eye submit

A steadier per-eye submission path.

■ Hold full refresh

Holds the full refresh rate under specific conditions.

5.7 Motion Smoothing — Temporal Blend & Frame Extrapolation

Two cooperating systems that make on-screen motion smoother, aiming to fill the gap between the game's frame-rate and your headset's refresh rate.

■ Temporal blend

A TAA-style accumulator that blends the current frame with clamped history to cut flicker and shimmer. It uses a full 3×3 neighbourhood clamp in YCoCg colour space (so colour/hue ghosting is suppressed) and a motion-adaptive strength that backs off on moving content — steadier images without smearing motion.

■ Optical flow extrapolation

Estimates on-screen motion by block-matching between frames and warps the last frame forward to synthesise in-between frames. A disocclusion guard fades the warp at object edges (where flow diverges) to avoid smearing, and the warp magnitude is capped to prevent rubber-banding.

■ Adaptive, any-frame-rate cadence

The extrapolator measures the game's actual content rate and synthesises exactly enough in-between frames to fill up toward the headset refresh — at 30, 45, 60 fps and beyond. When the game already matches the headset, it does nothing. 'Extrap. strength' tunes the effect.

5.8 6DoF, Directional Tracking & VR-Data Output

A deep toolkit for adding positional feel to flat content and for driving other apps from your head motion — popular for sim, racing and cockpit games. (For sending your pose to external games and mods, see Sections 7 and 8.)

■ 6DoF mode — Default vs Off-axis (window)

Two projection styles for the positional effect: **Default** shifts the image as a whole, while **Off-axis (window)** treats the screen like a real window you look through, so the perspective skews correctly as you move off-centre. Radial parallax works in both.

■ Simulated 6DoF

Fakes positional depth on a source that only has rotation, by shifting regions of the image as you move. Three granularities: **Bands** (horizontal strips react to sideways motion), **Columns** (vertical strips react to up/down), and a

full **2D cell grid** that combines both so every region reacts on its own — the most granular, strongest simulated-6DoF feel. The modes are mutually exclusive.

■ **5-zone radial parallax**

A soft depth taper across the screen: the centre stays the responsive anchor while outer zones move more and trail slightly (follow-through), giving a gentle sense of depth over the whole surface. A rim-fade control sets where the taper starts, and a horizon option layers depth along perspective (distant centre still, near edges sweep) for corridors and roads. Works in both projection modes; needs simulated 6DoF enabled.

■ **Directional 6DoF (tilt & turn)**

Adds head yaw/pitch/roll as extra motion parallax on top of the positional 6DoF, smoothed in lock-step with it, so leaning and turning both nudge the scene. Requires simulated 6DoF.

■ **Dynamic-depth 6DoF**

Uses the content-driven depth map so the parallax reacts to what's actually near or far in the image, for a more convincing positional illusion.

■ **Stable Lock**

A directional soft-lock that keeps the screen steady yet responsive. A dead-zone ignores tiny movement so a still head reads rock-solid, while a pull limit guarantees a fast turn can never leave the screen more than a set number of degrees behind before it's pulled along. Separate XY and Z parallax strengths tune how much the screen shifts.

5.9 The Katanga Game Engine

The system that brings live 3D games onto the screen, built for robustness during long sessions and messy game exits.

■ **Automatic shared-texture detection**

Finds the geo-11 / 3Dmigoto shared stereo texture and switches to it the moment a game provides one.

■ **Seamless reconnect & reprobe**

If the game's output drops or changes, OSIRIS re-probes and reconnects without you doing anything.

■ **Desktop fallback**

No game? It shows your desktop. When a game exits, it returns to the desktop cleanly instead of freezing.

■ **Freeze recovery**

Hardened against game-exit and alt-tab edge cases so the viewer keeps running and always finds its way back to a working desktop view.

5.10 Presets

Save entire configurations and recall them instantly.

■ **Save / Load / Overwrite**

Store any look as a named preset and bring it back with one click.

■ **Delete (with confirm)**

Remove presets you no longer want. A red X asks for confirmation first; the **default** preset is protected and can't be deleted.

■ **Auto-load default**

The preset named **default** loads automatically on startup — set it to your everyday configuration so OSIRIS is ready the moment the viewer launches.

5.11 Interface, Themes & the In-VR Panel

OSIRIS is controlled from two synchronised interfaces, and its look is customisable.

■ **Desktop control panel**

The full-featured window that opens automatically with the viewer. Every setting in this manual lives here, organised into collapsible sections (3D Mode, Geometry, Behaviour, Image, Edge Stretch, VR Data, Presets).

■ **In-VR panel (ImGui overlay)**

A mirror of the desktop panel that you can summon inside the headset, so you can tune while watching the result. It carries the same sections — including the full Experimental Features set and every Edge-Stretch and Hybrid Immersion slider — and stays in sync with the desktop both ways. It renders at headset rate and is isolated from capture, so it never disturbs the feed.

■ GUI Themes

Cosmetic themes for the desktop panel (such as Dark Blue). Purely a look-and-feel choice for the control window — it doesn't change anything the headset renders.

■ Live two-way sync

Anything you change in one panel updates the other instantly. The desktop panel intelligently idles its redraw when you're not touching it, so tuning from inside VR never costs the game any performance.

SECTION 6

VR Controller Hotkeys

You can control OSIRIS entirely from your VR controllers — no need to reach for the desktop. The bindings below are the defaults; controller hotkeys can be turned on/off as a group, and several actions are left unbound so you can assign them yourself in the hotkeys panel.

Controller input	Action
A button	Swap eyes (fix inverted depth)
B button	Recenter the view / screen
X button	Toggle head-lock on/off
Right grip	Toggle simulated 6DoF
Left grip	Take a screenshot
Right trigger	Toggle mouse emulation
Left trigger	Roll the screen left
Right thumbstick — click	Cycle 3D mode
Right thumbstick — up / down	Move screen forward / back (Offset Z)
Left thumbstick — left / right	Move screen left / right (Offset X)
Left thumbstick — up / down	Move screen up / down (Offset Y)

Assignable actions (unbound by default)

These live in the hotkeys panel and can be mapped to a spare input: **Cycle screen shape**, **Roll right**, **Toggle joystick/gamepad emulation**, **Toggle Katanga overlay**, **Toggle Katanga filters**, and **Toggle the UDP 6DoF stream**. There's also a **Force-desktop** toggle that holds the desktop view (press again to release and re-probe the game) and a **restart** action for the capture pipeline.

Controller tips

- The whole controller-hotkey system can be switched off if you'd rather your controllers do nothing in-game.
- Offsets nudge in small steps, so you can fine-position the screen from your chair.
- Recenter is your friend: use it any time the screen drifts from where you want it.

SECTION 7

Head-Tracking Output & 6DoF Mods

Beyond displaying the game, OSIRIS can send your live head pose OUT to other software — so your real head movement drives the camera in flat games, sims and community 6DoF mods.

Pick the output method that a given game or mod understands. Several can run at once, each with its own per-axis gains (pitch, yaw, roll, X, Y, Z).

Method	What it drives
--------	----------------

UDP 6DoF stream	Broadcasts your 6DoF pose over UDP for community 6DoF head-tracking mods , and for bridges like FreePIE and VRCompanion. This is the main path for the mod hubs in Section 8.
TrackIR (via FreeTrack)	Feeds head data to TrackIR-aware games. The 'TrackIR Game' toggle redirects your pose into FreeTrack shared memory so those titles read it natively. A lean boost amplifies only the forward/back lean (which is physically small) without touching the UDP stream.
OpenTrack	The UDP output is compatible with OpenTrack pipelines, letting you route head data into anything OpenTrack supports.
Mouse emulation	Turns head-look into mouse movement for 3DoF camera control — works in essentially any game via the Interception driver (Section 8). Sensitivity, speed and smoothing are adjustable.
Gamepad emulation	Maps head/VR data onto a virtual Xbox controller stick (via the ViGEmBus driver) for games that read a gamepad. Sensitivity, dead-zone, smoothness and a max-angle clamp are provided.

Using OSIRIS with 6DoF game mods

- 1 Enable the **UDP 6DoF stream** (or the method your mod expects) in the VR Data section.
- 2 Install a 6DoF mod for your game from one of the hubs in Section 8.
- 3 Set the per-axis gains so the in-game camera moves the right amount for each real head motion.
- 4 For TrackIR games, switch on 'TrackIR Game' instead, and use lean boost if the lean/zoom feels weak.

SECTION 8

Links, Companion Tools & Hubs

Two curated hubs collect ready-made 6DoF head-tracking mods for many games — start here to find a mod for your title:

Resource	Link (opens in browser)
6DOF Head-Tracking Mods Hub The project's own curated hub of 6DoF mods.	https://github.com/BerZerker96/6DOF-Head-Tracking-Mods-Hub
6DoF Mods by itsloopyo A large community collection of 6DoF game mods.	https://github.com/itsloopyo/itsloopyo

Companion tools & drivers

These optional tools extend what OSIRIS can drive. Install the driver a given method needs:

Resource	Link (opens in browser)
Interception driver Required for mouse emulation to work in ALL games.	https://github.com/oblitum/Interception/releases
ViGEmBus driver Required for virtual-gamepad (joystick) emulation.	https://github.com/nefarius/ViGEmBus/releases
FreePIE Scriptable input bridge — consumes the UDP head-tracking stream.	https://github.com/Ofisare/FreePIE

VRCompanion

Companion app that pairs with OSIRIS's UDP output for many games.

<https://github.com/Ofisare/VRCompanion>

Project & author

OSIRIS is developed by **BerZerker96**. Browse the project and related repositories here: github.com/BerZerker96.

SECTION 9

Tips, Troubleshooting & Glossary

Quick tips

- **Depth looks wrong / inverted?** Toggle **Swap eyes**, then fine-tune **Convergence** and **Separation**.
- **Game feels heavy?** Lower **Supersampling** first, then enable **Fixed Foveated Rendering** and pull its start inward.
- **Motion looks juddery?** Enable **Temporal blend** and **Optical flow extrapolation** — they adapt to your fps automatically.
- **Black borders around the image?** Turn on an **Edge Stretch** method (Hybrid Immersion or Mirror), or add **Ambient light**.
- **Editing in VR slows the game?** That's fixed — the desktop panel idles itself when you're not touching it; the in-VR panel is the smoothest way to tune while playing.
- **Want it exactly the same next time?** Save a preset, and make your everyday look the **default** one.

Glossary

Term	Meaning
Katanga path	The route that reads a game's 3D output from a geo-11 / 3Dmigoto shared texture for true per-eye stereoscopy.
Desktop Duplication	The Windows API OSIRIS uses to mirror your desktop when no 3D game is present.
Edge stretch	Filling the curved screen's periphery so the source image has no black borders.
Foveated rendering	Spending less GPU on the periphery (where your eye is less sharp) to gain performance.
Temporal blend / TAA	Blending frames over time to reduce shimmer and flicker.
Frame extrapolation	Synthesising in-between frames from motion to smooth playback toward the headset refresh.
Convergence / Separation	The two controls that place stereo depth comfortably: where '0 depth' sits, and how far apart the eyes are.

OSIRIS VR Viewer · User Manual · Version 0.5.0 — Watch anything on a giant curved screen in VR. Settings, presets and this manual reflect the current build; exact values and labels may evolve between versions.