




Bernardo Xavier

Sheet: /
File: MP3_Player.kicad_sch

Title: MP3 Player – Main


Size: A4 Date: 2026-09-17

KiCad E.D.A. 10.0.6


Rev: 0.1

Id: 1/9


TagConnect Pins




Boot Set Pins



I2C MUX



I2C Test Points



$$C = 2 * (CL - C_{stray})$$


$$C = 2 * (6pf - 5pf)$$

$$C = 2pf \approx 2.2pf$$

$$C = 2 * (CL - C_{stray})$$

$$C = 2 * (6pf - 5pf)$$

$$C = 2pf \approx 2.2pf$$



Main MCU

Bernardo Xavier

Sheet: /MCU/
File: mcu.kicad_sch



Title: MP3 Player - MCU

Size: A4 Date: 2026-09-17

KiCad E.D.A. 10.0.6

Rev: 0.1

Id: 2/9



Battery BOM Placeholder

PWR_FLAG
For ERC Ignore

TP4
GND Test point

Bernardo Xavier

Sheet: /Power/
File: power.kicad_sch

Title: MP3 Player - Power


Size: A4 Date: 2026-09-17

KiCad E.D.A. 10.0.6


Rev: 0.1

Id: 4/9

RIGHT MIC



LEFT MIC



Headphone Jacks

I2S DAC

Bernardo Xavier


Sheet: /Audio/
File: audio.kicad_sch

Title: MP3 Player – Audio

Size: A4 Date: 2026-09-17
KiCad E.D.A. 10.0.6

Rev: 0.1
Id: 5/9

MicroSD Socket



Bernardo Xavier

Sheet: /Storage/

File: storage.kicad_sch

Title: MP3 Player – Storage

Size: A4


Date: 2026-09-17

Rev: 0.1


KiCad E.D.A. 10.0.6

Id: 6/9

Volume Buttons



Menu Buttons



Bernardo Xavier

Sheet: /Buttons/

File: buttons.kicad_sch

Title: MP3 Player – Buttons


Size: A4

Date: 2026-09-17

Rev: 0.1


KiCad E.D.A. 10.0.6

Id: 7/9



Display Connector

FCON1
13 Pin Flex Connector



Display BOM Placeholder

Bernardo Xavier

Sheet: /Display/

File: display.kicad_sch

Title: MP3 Player – Display


Size: A4

Date: 2026-09-17

Rev: 0.1

KiCad E.D.A. 10.0.6

Id: 8/9



Wireless CoProcessor

Bernardo Xavier

Sheet: /Wireless/

File: wireless.kicad_sch

Title: MP3 Player – Wireless

Size: A4

Date: 2026-09-17

Rev: 0.1

KiCad E.D.A. 10.0.6

Id: 9/9