

1.) COSINE WAVE

Sr. No.	AMPLITUDE (mV)	FREQUENCY (kHz)
1	1	10
2	1	20
3	2	10
4	2	20
5	2	15


Case 1: Amplitude: 1 mV || Frequency: 10 kHz






Case 2: Amplitude: 1 mV | | Frequency: 20 kHz






Case 3: Amplitude: 2 mV | | Frequency: 10 kHz







Case 4: Amplitude: 2 mV | | Frequency: 20 kHz





Case 5: Amplitude: 2 mV | | Frequency: 15 kHz







1.) SQUARE WAVE

Sr. No.	AMPLITUDE (mV)	FREQUENCY (kHz)
1	1	10
2	1	20
3	2	10
4	2	20
5	2	15


Case 1: Amplitude: 1 mV || Frequency: 10 kHz







Case 2: Amplitude: 1 mV | | Frequency: 20 kHz






Case 3: Amplitude: 2 mV | | Frequency: 10 kHz






Case 4: Amplitude: 2 mV | | Frequency: 20 kHz







Case 5: Amplitude: 2 mV || Frequency: 15 kHz



