

```

#include <reg51.h>

#include <stdio.h>

void serial_ISR(void) interrupt 4
{
    char ch;

    if(RI)
    {
        RI = 0;
        ch = SBUF

        printf("\n>>> INTERRUPT RECEIVED: ");
        printf("%c\n", ch);
    }
}

void delay(void)
{
    unsigned int i;
    for(i = 0; i < 50000; i++);
}

void main(void)
{
    SCON = 0x50;
    TMOD = 0x20
    TH1 = 0xFD

```

TR1 = 1

IE = 0x90;

TI = 1;

while(1)

{

printf("Hello World\n");

delay();

}

}

