Driving Servo Motors with L293D Shield

The motor shield actually breaks out Arduino's 16bit PWM output pins **#9** & **#10** to the edge of the shield with two 3-pin headers.

Power for the Servos comes from the Arduino's on-board 5V regulator, so you don't have to connect anything to the EXT_PWR terminal.

Wiring Servo Motor to L293D Motor Shield & Arduino



As we are using the onboard PWM pins, the sketch uses IDE’s built in Servo library.

Program

```
#include <Servo.h>
Servo myservo; // create servo object to control a servo
int pos = 0;        // variable to store the servo position
void setup()
{
        // attaches the servo on pin 10 to the servo object
        myservo.attach(10);
}
void loop()
{
        // sweeps from 0 degrees to 180 degrees
        for(pos = 0; pos <= 180; pos += 1)
        {
                myservo.write(pos);
                delay(15);
        }
        // sweeps from 180 degrees to 0 degrees
        for(pos = 180; pos>=0; pos-=1)
        {
                myservo.write(pos);
                delay(15);
        }
}
```

Program for servo motor Without shield

```
#include <Servo.h>

int servoPin = 9;

Servo servo;

int angle = 0;// servo position in degrees

void setup()

{

servo.attach(servoPin);

}

void loop()

{

//scan from 0 to 180 degrees

for(angle = 0; angle<180; angle++)

{

servo.write(angle);

delay(20);

}

//now scan back from 180 to 0 degrees

for(angle = 180;angle>0;angle--)

{

servo.write(angle);

delay(20);

}

}
```