
Expt09 DUSTER MAKZNG AZM: To construct a duster from the given work piece. APPLICATION: Cross bars In a cot, shelves. SUPPLIED MATERIAL SPECIFICATIONS Venteck wood of size 150 x 45 x 30 TOOLS REQUERED: ) Jack plane. 2) Hand saws 3) 87cel rule. 4) pencil. 5) marking bange. 6) Try square. 7) Firmer Chisel. 8) Cleaning brush. 9) Worden mallet. Dereparing 2) Marking 3) Cutting / Sauring 4) finishing. WORKING STEPS: Prepare the work place as described in previous section with a length of 150mm, 45mm & 30mm. 2 PREPARENG: a) Adjust the marking gauge to 10mm and set out the distance from the same along all the gour & MARKENG: Lides of the place on the 30mm thick Alde from b) Again, adjust the marking gauge to sum and set out astance along all 4 sides of piece. c) Now mark a distance of 5 mm perpendicular to these Jones on 30 x 45 mm² sides from volte ends d) Mark a déagonal elne on all the Zuner square



CUTTENG/SAWENGS a) Hold the piece horizontally in a way such that the portion to be cut is just above the faws Use a hand saw to cut along the required like markings but slightly Enside the love as shown Ru figure to the required sum dept. b) Now using a girmer chisel take a series of cut to remove the wood up to this sum depth : c) Hold the prece again using a firmer chisel scantly this of the wood from the along the material dagonal side. Take a deries of small cuts delicately on both dide DE FRNESHENG: pieces to remove the excess wood obtalu a your fruish of the socket and shoulder assembly yourt and clear off the waste by wire brush. the souther was produced from the given work piece and assembled joint was submitted for evaluation.