


Expt02 SCOOP MAKING USING GIZ SHEET To make a Big Scoop of goven size from a AIM: sheet metal piece. APPARATUS REQUIRED: 1) Stell rule 2) Scriber 3) Steel square 4) Straight snip 5) Anvil or Bench plate 6) Mallet PROCEDURE : 1. Check whether the given sheet is having its dimension as 200 nm x 150 mm. If the dimension 2 Checking is excess trum of wring hand shear. 2. Keep one corner of the sneet between body and tongre of steel square of check whether the sides 3. Reep this worner as reference corner & these two sides as reference sides. this corner should be pept at left hand side bottom position. using scel rule & scriber mark somm point Layout Marking on both side in vertical axis. 2. Mark 5mm on one side of the horizontal over a mon again make a point mark after 3. Now from Sum marking mark 10mm on both side 4. Make two magonal line attaching on joining 60mm marking on hovizontal axis to 10mm marking on vertical axis.



1. keep the pattern over grave stake such that Thearing: the line at hem portion & exactly coincides 2. fold the 5mm marking 180 deg. on andiel / both sides of sheet pattern in inner direction. 3. None fold 90° the horisontal from 60mm marking. 1. Make a shape on A shaped part in one square De folding: 2. Now use a strongent suip of unwanted portion 3. Now fold the two sides of shoet from the diagonal line 90°. 1. Now join the two edge portion A & B I docking & seaming: grom the comm 90° folded from horizontal 2. Check for dienensions of the complete scorp. thus the required swoop is made out of the Result: given sheet metal piece .