


Wiring:

Arduino	Module
5v	VCC
GND	GND
12	ECHO

As shown below:



Experimental phenomena:

After the program download is complete, open the serial monitor in the upper right corner of the Arduino IDE programming interface. We can see that the distance detected by the ultrasonic module will be printed.

! Note: The baud rate of the serial monitor should be the same as the baud rate set in the program.

