SanDisk Cruzer Blade

Users Guide

Version 1.1.0

August 2022

Table of Contents

Overview... 3
Specifications... 4
Architecture... 5
Using SanDisk Cruzer Blade... 5
Troubleshooting and FAQs... 6
Contact... 7

Overview

This document describes the process of using the SanDisk Cruzer Blade USB flash drive to transfer data up to 128 GB to other devices, and sharing data with other users.

Version 1.1.0 of the flash drive comes with a sleek and compact finish, which makes it portable and handy

Specifications

Category	Specification
Dimension	0.74*1.75*4.14 cm
Weight	4.54 grams
Storage	Up to 32 GB
Memory type	Flash drive
Hard drive	16 GB
Removable storage	32 GB
Compatible devices	Computer and laptop

Architecture



Using SanDisk Cruzer Blade

Perform the following steps to install the USB drive on your system:

- 1. Locate your device's USB port.
- 2. Insert the flash drive into the USB port.
- 3. Click the pop-up dialog box to open the flash drive.
- 4. Copy and paste files to the drive.

What to do next: After transferring your files to the flash drive, safely remove the device.

Note: To avoid possible loss of data, select the **Safely Remove External Device** option to eject the flash drive.

Troubleshooting and Frequently Asked Questions

Question: The USB device does not show up on my device

Solution: Check for damaged ports. Also, try to insert the device into multiple ports.

Question: How can I format my flash drive?

Solution: Right-click on the drive and select Delete from the dropdown menu.

Question: Can I use SanDisk Cruzer Blade on multiple operating systems?

Solution: The SanDisk Cruzer Blade flash drive is supported on Windows, Linux, and

MacOS.

Contact

Phone: 1800 120 5899

Chat: Visit us at http://kb-in.sandisk.com to chat with a customer support executive