

[HELIX INDUSTRIAL SYSTEMS — COMPANY LOGO PLACEHOLDER]

SMART FACTORY EQUIPMENT MAINTENANCE & CONDITION MONITORING MANUAL

Equipment Fleet: Helix SF-2040 Smart Factory Fleet (33 machine types) | Data Source: Factory Sensor Simulator 2040

FICTIONAL TRAINING DOCUMENT

This is a synthetic, entirely fictional document created for AI/RAG research and educational demonstration purposes only. Helix Industrial Systems, the SF-2040 fleet, and all machine specifications, thresholds and procedures described herein are fictional. This manual is not affiliated with, derived from, or representative of any real equipment manufacturer, standards body, or safety authority, and must never be used for actual maintenance, safety assessment, training, or certification.

Field	Value	Notes
Document Title	Smart Factory Equipment Maintenance & Condition Monitoring Manual	Training & demonstration use only
Revision	Revision 1.0	Initial synthetic release
Classification	Training & Demonstration Manual	Not for operational use
Equipment Fleet	Helix SF-2040 Smart Factory Fleet (fictional)	33 machine types across 8 machine families
Data Source	factory_sensor_simulator_2040.csv	500,000 machine records; 22 fields
Intended Use	RAG knowledge base / AI demo	Pairs with structured sensor + log data

Document Control

Revision History

Revision	Date	Author	Description of Change
1.0	2026-09-20	Helix Tech Pubs (synthetic)	First complete release for training/demo distribution

Document Control Table

Item	Detail
Document Owner	Helix Technical Publications Group (fictional)
Review Cycle	Annual or upon major revision
Distribution	Internal training and AI/RAG demonstration use only
Approval Status	Approved for synthetic/demo use
Related Documents	SF-2040 Machine Component Catalogue (fictional), SF-2040 Controls & Safety Reference (fictional)
Calibration Basis	Bands and the risk model in Chapters 3 and 8 were calibrated against the 500,000-record Factory Sensor Simulator 2040 dataset

List of Figures

- Figure 3.1 — Observed 7-Day Failure Rate by Operational-Hours Band
- Figure 7.1 — Troubleshooting Decision Tree: High Vibration Event
- Figure 7.2 — Troubleshooting Decision Tree: Overheating Event
- Figure 7.3 — Troubleshooting Decision Tree: Low Oil or Coolant Level
- Figure 7.4 — Troubleshooting Decision Tree: Low Remaining Useful Life / Imminent Failure
- Figure 7.5 — Troubleshooting Decision Tree: Suspected Sensor Fault
- Figure 8.1 — Observed 7-Day Failure Rate by Computed Risk Status

List of Tables

- Table 2.1 — Machine Family Register (33 machine types)
- Table 3.1 — Normal Operating Parameters Summary (all machine types)
- Table 3.2 — Machine-Type-Specific Operating Parameters
- Table 3.3 — Operational-Hours Life-Stage Bands
- Table 4.1 — Primary Sensor Reference
- Table 4.2 — Sensor Plausibility Limits
- Table 5.1 — Failure Mode Reference Summary
- Table 6.1 — Scheduled Inspection & Overhaul Intervals
- Table 8.1 — Maintenance Decision Matrix
- Table 8.2 — Condition Escalation Rules
- Table 8.3 — Work Order Priority and Response Times
- Table 8.4 — Worked Examples
- Tables 10.1 to 10.3 — Dataset Field Reference, Fleet Baseline Statistics, Fleet Band Distribution

Table of Contents

- Chapter 1 — Introduction
- Chapter 2 — Equipment Overview
- Chapter 3 — Normal Operating Parameters
- Chapter 4 — Machine Sensors & Data Fields
- Chapter 5 — Failure Modes
- Chapter 6 — Maintenance Procedures
- Chapter 7 — Troubleshooting Guide
- Chapter 8 — Maintenance Decision Matrix
- Chapter 9 — Maintenance Work Orders
- Chapter 10 — Appendix: Glossary, Codes & Dataset Reference

Chapter 1 — Introduction

1.1 Purpose

This manual establishes standardized inspection, monitoring, and maintenance procedures for the machines of the Helix SF-2040 Smart Factory Fleet. It gives maintenance personnel, reliability engineers and automated decision-support systems a consistent reference for normal operating ranges, sensor behaviour, common failure modes, risk scoring, and corrective actions.

NOTE

This is a fictional reference manual created for software demonstration purposes. All figures, thresholds, and procedures are illustrative and must not be applied to real equipment.

1.2 Scope

This document covers line maintenance, scheduled inspection and overhaul intervals, condition-based maintenance triggers, and first-level troubleshooting for the 33 machine types in the fleet (Table 2.1). It does not cover heavy structural repair, building services, process-recipe engineering, or the internal software of machine controllers beyond the monitoring counters described in Chapter 4.

1.3 Responsibilities

Role	Responsibility
Line Maintenance Technician	Performs scheduled inspections, records sensor readings, raises work orders for anomalies
Maintenance Supervisor	Reviews inspection reports, authorizes return-to-service, escalates critical findings
Reliability Engineer	Analyses recurring failure trends, maintains the risk model and updates inspection intervals
Production Supervisor	Coordinates machine downtime windows and derating decisions with maintenance
Quality Assurance	Audits compliance with inspection schedules and documentation standards

1.4 Safety Philosophy

Maintenance actions described in this manual follow a layered safety approach: continuous parameter monitoring, scheduled preventive inspection, and decision-based escalation when readings exceed defined thresholds. No corrective action should be deferred when a parameter is in the Critical range as defined in Chapter 3, and every machine must be locked out and tagged out before any physical inspection.

WARNING

A machine must never be returned to service while any monitored parameter remains in the Critical range, or while Failure_Within_7_Days is True, without engineering sign-off as defined in Chapter 8.

1.5 Maintenance Categories

- Line Maintenance — routine checks performed between shifts
- Scheduled (Preventive) Maintenance — interval-based inspections by calendar days or operational hours
- Condition-Based Maintenance — triggered by sensor anomalies, risk score, or exceedances
- Unscheduled (Corrective) Maintenance — triggered by an operator report, alarm, or failure event

1.6 Fleet Overview

The SF-2040 fleet comprises 33 machine types grouped into eight machine families (Table 2.1): machining and fabrication, forming, thermal, fluid and process, material handling, robotics and assembly, packaging, and inspection and metrology. All machines report a common set of core sensors (temperature, vibration, sound, oil level, coolant level, power consumption) plus operating-hours and event counters. Selected machine types additionally report a type-specific sensor (Chapter 3, Table 3.2). Roughly 30% of machines operate under AI supervision.

1.7 Using This Manual with Structured Data

This manual is designed to be paired with the structured machine records described in Chapter 10 (Table 10.1). To turn a record into a maintenance recommendation, apply the following interpretation rules in order:

1. Assess each reported parameter against its Normal / Warning / Critical band in Chapter 3 (Tables 3.1 and 3.2).
2. Compute the estimated remaining useful life (RUL_est) and the Risk Score (%) using the model in Chapter 8. Map the score to a maintenance status with Table 8.1.
3. If Failure_Within_7_Days is True, or Remaining_Useful_Life_days is 6 or fewer, treat the machine as Critical regardless of any other value (Rule E3, Table 8.2).
4. Apply the condition escalation rules in Table 8.2 for secondary parameters that are in the Critical band.
5. Match the combination of abnormal parameters to a failure mode in Chapter 5 and quote the corresponding Immediate Action and Engineering Recommendation.
6. Check data quality first (Section 4.13): negative vibration, power or flow readings, or a level reading of exactly 0.0, are sensor-fault indicators and must be flagged before action is taken.
7. Blank (null) values in Laser_Intensity, Hydraulic_Pressure_bar, Coolant_Flow_L_min and Heat_Index mean the sensor is not fitted to that machine type. They are not missing data and must not be reported as faults.
8. AI_Override_Events is only meaningful when AI_Supervision is True; it is always 0 when AI_Supervision is False.

Recommended structure of a recommendation report

- Machine ID, machine type and machine family
- Maintenance status, Risk Score (%), RUL_est and recorded RUL, with the key drivers
- Parameter assessment (each parameter marked Normal / Warning / Critical)
- Detected failure mode(s) with the Chapter 5 section reference
- Recommended action, work order type (Chapter 9) and target response time (Table 8.3)
- Data-quality flags and any items requiring physical verification

Chapter 2 — Equipment Overview

2.1 Fleet Architecture

Each SF-2040 machine consists of a mechanical or process core, a drive and motion system, a lubrication system, a cooling system, an electrical power supply, and a controller with an optional AI supervision layer. Despite the diversity of the 33 machine types, all machines share the same core condition-monitoring instrumentation so that fleet-wide thresholds can be applied consistently. Fleet averages of every core sensor differ by no more than about 2% between machine types, so a single set of bands (Chapter 3) applies to all types.

2.2 Machine Family Register

Table 2.1 lists every machine type in the dataset, its family, its type-specific sensor (if any), and its typical wear-critical components. The wear-critical components guide where to look during inspection when a machine enters the Warning or Critical band.

Table 2.1 — Machine Family Register (33 machine types)

Machine Type	Family	Type-Specific Sensor	Typical Wear-Critical Components
CNC_Lathe	Machining & Fabrication	Coolant_Flow_L_min	Spindle bearings, chuck, ways, coolant pump
CNC_Mill	Machining & Fabrication	Coolant_Flow_L_min	Spindle, tool changer, ball screws, coolant pump
Grinder	Machining & Fabrication	None	Spindle bearings, grinding wheel, dresser
Laser_Cutter	Machining & Fabrication	Laser_Intensity	Laser source, focusing optics, assist-gas nozzle
Press_Brake	Machining & Fabrication	None	Ram guides, back-gauge drive, ram drive system
3D_Printer	Machining & Fabrication	None	Print head/extruder, heated bed, motion axes
Hydraulic_Press	Forming	Hydraulic_Pressure_bar	Hydraulic pump, cylinders, seals, servo valves
Injection_Molder	Forming	Hydraulic_Pressure_bar	Hydraulic unit, screw and barrel, clamp unit
Boiler	Thermal	Heat_Index	Burner, tubes, feedwater pump, safety valve
Furnace	Thermal	Heat_Index	Heating elements or burners, refractory, temperature controls
Heat_Exchanger	Thermal	Heat_Index	Plates or tubes (fouling), gaskets, flow control
Dryer	Thermal	None	Heating stage, blower, airflow dampers
Industrial_Chiller	Thermal	Coolant_Flow_L_min	Compressor, condenser, evaporator, circulation pump
Pump	Fluid & Process	None	Impeller, mechanical seal, bearings
Compressor	Fluid & Process	None	Compression stage, bearings, lubrication system, inlet filter
Mixer	Fluid & Process	None	Agitator shaft, seals, gearbox
Valve_Controller	Fluid & Process	None	Actuator, positioner, stem seals
AGV	Material Handling	None	Drive wheels, traction motor and battery, navigation sensors
Forklift_Electric	Material Handling	None	Mast and lift chain, traction motor, battery
Crane	Material Handling	None	Hoist rope or chain, brakes, gearbox
Conveyor_Belt	Material Handling	None	Belt, idlers, drive motor, gearbox
Shuttle_System	Material Handling	None	Drive wheels and rails, motors, positioning encoders
Palletizer	Material Handling	None	Gripper, lift axis, drive gearboxes
Robot_Arm	Robotics & Assembly	None	Joint reducers, servo motors, cabling
Pick_and_Place	Robotics & Assembly	None	Linear axes, vacuum gripper, feeders
Automated_Screwdriver	Robotics & Assembly	None	Torque transducer, spindle, screw feeders
Labeler	Packaging	None	Applicator, peel edge, drive rollers
Vacuum_Packer	Packaging	None	Vacuum pump, seal bars, gaskets
Shrink_Wrapper	Packaging	None	Heat tunnel, film drive, sealing wire
Carton_Former	Packaging	None	Forming mandrel, glue system, drive cams

Machine Type	Family	Type-Specific Sensor	Typical Wear-Critical Components
CMM	Inspection & Metrology	None	Air bearings, probe, guideways
Vision_System	Inspection & Metrology	None	Camera, lighting, optics
XRay_Inspector	Inspection & Metrology	None	X-ray tube, detector, shielding interlocks

2.3 Drive and Motion System

Motors, gearboxes, bearings, couplings, belts and guideways transmit motion. Wear here shows first as rising vibration and sound, followed by rising temperature and power draw. Vibration is the primary early indicator of drive-train degradation.

2.4 Lubrication System

Oil-lubricated bearings, gearboxes and slideways rely on an adequate oil level. A falling oil level indicates leakage or consumption; combined with rising vibration or temperature it indicates lubrication starvation, which accelerates wear rapidly.

2.5 Cooling System

Coolant removes heat from spindles, drives, hydraulic units and process heads. Coolant level (all machines) and coolant flow (CNC_Lathe, CNC_Mill, Industrial_Chiller) indicate whether the circuit can hold temperature. Loss of coolant is a leading cause of thermal overload.

2.6 Electrical and Power System

Power consumption reflects mechanical load and electrical health. Abnormally high draw suggests friction, overload or motor/drive degradation; readings that are negative are physically impossible and indicate a metering fault.

2.7 Hydraulic System (Type-Specific)

Hydraulic_Press and Injection_Molder machines use a hydraulic power unit monitored by a pressure transducer (Hydraulic_Pressure_bar). Pressure loss indicates leaks, pump wear or valve faults; over-pressure indicates relief-valve or control faults.

2.8 Thermal Process Systems (Type-Specific)

Boiler, Furnace and Heat_Exchanger machines report a dimensionless Heat_Index describing the state of the heat-transfer process against its design point. Deviation in either direction indicates fouling, burner or element faults, or loss of process control.

2.9 Controller and AI Supervision

Every machine controller counts error codes raised in the last 30 days. Machines under AI supervision additionally count AI override events — occasions when an operator overrode an AI-suggested action. Frequent overrides indicate that the AI supervision layer and operators disagree and that the model or the process needs review.

Chapter 3 — Normal Operating Parameters

Table 3.1 lists the parameters monitored on every SF-2040 machine, together with their normal, warning, and critical operating bands and the corresponding recommended action. Table 3.2 lists the additional parameters reported only by specific machine types. These bands form the basis for all condition-based maintenance logic referenced throughout this manual.

Table 3.1 — Normal Operating Parameters Summary (all machine types)

Parameter	Normal	Warning	Critical	Recommended Action
Operational Hours (h) [Operational_Hours]	0 – 70,000	70,000 – 85,000	> 85,000	Warning: plan life assessment. Critical: overhaul or replacement review (Chapter 6.6)
Remaining Useful Life (days) [Remaining_Useful_Life_days]	> 195	45 – 195	< 45	Schedule work before the RUL is exhausted; 6 or fewer days = imminent failure (Chapter 8)
Temperature (°C) [Temperature_C]	0 – 75	75 – 90	> 90	Inspect cooling circuit, lubrication and load; check fans and heat paths
Vibration (mm/s) [Vibration_mms]	0 – 13	13 – 18	> 18	Inspect bearings, couplings, mounting and balance
Sound Level (dB) [Sound_dB]	Up to 85	85 – 95	> 95	Inspect gears, bearings, guards and fasteners for looseness or wear
Oil Level (%) [Oil_Level_pct]	50 – 100	30 – 50	< 30	Check for leaks, top up, inspect seals and filter
Coolant Level (%) [Coolant_Level_pct]	40 – 100	20 – 40	< 20	Check for leaks, top up, inspect pump and hoses
Power Consumption (kW) [Power_Consumption_kW]	0 – 230	230 – 290	> 290	Check mechanical load, motor/drive condition and electrical connections
Days Since Last Maintenance [Last_Maintenance_Days_Ago]	0 – 180	181 – 300	> 300	Schedule preventive maintenance per Table 6.1
Error Codes, Last 30 Days [Error_Codes_Last_30_Days]	0 – 4	5 – 6	7 or more	Review controller log; resolve the recurring error root cause
Failure History Count [Failure_History_Count]	0 – 3	4 – 5	6 or more	Reliability review and root cause analysis (Chapter 9.4)
AI Override Events [AI_Override_Events] (AI-supervised machines only)	0 – 2	3 – 4	5 or more	Review operator override reasons; recalibrate or retrain AI supervision
Maintenance History Count [Maintenance_History_Count]	Reference value	—	—	Reference only. Fewer than 3 maintenance events on a machine above 50,000 h suggests under-servicing
Installation Year [Installation_Year]	Reference value	—	—	Descriptive metadata only. Do not derive wear or age from it; use Operational_Hours

NOTE

Boundary convention: a reading exactly equal to a band limit belongs to the lower-severity band (for example, exactly 75 °C is Normal). Warning-range readings require increased monitoring frequency and entry into the condition-based inspection cycle. Critical-range readings require corrective action per Chapter 8.

Table 3.2 — Machine-Type-Specific Operating Parameters

Parameter (Machine Types)	Normal	Warning	Critical	Recommended Action
Laser Intensity (% of rated output) [Laser_Intensity] Laser_Cutter	58 – 92	45 – 58 or 92 – 105	< 45 or > 105	Low: inspect optics, source and cooling. High: check power control loop and calibration
Hydraulic Pressure (bar) [Hydraulic_Pressure_bar] Hydraulic_Press, Injection_Molder	95 – 145	80 – 95 or 145 – 160	< 80 or > 160	Low: inspect pump, seals, leaks. High: inspect relief valve and pressure control
Coolant Flow (L/min) [Coolant_Flow_L_min] CNC_Lathe, CNC_Mill, Industrial_Chiller	25 – 58	15 – 25 or 58 – 70	< 15 or > 70	Low: inspect strainer, pump, lines and valves. High: verify sensor and pump speed
Heat Index (dimensionless) [Heat_Index] Boiler, Furnace, Heat_Exchanger	420 – 580	380 – 420 or 580 – 620	< 380 or > 620	Inspect burners or elements, fouling, insulation and control loop

NOTE

Type-specific parameters are only reported by the machine types shown. For all other machine types these fields are blank in the dataset because the sensor is not fitted. A blank value is not a fault and must not be treated as missing data or as an anomaly.

3.1 Life-Stage Bands (Operational Hours)

Operational hours are the dominant indicator of remaining life across the fleet. Failures are effectively absent below 70,000 h and rise steeply thereafter. Table 3.3 gives the observed 7-day failure rate in each life-stage band, taken from the 500,000-record fleet dataset.

Table 3.3 — Operational-Hours Life-Stage Bands

Operational Hours Band (h)	Life Stage	Records	Observed 7-Day Failure Rate	Median Recorded RUL (days)	Policy
0 - 70,000	Normal service	350,011	0.00%	600	Routine PM
70,001 - 80,000	Early wear-out	50,016	0.04%	200	Life assessment
80,001 - 85,000	Wear-out	25,025	1.23%	125	Life assessment, plan overhaul
85,001 - 90,000	Late wear-out	24,862	10.09%	75	Overhaul or replace
90,001 - 95,000	End of life	24,912	35.94%	25	Overhaul or replace
95,001 - 100,000	End of life	25,174	72.46%	0	Immediate review




Figure 3.1 — Observed 7-day failure rate by operational-hours band.

NOTE

Hours-based life stages are the strongest single predictor of failure in the fleet. Temperature and vibration shorten remaining life further (Chapter 8) but the other parameters in Table 3.1 act mainly as secondary condition indicators and should be assessed alongside hours, temperature and vibration rather than as stand-alone predictors of imminent failure.

Chapter 4 — Machine Sensors & Data Fields

Table 4.1 summarizes the sensors and counters used to monitor SF-2040 machines, with the corresponding dataset column.

Table 4.1 — Primary Sensor Reference

Sensor / Counter	Dataset Column	Unit	Applies To	Function
Operating-hours meter	Operational_Hours	h	All	Cumulative running time; primary life indicator
Temperature sensor	Temperature_C	°C	All	Core or housing temperature
Vibration accelerometer	Vibration_mms	mm/s	All	Drive-train and structural vibration
Acoustic sensor	Sound_dB	dB	All	Machine noise level
Oil level sensor	Oil_Level_pct	%	All	Lubricant reservoir level
Coolant level sensor	Coolant_Level_pct	%	All	Coolant reservoir level
Power meter	Power_Consumption_kW	kW	All	Electrical load
Laser intensity monitor	Laser_Intensity	%	Laser_Cutter	Source output level
Hydraulic pressure transducer	Hydraulic_Pressure_bar	bar	Hydraulic_Press, Injection_Molder	Hydraulic supply pressure
Coolant flow meter	Coolant_Flow_L_min	L/min	CNC_Lathe, CNC_Mill, Industrial_Chiller	Coolant circulation rate
Heat index calculator	Heat_Index	index	Boiler, Furnace, Heat_Exchanger	Heat-transfer process state
Controller error counter	Error_Codes_Last_30_Days	count	All	Error codes raised in 30 days
Service records	Last_Maintenance_Days_Ago, Maintenance_History_Count, Failure_History_Count	days / count	All	Maintenance and failure history
AI supervision monitor	AI_Supervision, AI_Override_Events	flag / count	All (overrides only when supervised)	AI supervision status and operator overrides

4.1 Operating-Hours Meter

Attribute	Detail
Purpose	Records cumulative running time; the primary indicator of life consumption and wear-out
Units	Hours (h)
Location	Machine controller
Inspection Method	Cross-check against controller run-time log at each 180-day PM
Expected Behaviour	Monotonic increase; below 70,000 h for machines in normal service
Failure Symptoms	Counter reset, non-monotonic behaviour, or mismatch with production records

4.2 Temperature Sensor

Attribute	Detail
Purpose	Monitors core or housing temperature as a primary thermal health indicator
Units	°C
Location	Main housing or heat-critical component (spindle, motor, process head)
Inspection Method	Signal trend review each shift; calibration check at 180-day PM
Expected Behaviour	Stable up to 75 °C, rising with load. Values below about 25 °C are expected only during standby or cold start
Failure Symptoms	Sustained reading above 75 °C, erratic fluctuation, or reading below 0 °C or above 110 °C (sensor suspect)

4.3 Vibration Sensor (Accelerometer)

Attribute	Detail
Purpose	Detects imbalance, bearing wear, looseness and drive-train degradation
Units	mm/s (RMS)
Location	Bearing housing or drive frame
Inspection Method	Mount and cable check; signal trend review each shift
Expected Behaviour	Stable within 0 – 13 mm/s; a gradual upward trend signals developing wear
Failure Symptoms	Sustained reading above 13 mm/s, erratic spikes, negative reading (physically impossible), or signal dropout

4.4 Acoustic Sensor

Attribute	Detail
Purpose	Detects abnormal noise from gears, bearings, air leaks and impact events
Units	dB
Location	Machine enclosure
Inspection Method	Trend review; comparison with an audible walkaround
Expected Behaviour	Stable up to 85 dB; rises with load
Failure Symptoms	Sustained reading above 85 dB, sudden step change, or reading above 105 dB (verify sensor)

4.5 Oil Level Sensor

Attribute	Detail
Purpose	Monitors lubricant reservoir level to protect bearings and gears
Units	% of reservoir capacity
Location	Lubrication reservoir sight glass or float sensor
Inspection Method	Sight-glass or dipstick verification each week
Expected Behaviour	50 – 100% with slow consumption between top-ups
Failure Symptoms	Reading below 50% and falling; exactly 0.0% (empty or sensor dropout); visible staining or leaks

4.6 Coolant Level Sensor

Attribute	Detail
Purpose	Monitors coolant reservoir level to protect against thermal overload
Units	% of reservoir capacity
Location	Coolant tank
Inspection Method	Sight-glass verification each week; concentration check at PM
Expected Behaviour	40 – 100% with slow consumption between top-ups
Failure Symptoms	Reading below 40% and falling; exactly 0.0% (empty or sensor dropout); wet lines or floor

4.7 Power Meter

Attribute	Detail
Purpose	Measures electrical load as an indicator of mechanical and electrical condition
Units	kW
Location	Machine power feed
Inspection Method	Trend review; thermographic check of connections at PM
Expected Behaviour	0 – 230 kW depending on machine type and duty cycle
Failure Symptoms	Sustained reading above 230 kW, negative reading (impossible; meter fault), or reading inconsistent with duty cycle

4.8 Laser Intensity Monitor (Laser_Cutter)

Attribute	Detail
Purpose	Monitors laser source output as a percentage of rated output
Units	% of rated output (normalised dataset units)
Location	Beam path pick-off
Inspection Method	Power calibration against reference meter at 90-day PM
Expected Behaviour	Stable within 58 – 92
Failure Symptoms	Drift below 58 (source or optics degradation) or above 92 (control-loop fault)

4.9 Hydraulic Pressure Transducer (Hydraulic_Press, Injection_Molder)

Attribute	Detail
Purpose	Monitors hydraulic supply pressure
Units	bar
Location	Pump discharge line
Inspection Method	Reservoir level check and pressure verification at PM
Expected Behaviour	Stable within 95 – 145 bar during production
Failure Symptoms	Pressure below 95 bar with fluid loss (leak or pump wear); above 145 bar (relief-valve or control fault)

4.10 Coolant Flow Meter (CNC_Lathe, CNC_Mill, Industrial_Chiller)

Attribute	Detail
Purpose	Monitors coolant circulation to confirm the circuit can carry away heat
Units	L/min
Location	Coolant supply line
Inspection Method	Strainer inspection and flow verification at PM
Expected Behaviour	Stable within 25 – 58 L/min
Failure Symptoms	Flow below 25 L/min (blockage, pump wear) or above 58 L/min (sensor or pump-speed fault); negative reading is a sensor fault

4.11 Heat Index (Boiler, Furnace, Heat_Exchanger)

Attribute	Detail
Purpose	Describes the heat-transfer process state relative to its design point
Units	Dimensionless index
Location	Process controller
Inspection Method	Trend review; burner, element and fouling inspection at PM
Expected Behaviour	Stable within 420 – 580
Failure Symptoms	Persistent deviation outside 420 – 580 in either direction

4.12 Controller and Event Counters

Attribute	Detail
Purpose	Track controller error codes, maintenance and failure history, and AI supervision overrides
Units	Counts and days
Location	Machine controller and maintenance system
Inspection Method	Log review each week; reconcile history counts against work orders
Expected Behaviour	0 – 4 error codes per 30 days; 0 – 3 lifetime failures; 0 – 2 AI overrides on supervised machines
Failure Symptoms	7 or more error codes in 30 days; 6 or more lifetime failures; 5 or more AI overrides; more than 300 days since maintenance

4.13 Data Quality and Sensor Plausibility

Simulated and real sensor streams both contain noise. Before acting on a reading, check it against the plausibility limits in Table 4.2. A reading outside its limit is a sensor-fault indicator: raise a sensor verification task (Chapter 6.7) in parallel with the maintenance assessment, and treat the machine's status as provisional until the sensor is verified.

Table 4.2 — Sensor Plausibility Limits

Field	Suspect if	Reason	Records in Fleet Dataset
Vibration_mms	< 0 or > 25	RMS vibration cannot be negative; above 25 mm/s verify sensor before escalating	11,467 negative; 656 above 25
Power_Consumption_kW	< 0	Consumption cannot be negative (meter fault)	15,175 negative
Temperature_C	< 0 or > 110	Outside physical operating range of the machines	18 below 0; 222 above 110
Sound_dB	> 105	Beyond plausible enclosure noise; verify sensor	671 above 105
Coolant_Flow_L_min	< 0	Flow cannot be negative	1 negative
Oil_Level_pct	Exactly 0.0	Empty reservoir or sensor dropout; treat as Critical until verified	107 records
Coolant_Level_pct	Exactly 0.0	Empty reservoir or sensor dropout; treat as Critical until verified	2,251 records

NOTE

Level sensors saturate at 100%. A reading of exactly 100.0 for oil or coolant level is a full reservoir, not a fault. The Risk Score model in Chapter 8 uses recorded values as they appear; the sensor-fault flag is raised in parallel and does not by itself change the computed score.

Chapter 5 — Failure Modes

This chapter describes the failure modes most frequently identified through condition monitoring on the SF-2040 fleet, together with their symptoms, likely causes, detection logic, severity, and recommended response. Section 5.1 covers the primary fleet-monitored failure modes; Section 5.2 covers additional modes relevant to comprehensive maintenance; Section 5.3 covers modes specific to machine types with a type-specific sensor. Detection logic is expressed in terms of the dataset columns and the bands in Chapter 3.

Table 5.1 — Failure Mode Reference Summary

Section	Failure Mode	Key Detection Logic	Severity
5.1.1	End-of-Life Wear-Out	Operational_Hours > 85,000, or Risk Score 60% or more	High
5.1.2	Mechanical Degradation (Bearing / Drive-Train Wear)	Vibration > 13 mm/s with sound > 85 dB or temperature > 75 °C	Medium to High
5.1.3	Thermal Overload	Temperature > 90 °C, or > 75 °C with low coolant	High
5.1.4	Lubrication Loss / Oil Leakage	Oil level < 30% with elevated vibration or temperature	High
5.1.5	Coolant Circuit Failure	Coolant level < 20% or flow < 15 L/min with temperature > 75 °C	High
5.1.6	Sensor Fault / Data Integrity	Negative vibration, power or flow; temperature < 0; level exactly 0.0	Low to Medium
5.2.1	Electrical Overload	Power > 290 kW, or > 230 kW with temperature > 75 °C	Medium to High
5.2.2	Control / AI Supervision Anomaly	Error codes 7 or more, or AI overrides 5 or more	Medium
5.2.3	Maintenance Overdue	Last_Maintenance_Days_Ago > 300	Low to Medium
5.2.4	Chronic Repeat-Failure Asset	Failure_History_Count 6 or more	Medium
5.3.1	Laser Source Degradation	Laser_Intensity < 58 or > 92	Medium
5.3.2	Hydraulic Pressure Loss / Over-Pressure	Hydraulic_Pressure_bar < 95 or > 145	Medium to High
5.3.3	Coolant Flow Restriction	Coolant_Flow_L_min < 25 with rising temperature	Medium to High
5.3.4	Heat-Transfer / Combustion Instability	Heat_Index outside 420 – 580	Medium

5.1 Primary Fleet-Monitored Failure Modes

5.1.1 End-of-Life Wear-Out

Attribute	Detail
Symptoms	Progressive rise in vibration and temperature, falling remaining useful life, rising error codes; the dominant failure mode in the fleet
Possible Causes	Cumulative fatigue of bearings, seals, gears and structural components; ageing of electrical and electronic parts
Detection Logic	Operational_Hours above 85,000, or Risk Score 60% or more (Chapter 8), or Remaining_Useful_Life_days below 45. Failure_Within_7_Days True or RUL of 6 or fewer days means failure is imminent
Severity	High (Critical when Risk Score is 85% or more)
Immediate Action	Plan removal from service. If failure is imminent, lock out the machine within 24 hours and inspect before further production
Engineering Recommendation	Perform overhaul or replacement assessment per Chapter 6.6; schedule major overhaul or replacement and order long-lead spares

5.1.2 Mechanical Degradation (Bearing / Drive-Train Wear)

Attribute	Detail
Symptoms	Rising vibration trend, audible roughness, gradual rise in temperature and power draw
Possible Causes	Lubrication breakdown, contamination, fatigue of rolling elements, misalignment, loose mounting
Detection Logic	Vibration sustained above 13 mm/s, frequently with sound above 85 dB or temperature above 75 °C. Vibration above 18 mm/s is Critical
Severity	Medium to High
Immediate Action	Schedule bearing and drive-train inspection within 14 days; within 24 hours if vibration exceeds 18 mm/s
Engineering Recommendation	Inspect and replace bearing or coupling per Chapter 6.5 if vibration remains in the Critical band after re-check

5.1.3 Thermal Overload

Attribute	Detail
Symptoms	Temperature above normal for the load, thermal trips, discolouration, hot-spot odours
Possible Causes	Cooling circuit failure, blocked heat paths, excess load, lubrication loss, failing fans
Detection Logic	Temperature above 90 °C, or above 75 °C combined with coolant level below 40% or (where fitted) coolant flow below 25 L/min
Severity	High
Immediate Action	Reduce load; verify coolant level and flow; inspect fans and heat paths before further production
Engineering Recommendation	Restore cooling capacity per Chapter 6.3; investigate root cause before return to service

5.1.4 Lubrication Loss / Oil Leakage

Attribute	Detail
Symptoms	Falling oil level, visible staining, rising vibration and temperature
Possible Causes	Seal degradation, loose fitting, cracked line, excessive consumption
Detection Logic	Oil_Level_pct below 30% combined with vibration above 13 mm/s or temperature above 75 °C. Oil level below 30% with no other abnormal parameter is an isolated low-oil condition (Medium severity)
Severity	High (combined); Medium (isolated)
Immediate Action	Stop or derate the machine; perform visual leak check and top up before further running
Engineering Recommendation	Replace seal or line; verify root cause and oil quantity before return to service (Chapter 6.2)

5.1.5 Coolant Circuit Failure

Attribute	Detail
Symptoms	Low coolant level or flow, rising temperature, coolant odour or wet floor
Possible Causes	Leaking hose or fitting, pump wear, blocked strainer, air lock
Detection Logic	Coolant_Level_pct below 20%, or Coolant_Flow_L_min below 15 (where fitted), combined with temperature above 75 °C
Severity	High
Immediate Action	Reduce load; check for leaks; top up coolant; clear strainer
Engineering Recommendation	Replace hose, fitting or pump; verify flow returns to 25 – 58 L/min (Chapter 6.3)

5.1.6 Sensor Fault / Data Integrity

Attribute	Detail
Symptoms	Readings that are physically impossible, frozen, erratic or inconsistent with other parameters
Possible Causes	Wiring fault, connector corrosion, sensor drift or failure, telemetry error
Detection Logic	Any reading outside the plausibility limits in Table 4.2: negative vibration, power or flow; temperature below 0 °C; level exactly 0.0; readings inconsistent with cross-referenced parameters
Severity	Low to Medium
Immediate Action	Cross-check with a portable instrument or redundant sensor; keep the maintenance status provisional until verified
Engineering Recommendation	Calibrate or replace the affected sensor per Chapter 6.7 and raise a WO-S work order

5.2 Additional Failure Modes

5.2.1 Electrical Overload

Attribute	Detail
Symptoms	High power draw for the duty cycle, drive or breaker trips, warm cabling
Possible Causes	Mechanical friction or jam, motor or drive degradation, loose or corroded connections
Detection Logic	Power_Consumption_kW above 290, or above 230 with temperature above 75 °C
Severity	Medium to High
Immediate Action	Check mechanical load and connections; thermographic scan of the power feed
Engineering Recommendation	Repair or replace motor, drive or connection as indicated by inspection

5.2.2 Control / AI Supervision Anomaly

Attribute	Detail
Symptoms	Frequent controller error codes; operators repeatedly overriding AI-supervised decisions
Possible Causes	Underlying sensor or mechanical problem, mis-tuned control loop, AI model drift, recipe mismatch
Detection Logic	Error_Codes_Last_30_Days of 7 or more, or AI_Override_Events of 5 or more on an AI-supervised machine
Severity	Medium
Immediate Action	Review the controller error log and the reasons recorded for overrides
Engineering Recommendation	Correct the root cause; recalibrate or retrain the AI supervision model; verify sensors feeding the model

5.2.3 Maintenance Overdue

Attribute	Detail
Symptoms	Long interval since last service; missed inspections
Possible Causes	Scheduling gaps, production pressure, missing work-order closure
Detection Logic	Last_Maintenance_Days_Ago above 300 (Critical) or above 180 (Warning); machines above 70,000 h should not exceed 180 days
Severity	Low to Medium
Immediate Action	Schedule the next preventive maintenance at the earliest production window
Engineering Recommendation	Review PM scheduling compliance with Quality Assurance

5.2.4 Chronic Repeat-Failure Asset

Attribute	Detail
Symptoms	History of repeated failures despite maintenance
Possible Causes	Design weakness, wrong duty for the machine, recurring root cause not fixed, poor repair quality
Detection Logic	Failure_History_Count of 6 or more, or 4 or more on a machine above 70,000 h
Severity	Medium
Immediate Action	Open a reliability review
Engineering Recommendation	Perform root cause analysis (Chapter 9.4); consider replacement rather than repeated repair

5.3 Machine-Type-Specific Failure Modes

5.3.1 Laser Source Degradation (Laser_Cutter)

Attribute	Detail
Symptoms	Falling cut quality, need for slower feed rates, unstable beam
Possible Causes	Source ageing, contaminated or damaged optics, cooling problem, power-supply fault
Detection Logic	Laser_Intensity below 58 or above 92 (Critical below 45 or above 105)
Severity	Medium
Immediate Action	Inspect and clean optics; verify chiller and gas supply
Engineering Recommendation	Recalibrate output; replace optics or source module as indicated

5.3.2 Hydraulic Pressure Loss / Over-Pressure (Hydraulic_Press, Injection_Molder)

Attribute	Detail
Symptoms	Slow or weak actuation, fluid loss, pressure alarms, elevated vibration
Possible Causes	Seal wear, fitting failure, pump wear, relief-valve or control fault
Detection Logic	Hydraulic_Pressure_bar below 95 (Critical below 80) or above 145 (Critical above 160), especially with rising vibration or falling oil level
Severity	Medium to High
Immediate Action	Inspect reservoir level and visible lines before further production
Engineering Recommendation	Replace affected seal, fitting or pump; verify supply pressure returns to 95 – 145 bar (Chapter 6.4)

5.3.3 Coolant Flow Restriction (CNC_Lathe, CNC_Mill, Industrial_Chiller)

Attribute	Detail
Symptoms	Falling flow, rising spindle or process temperature, pump noise
Possible Causes	Clogged strainer or filter, pump wear, partly closed valve, air lock
Detection Logic	Coolant_Flow_L_min below 25 (Critical below 15) with rising temperature
Severity	Medium to High
Immediate Action	Inspect strainer, valves and lines; verify pump operation
Engineering Recommendation	Clean or replace strainer; repair or replace pump; verify flow returns to 25 – 58 L/min

5.3.4 Heat-Transfer / Combustion Instability (Boiler, Furnace, Heat_Exchanger)

Attribute	Detail
Symptoms	Heat_Index drift, unstable temperature control, fouling deposits, abnormal combustion or element behaviour
Possible Causes	Burner or element degradation, fouled heat-exchange surfaces, insulation or refractory damage, control-loop fault
Detection Logic	Heat_Index below 420 or above 580 (Critical below 380 or above 620)
Severity	Medium
Immediate Action	Inspect burner or elements, heat-transfer surfaces and control loop
Engineering Recommendation	Clean or replace fouled components; retune the control loop; repair insulation

Chapter 6 — Maintenance Procedures

6.1 Scheduled Inspection and Overhaul Intervals

Table 6.1 — Scheduled Inspection & Overhaul Intervals

Inspection	Trigger	Key Checks
Post-Shift Walkaround	Every shift	Visual leak check, fluid stains, guards, unusual noise or odour
Weekly Check	Every 7 days	Oil and coolant level verification, controller error log review
90-Day Inspection	Every 90 days	Vibration trend review, filter and strainer check, type-specific sensor verification
180-Day Preventive Maintenance	Every 180 days (maximum interval)	Lubrication service, coolant service, sensor calibration check, electrical connection check
Minor Overhaul	Every 25,000 operational hours	Bearing and seal inspection, drive alignment, wear-part replacement
Major Overhaul	At 50,000 operational hours	Full strip inspection, replacement of wear components, control system check
Life Assessment	At 70,000 operational hours	Structural and wear assessment; decide on life extension, overhaul or replacement planning
Replacement Review	At 85,000 operational hours	Overhaul or replace; machines above this level have an observed failure rate of about 40%
Post-Vibration-Event Inspection	After vibration above 18 mm/s	Bearing inspection, alignment and fastener check
Post-Exceedance Inspection	After temperature, power or level exceedance	Inspect affected subsystem; engineering review before return to service

6.2 Lubrication System Inspection Procedure

1. Lock out and tag out the machine; confirm it has cooled to a safe handling temperature.
2. Verify oil level against the minimum dispatch mark (dataset Oil_Level_pct must be 50% or more).
3. Inspect oil filter and drain for debris; record any metallic content found.
4. Inspect seals, fittings and lines for staining or seepage.
5. Top up with the specified lubricant and record the quantity added; investigate consumption if the top-up is frequent.
6. Record results on the Inspection Report (Chapter 9).

CAUTION

Allow adequate cooling time before opening lubrication access panels to avoid burn hazard. Never top up a running machine unless the procedure specifically allows it.

6.3 Cooling System Inspection Procedure

1. Lock out and tag out the machine; isolate coolant supply where required.
2. Verify coolant level against the minimum mark (Coolant_Level_pct must be 40% or more).
3. Inspect hoses, fittings and pump for leaks or chafing.
4. Clean or replace the strainer or filter.
5. Restart and verify flow returns to 25 – 58 L/min where a flow meter is fitted, and that temperature stabilizes below 75 °C.
6. Record results on the Inspection Report.

6.4 Hydraulic System Inspection Procedure (Hydraulic_Press, Injection_Molder)

1. Inspect reservoir fluid level against the minimum mark.
2. Check visible hydraulic lines, cylinders and fittings for seepage or chafing.
3. Verify pump discharge pressure against Table 3.2 (95 – 145 bar).
4. Inspect relief valve setting and accumulator pre-charge.
5. Replace filters and worn seals as indicated.

6.5 Bearing and Drive-Train Inspection Procedure

1. Review vibration trend data for the preceding 10 shifts.
2. Perform oil analysis or grease sampling for metallic contamination.
3. Inspect mountings, couplings, belts and alignment where vibration trend exceeds 13 mm/s.
4. Replace the bearing or coupling where vibration exceeds 18 mm/s after re-check, or where debris analysis confirms wear.
5. Disposition per the Maintenance Decision Matrix (Chapter 8).

6.6 End-of-Life Overhaul / Replacement Assessment

Apply this procedure to any machine above 70,000 operational hours, and always to a machine with Risk Score of 60% or more.

1. Retrieve the maintenance and failure history (Maintenance_History_Count, Failure_History_Count).
2. Perform a full strip inspection of the wear-critical components listed in Table 2.1 for the machine type.
3. Compare estimated overhaul cost and expected life extension with the cost of replacement.
4. Recommend one of: major overhaul, component replacement, or full machine replacement.
5. Record the disposition on the Maintenance Completion Form and update the asset life record.

6.7 Sensor Verification Procedure

1. Identify the suspect channel using Table 4.2.
2. Inspect wiring, connector and mounting; look for corrosion, damage or looseness.
3. Compare with a calibrated portable instrument or redundant sensor.
4. Recalibrate the sensor; replace it if the error cannot be corrected.
5. Record the result and re-run the risk assessment using the verified reading.

6.8 Thermal Process Inspection (Boiler, Furnace, Heat_Exchanger)

1. Inspect burners, heating elements or plates for fouling, scale or damage.
2. Check insulation and refractory for cracks or loss.
3. Verify safety valves and interlocks per site procedure.
4. Compare Heat_Index against the 420 – 580 normal band after cleaning and tuning.

Chapter 7 — Troubleshooting Guide

This chapter presents decision-tree style troubleshooting logic for common exceedance events. Each tree should be read top to bottom.

7.1 Figure 7.1 — High Vibration Event

Step 1: Vibration reading exceeds the Warning threshold (13 mm/s). Check first that the reading is plausible (not negative and not above 25 mm/s).

Step 2: Check sound level, temperature and oil level.

Step 3a: If sound is 85 dB or below, temperature is 75 °C or below and oil level is 50% or more — continue monitoring and re-check next shift.

Step 3b: If sound above 85 dB, temperature above 75 °C or oil level below 50% — proceed to bearing and drive-train inspection (Chapter 6.5).

Step 4: If inspection confirms wear — replace the bearing or coupling.

Step 5: If vibration exceeds the Critical threshold (18 mm/s) at any point — inspect within 24 hours and set status to at least Maintenance Due (Chapter 8).

7.2 Figure 7.2 — Overheating Event

Step 1: Temperature exceeds the Warning threshold (75 °C). Confirm the reading is plausible (0 – 110 °C).

Step 2: Check coolant level (and flow if fitted), oil level and power consumption.

Step 3a: If coolant level is below 40% or flow below 25 L/min — inspect the cooling circuit (Chapter 6.3).

Step 3b: If oil level is below 50% — inspect the lubrication system (Chapter 6.2).

Step 3c: If power is above 230 kW — suspect mechanical overload or electrical fault (Section 5.2.1).

Step 4: If temperature exceeds the Critical threshold (90 °C) — reduce load or stop the machine and inspect before further production.

7.3 Figure 7.3 — Low Oil or Coolant Level

Step 1: Oil level below 50% or coolant level below 40% (Warning). If the reading is exactly 0.0, verify with a sight glass — the reservoir may be empty or the sensor may have dropped out.

Step 2: Inspect visually for leaks at seals, hoses and fittings.

Step 3a: If no leak is found — replenish and monitor the consumption rate.

Step 3b: If a leak is found — repair, replenish and verify before restart.

Step 4: If the level is below the Critical threshold (oil below 30%, coolant below 20%) combined with elevated vibration or temperature — assess for lubrication loss or coolant circuit failure (Sections 5.1.4, 5.1.5).

7.4 Figure 7.4 — Low Remaining Useful Life / Imminent Failure

Step 1: Failure_Within_7_Days is True, or Remaining_Useful_Life_days is 6 or fewer — treat as imminent failure (Priority P1).

Step 2: Lock out the machine within 24 hours; do not continue production unless engineering signs off.

Step 3: Review Operational_Hours, vibration and temperature to confirm the wear-out pattern (Section 5.1.1).

Step 4: Perform the overhaul or replacement assessment (Chapter 6.6) and order spares.

Step 5: If RUL is 7 to 44 days — Critical status without imminent flag; schedule corrective work within 7 days. If RUL is 45 to 195 days — apply the Monitor or Maintenance Due actions in Table 8.1.

7.5 Figure 7.5 — Suspected Sensor Fault

Step 1: A reading is outside its plausibility limit (Table 4.2), frozen, or inconsistent with related parameters.

Step 2: Cross-check with a portable instrument or redundant sensor.

Step 3a: If the reading is confirmed — treat it as real and proceed with the normal assessment.

Step 3b: If the reading is not confirmed — recalibrate or replace the sensor (Chapter 6.7) and raise a WO-S work order.

Step 4: Re-run the risk assessment with the verified value. Do not downgrade the maintenance status until verification is complete.

Chapter 8 — Maintenance Decision Matrix

This chapter provides the risk-based framework used to translate machine readings into a maintenance status and a recommended action. The framework has four parts: an estimated remaining useful life model (8.1), a risk score and status matrix (8.2), condition escalation rules for secondary indicators (8.3), and priority and response times (8.4). Worked examples follow in 8.5.

8.1 Estimated Remaining Useful Life (RUL_est)

The estimated remaining useful life in days is computed from the three parameters that consume machine life:

$$\text{RUL_est (days)} = 996 - 0.0099 \times \text{Operational_Hours} - 0.50 \times \text{Temperature_C} - 1.94 \times \text{Vibration_mms}$$

Life-consumption term	Effect on RUL_est	Interpretation
Operational_Hours	-9.9 days per +1,000 h	Dominant driver: over 90% of modelled life consumption at fleet-average temperature and vibration
Temperature_C	-0.50 days per +1 °C	Heat accelerates wear; +10 °C costs 5 days
Vibration_mms	-1.94 days per +1 mm/s	Mechanical degradation indicator; +5 mm/s costs about 10 days

The model was calibrated on the 500,000-record fleet dataset. RUL_est correlates 0.986 with the recorded Remaining_Useful_Life_days, with a typical residual of about ±50 days (one standard deviation). Because of this residual, treat RUL_est as an estimate: where it disagrees with the recorded Remaining_Useful_Life_days by more than 100 days, flag the record for engineering review. Remaining useful life cannot be negative; report negative RUL_est values as 0.

8.2 Risk Score and Maintenance Status

The Risk Score expresses how much of a 300-day planning horizon has been consumed:

$$\text{Risk Score (\%)} = 100 \times \max(0 , \min(1 , 1 - \text{RUL_est} / 300))$$

A machine with RUL_est of 300 days or more scores 0%; a machine with RUL_est of 0 days or less scores 100%. Table 8.1 maps the score to a maintenance status.

Table 8.1 — Maintenance Decision Matrix

Risk Score	Status	RUL_est	Typical Indicators	Recommended Action	Observed 7-Day Failure Rate
0 – 35%	Healthy	More than 195 days	Hours below about 76,000 at average temperature and vibration; parameters Normal; vibration 13 mm/s or below	No action required; continue scheduled monitoring	0.00%
35 – 60%	Monitor	120 – 195 days	Hours about 76,000 – 83,500, or one or more parameters in Warning band; vibration 13 – 18 mm/s	Increase monitoring frequency; begin life assessment; schedule inspection within 90 days	0.27%
60 – 85%	Maintenance Due	45 – 120 days	Hours about 83,500 – 91,000, or a primary parameter in Critical band (Rule E4)	Schedule corrective maintenance or overhaul within 14 days and complete within 30 days	9.8%
85 – 100%	Critical	Less than 45 days	Hours above about 91,000; wear-out pattern with rising vibration or temperature	Remove from service or derate; corrective action within 7 days; within 24 hours if failure is imminent	58.7%

NOTE

Risk score bands were calibrated against fleet-wide condition monitoring data. 99.7% of all machines that failed within 7 days scored 60% or more (Maintenance Due or Critical), and the Healthy band contained essentially no failures. A Maintenance Due status does not by itself require immediate shutdown; disposition is determined by the parameter in the Critical band and the failure mode guidance in Chapter 5. A Critical status with Failure_Within_7_Days True requires immediate lockout. The hours figures in Table 8.1 assume average temperature (60 °C) and vibration (10 mm/s); hotter or rougher machines reach each status at fewer hours. The life-stage bands in Table 3.1 are planning triggers: a machine in the Warning life stage (70,000 – 85,000 h) may still score Healthy, in which case apply the life-assessment action at low priority.




Figure 8.1 — Observed 7-day failure rate by computed risk status.

8.3 Condition Escalation Rules

The Risk Score is driven by life-consumption parameters. The remaining parameters in Table 3.1 and 3.2 (secondary parameters) are engineering condition indicators: they do not change RUL_est but they raise the maintenance status when they are in the Critical band. Secondary parameters are Sound_dB, Oil_Level_pct, Coolant_Level_pct, Power_Consumption_kW, Last_Maintenance_Days_Ago, Error_Codes_Last_30_Days, Failure_History_Count, AI_Override_Events and the type-specific sensors. Apply the rules in Table 8.2 after computing the Risk Score; the final status is the highest status resulting from any rule.

Table 8.2 — Condition Escalation Rules

Rule	Condition	Resulting Status
E1	One secondary parameter in the Critical band	At least Monitor
E2	Two or more secondary parameters in the Critical band	At least Maintenance Due
E3	Failure_Within_7_Days is True, or Remaining_Useful_Life_days is 6 or fewer, or an oil or coolant level is verified empty (0.0%)	Critical (Priority P1)
E4	A primary parameter in the Critical band: Operational_Hours above 85,000, Temperature_C above 90, or Vibration_mms above 18	At least Maintenance Due
E5	Sensor-plausibility failure (Table 4.2)	Status provisional; never downgrade until the sensor is verified (verification task within 24 hours)
E6	Recorded Remaining_Useful_Life_days and RUL_est differ by more than 100 days	Flag for engineering review; use the more severe of the two indications for planning

8.4 Priority and Response Times

Table 8.3 — Work Order Priority and Response Times

Priority	Status	Target Response	Work Order Type
P1 — Immediate	Critical with imminent failure (E3)	Lock out within 24 hours; inspect before any further production	WO-R or WO-O; INSP-C
P2 — Urgent	Critical (no imminent flag) or Maintenance Due	Critical: within 7 days. Maintenance Due: schedule within 14 days, complete within 30 days	WO-R, WO-X or WO-O; INSP-C or INSP-D
P3 — Planned	Monitor	Inspection within 90 days; daily trend review	INSP-B or INSP-D; WO-L
P4 — Routine	Healthy	Next scheduled inspection per Table 6.1	INSP-A or INSP-B

8.5 Worked Examples

Table 8.4 applies the framework to five real records from the fleet dataset.

Table 8.4 — Worked Examples

Record	Key Readings	RUL_est / Risk	Status and Rule	Recommended Action
MC_000018 Furnace	54,071 h; 53.1 °C; 3.76 mm/s; oil 79.1%; coolant 45.8%; errors 0; last PM 78 d; recorded RUL 433 d; failure flag False	427 d / 0.0%	Healthy (risk below 35%)	No action. Continue scheduled monitoring; next inspection per Table 6.1.
MC_000260 Hydraulic_Press	80,880 h; 51.7 °C; 11.28 mm/s; oil 78.9%; coolant 69.0%; errors 2; last PM 65 d; recorded RUL 116 d; failure flag False	148 d / 50.8%	Monitor (risk 35–60%)	Increase monitoring; hours 80,880 place the machine in the Warning life stage, so begin life assessment (Section 6.1) and schedule inspection within 90 days.
MC_000381 Vision_System	86,707 h; 65.0 °C; 8.52 mm/s; oil 57.0%; coolant 47.7%; errors 3; last PM 21 d; recorded RUL 19 d; failure flag False	89 d / 70.5%	Maintenance Due (risk 60–85%); hours above 85,000 also trigger E4	Schedule corrective maintenance or overhaul within 14 days (complete within 30 days); perform end-of-life assessment (Chapter 6.6).
MC_000002 Pick_and_Place	94,006 h; 49.6 °C; 23.78 mm/s; oil 43.0%; coolant 36.0%; errors 6; last PM 258 d; recorded RUL 0 d; failure flag True	0 d / 100.0%	Critical; E3 applies because Failure_Within_7_Days is True. Vibration above 18 mm/s is also Critical (E4)	Priority P1: lock out within 24 hours. Inspect drive-train (Sections 5.1.2 and 5.1.1); overhaul or replace before return to service.
MC_000335 Dryer	4,704 h; 80.2 °C; 7.97 mm/s; oil 17.5%; coolant 18.0%; errors 1; last PM 264 d; recorded RUL 862 d; failure flag False	894 d / 0.0%	Healthy by risk (0%), but oil level below 30% and coolant level below 20% are two Critical secondary parameters: E2 raises status to Maintenance Due	Inspect lubrication and cooling systems within 14 days (Chapters 6.2, 6.3; Sections 5.1.4, 5.1.5). Temperature 80.2 °C is in the Warning band, which supports cooling degradation.

Chapter 9 — Maintenance Work Orders

This chapter provides templates used to document inspection and maintenance activity.

9.1 Inspection Report Template

Field	Entry
Machine ID / Machine Type	_____
Installation Year	_____
Operational Hours	_____
Days Since Last Maintenance	_____
Inspection Type	_____
Date / Time	_____
Temperature (°C) / Vibration (mm/s)	_____
Sound (dB) / Power (kW)	_____
Oil Level (%) / Coolant Level (%)	_____
Type-Specific Reading (laser, hydraulic, flow, heat index)	_____
Error Codes (30 d) / AI Override Events	_____
Computed RUL_est (days) / Risk Score (%)	_____
Findings / Detected Failure Mode	_____
Inspector Name	_____

9.2 Maintenance Completion Form

Field	Entry
Work Order Number	_____
Task Description	_____
Parts Replaced	_____
Test Results	_____
Return-to-Service Status	_____

9.3 Replacement Checklist

- Confirm correct part number and serial traceability
- Verify torque values per component specification
- Perform post-installation functional test
- Update component life/cycle tracking record

9.4 Root Cause Analysis Template

Field	Entry
Problem Statement	_____
Contributing Factors	_____
Root Cause	_____
Corrective Action	_____
Preventive Action	_____

9.5 Sign-Off

Role	Name	Signature	Date
Technician Sign-off			
Supervisor Sign-off			

9.6 Work Order Types by Status

Status	Typical Work Order	Notes
Healthy	INSP-A / INSP-B	Routine inspection; no corrective work order
Monitor	INSP-B / INSP-D, optionally WO-L	Increase monitoring; lubrication or coolant service if levels are in the Warning band
Maintenance Due	INSP-C followed by WO-R, WO-X or WO-O	Corrective repair, replacement or overhaul within the Table 8.3 timeframe
Critical	INSP-C immediately, then WO-R, WO-X or WO-O	Lockout; engineering sign-off required for return to service
Sensor fault flagged	WO-S	Verification or calibration; re-run the risk assessment afterwards

Chapter 10 — Appendix

10.1 Engineering Glossary

Term	Definition
RUL	Remaining Useful Life — estimated days until the machine reaches end of useful life
RUL_est	Estimated RUL computed from Operational_Hours, Temperature_C and Vibration_mms (Chapter 8)
Risk Score	Percentage measure of consumption of the 300-day planning horizon, derived from RUL_est
Failure_Within_7_Days	Boolean dataset flag that is True when recorded RUL is 6 days or fewer
Wear-Out	Failure mechanism dominated by cumulative operating hours
PM	Preventive Maintenance — interval-based service
Derate	Reducing machine load or speed to lower stress while awaiting maintenance
Lockout / Tagout	Isolating and tagging energy sources so a machine cannot be started during work
AI Supervision	Automated decision-support layer overseeing machine operation
AI Override Event	An occasion when an operator overrides an AI-suggested action
Heat Index	Dimensionless indicator of heat-transfer process state for thermal machines
Disposition	Engineering decision on repair, replace, overhaul or continue-monitoring status

10.2 Abbreviations

Abbreviation	Meaning
AGV	Automated Guided Vehicle
CMM	Coordinate Measuring Machine
CNC	Computer Numerical Control
dB	Decibel
kW	Kilowatt
L/min	Litres per minute
mm/s	Millimetres per second (RMS vibration)
PM	Preventive Maintenance
RCA	Root Cause Analysis
RMS	Root Mean Square
RUL	Remaining Useful Life

10.3 Inspection Symbols & Maintenance Codes

Code	Meaning
INSP-A	Routine post-shift or weekly inspection
INSP-B	Interval-based scheduled inspection (90-day, 180-day)
INSP-C	Condition-based inspection (triggered by exceedance or risk status)
INSP-D	Life assessment or overhaul-milestone inspection
WO-R	Work order — repair
WO-X	Work order — replacement
WO-O	Work order — overhaul
WO-L	Work order — lubrication or coolant service
WO-S	Work order — sensor verification or calibration

10.4 Dataset Field Reference

Table 10.1 maps each column of `factory_sensor_simulator_2040.csv` to its meaning and its section in this manual.

Table 10.1 — Dataset Field Reference

Column	Type / Unit	Applies To	Meaning and Manual Reference
Machine_ID	Text (MC_000000 format)	All	Unique machine record identifier
Machine_Type	Text (33 values)	All	Machine type; see Table 2.1
Installation_Year	Integer	All	Descriptive metadata only; not used for wear (Table 3.1)
Operational_Hours	Integer, h	All	Cumulative running hours; primary life indicator (Tables 3.1, 3.3)
Temperature_C	Decimal, °C	All	Temperature; Table 3.1, Section 4.2
Vibration_mms	Decimal, mm/s	All	Vibration; Table 3.1, Section 4.3
Sound_dB	Decimal, dB	All	Noise level; Section 4.4
Oil_Level_pct	Decimal, %	All	Oil reservoir level; Section 4.5
Coolant_Level_pct	Decimal, %	All	Coolant reservoir level; Section 4.6
Power_Consumption_kW	Decimal, kW	All	Electrical load; Section 4.7
Last_Maintenance_Days_Ago	Integer, days	All	Days since last maintenance; Section 5.2.3
Maintenance_History_Count	Integer	All	Lifetime maintenance events; reference value
Failure_History_Count	Integer	All	Lifetime failures; Section 5.2.4
AI_Supervision	Boolean	All	True if under AI supervision (about 30% of machines)
Error_Codes_Last_30_Days	Integer	All	Controller error codes in 30 days; Section 5.2.2
Remaining_Useful_Life_days	Decimal, days	All	Recorded RUL; floors at 0; see Chapters 3 and 8
Failure_Within_7_Days	Boolean	All	True when recorded RUL is 6 days or fewer; triggers Rule E3
Laser_Intensity	Decimal, % (blank if n/a)	Laser_Cutter	Section 4.8, Table 3.2
Hydraulic_Pressure_bar	Decimal, bar (blank if n/a)	Hydraulic_Press, Injection_Molder	Section 4.9, Table 3.2
Coolant_Flow_L_min	Decimal, L/min (blank if n/a)	CNC_Lathe, CNC_Mill, Industrial_Chiller	Section 4.10, Table 3.2
Heat_Index	Decimal, index (blank if n/a)	Boiler, Furnace, Heat_Exchanger	Section 4.11, Table 3.2
AI_Override_Events	Integer	All (0 unless AI_Supervision is True)	Operator overrides of AI decisions; Section 5.2.2

10.5 Fleet Baseline Statistics

Table 10.2 gives descriptive statistics for the 500,000-record fleet dataset. Type-specific parameters are computed only over the machine types that report them. Overall, 6.0% of records (30,032) have Failure_Within_7_Days True.

Table 10.2 — Fleet Baseline Statistics

Parameter	N	Mean	Std Dev	5th Pct	Median	95th Pct
Operational_Hours	500,000	50,012	28,862	5,012	49,973	95,032
Temperature_C	500,000	60.0	15.0	35.4	60.0	84.7
Vibration_mms	500,000	10.0	5.0	1.8	10.0	18.2
Sound_dB	500,000	75.0	10.0	58.5	75.0	91.4
Oil_Level_pct	500,000	69.5	18.8	37.2	70.0	100.0
Coolant_Level_pct	500,000	64.1	23.2	23.8	65.0	100.0
Power_Consumption_kW	500,000	149.9	80.0	18.3	149.9	281.2
Last_Maintenance_Days_Ago	500,000	182	106	18	182	347
Maintenance_History_Count	500,000	5.0	2.2	2.0	5.0	9.0
Failure_History_Count	500,000	2.0	1.4	0.0	2.0	5.0
Error_Codes_Last_30_Days	500,000	3.0	1.7	1.0	3.0	6.0
Remaining_Useful_Life_days	500,000	452	289	0	451	905
Laser_Intensity	15,156	75.0	10.0	58.4	75.0	91.5
Hydraulic_Pressure_bar	30,340	119.9	15.0	95.3	119.9	144.5
Coolant_Flow_L_min	45,624	40.0	10.0	23.6	40.0	56.4
Heat_Index	45,214	500	50	417	500	582
AI_Override_Events (supervised only)	150,415	2.0	1.4	0.0	2.0	5.0

10.6 Fleet Band Distribution

Table 10.3 shows the share of records falling in each band of Tables 3.1 and 3.2. Use it to judge how unusual a given reading is.

Table 10.3 — Fleet Band Distribution

Parameter	Normal	Warning	Critical
Operational_Hours	70.0%	15.0%	15.0%
Remaining_Useful_Life_days	75.4%	15.1%	9.5%
Temperature_C	84.2%	13.5%	2.3%
Vibration_mms	72.6%	21.9%	5.4%
Sound_dB	84.2%	13.5%	2.3%
Oil_Level_pct	84.2%	13.6%	2.3%
Coolant_Level_pct	84.1%	12.3%	3.6%
Power_Consumption_kW	84.2%	11.8%	4.0%
Last_Maintenance_Days_Ago	49.5%	32.9%	17.6%
Error_Codes_Last_30_Days	81.5%	15.1%	3.4%
Failure_History_Count	85.7%	12.6%	1.7%
AI_Override_Events (supervised only)	67.6%	27.1%	5.3%
Laser_Intensity (Laser_Cutter)	91.0%	8.7%	0.3%
Hydraulic_Pressure_bar (hydraulic types)	90.5%	8.7%	0.7%
Coolant_Flow_L_min (CNC, chiller)	89.7%	9.5%	0.7%
Heat_Index (thermal types)	89.0%	9.3%	1.7%

10.7 Revision Notes

This Revision 1.0 release represents the first complete synthetic version of this training manual, intended solely for use as reference content in AI/RAG demonstration systems.